



Objective-C API Reference

Table of contents

Introduction	3
Using Yocto—Demo with Objective-C	4
Control of the Led function	4
Control of the module part	6
Error handling	8
Reference	9
General functions	9
AnButton function interface	15
CarbonDioxide function interface	24
ColorLed function interface	32
Current function interface	40
DataLogger function interface	48
Formatted data sequence	58
Recorded data sequence	60
External power supply control interface	63
Yocto-hub port interface	69
Humidity function interface	76
Led function interface	84
LightSensor function interface	91
Module control interface	100
Network function interface	110
Pressure function interface	123
Relay function interface	131
Servo function interface	139
Temperature function interface	146
Voltage function interface	155
Voltage source function interface	163
Wireless function interface	172
Index	180

1. Introduction

This manual is intended to be used as a reference for Yoctopuce Objective-C library, in order to interface your code with USB sensors and controllers.

The next chapter is taken from the free USB device Yocto—Demo, in order to provide a concrete examples of how the library is used within a program.

The remaining part of the manual is a function-by-function, class-by-class documentation of the API. The first section describes all general-purpose global function, while the forthcoming sections describe the various classes that you may have to use depending on the Yoctopuce device beeing used. For more informations regarding the purpose and the usage of a given device attribute, please refer to the extended discussion provided in the device-specific user manual.

2. Using Yocto—Demo with Objective-C

Objective-C is language of choice for programming on Mac OS X, due to its integration with the Cocoa framework. In order to use the Objective-C library, you need XCode version 4.2 (earlier versions will not work), available freely when you run Lion. If you are still under Snow Leopard, you need to be registered as Apple developer to be able to download XCode 4.2. The Yoctopuce library is ARC compatible. You can therefore implement your projects either using the traditional *retain / release* method, or using the *Automatic Reference Counting*.

Yoctopuce Objective-C libraries¹ are integrally provided as source files. A section of the low-level library is written in pure C, but you should not need to interact directly with it: everything was done to ensure the simplest possible interaction from Objective-C.

You will soon notice that the Objective-C API defines many functions which return objects. You do not need to deallocate these objects yourself, the API does it automatically at the end of the application.

In order to keep them simple, all the examples provided in this documentation are console applications. Naturally, the libraries function in a strictly identical manner if you integrate them in an application with a graphical interface. You can find on Yoctopuce blog a detailed example² with video shots showing how to integrate the library into your projects.

2.1. Control of the Led function

Launch Xcode 4.2 and open the corresponding sample project provided in the directory **Examples/Doc-GettingStarted-Yocto-Demo** of the Yoctopuce library.

```
#import <Foundation/Foundation.h>
#import "yocto_api.h"
#import "yocto_led.h"

static void usage(void)
{
    NSLog(@"usage: demo <serial_number> [ on | off ]");
    NSLog(@"          demo <logical_name> [ on | off ]");
    NSLog(@"          demo any [ on | off ]           (use any discovered device)"
);
    exit(1);
}

int main(int argc, const char * argv[])
{
    NSError *error;
    if(argc < 3) {
        usage();
    }
}
```

¹ www.yoctopuce.com/EN/libraries.php

² www.yoctopuce.com/EN/article/new-objective-c-library-for-mac-os-x

```

@autoreleasepool {
    NSString *target = [NSString stringWithUTF8String:argv[1]];
    NSString *on_off = [NSString stringWithUTF8String:argv[2]];
    YLed *led;

    if(yRegisterHub(@"usb", &error) != YAPI_SUCCESS) {
        NSLog(@"RegisterHub error: %@", [error localizedDescription]);
        return 1;
    }
    if([target isEqualToString:@"any"]){
        led = yFirstLed();
    }else{
        led = yFindLed([target stringByAppendingString:@"led"]);
    }
    if ([led isOnline]) {
        if ([on_off isEqualToString:@"on"])
            [led set_power:Y_POWER_ON];
        else
            [led set_power:Y_POWER_OFF];
    } else {
        NSLog(@"Module not connected (check identification and USB cable)\n");
    }
    return 0;
}

```

There are only a few really important lines in this example. We will look at them in details.

yocto_api.h et yocto_led.h

These two import files provide access to the functions allowing you to manage Yoctopuce modules. `yocto_api.h` must always be used, `yocto_led.h` is necessary to manage modules containing a led, such as Yocto-Demo.

yRegisterHub

The `yRegisterHub` function initializes the Yoctopuce API and indicates where the modules should be looked for. When used with the parameter `@usb`, it will use the modules locally connected to the computer running the library. If the initialization does not succeed, this function returns a value different from `YAPI_SUCCESS` and `errmsg` contains the error message.

yFindLed

The `yFindLed` function allows you to find a led from the serial number of the module on which it resides and from its function name. You can use logical names as well, as long as you have initialized them. Let us imagine a Yocto-Demo module with serial number `YCTOPOC1-123456` which you have named `"MyModule"`, and for which you have given the `led` function the name `"MyFunction"`. The following five calls are strictly equivalent, as long as `"MyFunction"` is defined only once.

```

YLed *led = yFindLed(@"YCTOPOC1-123456.led");
YLed *led = yFindLed(@"YCTOPOC1-123456.MyFunction");
YLed *led = yFindLed(@"MyModule.led");
YLed *led = yFindLed(@"MyModule.MyFunction");
YLed *led = yFindLed(@"MyFunction");

```

`yFindLed` returns an object which you can then use at will to control the led.

isOnline

The `isOnline()` method of the object returned by `yFindLed` allows you to know if the corresponding module is present and in working order.

set_power

The `set_power()` function of the object returned by `yFindLed` allows you to turn on and off the led. The argument is `Y_POWER_ON` or `Y_POWER_OFF`. In the reference on the programming interface, you will find more methods to precisely control the luminosity and make the led blink automatically.

2.2. Control of the module part

Each module can be controlled in a similar manner, you can find below a simple sample program displaying the main parameters of the module and enabling you to activate the localization beacon.

```
#import <Foundation/Foundation.h>
#import "yocto_api.h"

static void usage(const char *exe)
{
    NSLog(@"usage: %s <serial or logical name> [ON/OFF]\n", exe);
    exit(1);
}

int main (int argc, const char * argv[])
{
    NSError *error;

    @autoreleasepool {
        // Setup the API to use local USB devices
        if (yRegisterHub(@"usb", &error) != YAPI_SUCCESS) {
            NSLog(@"RegisterHub error: %@", [error localizedDescription]);
            return 1;
        }
        if (argc < 2)
            usage(argv[0]);
        NSString *serial_or_name = [NSString stringWithUTF8String:argv[1]];
        YModule *module = yFindModule(serial_or_name); // use serial or logical name
        if (module.isOnline) {
            if (argc > 2) {
                if (strcmp(argv[2], "ON")==0)
                    module.beacon = Y_BEACON_ON;
                else
                    module.beacon = Y_BEACON_OFF;
            }
            NSLog(@"serial:      %@\n", module.serialNumber);
            NSLog(@"logical name:  %@\n", module.logicalName);
            NSLog(@"luminosity:   %d\n", module.luminosity);
            NSLog(@"beacon:      ");
            if (module.beacon == Y_BEACON_ON)
                NSLog(@"ON\n");
            else
                NSLog(@"OFF\n");
            NSLog(@"upTime:      %d sec\n", module.upTime/1000);
            NSLog(@"USB current:  %d mA\n", module.usbCurrent);
        } else {
            NSLog(@"%% not connected (check identification and USB cable)
\n", serial_or_name);
        }
    }
    return 0;
}
```

Each property xxx of the module can be read thanks to a method of type get_xxxx, and properties which are not read-only can be modified with the help of the set_xxx: method. For more details regarding the used functions, refer to the [API](#) chapters.

Changing the module settings

When you want to modify the settings of a module, you only need to call the corresponding set_xxx: function. However, this modification is performed only in the random access memory (RAM) of the module: if the module is restarted, the modifications are lost. To memorize them persistently, it is necessary to ask the module to save its current configuration in its permanent memory. To do so, use the saveToFlash method. Inversely, it is possible to force the module to forget its current settings by using the revertFromFlash method. The short example below allows you to modify the logical name of a module.

```
#import <Foundation/Foundation.h>
#import "yocto_api.h"

static void usage(const char *exe)
{
    NSLog(@"usage: %s <serial> <newLogicalName>\n", exe);
    exit(1);
}
```

```

int main (int argc, const char * argv[])
{
    NSError *error;

    @autoreleasepool {
        // Setup the API to use local USB devices
        if(yRegisterHub(@"usb", &error) != YAPI_SUCCESS) {
            NSLog(@"RegisterHub error: %@", [error localizedDescription]);
            return 1;
        }

        if(argc < 2)
            usage(argv[0]);

        NSString *serial_or_name = [NSString stringWithUTF8String:argv[1]];
        YModule *module = yFindModule(serial_or_name); // use serial or logical name

        if (module.isOnline) {
            if (argc >= 3){
                NSString *newname = [NSString stringWithUTF8String:argv[2]];
                if (!yCheckLogicalName(newname)){
                    NSLog(@"Invalid name (%@)\n", newname);
                    usage(argv[0]);
                }
                module.logicalName = newname;
                [module saveToFlash];
            }
            NSLog(@"Current name: %@\n", module.logicalName);
        } else {
            NSLog(@"%@ not connected (check identification and USB cable)
\n", serial_or_name);
        }
    }
    return 0;
}

```

Warning: the number of write cycles of the nonvolatile memory of the module is limited. When this limit is reached, nothing guaranties that the saving process is performed correctly. This limit, linked to the technology employed by the module micro-processor, is located at about 100000 cycles. In short, you can use the `saveToFlash` function only 100000 times in the life of the module. Make sure you do not call this function within a loop.

Listing the modules

Obtaining the list of the connected modules is performed with the `yFirstModule()` function which returns the first module found. Then, you only need to call the `nextModule()` function of this object to find the following modules, and this as long as the returned value is not `NULL`. Below a short example listing the connected modules.

```

#import <Foundation/Foundation.h>
#import "yocto_api.h"

int main (int argc, const char * argv[])
{
    NSError *error;

    @autoreleasepool {
        // Setup the API to use local USB devices
        if(yRegisterHub(@"usb", &error) != YAPI_SUCCESS) {
            NSLog(@"RegisterHub error: %@\n", [error localizedDescription]);
            return 1;
        }

        NSLog(@"Device list:\n");

        YModule *module = yFirstModule();
        while (module != NULL) {
            NSLog(@"%@ %@", module.serialNumber, module.productName);
            module = [module nextModule];
        }
    }
    return 0;
}

```

2.3. Error handling

When you implement a program which must interact with USB modules, you cannot disregard error handling. Inevitably, there will be a time when a user will have unplugged the device, either before running the software, or even while the software is running. The Yoctopuce library is designed to help you support this kind of behavior, but your code must nevertheless be conceived to interpret in the best possible way the errors indicated by the library.

The simplest way to work around the problem is the one used in the short examples provided in this chapter: before accessing a module, check that it is online with the `isOnline` function, and then hope that it will stay so during the fraction of a second necessary for the following code lines to run. This method is not perfect, but it can be sufficient in some cases. You must however be aware that you cannot completely exclude an error which would occur after the call to `isOnline` and which could crash the software. The only way to prevent this is to implement one of the two error handling techniques described below.

The method recommended by most programming languages for unpredictable error handling is the use of exceptions. By default, it is the behavior of the Yoctopuce library. If an error happens while you try to access a module, the library throws an exception. In this case, there are three possibilities:

- If your code catches the exception and handles it, everything goes well.
- If your program is running in debug mode, you can relatively easily determine where the problem happened and view the explanatory message linked to the exception.
- Otherwise... the exception makes your program crash, bang!

As this latest situation is not the most desirable, the Yoctopuce library offers another possibility for error handling, allowing you to create a robust program without needing to catch exceptions at every line of code. You simply need to call the `yDisableExceptions()` function to commute the library to a mode where exceptions for all the functions are systematically replaced by specific return values, which can be tested by the caller when necessary. For each function, the name of each return value in case of error is systematically documented in the [library reference](#). The name always follows the same logic: a `get_state()` method returns a `Y_STATE_INVALID` value, a `get_currentValue` method returns a `Y_CURRENTVALUE_INVALID` value, and so on. In any case, the returned value is of the expected type and is not a null pointer which would risk crashing your program. At worst, if you display the value without testing it, it will be outside the expected bounds for the returned value. In the case of functions which do not normally return information, the return value is `YAPI_SUCCESS` if everything went well, and a different error code in case of failure.

When you work without exceptions, you can obtain an error code and an error message explaining the source of the error. You can request them from the object which returned the error, calling the `errType()` and `errMessage()` methods. Their returned values contain the same information as in the exceptions when they are active.

3. Reference

3.1. General functions

These general functions should be used to initialize and configure the Yoctopuce library. In most cases, a simple call to function `yRegisterHub()` should be enough. The module-specific functions `yFind...()` or `yFirst...()` should then be used to retrieve an object that provides interaction with the module.

In order to use the functions described here, you should include:

```
#import "yocto_api.h"
```

Global functions	
yCheckLogicalName(name)	Checks if a given string is valid as logical name for a module or a function.
yDisableExceptions()	Disables the use of exceptions to report runtime errors.
yEnableExceptions()	Re-enables the use of exceptions for runtime error handling.
yEnableUSBHost(osContext)	This function is used only on Android.
yFreeAPI()	Frees dynamically allocated memory blocks used by the Yoctopuce library.
yGetAPIVersion()	Returns the version identifier for the Yoctopuce library in use.
yGetTickCount()	Returns the current value of a monotone millisecond-based time counter.
yHandleEvents(errmsg)	Maintains the device-to-library communication channel.
yInitAPI(mode, errmsg)	Initializes the Yoctopuce programming library explicitly.
yRegisterDeviceArrivalCallback(arrivalCallback)	Register a callback function, to be called each time a device is plugged.
yRegisterDeviceRemovalCallback(removalCallback)	

Register a callback function, to be called each time a device is unplugged.

yRegisterHub(url, errmsg)

Setup the Yoctopuce library to use modules connected on a given machine.

yRegisterLogFunction(logfun)

Register a log callback function.

ySetDelegate(object)

(Objective-C only) Register an object that must follow the protocol YDeviceHotPlug.

ySetTimeout(callback, ms_timeout, optional_arguments)

Invoke the specified callback function after a given timeout.

ySleep(ms_duration, errmsg)

Pauses the execution flow for a specified duration.

yUnregisterHub(url)

Setup the Yoctopuce library to no more use modules connected on a previously registered machine with RegisterHub.

yUpdateDeviceList(errmsg)

Triggers a (re)detection of connected Yoctopuce modules.

yUpdateDeviceList_async(callback, context)

Triggers a (re)detection of connected Yoctopuce modules.

yCheckLogicalName()

Checks if a given string is valid as logical name for a module or a function.

BOOL yCheckLogicalName(NSString * name)

A valid logical name has a maximum of 19 characters, all among A..Z, a..z, 0..9, _, and -. If you try to configure a logical name with an incorrect string, the invalid characters are ignored.

Parameters :

name a string containing the name to check.

Returns :

`true` if the name is valid, `false` otherwise.

yDisableExceptions()

Disables the use of exceptions to report runtime errors.

void yDisableExceptions()

When exceptions are disabled, every function returns a specific error value which depends on its type and which is documented in this reference manual.

yEnableExceptions()

Re-enables the use of exceptions for runtime error handling.

void yEnableExceptions()

Be aware that when exceptions are enabled, every function that fails triggers an exception. If the exception is not caught by the user code, it either fires the debugger or aborts (i.e. crash) the program. On failure, throws an exception or returns a negative error code.

This function is used only on Android.

Before calling `yRegisterHub("usb")` you need to activate the USB host port of the system. This function takes as argument, an object of class `android.content.Context` (or any subclass). It is not necessary to call this function to reach modules through the network.

Parameters :

osContext an object of class `android.content.Context` (or any subclass).
On failure, throws an exception.

yFreeAPI()

Frees dynamically allocated memory blocks used by the Yoctopuce library.

`void yFreeAPI()`

It is generally not required to call this function, unless you want to free all dynamically allocated memory blocks in order to track a memory leak for instance. You should not call any other library function after calling `yFreeAPI()`, or your program will crash.

yGetAPIVersion()

Returns the version identifier for the Yoctopuce library in use.

`NSString* yGetAPIVersion()`

The version is a string in the form `"Major.Minor.Build"`, for instance `"1.01.5535"`. For languages using an external DLL (for instance C#, VisualBasic or Delphi), the character string includes as well the DLL version, for instance `"1.01.5535 (1.01.5439)"`.

If you want to verify in your code that the library version is compatible with the version that you have used during development, verify that the major number is strictly equal and that the minor number is greater or equal. The build number is not relevant with respect to the library compatibility.

Returns :

a character string describing the library version.

yGetTickCount()

Returns the current value of a monotone millisecond-based time counter.

`u64 yGetTickCount()`

This counter can be used to compute delays in relation with Yoctopuce devices, which also uses the millisecond as timebase.

Returns :

a long integer corresponding to the millisecond counter.

yHandleEvents()

Maintains the device-to-library communication channel.

`YRETCODE yHandleEvents(NSError** errmsg)`

If your program includes significant loops, you may want to include a call to this function to make sure that the library takes care of the information pushed by the modules on the

communication channels. This is not strictly necessary, but it may improve the reactivity of the library for the following commands.

This function may signal an error in case there is a communication problem while contacting a module.

Parameters :

errmsg a string passed by reference to receive any error message.

Returns :

YAPI_SUCCESS when the call succeeds. On failure, throws an exception or returns a negative error code.

yInitAPI()

Initializes the Yoctopuce programming library explicitly.

YRETCODE **yInitAPI**(int **mode**, NSError** **errmsg**)

It is not strictly needed to call `yInitAPI()`, as the library is automatically initialized when calling `yRegisterHub()` for the first time.

When `Y_DETECT_NONE` is used as detection mode, you must explicitly use `yRegisterHub()` to point the API to the VirtualHub on which your devices are connected before trying to access them.

Parameters :

mode an integer corresponding to the type of automatic device detection to use. Possible values are `Y_DETECT_NONE`, `Y_DETECT_USB`, `Y_DETECT_NET`, and `Y_DETECT_ALL`.

errmsg a string passed by reference to receive any error message.

Returns :

YAPI_SUCCESS when the call succeeds. On failure, throws an exception or returns a negative error code.

yRegisterDeviceArrivalCallback()

Register a callback function, to be called each time a device is plugged.

void **yRegisterDeviceArrivalCallback**(yDeviceUpdateCallback **arrivalCallback**)

This callback will be invoked while `yUpdateDeviceList` is running. You will have to call this function on a regular basis.

Parameters :

arrivalCallback a procedure taking a `YModule` parameter, or null to unregister a previously registered callback.

yRegisterDeviceRemovalCallback()

Register a callback function, to be called each time a device is unplugged.

void **yRegisterDeviceRemovalCallback**(yDeviceUpdateCallback **removalCallback**)

This callback will be invoked while `yUpdateDeviceList` is running. You will have to call this function on a regular basis.

Parameters :

removalCallback a procedure taking a `YModule` parameter, or null to unregister a previously registered callback.

yRegisterHub()

Setup the Yoctopuce library to use modules connected on a given machine.

```
YRETCODE yRegisterHub( NSString * url, NSError** errmsg)
```

When using Yoctopuce modules through the VirtualHub gateway, you should provide as parameter the address of the machine on which the VirtualHub software is running (typically "http://127.0.0.1:4444", which represents the local machine). When you use a language which has direct access to the USB hardware, you can use the pseudo-URL "usb" instead.

Be aware that only one application can use direct USB access at a given time on a machine. Multiple access would cause conflicts while trying to access the USB modules. In particular, this means that you must stop the VirtualHub software before starting an application that uses direct USB access. The workaround for this limitation is to setup the library to use the VirtualHub rather than direct USB access. If access control has been activated on the VirtualHub you want to reach, the URL parameter should look like: `http://username:password@adresse:port`

Parameters :

- url** a string containing either "usb" or the root URL of the hub to monitor
- errmsg** a string passed by reference to receive any error message.

Returns :

YAPI_SUCCESS when the call succeeds. On failure, throws an exception or returns a negative error code.

yRegisterLogFunction()

Register a log callback function.

```
void yRegisterLogFunction( yLogCallback logfun)
```

This callback will be called each time the API have something to say. Quite usefull to debug the API.

Parameters :

- logfun** a procedure taking a string parameter, or null to unregister a previously registered callback.

ySetDelegate()

(Objective-C only) Register an object that must follow the protocol YDeviceHotPlug.

```
void ySetDelegate( id object)
```

The methods `yDeviceArrival` and `yDeviceRemoval` will be invoked while `yUpdateDeviceList` is running. You will have to call this function on a regular basis.

Parameters :

- object** an object that must follow the protocol YAPIDelegate, or nil to unregister a previously registered object.

Invoke the specified callback function after a given timeout.

This function behaves more or less like Javascript `setTimeout`, but during the waiting time, it will call `yHandleEvents` and `yUpdateDeviceList` periodically, in order to keep the API up-to-date with current devices.

Parameters :

callback	the function to call after the timeout occurs. On Microsoft Internet Explorer, the callback must be provided as a string to be evaluated.
ms_timeout	an integer corresponding to the duration of the timeout, in milliseconds.
optional_arguments	additional arguments to be passed to the callback function can be provided, if needed (not supported on Microsoft Internet Explorer).

Returns :

YAPI_SUCCESS when the call succeeds. On failure, throws an exception or returns a negative error code.

ySleep()

Pauses the execution flow for a specified duration.

YRETCODE **ySleep**(unsigned **ms_duration**, NSError ** **errmsg**)

This function implements a passive waiting loop, meaning that it does not consume CPU cycles significantly. The processor is left available for other threads and processes. During the pause, the library nevertheless reads from time to time information from the Yoctopuce modules by calling `yHandleEvents()`, in order to stay up-to-date.

This function may signal an error in case there is a communication problem while contacting a module.

Parameters :

ms_duration	an integer corresponding to the duration of the pause, in milliseconds.
errmsg	a string passed by reference to receive any error message.

Returns :

YAPI_SUCCESS when the call succeeds. On failure, throws an exception or returns a negative error code.

yUnregisterHub()

Setup the Yoctopuce library to no more use modules connected on a previously registered machine with RegisterHub.

void **yUnregisterHub**(NSString * **url**)

Parameters :

url	a string containing either " usb " or the root URL of the hub to monitor
------------	---

yUpdateDeviceList()

Triggers a (re)detection of connected Yoctopuce modules.

YRETCODE **yUpdateDeviceList**(NSError** **errmsg**)

The library searches the machines or USB ports previously registered using `yRegisterHub()`, and invokes any user-defined callback function in case a change in the list of connected devices is detected.

This function can be called as frequently as desired to refresh the device list and to make the application aware of hot-plug events.

Parameters :

errmsg	a string passed by reference to receive any error message.
---------------	--

Returns :

YAPI_SUCCESS when the call succeeds. On failure, throws an exception or returns a negative error code.

Triggers a (re)detection of connected Yoctopuce modules.

The library searches the machines or USB ports previously registered using `yRegisterHub()`, and invokes any user-defined callback function in case a change in the list of connected devices is detected.

This function can be called as frequently as desired to refresh the device list and to make the application aware of hot-plug events.

This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox Javascript VM that does not implement context switching during blocking I/O calls.

Parameters :

callback callback function that is invoked when the result is known. The callback function receives two arguments: the caller-specific context object and the result code (`YAPI_SUCCESS` if the operation completes successfully).

context caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

3.2. AnButton function interface

Yoctopuce application programming interface allows you to measure the state of a simple button as well as to read an analog potentiometer (variable resistance). This can be use for instance with a continuous rotating knob, a throttle grip or a joystick. The module is capable to calibrate itself on min and max values, in order to compute a calibrated value that varies proportionally with the potentiometer position, regardless of its total resistance.

In order to use the functions described here, you should include:

```
#import "yocto_anbutton.h"
```

Global functions

`yFindAnButton(func)`

Retrieves an analog input for a given identifier.

`yFirstAnButton()`

Starts the enumeration of analog inputs currently accessible.

YAnButton methods

`anbutton→describe()`

Returns a descriptive text that identifies the function.

`anbutton→get_advertisedValue()`

Returns the current value of the analog input (no more than 6 characters).

`anbutton→get_analogCalibration()`

Tells if a calibration process is currently ongoing.

`anbutton→get_calibratedValue()`

Returns the current calibrated input value (between 0 and 1000, included).

`anbutton→get_calibrationMax()`

Returns the maximal value measured during the calibration (between 0 and 4095, included).

`anbutton→get_calibrationMin()`

Returns the minimal value measured during the calibration (between 0 and 4095, included).

`anbutton→get_errorMessage()`

Returns the error message of the latest error with this function.

`anbutton→get_errorType()`

Returns the numerical error code of the latest error with this function.

anbutton→get_functionDescriptor()

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

anbutton→get_hardwareId()

Returns the unique hardware identifier of the function.

anbutton→get_isPressed()

Returns true if the input (considered as binary) is active (closed contact), and false otherwise.

anbutton→get_lastTimePressed()

Returns the number of elapsed milliseconds between the module power on and the last time the input button was pressed (the input contact transitionned from open to closed).

anbutton→get_lastTimeReleased()

Returns the number of elapsed milliseconds between the module power on and the last time the input button was released (the input contact transitionned from closed to open).

anbutton→get_logicalName()

Returns the logical name of the analog input.

anbutton→get_module()

Get the `YModule` object for the device on which the function is located.

anbutton→get_module_async(callback, context)

Get the `YModule` object for the device on which the function is located (asynchronous version).

anbutton→get_rawValue()

Returns the current measured input value as-is (between 0 and 4095, included).

anbutton→get_sensitivity()

Returns the sensibility for the input (between 1 and 255, included) for triggering user callbacks.

anbutton→get_userData()

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

anbutton→isOnline()

Checks if the function is currently reachable, without raising any error.

anbutton→isOnline_async(callback, context)

Checks if the function is currently reachable, without raising any error (asynchronous version).

anbutton→load(msValidity)

Preloads the function cache with a specified validity duration.

anbutton→load_async(msValidity, callback, context)

Preloads the function cache with a specified validity duration (asynchronous version).

anbutton→nextAnButton()

Continues the enumeration of analog inputs started using `yFirstAnButton()`.

anbutton→registerValueCallback(callback)

Registers the callback function that is invoked on every change of advertised value.

anbutton→set_analogCalibration(newval)

Starts or stops the calibration process.

anbutton→set_calibrationMax(newval)

Changes the maximal calibration value for the input (between 0 and 4095, included), without actually starting the automated calibration.

anbutton→set_calibrationMin(newval)

Changes the minimal calibration value for the input (between 0 and 4095, included), without actually starting the automated calibration.

anbutton→**set_logicalName(newval)**

Changes the logical name of the analog input.

anbutton→**set_sensitivity(newval)**

Changes the sensibility for the input (between 1 and 255, included) for triggering user callbacks.

anbutton→**set_userData(data)**

Stores a user context provided as argument in the userData attribute of the function.

yFindAnButton()

Retrieves an analog input for a given identifier.

YAnButton* **yFindAnButton(NSString* func)**

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the analog input is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YAnButton.isOnline()` to test if the analog input is indeed online at a given time. In case of ambiguity when looking for an analog input by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

Parameters :

func a string that uniquely characterizes the analog input

Returns :

a `YAnButton` object allowing you to drive the analog input.

yFirstAnButton()

Starts the enumeration of analog inputs currently accessible.

YAnButton* **yFirstAnButton()**

Use the method `YAnButton.nextAnButton()` to iterate on next analog inputs.

Returns :

a pointer to a `YAnButton` object, corresponding to the first analog input currently online, or a `null` pointer if there are none.

[anbutton describe]

Returns a descriptive text that identifies the function.

-(NSString*) describe

The text always includes the class name, and may include as well either the logical name of the function or its hardware identifier.

Returns :

a string that describes the function

[anbutton advertisedValue]

Returns the current value of the analog input (no more than 6 characters).

-(NSString*) advertisedValue

Returns :

a string corresponding to the current value of the analog input (no more than 6 characters)

On failure, throws an exception or returns Y_ADVERTISEDVALUE_INVALID.

[anbutton analogCalibration]

Tells if a calibration process is currently ongoing.

-(Y_ANALOGCALIBRATION_enum) analogCalibration

Returns :

either Y_ANALOGCALIBRATION_OFF or Y_ANALOGCALIBRATION_ON

On failure, throws an exception or returns Y_ANALOGCALIBRATION_INVALID.

[anbutton calibratedValue]

Returns the current calibrated input value (between 0 and 1000, included).

-(unsigned) calibratedValue

Returns :

an integer corresponding to the current calibrated input value (between 0 and 1000, included)

On failure, throws an exception or returns Y_CALIBRATEDVALUE_INVALID.

[anbutton calibrationMax]

Returns the maximal value measured during the calibration (between 0 and 4095, included).

-(unsigned) calibrationMax

Returns :

an integer corresponding to the maximal value measured during the calibration (between 0 and 4095, included)

On failure, throws an exception or returns Y_CALIBRATIONMAX_INVALID.

[anbutton calibrationMin]

Returns the minimal value measured during the calibration (between 0 and 4095, included).

-(unsigned) calibrationMin

Returns :

an integer corresponding to the minimal value measured during the calibration (between 0 and 4095, included)

On failure, throws an exception or returns Y_CALIBRATIONMIN_INVALID.

Returns the error message of the latest error with this function.

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

Returns :

a string corresponding to the latest error message that occurred while using this function object

Returns the numerical error code of the latest error with this function.

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

Returns :

a number corresponding to the code of the latest error that occurred while using this function object

[anbutton anbuttonDescriptor]

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

[-\(YFUN_DESCR\) functionDescriptor](#)

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

Returns :

an identifier of type `YFUN_DESCR`. If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

Returns the unique hardware identifier of the function.

The unique hardware identifier is made of the device serial number and of the hardware identifier of the function.

Returns :

a string that uniquely identifies the function. On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

[anbutton isPressed]

Returns true if the input (considered as binary) is active (closed contact), and false otherwise.

[-\(Y_ISPRESSED_enum\) isPressed](#)

Returns :

either `Y_ISPRESSED_FALSE` or `Y_ISPRESSED_TRUE`, according to true if the input (considered as binary) is active (closed contact), and false otherwise

On failure, throws an exception or returns `Y_ISPRESSED_INVALID`.

[anbutton lastTimePressed]

Returns the number of elapsed milliseconds between the module power on and the last time the input button was pressed (the input contact transitionned from open to closed).

[-\(unsigned\) lastTimePressed](#)

Returns :

an integer corresponding to the number of elapsed milliseconds between the module power on and the last time the input button was pressed (the input contact transitionned from open to closed)

On failure, throws an exception or returns `Y_LASTTIMEPRESSED_INVALID`.

[anbutton lastTimeReleased]

Returns the number of elapsed milliseconds between the module power on and the last time the input button was released (the input contact transitionned from closed to open).

-(unsigned) lastTimeReleased

Returns :

an integer corresponding to the number of elapsed milliseconds between the module power on and the last time the input button was released (the input contact transitionned from closed to open)

On failure, throws an exception or returns `Y_LASTTIMERELEASED_INVALID`.

[anbutton logicalName]

Returns the logical name of the analog input.

-(NSString*) logicalName

Returns :

a string corresponding to the logical name of the analog input

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

[anbutton module]

Get the `YModule` object for the device on which the function is located.

-(YModule*) module

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

Returns :

an instance of `YModule`

Get the `YModule` object for the device on which the function is located (asynchronous version).

If the function cannot be located on any module, the returned `YModule` object does not show as on-line. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

Parameters :

callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the requested `YModule` object

context caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[anbutton rawValue]

Returns the current measured input value as-is (between 0 and 4095, included).

-(unsigned) rawValue

Returns :

an integer corresponding to the current measured input value as-is (between 0 and 4095, included)

On failure, throws an exception or returns `Y_RAWVALUE_INVALID`.

[anbutton sensitivity]

Returns the sensibility for the input (between 1 and 255, included) for triggering user callbacks.

-(unsigned) sensitivity

Returns :

an integer corresponding to the sensibility for the input (between 1 and 255, included) for triggering user callbacks

On failure, throws an exception or returns `Y_SENSITIVITY_INVALID`.

[anbutton userData]

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

-(void*) userData

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

Returns :

the object stored previously by the caller.

[anbutton isOnline]

Checks if the function is currently reachable, without raising any error.

-(BOOL) isOnline

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

Returns :

`true` if the function can be reached, and `false` otherwise

Checks if the function is currently reachable, without raising any error (asynchronous version).

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox Javascript VM that does not implement context switching during blocking I/O calls.

Parameters :

callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the boolean result

context caller-specific object that is passed as-is to the callback function

Returns :
nothing : the result is provided to the callback.

[anbutton load:]

Preloads the function cache with a specified validity duration.

-(YRETCODE) **load** : (int) **msValidity**

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

Parameters :

msValidity an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

Returns :

YAPI_SUCCESS when the call succeeds. On failure, throws an exception or returns a negative error code.

Preloads the function cache with a specified validity duration (asynchronous version).

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

Parameters :

msValidity an integer corresponding to the validity of the loaded function parameters, in milliseconds

callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the error code (or YAPI_SUCCESS)

context caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[anbutton nextAnButton]

Continues the enumeration of analog inputs started using `yFirstAnButton()`.

-(YAnButton*) **nextAnButton**

Returns :

a pointer to a YAnButton object, corresponding to an analog input currently online, or a null pointer if there are no more analog inputs to enumerate.

[anbutton registerValueCallback:]

Registers the callback function that is invoked on every change of advertised value.

-(void) **registerValueCallback** : (YFunctionUpdateCallback) **callback**

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

Parameters :

callback the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

[anbutton setAnalogCalibration:]

Starts or stops the calibration process.

-(int) setAnalogCalibration : (Y_ANALOGCALIBRATION_enum) **newval**

Remember to call the `saveToFlash()` method of the module at the end of the calibration if the modification must be kept.

Parameters :

newval either `Y_ANALOGCALIBRATION_OFF` or `Y_ANALOGCALIBRATION_ON`

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[anbutton setCalibrationMax:]

Changes the maximal calibration value for the input (between 0 and 4095, included), without actually starting the automated calibration.

-(int) setCalibrationMax : (unsigned) **newval**

Remember to call the `saveToFlash()` method of the module if the modification must be kept.

Parameters :

newval an integer corresponding to the maximal calibration value for the input (between 0 and 4095, included), without actually starting the automated calibration

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[anbutton setCalibrationMin:]

Changes the minimal calibration value for the input (between 0 and 4095, included), without actually starting the automated calibration.

-(int) setCalibrationMin : (unsigned) **newval**

Remember to call the `saveToFlash()` method of the module if the modification must be kept.

Parameters :

newval an integer corresponding to the minimal calibration value for the input (between 0 and 4095, included), without actually starting the automated calibration

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[anbutton setLogicalName:]

Changes the logical name of the analog input.

`-(int) setLogicalName : (NSString*) newval`

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

Parameters :

newval a string corresponding to the logical name of the analog input

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[anbutton setSensitivity:]

Changes the sensibility for the input (between 1 and 255, included) for triggering user callbacks.

`-(int) setSensitivity : (unsigned) newval`

Remember to call the `saveToFlash()` method of the module if the modification must be kept.

Parameters :

newval an integer corresponding to the sensibility for the input (between 1 and 255, included) for triggering user callbacks

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[anbutton setUserData:]

Stores a user context provided as argument in the `userData` attribute of the function.

`-(void) setUserData : (void*) data`

This attribute is never touched by the API, and is at disposal of the caller to store a context.

Parameters :

data any kind of object to be stored

3.3. CarbonDioxide function interface

The Yoctopuce application programming interface allows you to read an instant measure of the sensor, as well as the minimal and maximal values observed.

In order to use the functions described here, you should include:

`#import "yocto_carbondioxide.h"`

Global functions

yFindCarbonDioxide(func)

Retrieves a CO2 sensor for a given identifier.

yFirstCarbonDioxide()

Starts the enumeration of CO2 sensors currently accessible.

YCarbonDioxide methods

carbondioxide→calibrateFromPoints(rawValues, refValues)

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

carbondioxide→describe()

Returns a descriptive text that identifies the function.

carbondioxide→get_advertisedValue()

Returns the current value of the CO2 sensor (no more than 6 characters).

carbondioxide→get_currentRawValue()

Returns the uncalibrated, unrounded raw value returned by the sensor.

carbondioxide→get_currentValue()

Returns the current measured value.

carbondioxide→get_errorMessage()

Returns the error message of the latest error with this function.

carbondioxide→get_errorType()

Returns the numerical error code of the latest error with this function.

carbondioxide→get_functionDescriptor()

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

carbondioxide→get_hardwareId()

Returns the unique hardware identifier of the function.

carbondioxide→get_highestValue()

Returns the maximal value observed.

carbondioxide→get_logicalName()

Returns the logical name of the CO2 sensor.

carbondioxide→get_lowestValue()

Returns the minimal value observed.

carbondioxide→get_module()

Get the `YModule` object for the device on which the function is located.

carbondioxide→get_module_async(callback, context)

Get the `YModule` object for the device on which the function is located (asynchronous version).

carbondioxide→get_resolution()

Returns the resolution of the measured values.

carbondioxide→get_unit()

Returns the measuring unit for the measured value.

carbondioxide→get_userData()

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

carbondioxide→isOnline()

Checks if the function is currently reachable, without raising any error.

carbondioxide→isOnline_async(callback, context)

Checks if the function is currently reachable, without raising any error (asynchronous version).

carbondioxide→load(msValidity)

Preloads the function cache with a specified validity duration.

carbondioxide→load_async(msValidity, callback, context)

Preloads the function cache with a specified validity duration (asynchronous version).

carbondioxide→nextCarbonDioxide()

Continues the enumeration of CO2 sensors started using `yFirstCarbonDioxide()`.

`carbondioxide→registerValueCallback(callback)`

Registers the callback function that is invoked on every change of advertised value.

`carbondioxide→set_highestValue(newval)`

Changes the recorded maximal value observed.

`carbondioxide→set_logicalName(newval)`

Changes the logical name of the CO2 sensor.

`carbondioxide→set_lowestValue(newval)`

Changes the recorded minimal value observed.

`carbondioxide→set_userData(data)`

Stores a user context provided as argument in the `userData` attribute of the function.

`yFindCarbonDioxide()`

Retrieves a CO2 sensor for a given identifier.

`YCarbonDioxide* yFindCarbonDioxide(NSString* func)`

The identifier can be specified using several formats:

- `FunctionLogicalName`
- `ModuleSerialNumber.FunctionIdentifier`
- `ModuleSerialNumber.FunctionLogicalName`
- `ModuleLogicalName.FunctionIdentifier`
- `ModuleLogicalName.FunctionLogicalName`

This function does not require that the CO2 sensor is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YCarbonDioxide.isOnline()` to test if the CO2 sensor is indeed online at a given time. In case of ambiguity when looking for a CO2 sensor by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

Parameters :

`func` a string that uniquely characterizes the CO2 sensor

Returns :

a `YCarbonDioxide` object allowing you to drive the CO2 sensor.

`yFirstCarbonDioxide()`

Starts the enumeration of CO2 sensors currently accessible.

`YCarbonDioxide* yFirstCarbonDioxide()`

Use the method `YCarbonDioxide.nextCarbonDioxide()` to iterate on next CO2 sensors.

Returns :

a pointer to a `YCarbonDioxide` object, corresponding to the first CO2 sensor currently online, or a `null` pointer if there are none.

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

It is possible to configure up to five correction points. Correction points must be provided in ascending order, and be in the range of the sensor. The device will automatically perform a linear interpolation of the error correction between specified points. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

For more information on advanced capabilities to refine the calibration of sensors, please contact support@yoctopuce.com.

Parameters :

rawValues array of floating point numbers, corresponding to the raw values returned by the sensor for the correction points.

refValues array of floating point numbers, corresponding to the corrected values for the correction points.

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[carbondioxide describe]

Returns a descriptive text that identifies the function.

`-(NSString*) describe`

The text always includes the class name, and may include as well either the logical name of the function or its hardware identifier.

Returns :

a string that describes the function

[carbondioxide advertisedValue]

Returns the current value of the CO2 sensor (no more than 6 characters).

`-(NSString*) advertisedValue`

Returns :

a string corresponding to the current value of the CO2 sensor (no more than 6 characters)

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

[carbondioxide currentRawValue]

Returns the uncalibrated, unrounded raw value returned by the sensor.

`-(double) currentRawValue`

Returns :

a floating point number corresponding to the uncalibrated, unrounded raw value returned by the sensor

On failure, throws an exception or returns `Y_CURRENTRAWVALUE_INVALID`.

[carbondioxide currentValue]

Returns the current measured value.

`-(double) currentValue`

Returns :

a floating point number corresponding to the current measured value

On failure, throws an exception or returns `Y_CURRENTVALUE_INVALID`.

Returns the error message of the latest error with this function.

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

Returns :

a string corresponding to the latest error message that occurred while using this function object

Returns the numerical error code of the latest error with this function.

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

Returns :

a number corresponding to the code of the latest error that occurred while using this function object

[carbondioxide carbondioxideDescriptor]

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

`-(YFUN_DESCR) functionDescriptor`

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

Returns :

an identifier of type `YFUN_DESCR`. If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

Returns the unique hardware identifier of the function.

The unique hardware identifier is made of the device serial number and of the hardware identifier of the function.

Returns :

a string that uniquely identifies the function. On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

[carbondioxide highestValue]

Returns the maximal value observed.

`-(double) highestValue`

Returns :

a floating point number corresponding to the maximal value observed

On failure, throws an exception or returns `Y_HIGHESTVALUE_INVALID`.

[carbondioxide logicalName]

Returns the logical name of the CO2 sensor.

`-(NSString*) logicalName`

Returns :

a string corresponding to the logical name of the CO2 sensor

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

[carbondioxide lowestValue]

Returns the minimal value observed.

-(double) lowestValue

Returns :

a floating point number corresponding to the minimal value observed

On failure, throws an exception or returns `Y_LOWESTVALUE_INVALID`.

[carbondioxide module]

Get the `YModule` object for the device on which the function is located.

-(YModule*) module

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

Returns :

an instance of `YModule`

Get the `YModule` object for the device on which the function is located (asynchronous version).

If the function cannot be located on any module, the returned `YModule` object does not show as on-line. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

Parameters :

callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the requested `YModule` object

context caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[carbondioxide resolution]

Returns the resolution of the measured values.

-(double) resolution

The resolution corresponds to the numerical precision of the values, which is not always the same as the actual precision of the sensor.

Returns :

a floating point number corresponding to the resolution of the measured values

On failure, throws an exception or returns `Y_RESOLUTION_INVALID`.

[carbondioxide unit]

Returns the measuring unit for the measured value.

-(NSString*) unit

Returns :

a string corresponding to the measuring unit for the measured value

On failure, throws an exception or returns `Y_UNIT_INVALID`.

[carbondioxide userData]

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

-(void*) **userData**

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

Returns :

the object stored previously by the caller.

[carbondioxide isOnline]

Checks if the function is currently reachable, without raising any error.

-(BOOL) **isOnline**

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

Returns :

`true` if the function can be reached, and `false` otherwise

Checks if the function is currently reachable, without raising any error (asynchronous version).

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox Javascript VM that does not implement context switching during blocking I/O calls.

Parameters :

callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the boolean result

context caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[carbondioxide load:]

Preloads the function cache with a specified validity duration.

-(YRETCODE) **load** : (int) **msValidity**

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

Parameters :

msValidity an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

Returns :

`YAPI_SUCCESS` when the call succeeds. On failure, throws an exception or returns a negative error code.

Preloads the function cache with a specified validity duration (asynchronous version).

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

Parameters :

msValidity an integer corresponding to the validity of the loaded function parameters, in milliseconds

callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the error code (or `YAPI_SUCCESS`)

context caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[carbondioxide nextCarbonDioxide]

Continues the enumeration of CO2 sensors started using `yFirstCarbonDioxide()`.

-(YCarbonDioxide*) **nextCarbonDioxide**

Returns :

a pointer to a `YCarbonDioxide` object, corresponding to a CO2 sensor currently online, or a `null` pointer if there are no more CO2 sensors to enumerate.

[carbondioxide registerValueCallback:]

Registers the callback function that is invoked on every change of advertised value.

-(void) **registerValueCallback** : (YFunctionUpdateCallback) **callback**

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

Parameters :

callback the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

[carbondioxide setHighestValue:]

Changes the recorded maximal value observed.

-(int) **setHighestValue** : (double) **newval**

Parameters :

newval a floating point number corresponding to the recorded maximal value observed

Returns :

YAPI_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

[carbondioxide setLogicalName:]

Changes the logical name of the CO2 sensor.

`-(int) setLogicalName : (NSString*) newval`

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

Parameters :

newval a string corresponding to the logical name of the CO2 sensor

Returns :

YAPI_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

[carbondioxide setLowestValue:]

Changes the recorded minimal value observed.

`-(int) setLowestValue : (double) newval`

Parameters :

newval a floating point number corresponding to the recorded minimal value observed

Returns :

YAPI_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

[carbondioxide setUserData:]

Stores a user context provided as argument in the userData attribute of the function.

`-(void) setUserData : (void*) data`

This attribute is never touched by the API, and is at disposal of the caller to store a context.

Parameters :

data any kind of object to be stored

3.4. ColorLed function interface

Yoctopuce application programming interface allows you to drive a color led using RGB coordinates as well as HSL coordinates. The module performs all conversions from RGB to HSL automatically. It is then self-evident to turn on a led with a given hue and to progressively vary its saturation or lightness. If needed, you can find more information on the difference between RGB and HSL in the section following this one.

In order to use the functions described here, you should include:

`#import "yocto_colorled.h"`

Global functions

`yFindColorLed(func)`

Retrieves an RGB led for a given identifier.

yFirstColorLed()

Starts the enumeration of RGB leds currently accessible.

YColorLed methods

colorled→describe()

Returns a descriptive text that identifies the function.

colorled→get_advertisedValue()

Returns the current value of the RGB led (no more than 6 characters).

colorled→get_errorMessage()

Returns the error message of the latest error with this function.

colorled→get_errorType()

Returns the numerical error code of the latest error with this function.

colorled→get_functionDescriptor()

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

colorled→get_hardwareId()

Returns the unique hardware identifier of the function.

colorled→get_hslColor()

Returns the current HSL color of the led.

colorled→get_logicalName()

Returns the logical name of the RGB led.

colorled→get_module()

Get the `YModule` object for the device on which the function is located.

colorled→get_module_async(callback, context)

Get the `YModule` object for the device on which the function is located (asynchronous version).

colorled→get_rgbColor()

Returns the current RGB color of the led.

colorled→get_rgbColorAtPowerOn()

Returns the configured color to be displayed when the module is turned on.

colorled→get_userData()

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

colorled→hslMove(hsl_target, ms_duration)

Performs a smooth transition in the HSL color space between the current color and a target color.

colorled→isOnline()

Checks if the function is currently reachable, without raising any error.

colorled→isOnline_async(callback, context)

Checks if the function is currently reachable, without raising any error (asynchronous version).

colorled→load(msValidity)

Preloads the function cache with a specified validity duration.

colorled→load_async(msValidity, callback, context)

Preloads the function cache with a specified validity duration (asynchronous version).

colorled→nextColorLed()

Continues the enumeration of RGB leds started using `yFirstColorLed()`.

colorled→registerValueCallback(callback)

Registers the callback function that is invoked on every change of advertised value.

colorled→**rgbMove**(**rgb_target**, **ms_duration**)

Performs a smooth transition in the RGB color space between the current color and a target color.

colorled→**set_hslColor**(**newval**)

Changes the current color of the led, using a color HSL.

colorled→**set_logicalName**(**newval**)

Changes the logical name of the RGB led.

colorled→**set_rgbColor**(**newval**)

Changes the current color of the led, using a RGB color.

colorled→**set_rgbColorAtPowerOn**(**newval**)

Changes the color that the led will display by default when the module is turned on.

colorled→**set_userData**(**data**)

Stores a user context provided as argument in the `userData` attribute of the function.

yFindColorLed()

Retrieves an RGB led for a given identifier.

YColorLed* **yFindColorLed**(**NSString*** **func**)

The identifier can be specified using several formats:

- `FunctionLogicalName`
- `ModuleSerialNumber.FunctionIdentifier`
- `ModuleSerialNumber.FunctionLogicalName`
- `ModuleLogicalName.FunctionIdentifier`
- `ModuleLogicalName.FunctionLogicalName`

This function does not require that the RGB led is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YColorLed.isOnline()` to test if the RGB led is indeed online at a given time. In case of ambiguity when looking for an RGB led by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

Parameters :

func a string that uniquely characterizes the RGB led

Returns :

a `YColorLed` object allowing you to drive the RGB led.

yFirstColorLed()

Starts the enumeration of RGB leds currently accessible.

YColorLed* **yFirstColorLed**()

Use the method `YColorLed.nextColorLed()` to iterate on next RGB leds.

Returns :

a pointer to a `YColorLed` object, corresponding to the first RGB led currently online, or a `null` pointer if there are none.

[colorled describe]

Returns a descriptive text that identifies the function.

`-(NSString*) describe`

The text always includes the class name, and may include as well either the logical name of the function or its hardware identifier.

Returns :
a string that describes the function

[colored advertisedValue]

Returns the current value of the RGB led (no more than 6 characters).

`-(NSString*) advertisedValue`

Returns :
a string corresponding to the current value of the RGB led (no more than 6 characters)

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

Returns the error message of the latest error with this function.

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

Returns :
a string corresponding to the latest error message that occurred while using this function object

Returns the numerical error code of the latest error with this function.

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

Returns :
a number corresponding to the code of the latest error that occurred while using this function object

[colored coloredDescriptor]

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

`-(YFUN_DESCR) functionDescriptor`

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

Returns :
an identifier of type `YFUN_DESCR`. If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

Returns the unique hardware identifier of the function.

The unique hardware identifier is made of the device serial number and of the hardware identifier of the function.

Returns :
a string that uniquely identifies the function On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

[colorled hslColor]

Returns the current HSL color of the led.

-(unsigned) hslColor

Returns :

an integer corresponding to the current HSL color of the led

On failure, throws an exception or returns `Y_HSLCOLOR_INVALID`.

[colorled logicalName]

Returns the logical name of the RGB led.

-(NSString*) logicalName

Returns :

a string corresponding to the logical name of the RGB led

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

[colorled module]

Get the `YModule` object for the device on which the function is located.

-(YModule*) module

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

Returns :

an instance of `YModule`

Get the `YModule` object for the device on which the function is located (asynchronous version).

If the function cannot be located on any module, the returned `YModule` object does not show as on-line. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

Parameters :

callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the requested `YModule` object

context caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[colorled rgbColor]

Returns the current RGB color of the led.

-(unsigned) rgbColor

Returns :

an integer corresponding to the current RGB color of the led

On failure, throws an exception or returns `Y_RGBCOLOR_INVALID`.

[colorled rgbColorAtPowerOn]

Returns the configured color to be displayed when the module is turned on.

-(unsigned) rgbColorAtPowerOn

Returns :

an integer corresponding to the configured color to be displayed when the module is turned on

On failure, throws an exception or returns `Y_RGBCOLORATPOWERON_INVALID`.

[colorled userData]

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

-(void*) userData

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

Returns :

the object stored previously by the caller.

[colorled hslMove:]

Performs a smooth transition in the HSL color space between the current color and a target color.

-(int) hslMove : (int) hsl_target : (int) ms_duration

Parameters :

hsl_target desired HSL color at the end of the transition

ms_duration duration of the transition, in millisecond

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[colorled isOnline]

Checks if the function is currently reachable, without raising any error.

-(BOOL) isOnline

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

Returns :

`true` if the function can be reached, and `false` otherwise

Checks if the function is currently reachable, without raising any error (asynchronous version).

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox Javascript VM that does not implement context switching during blocking I/O calls.

Parameters :

- callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the boolean result
- context** caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[colorled load:]

Preloads the function cache with a specified validity duration.

-(YRETCODE) **load** : (int) **msValidity**

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

Parameters :

- msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

Returns :

YAPI_SUCCESS when the call succeeds. On failure, throws an exception or returns a negative error code.

Preloads the function cache with a specified validity duration (asynchronous version).

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

Parameters :

- msValidity** an integer corresponding to the validity of the loaded function parameters, in milliseconds
- callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the error code (or YAPI_SUCCESS)
- context** caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[colorled nextColorLed]

Continues the enumeration of RGB leds started using `yFirstColorLed()`.

-(YColorLed*) **nextColorLed**

Returns :

a pointer to a `YColorLed` object, corresponding to an RGB led currently online, or a null pointer if there are no more RGB leds to enumerate.

[colorled registerValueCallback:]

Registers the callback function that is invoked on every change of advertised value.

-(void) **registerValueCallback** : (YFunctionUpdateCallback) **callback**

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

Parameters :

callback the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

[colorled rgbMove:]

Performs a smooth transition in the RGB color space between the current color and a target color.

-(int) **rgbMove** : (int) **rgb_target** : (int) **ms_duration**

Parameters :

rgb_target desired RGB color at the end of the transition

ms_duration duration of the transition, in millisecond

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[colorled setHslColor:]

Changes the current color of the led, using a color HSL.

-(int) **setHslColor** : (unsigned) **newval**

Encoding is done as follows: 0xHHSSLL.

Parameters :

newval an integer corresponding to the current color of the led, using a color HSL

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[colorled setLogicalName:]

Changes the logical name of the RGB led.

-(int) **setLogicalName** : (NSString*) **newval**

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

Parameters :

newval a string corresponding to the logical name of the RGB led

Returns :

YAPI_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

[colorled setRgbColor:]

Changes the current color of the led, using a RGB color.

-(int) setRgbColor : (unsigned) newval

Encoding is done as follows: 0xRRGGBB.

Parameters :

newval an integer corresponding to the current color of the led, using a RGB color

Returns :

YAPI_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

[colorled setRgbColorAtPowerOn:]

Changes the color that the led will display by default when the module is turned on.

-(int) setRgbColorAtPowerOn : (unsigned) newval

This color will be displayed as soon as the module is powered on. Remember to call the `saveToFlash()` method of the module if the change should be kept.

Parameters :

newval an integer corresponding to the color that the led will display by default when the module is turned on

Returns :

YAPI_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

[colorled setUserData:]

Stores a user context provided as argument in the userData attribute of the function.

-(void) setUserData : (void*) data

This attribute is never touched by the API, and is at disposal of the caller to store a context.

Parameters :

data any kind of object to be stored

3.5. Current function interface

The Yoctopuce application programming interface allows you to read an instant measure of the sensor, as well as the minimal and maximal values observed.

In order to use the functions described here, you should include:

#import "yocto_current.h"

Global functions

yFindCurrent(func)

Retrieves a current sensor for a given identifier.

yFirstCurrent()

Starts the enumeration of current sensors currently accessible.

YCurrent methods

current→calibrateFromPoints(rawValues, refValues)

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

current→describe()

Returns a descriptive text that identifies the function.

current→get_advertisedValue()

Returns the current value of the current sensor (no more than 6 characters).

current→get_currentRawValue()

Returns the uncalibrated, unrounded raw value returned by the sensor.

current→get_currentValue()

Returns the current measured value.

current→get_errorMessage()

Returns the error message of the latest error with this function.

current→get_errorType()

Returns the numerical error code of the latest error with this function.

current→get_functionDescriptor()

Returns a unique identifier of type YFUN_DESCR corresponding to the function.

current→get_hardwareId()

Returns the unique hardware identifier of the function.

current→get_highestValue()

Returns the maximal value observed.

current→get_logicalName()

Returns the logical name of the current sensor.

current→get_lowestValue()

Returns the minimal value observed.

current→get_module()

Get the YModule object for the device on which the function is located.

current→get_module_async(callback, context)

Get the YModule object for the device on which the function is located (asynchronous version).

current→get_resolution()

Returns the resolution of the measured values.

current→get_unit()

Returns the measuring unit for the measured value.

current→get_userData()

Returns the value of the userData attribute, as previously stored using method set_userData.

current→isOnline()

Checks if the function is currently reachable, without raising any error.

current→isOnline_async(callback, context)

Checks if the function is currently reachable, without raising any error (asynchronous version).

current→load(msValidity)

Preloads the function cache with a specified validity duration.

current→**load_async**(**msValidity**, **callback**, **context**)

Preloads the function cache with a specified validity duration (asynchronous version).

current→**nextCurrent**()

Continues the enumeration of current sensors started using `yFirstCurrent()`.

current→**registerValueCallback**(**callback**)

Registers the callback function that is invoked on every change of advertised value.

current→**set_highestValue**(**newval**)

Changes the recorded maximal value observed.

current→**set_logicalName**(**newval**)

Changes the logical name of the current sensor.

current→**set_lowestValue**(**newval**)

Changes the recorded minimal value observed.

current→**set_userData**(**data**)

Stores a user context provided as argument in the `userData` attribute of the function.

yFindCurrent()

Retrieves a current sensor for a given identifier.

YCurrent* **yFindCurrent**(**NSString*** **func**)

The identifier can be specified using several formats:

- `FunctionLogicalName`
- `ModuleSerialNumber.FunctionIdentifier`
- `ModuleSerialNumber.FunctionLogicalName`
- `ModuleLogicalName.FunctionIdentifier`
- `ModuleLogicalName.FunctionLogicalName`

This function does not require that the current sensor is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YCurrent.isOnline()` to test if the current sensor is indeed online at a given time. In case of ambiguity when looking for a current sensor by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

Parameters :

func a string that uniquely characterizes the current sensor

Returns :

a `YCurrent` object allowing you to drive the current sensor.

yFirstCurrent()

Starts the enumeration of current sensors currently accessible.

YCurrent* **yFirstCurrent**()

Use the method `YCurrent.nextCurrent()` to iterate on next current sensors.

Returns :

a pointer to a `YCurrent` object, corresponding to the first current sensor currently online, or a `null` pointer if there are none.

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

It is possible to configure up to five correction points. Correction points must be provided in ascending order, and be in the range of the sensor. The device will automatically perform a linear interpolation of the error correction between specified points. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

For more information on advanced capabilities to refine the calibration of sensors, please contact support@yoctopuce.com.

Parameters :

rawValues array of floating point numbers, corresponding to the raw values returned by the sensor for the correction points.

refValues array of floating point numbers, corresponding to the corrected values for the correction points.

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[current describe]

Returns a descriptive text that identifies the function.

`-(NSString*) describe`

The text always includes the class name, and may include as well either the logical name of the function or its hardware identifier.

Returns :

a string that describes the function

[current advertisedValue]

Returns the current value of the current sensor (no more than 6 characters).

`-(NSString*) advertisedValue`

Returns :

a string corresponding to the current value of the current sensor (no more than 6 characters)

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

[current currentRawValue]

Returns the uncalibrated, unrounded raw value returned by the sensor.

`-(double) currentRawValue`

Returns :

a floating point number corresponding to the uncalibrated, unrounded raw value returned by the sensor

On failure, throws an exception or returns `Y_CURRENTRAWVALUE_INVALID`.

[current currentValue]

Returns the current measured value.

`-(double) currentValue`

Returns :

a floating point number corresponding to the current measured value

On failure, throws an exception or returns `Y_CURRENTVALUE_INVALID`.

Returns the error message of the latest error with this function.

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

Returns :

a string corresponding to the latest error message that occurred while using this function object

Returns the numerical error code of the latest error with this function.

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

Returns :

a number corresponding to the code of the latest error that occurred while using this function object

[current currentDescriptor]

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

`-(YFUN_DESCR) functionDescriptor`

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

Returns :

an identifier of type `YFUN_DESCR`. If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

Returns the unique hardware identifier of the function.

The unique hardware identifier is made of the device serial number and of the hardware identifier of the function.

Returns :

a string that uniquely identifies the function On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

[current highestValue]

Returns the maximal value observed.

`-(double) highestValue`

Returns :

a floating point number corresponding to the maximal value observed

On failure, throws an exception or returns `Y_HIGHESTVALUE_INVALID`.

[current logicalName]

Returns the logical name of the current sensor.

`-(NSString*) logicalName`

Returns :

a string corresponding to the logical name of the current sensor

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

[current lowestValue]

Returns the minimal value observed.

-(double) lowestValue

Returns :

a floating point number corresponding to the minimal value observed

On failure, throws an exception or returns `Y_LOWESTVALUE_INVALID`.

[current module]

Get the `YModule` object for the device on which the function is located.

-(YModule*) module

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

Returns :

an instance of `YModule`

Get the `YModule` object for the device on which the function is located (asynchronous version).

If the function cannot be located on any module, the returned `YModule` object does not show as on-line. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

Parameters :

callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the requested `YModule` object

context caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[current resolution]

Returns the resolution of the measured values.

-(double) resolution

The resolution corresponds to the numerical precision of the values, which is not always the same as the actual precision of the sensor.

Returns :

a floating point number corresponding to the resolution of the measured values

On failure, throws an exception or returns `Y_RESOLUTION_INVALID`.

[current unit]

Returns the measuring unit for the measured value.

-(NSString*) unit

Returns :

a string corresponding to the measuring unit for the measured value

On failure, throws an exception or returns Y_UNIT_INVALID.

[current userData]

Returns the value of the userData attribute, as previously stored using method set_userdata.

-(void*) userData

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

Returns :

the object stored previously by the caller.

[current isOnline]

Checks if the function is currently reachable, without raising any error.

-(BOOL) isOnline

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

Returns :

true if the function can be reached, and false otherwise

Checks if the function is currently reachable, without raising any error (asynchronous version).

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox Javascript VM that does not implement context switching during blocking I/O calls.

Parameters :

callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the boolean result

context caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[current load:]

Preloads the function cache with a specified validity duration.

-(YRETCODE) **load** : (int) **msValidity**

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

Parameters :

msValidity an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

Returns :

YAPI_SUCCESS when the call succeeds. On failure, throws an exception or returns a negative error code.

Preloads the function cache with a specified validity duration (asynchronous version).

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

Parameters :

msValidity an integer corresponding to the validity of the loaded function parameters, in milliseconds

callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the error code (or YAPI_SUCCESS)

context caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[current nextCurrent]

Continues the enumeration of current sensors started using `yFirstCurrent()`.

-(YCurrent*) **nextCurrent**

Returns :

a pointer to a YCurrent object, corresponding to a current sensor currently online, or a null pointer if there are no more current sensors to enumerate.

[current registerValueCallback:]

Registers the callback function that is invoked on every change of advertised value.

-(void) **registerValueCallback** : (YFunctionUpdateCallback) **callback**

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

Parameters :

callback the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

[current setHighestValue:]

Changes the recorded maximal value observed.

`-(int) setHighestValue : (double) newval`

Parameters :

newval a floating point number corresponding to the recorded maximal value observed

Returns :

YAPI_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

[current setLogicalName:]

Changes the logical name of the current sensor.

`-(int) setLogicalName : (NSString*) newval`

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

Parameters :

newval a string corresponding to the logical name of the current sensor

Returns :

YAPI_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

[current setLowestValue:]

Changes the recorded minimal value observed.

`-(int) setLowestValue : (double) newval`

Parameters :

newval a floating point number corresponding to the recorded minimal value observed

Returns :

YAPI_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

[current setUserData:]

Stores a user context provided as argument in the userData attribute of the function.

`-(void) setUserData : (void*) data`

This attribute is never touched by the API, and is at disposal of the caller to store a context.

Parameters :

data any kind of object to be stored

3.6. DataLogger function interface

Yoctopuce sensors include a non-volatile memory capable of storing ongoing measured data automatically, without requiring a permanent connection to a computer. The Yoctopuce

application programming interface includes functions to control how this internal data logger works. Because the sensors do not include a battery, they do not have an absolute time reference. Therefore, measures are simply indexed by the absolute run number and time relative to the start of the run. Every new power up starts a new run. It is however possible to setup an absolute UTC time by software at a given time, so that the data logger keeps track of it until it is next powered off.

In order to use the functions described here, you should include:

```
#import "yocto_datalogger.h"
```

Global functions

yFindDataLogger(func)

Retrieves a data logger for a given identifier.

yFirstDataLogger()

Starts the enumeration of data loggers currently accessible.

YDataLogger methods

datalogger→describe()

Returns a descriptive text that identifies the function.

datalogger→forgetAllDataStreams()

Clears the data logger memory and discards all recorded data streams.

datalogger→get_advertisedValue()

Returns the current value of the data logger (no more than 6 characters).

datalogger→get_autoStart()

Returns the default activation state of the data logger on power up.

datalogger→get_currentRunIndex()

Returns the current run number, corresponding to the number of times the module was powered on with the dataLogger enabled at some point.

datalogger→get_dataRun(runIdx)

Returns a data run object holding all measured data for a given period during which the module was turned on (a run).

datalogger→get_dataStreams(v)

Builds a list of all data streams hold by the data logger.

datalogger→get_errorMessage()

Returns the error message of the latest error with this function.

datalogger→get_errorType()

Returns the numerical error code of the latest error with this function.

datalogger→get_functionDescriptor()

Returns a unique identifier of type YFUN_DESCR corresponding to the function.

datalogger→get_hardwareId()

Returns the unique hardware identifier of the function.

datalogger→get_logicalName()

Returns the logical name of the data logger.

datalogger→get_measureNames()

Returns the names of the measures recorded by the data logger.

datalogger→get_module()

Get the YModule object for the device on which the function is located.

datalogger→get_module_async(callback, context)

Get the `YModule` object for the device on which the function is located (asynchronous version).

`datalogger→get_oldestRunIndex()`

Returns the index of the oldest run for which the non-volatile memory still holds recorded data.

`datalogger→get_recording()`

Returns the current activation state of the data logger.

`datalogger→get_timeUTC()`

Returns the Unix timestamp for current UTC time, if known.

`datalogger→get_userData()`

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

`datalogger→isOnline()`

Checks if the function is currently reachable, without raising any error.

`datalogger→isOnline_async(callback, context)`

Checks if the function is currently reachable, without raising any error (asynchronous version).

`datalogger→load(msValidity)`

Preloads the function cache with a specified validity duration.

`datalogger→load_async(msValidity, callback, context)`

Preloads the function cache with a specified validity duration (asynchronous version).

`datalogger→nextDataLogger()`

Continues the enumeration of data loggers started using `yFirstDataLogger()`.

`datalogger→registerValueCallback(callback)`

Registers the callback function that is invoked on every change of advertised value.

`datalogger→set_autoStart(newval)`

Changes the default activation state of the data logger on power up.

`datalogger→set_logicalName(newval)`

Changes the logical name of the data logger.

`datalogger→set_recording(newval)`

Changes the activation state of the data logger to start/stop recording data.

`datalogger→set_timeUTC(newval)`

Changes the current UTC time reference used for recorded data.

`datalogger→set_userData(data)`

Stores a user context provided as argument in the `userData` attribute of the function.

`yFindDataLogger()`

Retrieves a data logger for a given identifier.

`YDataLogger* yFindDataLogger(NSString* func)`

The identifier can be specified using several formats:

- `FunctionLogicalName`
- `ModuleSerialNumber.FunctionIdentifier`
- `ModuleSerialNumber.FunctionLogicalName`
- `ModuleLogicalName.FunctionIdentifier`
- `ModuleLogicalName.FunctionLogicalName`

This function does not require that the data logger is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YDataLogger.isOnline()` to test if

the data logger is indeed online at a given time. In case of ambiguity when looking for a data logger by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

Parameters :

func a string that uniquely characterizes the data logger

Returns :

a `YDataLogger` object allowing you to drive the data logger.

yFirstDataLogger()

Starts the enumeration of data loggers currently accessible.

`YDataLogger* yFirstDataLogger()`

Use the method `YDataLogger.nextDataLogger()` to iterate on next data loggers.

Returns :

a pointer to a `YDataLogger` object, corresponding to the first data logger currently online, or a `null` pointer if there are none.

[datalogger describe]

Returns a descriptive text that identifies the function.

`-(NSString*) describe`

The text always includes the class name, and may include as well either the logical name of the function or its hardware identifier.

Returns :

a string that describes the function

[datalogger forgetAllDataStreams]

Clears the data logger memory and discards all recorded data streams.

`-(int) forgetAllDataStreams`

This method also resets the current run index to zero.

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[datalogger advertisedValue]

Returns the current value of the data logger (no more than 6 characters).

`-(NSString*) advertisedValue`

Returns :

a string corresponding to the current value of the data logger (no more than 6 characters)

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

[datalogger autoStart]

Returns the default activation state of the data logger on power up.

-(Y_AUTOSTART_enum) autoStart

Returns :

either Y_AUTOSTART_OFF or Y_AUTOSTART_ON, according to the default activation state of the dataLogger on power up

On failure, throws an exception or returns Y_AUTOSTART_INVALID.

[dataLogger currentRunIndex]

Returns the current run number, corresponding to the number of times the module was powered on with the dataLogger enabled at some point.

-(unsigned) currentRunIndex

Returns :

an integer corresponding to the current run number, corresponding to the number of times the module was powered on with the dataLogger enabled at some point

On failure, throws an exception or returns Y_CURRENTRUNINDEX_INVALID.

Returns a data run object holding all measured data for a given period during which the module was turned on (a run).

This object can then be used to retrieve measures (min, average and max) at a desired data rate.

Parameters :

runIdx the index of the desired run

Returns :

an YDataRun object

On failure, throws an exception or returns null.

[dataLogger dataStreams:]

Builds a list of all data streams hold by the data logger.

-(int) dataStreams : (NSArray**) **v**

The caller must pass by reference an empty array to hold YDataStream objects, and the function fills it with objects describing available data sequences.

Parameters :

v an array of YDataStream objects to be filled in

Returns :

YAPI_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

Returns the error message of the latest error with this function.

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

Returns :

a string corresponding to the latest error message that occurred while using this function object

Returns the numerical error code of the latest error with this function.

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

Returns :

a number corresponding to the code of the latest error that occurred while using this function object

[**datalogger** **dataloggerDescriptor**]

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

`-(YFUN_DESCR) functionDescriptor`

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

Returns :

an identifier of type `YFUN_DESCR`. If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

Returns the unique hardware identifier of the function.

The unique hardware identifier is made of the device serial number and of the hardware identifier of the function.

Returns :

a string that uniquely identifies the function On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

[**datalogger** **logicalName**]

Returns the logical name of the data logger.

`-(NSString*) logicalName`

Returns :

a string corresponding to the logical name of the data logger

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

Returns the names of the measures recorded by the data logger.

In most case, the measure names match the hardware identifier of the sensor that produced the data.

Returns :

a list of strings (the measure names) On failure, throws an exception or returns an empty array.

[**datalogger** **module**]

Get the `YModule` object for the device on which the function is located.

`-(YModule*) module`

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

Returns :

an instance of `YModule`

Get the `YModule` object for the device on which the function is located (asynchronous version).

If the function cannot be located on any module, the returned `YModule` object does not show as on-line. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

Parameters :

callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the requested `YModule` object

context caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[**datalogger oldestRunIndex**]

Returns the index of the oldest run for which the non-volatile memory still holds recorded data.

-(unsigned) `oldestRunIndex`

Returns :

an integer corresponding to the index of the oldest run for which the non-volatile memory still holds recorded data

On failure, throws an exception or returns `Y_OLDESTRUNINDEX_INVALID`.

[**datalogger recording**]

Returns the current activation state of the data logger.

-(`Y_RECORDING_enum`) `recording`

Returns :

either `Y_RECORDING_OFF` or `Y_RECORDING_ON`, according to the current activation state of the data logger

On failure, throws an exception or returns `Y_RECORDING_INVALID`.

[**datalogger timeUTC**]

Returns the Unix timestamp for current UTC time, if known.

-(unsigned) `timeUTC`

Returns :

an integer corresponding to the Unix timestamp for current UTC time, if known

On failure, throws an exception or returns `Y_TIMEUTC_INVALID`.

[**datalogger userData**]

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

-(void*) userData

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

Returns :
the object stored previously by the caller.

[datalogger isOnline]

Checks if the function is currently reachable, without raising any error.

-(BOOL) isOnline

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

Returns :
`true` if the function can be reached, and `false` otherwise

Checks if the function is currently reachable, without raising any error (asynchronous version).

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox Javascript VM that does not implement context switching during blocking I/O calls.

Parameters :
callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the boolean result
context caller-specific object that is passed as-is to the callback function

Returns :
nothing : the result is provided to the callback.

[datalogger load:]

Preloads the function cache with a specified validity duration.

-(YRETCODE) load : (int) msValidity

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

Parameters :
msValidity an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

Returns :
`YAPI_SUCCESS` when the call succeeds. On failure, throws an exception or returns a negative error code.

Preloads the function cache with a specified validity duration (asynchronous version).

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

Parameters :

- msValidity** an integer corresponding to the validity of the loaded function parameters, in milliseconds
- callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the error code (or `YAPI_SUCCESS`)
- context** caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[**datalogger nextDataLogger**]

Continues the enumeration of data loggers started using `yFirstDataLogger()`.

-(YDataLogger*) **nextDataLogger**

Returns :

a pointer to a `YDataLogger` object, corresponding to a data logger currently online, or a null pointer if there are no more data loggers to enumerate.

[**datalogger registerValueCallback:**]

Registers the callback function that is invoked on every change of advertised value.

-(void) **registerValueCallback** : (YFunctionUpdateCallback) **callback**

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

Parameters :

- callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

[**datalogger setAutoStart:**]

Changes the default activation state of the data logger on power up.

-(int) **setAutoStart** : (Y_AUTOSTART_enum) **newval**

Remember to call the `saveToFlash()` method of the module if the modification must be kept.

Parameters :

- newval** either `Y_AUTOSTART_OFF` or `Y_AUTOSTART_ON`, according to the default activation state of the data logger on power up

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[datalogger setLogicalName:]

Changes the logical name of the data logger.

-(int) setLogicalName : (NSString*) newval

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

Parameters :

newval a string corresponding to the logical name of the data logger

Returns :

YAPI_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

[datalogger setRecording:]

Changes the activation state of the data logger to start/stop recording data.

-(int) setRecording : (Y_RECORDING_enum) newval

Parameters :

newval either `Y_RECORDING_OFF` or `Y_RECORDING_ON`, according to the activation state of the data logger to start/stop recording data

Returns :

YAPI_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

[datalogger setTimeUTC:]

Changes the current UTC time reference used for recorded data.

-(int) setTimeUTC : (unsigned) newval

Parameters :

newval an integer corresponding to the current UTC time reference used for recorded data

Returns :

YAPI_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

[datalogger setUserData:]

Stores a user context provided as argument in the userData attribute of the function.

-(void) setUserData : (void*) data

This attribute is never touched by the API, and is at disposal of the caller to store a context.

Parameters :

data any kind of object to be stored

3.7. Formatted data sequence

A run is a continuous interval of time during which a module was powered on. A data run provides easy access to all data collected during a given run, providing on-the-fly resampling at the desired reporting rate.

In order to use the functions described here, you should include:

```
#import "yocto_datalogger.h"
```

YDataRun methods

datarun→get_averageValue(measureName, pos)

Returns the average value of the measure observed at the specified time period.

datarun→get_duration()

Returns the duration (in seconds) of the data run.

datarun→get_maxValue(measureName, pos)

Returns the maximal value of the measure observed at the specified time period.

datarun→get_measureNames()

Returns the names of the measures recorded by the data logger.

datarun→get_minValue(measureName, pos)

Returns the minimal value of the measure observed at the specified time period.

datarun→get_startTimeUTC()

Returns the start time of the data run, relative to the Jan 1, 1970.

datarun→get_valueCount()

Returns the number of values accessible in this run, given the selected data samples interval.

datarun→get_valueInterval()

Returns the number of seconds covered by each value in this run.

datarun→set_valueInterval(valueInterval)

Changes the number of seconds covered by each value in this run.

Returns the average value of the measure observed at the specified time period.

Parameters :

measureName the name of the desired measure (one of the names returned by `get_measureNames`)

pos the position index, between 0 and the value returned by `get_valueCount`

Returns :

a floating point number (the average value)

On failure, throws an exception or returns `Y_AVERAGEVALUE_INVALID`.

Returns the duration (in seconds) of the data run.

When the datalogger is actively recording and the specified run is the current run, calling this method reloads last sequence(s) from device to make sure it includes the latest recorded data.

Returns :

an unsigned number corresponding to the number of seconds between the beginning of the run (when the module was powered up) and the last recorded measure.

Returns the maximal value of the measure observed at the specified time period.

Parameters :

measureName the name of the desired measure (one of the names returned by `get_measureNames`)
pos the position index, between 0 and the value returned by `get_valueCount`

Returns :

a floating point number (the maximal value)

On failure, throws an exception or returns `Y_MAXVALUE_INVALID`.

Returns the names of the measures recorded by the data logger.

In most case, the measure names match the hardware identifier of the sensor that produced the data.

Returns :

a list of strings (the measure names) On failure, throws an exception or returns an empty array.

Returns the minimal value of the measure observed at the specified time period.

Parameters :

measureName the name of the desired measure (one of the names returned by `get_measureNames`)
pos the position index, between 0 and the value returned by `get_valueCount`

Returns :

a floating point number (the minimal value)

On failure, throws an exception or returns `Y_MINVALUE_INVALID`.

Returns the start time of the data run, relative to the Jan 1, 1970.

If the UTC time was not set in the datalogger at any time during the recording of this data run, and if this is not the current run, this method returns 0.

Returns :

an unsigned number corresponding to the number of seconds between the Jan 1, 1970 and the beginning of this data run (i.e. Unix time representation of the absolute time).

Returns the number of values accessible in this run, given the selected data samples interval.

When the datalogger is actively recording and the specified run is the current run, calling this method reloads last sequence(s) from device to make sure it includes the latest recorded data.

Returns :

an unsigned number corresponding to the run duration divided by the samples interval.

Returns the number of seconds covered by each value in this run.

By default, the value interval is set to the coarsest data rate archived in the data logger flash for this run. The value interval can however be configured at will to a different rate when desired.

Returns :

an unsigned number corresponding to a number of seconds covered by each data sample in the Run.

Changes the number of seconds covered by each value in this run.

By default, the value interval is set to the coarsest data rate archived in the data logger flash for this run. The value interval can however be configured at will to a different rate when desired.

Parameters :

valueInterval an integer number of seconds.

Returns :

nothing

3.8. Recorded data sequence

DataStream objects represent a recorded measure sequence. They are returned by the data logger present on Yoctopuce sensors.

In order to use the functions described here, you should include:

```
#import "yocto_datalogger.h"
```

YDataStream methods

datastream→get_columnCount()

Returns the number of data columns present in this stream.

datastream→get_columnNames()

Returns the title (or meaning) of each data column present in this stream.

datastream→get_data(row, col)

Returns a single measure from the data stream, specified by its row and column index.

datastream→get_dataRows()

Returns the whole data set contained in the stream, as a bidimensional table of numbers.

datastream→get_dataSamplesInterval()

Returns the number of seconds elapsed between two consecutive rows of this data stream.

datastream→get_rowCount()

Returns the number of data rows present in this stream.

datastream→get_runIndex()

Returns the run index of the data stream.

datastream→get_startTime()

Returns the start time of the data stream, relative to the beginning of the run.

datastream→get_startTimeUTC()

Returns the start time of the data stream, relative to the Jan 1, 1970.

[datastream columnCount]

Returns the number of data columns present in this stream.

-(unsigned) columnCount

The meaning of the values present in each column can be obtained using the method `get_columnNames()`.

This method fetches the whole data stream from the device, if not yet done.

an unsigned number corresponding to the number of rows. On failure, throws an exception or returns zero.

Returns the title (or meaning) of each data column present in this stream.

In most case, the title of the data column is the hardware identifier of the sensor that produced the data. For archived streams created by summarizing a high-resolution data stream, there can be a suffix appended to the sensor identifier, such as `_min` for the minimum value, `_avg` for the average value and `_max` for the maximal value.

a list containing as many strings as there are columns in the data stream. On failure, throws an exception or returns an empty array.

a floating-point number On failure, throws an exception or returns Y_DATA_INVALID.

-(unsigned) dataSamplesInterval

By default, the data logger records one row per second, but there might be alternative streams at lower resolution created by summarizing the original stream for archiving purposes.

This method does not cause any access to the device, as the value is preloaded in the object at instantiation time.

Returns :

an unsigned number corresponding to a number of seconds.

[datastream rowCount]

Returns the number of data rows present in this stream.

-(unsigned) rowCount

This method fetches the whole data stream from the device, if not yet done.

Returns :

an unsigned number corresponding to the number of rows. On failure, throws an exception or returns zero.

[datastream runIndex]

Returns the run index of the data stream.

-(unsigned) runIndex

A run can be made of multiple datastreams, for different time intervals. This method does not cause any access to the device, as the value is preloaded in the object at instantiation time.

Returns :

an unsigned number corresponding to the run index.

[datastream startTime]

Returns the start time of the data stream, relative to the beginning of the run.

-(unsigned) startTime

If you need an absolute time, use `get_startTimeUTC()`.

This method does not cause any access to the device, as the value is preloaded in the object at instantiation time.

Returns :

an unsigned number corresponding to the number of seconds between the start of the run and the beginning of this data stream.

[datastream startTimeUTC]

Returns the start time of the data stream, relative to the Jan 1, 1970.

-(time_t) startTimeUTC

If the UTC time was not set in the datalogger at the time of the recording of this data stream, this method returns 0.

This method does not cause any access to the device, as the value is preloaded in the object at instantiation time.

Returns :

an unsigned number corresponding to the number of seconds between the Jan 1, 1970 and the beginning of this data stream (i.e. Unix time representation of the absolute time).

3.9. External power supply control interface

Yoctopuce application programming interface allows you to control the power source to use for module functions that require high current. The module can also automatically disconnect the external power when a voltage drop is observed on the external power source (external battery running out of power).

In order to use the functions described here, you should include:

```
#import "yocto_dualpower.h"
```

Global functions	
yFindDualPower(func)	Retrieves a dual power control for a given identifier.
yFirstDualPower()	Starts the enumeration of dual power controls currently accessible.
YDualPower methods	
dualpower→describe()	Returns a descriptive text that identifies the function.
dualpower→get_advertisedValue()	Returns the current value of the power control (no more than 6 characters).
dualpower→get_errorMessage()	Returns the error message of the latest error with this function.
dualpower→get_errorType()	Returns the numerical error code of the latest error with this function.
dualpower→get_extVoltage()	Returns the measured voltage on the external power source, in millivolts.
dualpower→get_functionDescriptor()	Returns a unique identifier of type YFUN_DESCR corresponding to the function.
dualpower→get_hardwareId()	Returns the unique hardware identifier of the function.
dualpower→get_logicalName()	Returns the logical name of the power control.
dualpower→get_module()	Get the YModule object for the device on which the function is located.
dualpower→get_module_async(callback, context)	Get the YModule object for the device on which the function is located (asynchronous version).
dualpower→get_powerControl()	Returns the selected power source for module functions that require lots of current.
dualpower→get_powerState()	Returns the current power source for module functions that require lots of current.
dualpower→get_userData()	Returns the value of the userData attribute, as previously stored using method set_userData.
dualpower→isOnline()	Checks if the function is currently reachable, without raising any error.
dualpower→isOnline_async(callback, context)	Checks if the function is currently reachable, without raising any error (asynchronous version).
dualpower→load(msValidity)	

Preloads the function cache with a specified validity duration.

dualpower→**load_async**(**msValidity**, **callback**, **context**)

Preloads the function cache with a specified validity duration (asynchronous version).

dualpower→**nextDualPower**()

Continues the enumeration of dual power controls started using `yFirstDualPower()`.

dualpower→**registerValueCallback**(**callback**)

Registers the callback function that is invoked on every change of advertised value.

dualpower→**set_logicalName**(**newval**)

Changes the logical name of the power control.

dualpower→**set_powerControl**(**newval**)

Changes the selected power source for module functions that require lots of current.

dualpower→**set_userData**(**data**)

Stores a user context provided as argument in the `userData` attribute of the function.

yFindDualPower()

Retrieves a dual power control for a given identifier.

`YDualPower*` **yFindDualPower**(`NSString*` **func**)

The identifier can be specified using several formats:

- `FunctionLogicalName`
- `ModuleSerialNumber.FunctionIdentifier`
- `ModuleSerialNumber.FunctionLogicalName`
- `ModuleLogicalName.FunctionIdentifier`
- `ModuleLogicalName.FunctionLogicalName`

This function does not require that the power control is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YDualPower.isOnline()` to test if the power control is indeed online at a given time. In case of ambiguity when looking for a dual power control by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

Parameters :

func a string that uniquely characterizes the power control

Returns :

a `YDualPower` object allowing you to drive the power control.

yFirstDualPower()

Starts the enumeration of dual power controls currently accessible.

`YDualPower*` **yFirstDualPower**()

Use the method `YDualPower.nextDualPower()` to iterate on next dual power controls.

Returns :

a pointer to a `YDualPower` object, corresponding to the first dual power control currently online, or a `null` pointer if there are none.

[dualpower describe]

Returns a descriptive text that identifies the function.

`-(NSString*) describe`

The text always includes the class name, and may include as well either the logical name of the function or its hardware identifier.

Returns :
a string that describes the function

[dualpower advertisedValue]

Returns the current value of the power control (no more than 6 characters).

`-(NSString*) advertisedValue`

Returns :
a string corresponding to the current value of the power control (no more than 6 characters)

On failure, throws an exception or returns `Y__ADVERTISEDVALUE__INVALID`.

Returns the error message of the latest error with this function.

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

Returns :
a string corresponding to the latest error message that occurred while using this function object

Returns the numerical error code of the latest error with this function.

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

Returns :
a number corresponding to the code of the latest error that occurred while using this function object

[dualpower extVoltage]

Returns the measured voltage on the external power source, in millivolts.

`-(unsigned) extVoltage`

Returns :
an integer corresponding to the measured voltage on the external power source, in millivolts

On failure, throws an exception or returns `Y__EXTVOLTAGE__INVALID`.

[dualpower dualpowerDescriptor]

Returns a unique identifier of type `YFUN__DESCR` corresponding to the function.

`-(YFUN__DESCR) functionDescriptor`

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

Returns :
an identifier of type `YFUN__DESCR`. If the function has never been contacted, the returned value is `Y__FUNCTIONDESCRIPTOR__INVALID`.

Returns the unique hardware identifier of the function.

The unique hardware identifier is made of the device serial number and of the hardware identifier of the function.

Returns :

a string that uniquely identifies the function On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

[dualpower logicalName]

Returns the logical name of the power control.

`-(NSString*) logicalName`

Returns :

a string corresponding to the logical name of the power control

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

[dualpower module]

Get the `YModule` object for the device on which the function is located.

`-(YModule*) module`

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

Returns :

an instance of `YModule`

Get the `YModule` object for the device on which the function is located (asynchronous version).

If the function cannot be located on any module, the returned `YModule` object does not show as on-line. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

Parameters :

callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the requested `YModule` object

context caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[dualpower powerControl]

Returns the selected power source for module functions that require lots of current.

`-(Y_POWERCONTROL_enum) powerControl`

Returns :

a value among `Y_POWERCONTROL_AUTO`, `Y_POWERCONTROL_FROM_USB`, `Y_POWERCONTROL_FROM_EXT` and `Y_POWERCONTROL_OFF` corresponding to the selected power source for module functions that require lots of current

On failure, throws an exception or returns `Y_POWERCONTROL_INVALID`.

[dualpower powerState]

Returns the current power source for module functions that require lots of current.

-(Y_POWERSTATE_enum) powerState

Returns :

a value among `Y_POWERSTATE_OFF`, `Y_POWERSTATE_FROM_USB` and `Y_POWERSTATE_FROM_EXT` corresponding to the current power source for module functions that require lots of current

On failure, throws an exception or returns `Y_POWERSTATE_INVALID`.

[dualpower userData]

Returns the value of the `userData` attribute, as previously stored using method `set_userdata`.

-(void*) userData

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

Returns :

the object stored previously by the caller.

[dualpower isOnline]

Checks if the function is currently reachable, without raising any error.

-(BOOL) isOnline

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

Returns :

`true` if the function can be reached, and `false` otherwise

Checks if the function is currently reachable, without raising any error (asynchronous version).

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox Javascript VM that does not implement context switching during blocking I/O calls.

Parameters :

callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the boolean result

context caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[dualpower load:]

Preloads the function cache with a specified validity duration.

-(YRETCODE) **load** : (int) **msValidity**

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

Parameters :

msValidity an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

Returns :

`YAPI_SUCCESS` when the call succeeds. On failure, throws an exception or returns a negative error code.

Preloads the function cache with a specified validity duration (asynchronous version).

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

Parameters :

msValidity an integer corresponding to the validity of the loaded function parameters, in milliseconds

callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the error code (or `YAPI_SUCCESS`)

context caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[dualpower nextDualPower]

Continues the enumeration of dual power controls started using `yFirstDualPower()`.

-(YDualPower*) **nextDualPower**

Returns :

a pointer to a `YDualPower` object, corresponding to a dual power control currently online, or a `null` pointer if there are no more dual power controls to enumerate.

[dualpower registerValueCallback:]

Registers the callback function that is invoked on every change of advertised value.

-(void) **registerValueCallback** : (YFunctionUpdateCallback) **callback**

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

Parameters :

callback the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

[dualpower setLogicalName:]

Changes the logical name of the power control.

`-(int) setLogicalName : (NSString*) newval`

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

Parameters :

newval a string corresponding to the logical name of the power control

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[dualpower setPowerControl:]

Changes the selected power source for module functions that require lots of current.

`-(int) setPowerControl : (Y_POWERCONTROL_enum) newval`

Parameters :

newval a value among `Y_POWERCONTROL_AUTO`, `Y_POWERCONTROL_FROM_USB`, `Y_POWERCONTROL_FROM_EXT` and `Y_POWERCONTROL_OFF` corresponding to the selected power source for module functions that require lots of current

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[dualpower setUserData:]

Stores a user context provided as argument in the `userData` attribute of the function.

`-(void) setUserData : (void*) data`

This attribute is never touched by the API, and is at disposal of the caller to store a context.

Parameters :

data any kind of object to be stored

3.10. Yocto-hub port interface

In order to use the functions described here, you should include:

`#import "yocto_hubport.h"`

Global functions

`yFindHubPort(func)`

Retrieves a Yocto-hub port for a given identifier.

`yFirstHubPort()`

Starts the enumeration of Yocto-hub ports currently accessible.

YHubPort methods

hubport→describe()

Returns a descriptive text that identifies the function.

hubport→get_advertisedValue()

Returns the current value of the Yocto-hub port (no more than 6 characters).

hubport→get_baudRate()

Returns the current baud rate used by this Yocto-hub port, in kbps.

hubport→get_enabled()

Returns true if the Yocto-hub port is powered, false otherwise.

hubport→get_errorMessage()

Returns the error message of the latest error with this function.

hubport→get_errorType()

Returns the numerical error code of the latest error with this function.

hubport→get_functionDescriptor()

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

hubport→get_hardwareId()

Returns the unique hardware identifier of the function.

hubport→get_logicalName()

Returns the logical name of the Yocto-hub port, which is always the serial number of the connected module.

hubport→get_module()

Get the `YModule` object for the device on which the function is located.

hubport→get_module_async(callback, context)

Get the `YModule` object for the device on which the function is located (asynchronous version).

hubport→get_portState()

Returns the current state of the Yocto-hub port.

hubport→get_userData()

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

hubport→isOnline()

Checks if the function is currently reachable, without raising any error.

hubport→isOnline_async(callback, context)

Checks if the function is currently reachable, without raising any error (asynchronous version).

hubport→load(msValidity)

Preloads the function cache with a specified validity duration.

hubport→load_async(msValidity, callback, context)

Preloads the function cache with a specified validity duration (asynchronous version).

hubport→nextHubPort()

Continues the enumeration of Yocto-hub ports started using `yFirstHubPort()`.

hubport→registerValueCallback(callback)

Registers the callback function that is invoked on every change of advertised value.

hubport→set_enabled(newval)

Changes the activation of the Yocto-hub port.

hubport→set_logicalName(newval)

It is not possible to configure the logical name of a Yocto-hub port.

hubport→**set_userData(data)**

Stores a user context provided as argument in the userData attribute of the function.

yFindHubPort()

Retrieves a Yocto-hub port for a given identifier.

YHubPort* **yFindHubPort(NSString* func)**

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the Yocto-hub port is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YHubPort.isOnline()` to test if the Yocto-hub port is indeed online at a given time. In case of ambiguity when looking for a Yocto-hub port by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

Parameters :

func a string that uniquely characterizes the Yocto-hub port

Returns :

a `YHubPort` object allowing you to drive the Yocto-hub port.

yFirstHubPort()

Starts the enumeration of Yocto-hub ports currently accessible.

YHubPort* **yFirstHubPort()**

Use the method `YHubPort.nextHubPort()` to iterate on next Yocto-hub ports.

Returns :

a pointer to a `YHubPort` object, corresponding to the first Yocto-hub port currently online, or a `null` pointer if there are none.

[hubport describe]

Returns a descriptive text that identifies the function.

-(NSString*) describe

The text always includes the class name, and may include as well either the logical name of the function or its hardware identifier.

Returns :

a string that describes the function

[hubport advertisedValue]

Returns the current value of the Yocto-hub port (no more than 6 characters).

-(NSString*) advertisedValue

Returns :

a string corresponding to the current value of the Yocto-hub port (no more than 6 characters)
On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

[hubport baudRate]

Returns the current baud rate used by this Yocto-hub port, in kbps.

-(int) baudRate

The default value is 1000 kbps, but a slower rate may be used if communication problems are hit.

Returns :

an integer corresponding to the current baud rate used by this Yocto-hub port, in kbps

On failure, throws an exception or returns `Y_BAUDRATE_INVALID`.

[hubport enabled]

Returns true if the Yocto-hub port is powered, false otherwise.

-(Y_ENABLED_enum) enabled

Returns :

either `Y_ENABLED_FALSE` or `Y_ENABLED_TRUE`, according to true if the Yocto-hub port is powered, false otherwise

On failure, throws an exception or returns `Y_ENABLED_INVALID`.

Returns the error message of the latest error with this function.

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

Returns :

a string corresponding to the latest error message that occurred while using this function object

Returns the numerical error code of the latest error with this function.

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

Returns :

a number corresponding to the code of the latest error that occurred while using this function object

[hubport hubportDescriptor]

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

-(YFUN_DESCR) functionDescriptor

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

Returns :

an identifier of type `YFUN_DESCR`. If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

Returns the unique hardware identifier of the function.

The unique hardware identifier is made of the device serial number and of the hardware identifier of the function.

Returns :

a string that uniquely identifies the function On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

[hubport logicalName]

Returns the logical name of the Yocto-hub port, which is always the serial number of the connected module.

`-(NSString*) logicalName`

Returns :

a string corresponding to the logical name of the Yocto-hub port, which is always the serial number of the connected module

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

[hubport module]

Get the `YModule` object for the device on which the function is located.

`-(YModule*) module`

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

Returns :

an instance of `YModule`

Get the `YModule` object for the device on which the function is located (asynchronous version).

If the function cannot be located on any module, the returned `YModule` object does not show as on-line. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

Parameters :

callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the requested `YModule` object

context caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[hubport portState]

Returns the current state of the Yocto-hub port.

`-(Y_PORTSTATE_enum) portState`

Returns :

a value among `Y_PORTSTATE_OFF`, `Y_PORTSTATE_ON` and `Y_PORTSTATE_RUN` corresponding to the current state of the Yocto-hub port

On failure, throws an exception or returns `Y_PORTSTATE_INVALID`.

[hubport userData]

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

-(void*) **userData**

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

Returns :
the object stored previously by the caller.

[hubport isOnline]

Checks if the function is currently reachable, without raising any error.

-(BOOL) **isOnline**

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

Returns :
`true` if the function can be reached, and `false` otherwise

Checks if the function is currently reachable, without raising any error (asynchronous version).

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox Javascript VM that does not implement context switching during blocking I/O calls.

Parameters :
callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the boolean result
context caller-specific object that is passed as-is to the callback function

Returns :
nothing : the result is provided to the callback.

[hubport load:]

Preloads the function cache with a specified validity duration.

-(YRETCODE) **load** : (int) **msValidity**

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

Parameters :
msValidity an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

Returns :
`YAPI_SUCCESS` when the call succeeds. On failure, throws an exception or returns a negative error code.

Preloads the function cache with a specified validity duration (asynchronous version).

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

Parameters :

- msValidity** an integer corresponding to the validity of the loaded function parameters, in milliseconds
- callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the error code (or `YAPI_SUCCESS`)
- context** caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[hubport nextHubPort]

Continues the enumeration of Yocto-hub ports started using `yFirstHubPort()`.

-(YHubPort*) **nextHubPort**

Returns :

a pointer to a `YHubPort` object, corresponding to a Yocto-hub port currently online, or a null pointer if there are no more Yocto-hub ports to enumerate.

[hubport registerValueCallback:]

Registers the callback function that is invoked on every change of advertised value.

-(void) **registerValueCallback** : (YFunctionUpdateCallback) **callback**

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

Parameters :

- callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

[hubport setEnabled:]

Changes the activation of the Yocto-hub port.

-(int) **setEnabled** : (Y_ENABLED_enum) **newval**

If the port is enabled, the * connected module will be powered. Otherwise, port power will be shut down.

Parameters :

- newval** either `Y_ENABLED_FALSE` or `Y_ENABLED_TRUE`, according to the activation of the Yocto-hub port

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[hubport setLogicalName:]

It is not possible to configure the logical name of a Yocto-hub port.

`-(int) setLogicalName : (NSString*) newval`

The logical name is automatically set to the serial number of the connected module.

Parameters :

`newval` a string

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[hubport setUserData:]

Stores a user context provided as argument in the `userData` attribute of the function.

`-(void) setUserData : (void*) data`

This attribute is never touched by the API, and is at disposal of the caller to store a context.

Parameters :

`data` any kind of object to be stored

3.11. Humidity function interface

The Yoctopuce application programming interface allows you to read an instant measure of the sensor, as well as the minimal and maximal values observed.

In order to use the functions described here, you should include:

`#import "yocto_humidity.h"`

Global functions

`yFindHumidity(func)`

Retrieves a humidity sensor for a given identifier.

`yFirstHumidity()`

Starts the enumeration of humidity sensors currently accessible.

YHumidity methods

`humidity→calibrateFromPoints(rawValues, refValues)`

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

`humidity→describe()`

Returns a descriptive text that identifies the function.

`humidity→get_advertisedValue()`

Returns the current value of the humidity sensor (no more than 6 characters).

`humidity→get_currentRawValue()`

Returns the unrounded and uncalibrated raw value returned by the sensor.

`humidity→get_currentValue()`

Returns the current measured value.

`humidity→get_errorMessage()`

Returns the error message of the latest error with this function.
humidity→get_errorType() Returns the numerical error code of the latest error with this function.
humidity→get_functionDescriptor() Returns a unique identifier of type <code>YFUN_DESCR</code> corresponding to the function.
humidity→get_hardwareId() Returns the unique hardware identifier of the function.
humidity→get_highestValue() Returns the maximal value observed.
humidity→get_logicalName() Returns the logical name of the humidity sensor.
humidity→get_lowestValue() Returns the minimal value observed.
humidity→get_module() Get the <code>YModule</code> object for the device on which the function is located.
humidity→get_module_async(callback, context) Get the <code>YModule</code> object for the device on which the function is located (asynchronous version).
humidity→get_resolution() Returns the resolution of the measured values.
humidity→get_unit() Returns the measuring unit for the measured value.
humidity→get_userData() Returns the value of the <code>userData</code> attribute, as previously stored using method <code>set_userData</code> .
humidity→isOnline() Checks if the function is currently reachable, without raising any error.
humidity→isOnline_async(callback, context) Checks if the function is currently reachable, without raising any error (asynchronous version).
humidity→load(msValidity) Preloads the function cache with a specified validity duration.
humidity→load_async(msValidity, callback, context) Preloads the function cache with a specified validity duration (asynchronous version).
humidity→nextHumidity() Continues the enumeration of humidity sensors started using <code>yFirstHumidity()</code> .
humidity→registerValueCallback(callback) Registers the callback function that is invoked on every change of advertised value.
humidity→set_highestValue(newval) Changes the recorded maximal value observed.
humidity→set_logicalName(newval) Changes the logical name of the humidity sensor.
humidity→set_lowestValue(newval) Changes the recorded minimal value observed.
humidity→set_userData(data)

Stores a user context provided as argument in the `userData` attribute of the function.

yFindHumidity()

Retrieves a humidity sensor for a given identifier.

`YHumidity*` **yFindHumidity**(`NSString*` **func**)

The identifier can be specified using several formats:

- `FunctionLogicalName`
- `ModuleSerialNumber.FunctionIdentifier`
- `ModuleSerialNumber.FunctionLogicalName`
- `ModuleLogicalName.FunctionIdentifier`
- `ModuleLogicalName.FunctionLogicalName`

This function does not require that the humidity sensor is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YHumidity.isOnline()` to test if the humidity sensor is indeed online at a given time. In case of ambiguity when looking for a humidity sensor by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

Parameters :

func a string that uniquely characterizes the humidity sensor

Returns :

a `YHumidity` object allowing you to drive the humidity sensor.

yFirstHumidity()

Starts the enumeration of humidity sensors currently accessible.

`YHumidity*` **yFirstHumidity**()

Use the method `YHumidity.nextHumidity()` to iterate on next humidity sensors.

Returns :

a pointer to a `YHumidity` object, corresponding to the first humidity sensor currently online, or a `null` pointer if there are none.

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

It is possible to configure up to five correction points. Correction points must be provided in ascending order, and be in the range of the sensor. The device will automatically perform a linear interpolation of the error correction between specified points. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

For more information on advanced capabilities to refine the calibration of sensors, please contact support@yoctopuce.com.

Parameters :

rawValues array of floating point numbers, corresponding to the raw values returned by the sensor for the correction points.

refValues array of floating point numbers, corresponding to the corrected values for the correction points.

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[humidity describe]

Returns a descriptive text that identifies the function.

`-(NSString*) describe`

The text always includes the class name, and may include as well either the logical name of the function or its hardware identifier.

Returns :
a string that describes the function

[humidity advertisedValue]

Returns the current value of the humidity sensor (no more than 6 characters).

`-(NSString*) advertisedValue`

Returns :
a string corresponding to the current value of the humidity sensor (no more than 6 characters)

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

[humidity currentRawValue]

Returns the unrounded and uncalibrated raw value returned by the sensor.

`-(double) currentRawValue`

Returns :
a floating point number corresponding to the unrounded and uncalibrated raw value returned by the sensor

On failure, throws an exception or returns `Y_CURRENTRAWVALUE_INVALID`.

[humidity currentValue]

Returns the current measured value.

`-(double) currentValue`

Returns :
a floating point number corresponding to the current measured value

On failure, throws an exception or returns `Y_CURRENTVALUE_INVALID`.

Returns the error message of the latest error with this function.

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

Returns :
a string corresponding to the latest error message that occurred while using this function object

Returns the numerical error code of the latest error with this function.

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

Returns :

a number corresponding to the code of the latest error that occurred while using this function object

[humidity humidityDescriptor]

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

-(YFUN_DESCR) functionDescriptor

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

Returns :

an identifier of type `YFUN_DESCR`. If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

Returns the unique hardware identifier of the function.

The unique hardware identifier is made of the device serial number and of the hardware identifier of the function.

Returns :

a string that uniquely identifies the function. On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

[humidity highestValue]

Returns the maximal value observed.

-(double) highestValue

Returns :

a floating point number corresponding to the maximal value observed

On failure, throws an exception or returns `Y_HIGHESTVALUE_INVALID`.

[humidity logicalName]

Returns the logical name of the humidity sensor.

-(NSString*) logicalName

Returns :

a string corresponding to the logical name of the humidity sensor

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

[humidity lowestValue]

Returns the minimal value observed.

-(double) lowestValue

Returns :

a floating point number corresponding to the minimal value observed

On failure, throws an exception or returns `Y_LOWESTVALUE_INVALID`.

[humidity module]

Get the `YModule` object for the device on which the function is located.

`-(YModule*) module`

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

Returns :

an instance of `YModule`

Get the `YModule` object for the device on which the function is located (asynchronous version).

If the function cannot be located on any module, the returned `YModule` object does not show as on-line. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

Parameters :

callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the requested `YModule` object

context caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[humidity resolution]

Returns the resolution of the measured values.

`-(double) resolution`

The resolution corresponds to the numerical precision of the values, which is not always the same as the actual precision of the sensor.

Returns :

a floating point number corresponding to the resolution of the measured values

On failure, throws an exception or returns `Y_RESOLUTION_INVALID`.

[humidity unit]

Returns the measuring unit for the measured value.

`-(NSString*) unit`

Returns :

a string corresponding to the measuring unit for the measured value

On failure, throws an exception or returns `Y_UNIT_INVALID`.

[humidity userData]

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

`-(void*) userData`

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

Returns :
the object stored previously by the caller.

[humidity isOnline]

Checks if the function is currently reachable, without raising any error.

-(BOOL) **isOnline**

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

Returns :
`true` if the function can be reached, and `false` otherwise

Checks if the function is currently reachable, without raising any error (asynchronous version).

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox Javascript VM that does not implement context switching during blocking I/O calls.

Parameters :
callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the boolean result
context caller-specific object that is passed as-is to the callback function

Returns :
nothing : the result is provided to the callback.

[humidity load:]

Preloads the function cache with a specified validity duration.

-(YRETCODE) **load** : (int) **msValidity**

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

Parameters :
msValidity an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

Returns :
`YAPI_SUCCESS` when the call succeeds. On failure, throws an exception or returns a negative error code.

Preloads the function cache with a specified validity duration (asynchronous version).

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox

javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

Parameters :

- msValidity** an integer corresponding to the validity of the loaded function parameters, in milliseconds
- callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the error code (or `YAPI_SUCCESS`)
- context** caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[humidity nextHumidity]

Continues the enumeration of humidity sensors started using `yFirstHumidity()`.

-(YHumidity*) **nextHumidity**

Returns :

a pointer to a `YHumidity` object, corresponding to a humidity sensor currently online, or a null pointer if there are no more humidity sensors to enumerate.

[humidity registerValueCallback:]

Registers the callback function that is invoked on every change of advertised value.

-(void) **registerValueCallback** : (YFunctionUpdateCallback) **callback**

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

Parameters :

- callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

[humidity setHighestValue:]

Changes the recorded maximal value observed.

-(int) **setHighestValue** : (double) **newval**

Parameters :

- newval** a floating point number corresponding to the recorded maximal value observed

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[humidity setLogicalName:]

Changes the logical name of the humidity sensor.

-(int) **setLogicalName** : (NSString*) **newval**

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

Parameters :

newval a string corresponding to the logical name of the humidity sensor

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[humidity setLowestValue:]

Changes the recorded minimal value observed.

-(int) setLowestValue : (double) **newval**

Parameters :

newval a floating point number corresponding to the recorded minimal value observed

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[humidity setUserData:]

Stores a user context provided as argument in the `userData` attribute of the function.

-(void) setUserData : (void*) **data**

This attribute is never touched by the API, and is at disposal of the caller to store a context.

Parameters :

data any kind of object to be stored

3.12. Led function interface

Yoctopuce application programming interface allows you not only to drive the intensity of the led, but also to have it blink at various preset frequencies.

In order to use the functions described here, you should include:

```
#import "yocto_led.h"
```

Global functions	
yFindLed(func)	Retrieves a led for a given identifier.
yFirstLed()	Starts the enumeration of leds currently accessible.
YLed methods	
led→describe()	Returns a descriptive text that identifies the function.
led→get_advertisedValue()	Returns the current value of the led (no more than 6 characters).
led→get_blinking()	Returns the current led signaling mode.

led→get_errorMessage()	Returns the error message of the latest error with this function.
led→get_errorType()	Returns the numerical error code of the latest error with this function.
led→get_functionDescriptor()	Returns a unique identifier of type <code>YFUN_DESCR</code> corresponding to the function.
led→get_hardwareId()	Returns the unique hardware identifier of the function.
led→get_logicalName()	Returns the logical name of the led.
led→get_luminosity()	Returns the current led intensity (in per cent).
led→get_module()	Get the <code>YModule</code> object for the device on which the function is located.
led→get_module_async(callback, context)	Get the <code>YModule</code> object for the device on which the function is located (asynchronous version).
led→get_power()	Returns the current led state.
led→get_userData()	Returns the value of the <code>userData</code> attribute, as previously stored using method <code>set_userData</code> .
led→isOnline()	Checks if the function is currently reachable, without raising any error.
led→isOnline_async(callback, context)	Checks if the function is currently reachable, without raising any error (asynchronous version).
led→load(msValidity)	Preloads the function cache with a specified validity duration.
led→load_async(msValidity, callback, context)	Preloads the function cache with a specified validity duration (asynchronous version).
led→nextLed()	Continues the enumeration of leds started using <code>yFirstLed()</code> .
led→registerValueCallback(callback)	Registers the callback function that is invoked on every change of advertised value.
led→set_blinking(newval)	Changes the current led signaling mode.
led→set_logicalName(newval)	Changes the logical name of the led.
led→set_luminosity(newval)	Changes the current led intensity (in per cent).
led→set_power(newval)	Changes the state of the led.
led→set_userData(data)	Stores a user context provided as argument in the <code>userData</code> attribute of the function.

yFindLed()

Retrieves a led for a given identifier.

`YLed* yFindLed(NSString* func)`

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the led is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YLed.isOnline()` to test if the led is indeed online at a given time. In case of ambiguity when looking for a led by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

Parameters :

func a string that uniquely characterizes the led

Returns :

a `YLed` object allowing you to drive the led.

yFirstLed()

Starts the enumeration of leds currently accessible.

`YLed* yFirstLed()`

Use the method `YLed.nextLed()` to iterate on next leds.

Returns :

a pointer to a `YLed` object, corresponding to the first led currently online, or a `null` pointer if there are none.

[led describe]

Returns a descriptive text that identifies the function.

`-(NSString*) describe`

The text always includes the class name, and may include as well either the logical name of the function or its hardware identifier.

Returns :

a string that describes the function

[led advertisedValue]

Returns the current value of the led (no more than 6 characters).

`-(NSString*) advertisedValue`

Returns :

a string corresponding to the current value of the led (no more than 6 characters)

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

[led blinking]

Returns the current led signaling mode.

-(Y_BLINKING_enum) blinking

Returns :

a value among Y_BLINKING_STILL, Y_BLINKING_RELAX, Y_BLINKING_AWARE, Y_BLINKING_RUN, Y_BLINKING_CALL and Y_BLINKING_PANIC corresponding to the current led signaling mode

On failure, throws an exception or returns Y_BLINKING_INVALID.

Returns the error message of the latest error with this function.

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

Returns :

a string corresponding to the latest error message that occurred while using this function object

Returns the numerical error code of the latest error with this function.

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

Returns :

a number corresponding to the code of the latest error that occurred while using this function object

[led ledDescriptor]

Returns a unique identifier of type YFUN_DESCR corresponding to the function.

-(YFUN_DESCR) functionDescriptor

This identifier can be used to test if two instances of YFunction reference the same physical function on the same physical device.

Returns :

an identifier of type YFUN_DESCR. If the function has never been contacted, the returned value is Y_FUNCTIONDESCRIPTOR_INVALID.

Returns the unique hardware identifier of the function.

The unique hardware identifier is made of the device serial number and of the hardware identifier of the function.

Returns :

a string that uniquely identifies the function On failure, throws an exception or returns Y_HARDWAREID_INVALID.

[led logicalName]

Returns the logical name of the led.

-(NSString*) logicalName

Returns :

a string corresponding to the logical name of the led

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

[led luminosity]

Returns the current led intensity (in per cent).

-(int) luminosity

Returns :

an integer corresponding to the current led intensity (in per cent)

On failure, throws an exception or returns `Y_LUMINOSITY_INVALID`.

[led module]

Get the `YModule` object for the device on which the function is located.

-(YModule*) module

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

Returns :

an instance of `YModule`

Get the `YModule` object for the device on which the function is located (asynchronous version).

If the function cannot be located on any module, the returned `YModule` object does not show as on-line. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

Parameters :

callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the requested `YModule` object

context caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[led power]

Returns the current led state.

-(Y_POWER_enum) power

Returns :

either `Y_POWER_OFF` or `Y_POWER_ON`, according to the current led state

On failure, throws an exception or returns `Y_POWER_INVALID`.

[led userData]

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

-(void*) userData

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

Returns :
the object stored previously by the caller.

[led isOnline]

Checks if the function is currently reachable, without raising any error.

-(BOOL) isOnline

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

Returns :
`true` if the function can be reached, and `false` otherwise

Checks if the function is currently reachable, without raising any error (asynchronous version).

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox Javascript VM that does not implement context switching during blocking I/O calls.

Parameters :
callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the boolean result
context caller-specific object that is passed as-is to the callback function

Returns :
nothing : the result is provided to the callback.

[led load:]

Preloads the function cache with a specified validity duration.

-(YRETCODE) load : (int) msValidity

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

Parameters :
msValidity an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

Returns :
`YAPI_SUCCESS` when the call succeeds. On failure, throws an exception or returns a negative error code.

Preloads the function cache with a specified validity duration (asynchronous version).

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for

a longer period, in order to reduce network traffic for instance. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

Parameters :

- msValidity** an integer corresponding to the validity of the loaded function parameters, in milliseconds
- callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the error code (or `YAPI_SUCCESS`)
- context** caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[led nextLed]

Continues the enumeration of leds started using `yFirstLed()`.

-(YLed*) **nextLed**

Returns :

a pointer to a YLed object, corresponding to a led currently online, or a null pointer if there are no more leds to enumerate.

[led registerValueCallback:]

Registers the callback function that is invoked on every change of advertised value.

-(void) **registerValueCallback** : (YFunctionUpdateCallback) **callback**

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

Parameters :

- callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

[led setBlinking:]

Changes the current led signaling mode.

-(int) **setBlinking** : (Y_BLINKING_enum) **newval**

Parameters :

- newval** a value among `Y_BLINKING_STILL`, `Y_BLINKING_RELAX`, `Y_BLINKING_AWARE`, `Y_BLINKING_RUN`, `Y_BLINKING_CALL` and `Y_BLINKING_PANIC` corresponding to the current led signaling mode

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[led setLogicalName:]

Changes the logical name of the led.

`-(int) setLogicalName : (NSString*) newval`

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

Parameters :

newval a string corresponding to the logical name of the led

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[led setLuminosity:]

Changes the current led intensity (in per cent).

`-(int) setLuminosity : (int) newval`

Parameters :

newval an integer corresponding to the current led intensity (in per cent)

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[led setPower:]

Changes the state of the led.

`-(int) setPower : (Y_POWER_enum) newval`

Parameters :

newval either `Y_POWER_OFF` or `Y_POWER_ON`, according to the state of the led

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[led setUserData:]

Stores a user context provided as argument in the `userData` attribute of the function.

`-(void) setUserData : (void*) data`

This attribute is never touched by the API, and is at disposal of the caller to store a context.

Parameters :

data any kind of object to be stored

3.13. LightSensor function interface

The Yoctopuce application programming interface allows you to read an instant measure of the sensor, as well as the minimal and maximal values observed.

In order to use the functions described here, you should include:

`#import "yocto_lightsensor.h"`

Global functions

yFindLightSensor(func)

Retrieves a light sensor for a given identifier.

yFirstLightSensor()

Starts the enumeration of light sensors currently accessible.

YLightSensor methods

lightsensor→calibrate(calibratedVal)

Changes the sensor-specific calibration parameter so that the current value matches a desired target (linear scaling).

lightsensor→calibrateFromPoints(rawValues, refValues)

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

lightsensor→describe()

Returns a descriptive text that identifies the function.

lightsensor→get_advertisedValue()

Returns the current value of the light sensor (no more than 6 characters).

lightsensor→get_currentRawValue()

Returns the unrounded and uncalibrated raw value returned by the sensor.

lightsensor→get_currentValue()

Returns the current measured value.

lightsensor→get_errorMessage()

Returns the error message of the latest error with this function.

lightsensor→get_errorType()

Returns the numerical error code of the latest error with this function.

lightsensor→get_functionDescriptor()

Returns a unique identifier of type YFUN_DESCR corresponding to the function.

lightsensor→get_hardwareId()

Returns the unique hardware identifier of the function.

lightsensor→get_highestValue()

Returns the maximal value observed.

lightsensor→get_logicalName()

Returns the logical name of the light sensor.

lightsensor→get_lowestValue()

Returns the minimal value observed.

lightsensor→get_module()

Get the YModule object for the device on which the function is located.

lightsensor→get_module_async(callback, context)

Get the YModule object for the device on which the function is located (asynchronous version).

lightsensor→get_resolution()

Returns the resolution of the measured values.

lightsensor→get_unit()

Returns the measuring unit for the measured value.

lightsensor→get_userData()

Returns the value of the userData attribute, as previously stored using method set_userData.

lightsensor→isOnline()

Checks if the function is currently reachable, without raising any error.

lightsensor→isOnline_async(callback, context)

Checks if the function is currently reachable, without raising any error (asynchronous version).

lightsensor→load(msValidity)

Preloads the function cache with a specified validity duration.

lightsensor→load_async(msValidity, callback, context)

Preloads the function cache with a specified validity duration (asynchronous version).

lightsensor→nextLightSensor()

Continues the enumeration of light sensors started using `yFirstLightSensor()`.

lightsensor→registerValueCallback(callback)

Registers the callback function that is invoked on every change of advertised value.

lightsensor→set_highestValue(newval)

Changes the recorded maximal value observed.

lightsensor→set_logicalName(newval)

Changes the logical name of the light sensor.

lightsensor→set_lowestValue(newval)

Changes the recorded minimal value observed.

lightsensor→set_userData(data)

Stores a user context provided as argument in the `userData` attribute of the function.

yFindLightSensor()

Retrieves a light sensor for a given identifier.

`YLightSensor* yFindLightSensor(NSString* func)`

The identifier can be specified using several formats:

- `FunctionLogicalName`
- `ModuleSerialNumber.FunctionIdentifier`
- `ModuleSerialNumber.FunctionLogicalName`
- `ModuleLogicalName.FunctionIdentifier`
- `ModuleLogicalName.FunctionLogicalName`

This function does not require that the light sensor is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YLightSensor.isOnline()` to test if the light sensor is indeed online at a given time. In case of ambiguity when looking for a light sensor by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

Parameters :

func a string that uniquely characterizes the light sensor

Returns :

a `YLightSensor` object allowing you to drive the light sensor.

yFirstLightSensor()

Starts the enumeration of light sensors currently accessible.

`YLightSensor* yFirstLightSensor()`

Use the method `YLightSensor.nextLightSensor()` to iterate on next light sensors.

Returns :

a pointer to a `YLightSensor` object, corresponding to the first light sensor currently online, or a `null` pointer if there are none.

[lightsensor calibrate:]

Changes the sensor-specific calibration parameter so that the current value matches a desired target (linear scaling).

-(int) **calibrate** : (double) **calibratedVal**

Parameters :

calibratedVal

the desired target value.

Remember to call the `saveToFlash()` method of the module if the modification must be kept.

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

It is possible to configure up to five correction points. Correction points must be provided in ascending order, and be in the range of the sensor. The device will automatically perform a linear interpolation of the error correction between specified points. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

For more information on advanced capabilities to refine the calibration of sensors, please contact support@yoctopuce.com.

Parameters :

rawValues array of floating point numbers, corresponding to the raw values returned by the sensor for the correction points.

refValues array of floating point numbers, corresponding to the corrected values for the correction points.

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[lightsensor describe]

Returns a descriptive text that identifies the function.

-(NSString*) **describe**

The text always includes the class name, and may include as well either the logical name of the function or its hardware identifier.

Returns :

a string that describes the function

[lightsensor advertisedValue]

Returns the current value of the light sensor (no more than 6 characters).

-(NSString*) **advertisedValue**

Returns :

a string corresponding to the current value of the light sensor (no more than 6 characters)

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

[lightsensor currentRawValue]

Returns the unrounded and uncalibrated raw value returned by the sensor.

-(double) `currentRawValue`

Returns :

a floating point number corresponding to the unrounded and uncalibrated raw value returned by the sensor

On failure, throws an exception or returns `Y_CURRENTRAWVALUE_INVALID`.

[lightsensor currentValue]

Returns the current measured value.

-(double) `currentValue`

Returns :

a floating point number corresponding to the current measured value

On failure, throws an exception or returns `Y_CURRENTVALUE_INVALID`.

Returns the error message of the latest error with this function.

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

Returns :

a string corresponding to the latest error message that occurred while using this function object

Returns the numerical error code of the latest error with this function.

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

Returns :

a number corresponding to the code of the latest error that occurred while using this function object

[lightsensor lightsensorDescriptor]

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

-(YFUN_DESCR) `functionDescriptor`

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

Returns :

an identifier of type `YFUN_DESCR`. If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

Returns the unique hardware identifier of the function.

The unique hardware identifier is made of the device serial number and of the hardware identifier of the function.

Returns :

a string that uniquely identifies the function On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

[lightsensor highestValue]

Returns the maximal value observed.

`-(double) highestValue`

Returns :

a floating point number corresponding to the maximal value observed

On failure, throws an exception or returns `Y_HIGHESTVALUE_INVALID`.

[lightsensor logicalName]

Returns the logical name of the light sensor.

`-(NSString*) logicalName`

Returns :

a string corresponding to the logical name of the light sensor

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

[lightsensor lowestValue]

Returns the minimal value observed.

`-(double) lowestValue`

Returns :

a floating point number corresponding to the minimal value observed

On failure, throws an exception or returns `Y_LOWESTVALUE_INVALID`.

[lightsensor module]

Get the `YModule` object for the device on which the function is located.

`-(YModule*) module`

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

Returns :

an instance of `YModule`

Get the `YModule` object for the device on which the function is located (asynchronous version).

If the function cannot be located on any module, the returned `YModule` object does not show as on-line. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

Parameters :

callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the requested `YModule` object

context caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[lightsensor resolution]

Returns the resolution of the measured values.

`-(double) resolution`

The resolution corresponds to the numerical precision of the values, which is not always the same as the actual precision of the sensor.

Returns :

a floating point number corresponding to the resolution of the measured values

On failure, throws an exception or returns `Y_RESOLUTION_INVALID`.

[lightsensor unit]

Returns the measuring unit for the measured value.

`-(NSString*) unit`

Returns :

a string corresponding to the measuring unit for the measured value

On failure, throws an exception or returns `Y_UNIT_INVALID`.

[lightsensor userData]

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

`-(void*) userData`

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

Returns :

the object stored previously by the caller.

[lightsensor isOnline]

Checks if the function is currently reachable, without raising any error.

`-(BOOL) isOnline`

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

Returns :

`true` if the function can be reached, and `false` otherwise

Checks if the function is currently reachable, without raising any error (asynchronous version).

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox Javascript VM that does not implement context switching during blocking I/O calls.

Parameters :

callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the boolean result

context caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[lightsensor load:]

Preloads the function cache with a specified validity duration.

-(YRETCODE) **load** : (int) **msValidity**

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

Parameters :

msValidity an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

Returns :

YAPI_SUCCESS when the call succeeds. On failure, throws an exception or returns a negative error code.

Preloads the function cache with a specified validity duration (asynchronous version).

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

Parameters :

msValidity an integer corresponding to the validity of the loaded function parameters, in milliseconds

callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the error code (or YAPI_SUCCESS)

context caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[lightsensor nextLightSensor]

Continues the enumeration of light sensors started using `yFirstLightSensor()`.

-(YLightSensor*) **nextLightSensor**

Returns :

a pointer to a `YLightSensor` object, corresponding to a light sensor currently online, or a `null` pointer if there are no more light sensors to enumerate.

[lightsensor registerValueCallback:]

Registers the callback function that is invoked on every change of advertised value.

`-(void) registerValueCallback : (YFunctionUpdateCallback) callback`

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

Parameters :

callback the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

[lightsensor setHighestValue:]

Changes the recorded maximal value observed.

`-(int) setHighestValue : (double) newval`

Parameters :

newval a floating point number corresponding to the recorded maximal value observed

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[lightsensor setLogicalName:]

Changes the logical name of the light sensor.

`-(int) setLogicalName : (NSString*) newval`

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

Parameters :

newval a string corresponding to the logical name of the light sensor

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[lightsensor setLowestValue:]

Changes the recorded minimal value observed.

`-(int) setLowestValue : (double) newval`

Parameters :

newval a floating point number corresponding to the recorded minimal value observed

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[lightsensor setData:]

Stores a user context provided as argument in the userData attribute of the function.

-(void) setData : (void*) data

This attribute is never touched by the API, and is at disposal of the caller to store a context.

Parameters :

data any kind of object to be stored

3.14. Module control interface

This interface is identical for all Yoctopuce USB modules. It can be used to control the module global parameters, and to enumerate the functions provided by each module.

In order to use the functions described here, you should include:

```
#import "yocto_api.h"
```

Global functions

yFindModule(func)

Allows you to find a module from its serial number or from its logical name.

yFirstModule()

Starts the enumeration of modules currently accessible.

YModule methods

module→describe()

Returns a descriptive text that identifies the module.

module→functionCount()

Returns the number of functions (beside the "module" interface) available on the module.

module→functionId(functionIndex)

Retrieves the hardware identifier of the *n*th function on the module.

module→functionName(functionIndex)

Retrieves the logical name of the *n*th function on the module.

module→functionValue(functionIndex)

Retrieves the advertised value of the *n*th function on the module.

module→get_beacon()

Returns the state of the localization beacon.

module→get_errorMessage()

Returns the error message of the last error with this module object.

module→get_errorType()

Returns the numerical error code of the last error with this module object.

module→get_firmwareRelease()

Returns the version of the firmware embedded in the module.

module→get_functionDescriptor()

Returns a unique identifier of type YFUN_DESCR corresponding to the function.

module→get_hardwareId()

Returns the unique hardware identifier of the module.

module→get_icon2d()
Returns the icon of the module.
module→get_logicalName()
Returns the logical name of the module.
module→get_luminosity()
Returns the luminosity of the module informative leds (from 0 to 100).
module→get_persistentSettings()
Returns the current state of persistent module settings.
module→get_productId()
Returns the USB device identifier of the module.
module→get_productName()
Returns the commercial name of the module, as set by the factory.
module→get_productRelease()
Returns the hardware release version of the module.
module→get_rebootCountdown()
Returns the remaining number of seconds before the module restarts, or zero when no reboot has been scheduled.
module→get_serialNumber()
Returns the serial number of the module, as set by the factory.
module→get_upTime()
Returns the number of milliseconds spent since the module was powered on.
module→get_usbBandwidth()
Returns the number of USB interfaces used by the module.
module→get_usbCurrent()
Returns the current consumed by the module on the USB bus, in milli-amps.
module→get_userData()
Returns the value of the userData attribute, as previously stored using method <code>set_userData</code> .
module→isOnline()
Checks if the module is currently reachable, without raising any error.
module→isOnline_async(callback, context)
Checks if the module is currently reachable, without raising any error.
module→load(msValidity)
Preloads the module cache with a specified validity duration.
module→load_async(msValidity, callback, context)
Preloads the module cache with a specified validity duration (asynchronous version).
module→nextModule()
Continues the module enumeration started using <code>yFirstModule()</code> .
module→reboot(secBeforeReboot)
Schedules a simple module reboot after the given number of seconds.
module→revertFromFlash()
Reloads the settings stored in the nonvolatile memory, as when the module is powered on.
module→saveToFlash()
Saves current settings in the nonvolatile memory of the module.
module→set_beacon(newval)

Turns on or off the module localization beacon.

module→**set_logicalName(newval)**

Changes the logical name of the module.

module→**set_luminosity(newval)**

Changes the luminosity of the module informative leds.

module→**set_usbBandwidth(newval)**

Changes the number of USB interfaces used by the module.

module→**set_userData(data)**

Stores a user context provided as argument in the userData attribute of the function.

module→**triggerFirmwareUpdate(secBeforeReboot)**

Schedules a module reboot into special firmware update mode.

yFindModule()

Allows you to find a module from its serial number or from its logical name.

YModule* **yFindModule(NSString* func)**

This function does not require that the module is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YModule.isOnline()` to test if the module is indeed online at a given time. In case of ambiguity when looking for a module by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

Parameters :

func a string containing either the serial number or the logical name of the desired module

Returns :

a `YModule` object allowing you to drive the module or get additional information on the module.

yFirstModule()

Starts the enumeration of modules currently accessible.

YModule* **yFirstModule()**

Use the method `YModule.nextModule()` to iterate on the next modules.

Returns :

a pointer to a `YModule` object, corresponding to the first module currently online, or a `null` pointer if there are none.

[module describe]

Returns a descriptive text that identifies the module.

-(NSString*) describe

The text may include either the logical name or the serial number of the module.

Returns :

a string that describes the module

[module functionCount]

Returns the number of functions (beside the "module" interface) available on the module.

-(int) **functionCount**

Returns :

the number of functions on the module

On failure, throws an exception or returns a negative error code.

[module functionId:]

Retrieves the hardware identifier of the *n*th function on the module.

-(NSString*) **functionId** : (int) **functionIndex**

Parameters :

functionIndex the index of the function for which the information is desired, starting at 0 for the first function.

Returns :

a string corresponding to the unambiguous hardware identifier of the requested module function

On failure, throws an exception or returns an empty string.

[module functionName:]

Retrieves the logical name of the *n*th function on the module.

-(NSString*) **functionName** : (int) **functionIndex**

Parameters :

functionIndex the index of the function for which the information is desired, starting at 0 for the first function.

Returns :

a string corresponding to the logical name of the requested module function

On failure, throws an exception or returns an empty string.

[module functionValue:]

Retrieves the advertised value of the *n*th function on the module.

-(NSString*) **functionValue** : (int) **functionIndex**

Parameters :

functionIndex the index of the function for which the information is desired, starting at 0 for the first function.

Returns :

a short string (up to 6 characters) corresponding to the advertised value of the requested module function

On failure, throws an exception or returns an empty string.

[module beacon]

Returns the state of the localization beacon.

-(Y_BEACON_enum) **beacon**

Returns :

either Y_BEACON_OFF or Y_BEACON_ON, according to the state of the localization beacon

On failure, throws an exception or returns Y_BEACON_INVALID.

Returns the error message of the last error with this module object.

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

Returns :

a string corresponding to the last error message that occurred while using this module object

Returns the numerical error code of the last error with this module object.

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

Returns :

a number corresponding to the code of the last error that occurred while using this module object

[module firmwareRelease]

Returns the version of the firmware embedded in the module.

`-(NSString*) firmwareRelease`

Returns :

a string corresponding to the version of the firmware embedded in the module

On failure, throws an exception or returns `Y_FIRMWARERELEASE_INVALID`.

[module moduleDescriptor]

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

`-(YFUN_DESCR) functionDescriptor`

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

Returns :

an identifier of type `YFUN_DESCR`. If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

Returns the unique hardware identifier of the module.

The unique hardware identifier is made of the device serial number followed by string ".module".

Returns :

a string that uniquely identifies the module

[module icon2d]

Returns the icon of the module.

`-(NSData*) icon2d`

The icon is a png image and does not exceed 1024 bytes.

Returns :

a binary buffer with module icon, in png format.

[module logicalName]

Returns the logical name of the module.

-(NSString*) logicalName

Returns :

a string corresponding to the logical name of the module

On failure, throws an exception or returns Y_LOGICALNAME_INVALID.

[module luminosity]

Returns the luminosity of the module informative leds (from 0 to 100).

-(int) luminosity

Returns :

an integer corresponding to the luminosity of the module informative leds (from 0 to 100)

On failure, throws an exception or returns Y_LUMINOSITY_INVALID.

[module persistentSettings]

Returns the current state of persistent module settings.

-(Y_PERSISTENTSETTINGS_enum) persistentSettings

Returns :

a value among Y_PERSISTENTSETTINGS_LOADED, Y_PERSISTENTSETTINGS_SAVED and Y_PERSISTENTSETTINGS_MODIFIED corresponding to the current state of persistent module settings

On failure, throws an exception or returns Y_PERSISTENTSETTINGS_INVALID.

[module productId]

Returns the USB device identifier of the module.

-(int) productId

Returns :

an integer corresponding to the USB device identifier of the module

On failure, throws an exception or returns Y_PRODUCTID_INVALID.

[module productName]

Returns the commercial name of the module, as set by the factory.

-(NSString*) productName

Returns :

a string corresponding to the commercial name of the module, as set by the factory

On failure, throws an exception or returns Y_PRODUCTNAME_INVALID.

[module productRelease]

Returns the hardware release version of the module.

`-(int) productRelease`

Returns :

an integer corresponding to the hardware release version of the module

On failure, throws an exception or returns `Y_PRODUCTRELEASE_INVALID`.

[module rebootCountdown]

Returns the remaining number of seconds before the module restarts, or zero when no reboot has been scheduled.

`-(int) rebootCountdown`

Returns :

an integer corresponding to the remaining number of seconds before the module restarts, or zero when no reboot has been scheduled

On failure, throws an exception or returns `Y_REBOOTCOUNTDOWN_INVALID`.

[module serialNumber]

Returns the serial number of the module, as set by the factory.

`-(NSString*) serialNumber`

Returns :

a string corresponding to the serial number of the module, as set by the factory

On failure, throws an exception or returns `Y_SERIALNUMBER_INVALID`.

[module upTime]

Returns the number of milliseconds spent since the module was powered on.

`-(unsigned) upTime`

Returns :

an integer corresponding to the number of milliseconds spent since the module was powered on

On failure, throws an exception or returns `Y_UPTIME_INVALID`.

[module usbBandwidth]

Returns the number of USB interfaces used by the module.

`-(Y_USBBANDWIDTH_enum) usbBandwidth`

Returns :

either `Y_USBBANDWIDTH_SIMPLE` or `Y_USBBANDWIDTH_DOUBLE`, according to the number of USB interfaces used by the module

On failure, throws an exception or returns `Y_USBBANDWIDTH_INVALID`.

[module usbCurrent]

Returns the current consumed by the module on the USB bus, in milli-amps.

`-(unsigned) usbCurrent`

Returns :

an integer corresponding to the current consumed by the module on the USB bus, in milli-amps
On failure, throws an exception or returns `Y_USBCURRENT_INVALID`.

[module userData]

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

-(void*) **userData**

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

Returns :
the object stored previously by the caller.

[module isOnline]

Checks if the module is currently reachable, without raising any error.

-(BOOL) **isOnline**

If there are valid cached values for the module, that have not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the requested module.

Returns :
`true` if the module can be reached, and `false` otherwise

Checks if the module is currently reachable, without raising any error.

If there are valid cached values for the module, that have not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the requested module.

This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox Javascript VM that does not implement context switching during blocking I/O calls.

Parameters :
callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving module object and the boolean result
context caller-specific object that is passed as-is to the callback function

Returns :
nothing : the result is provided to the callback.

[module load:]

Preloads the module cache with a specified validity duration.

-(YRETCODE) **load** : (int) **msValidity**

By default, whenever accessing a device, all module attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

Parameters :

msValidity an integer corresponding to the validity attributed to the loaded module parameters, in milliseconds

Returns :

`YAPI_SUCCESS` when the call succeeds. On failure, throws an exception or returns a negative error code.

Preloads the module cache with a specified validity duration (asynchronous version).

By default, whenever accessing a device, all module attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

Parameters :

msValidity an integer corresponding to the validity of the loaded module parameters, in milliseconds
callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving module object and the error code (or `YAPI_SUCCESS`)
context caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[module nextModule]

Continues the module enumeration started using `yFirstModule()`.

-(YModule*) **nextModule**

Returns :

a pointer to a `YModule` object, corresponding to the next module found, or a `null` pointer if there are no more modules to enumerate.

[module reboot:]

Schedules a simple module reboot after the given number of seconds.

-(int) **reboot** : (int) **secBeforeReboot**

Parameters :

secBeforeReboot number of seconds before rebooting

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[module revertFromFlash]

Reloads the settings stored in the nonvolatile memory, as when the module is powered on.

-(int) **revertFromFlash**

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[module saveToFlash]

Saves current settings in the nonvolatile memory of the module.

-(int) **saveToFlash**

Warning: the number of allowed save operations during a module life is limited (about 100000 cycles). Do not call this function within a loop.

Returns :

YAPI_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

[module setBeacon:]

Turns on or off the module localization beacon.

-(int) **setBeacon** : (Y_BEACON_enum) **newval**

Parameters :

newval either Y_BEACON_OFF or Y_BEACON_ON

Returns :

YAPI_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

[module setLogicalName:]

Changes the logical name of the module.

-(int) **setLogicalName** : (NSString*) **newval**

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

Parameters :

newval a string corresponding to the logical name of the module

Returns :

YAPI_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

[module setLuminosity:]

Changes the luminosity of the module informative leds.

-(int) **setLuminosity** : (int) **newval**

The parameter is a value between 0 and 100. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

Parameters :

newval an integer corresponding to the luminosity of the module informative leds

Returns :

YAPI_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

[module setUsbBandwidth:]

Changes the number of USB interfaces used by the module.

-(int) setUsbBandwidth : (Y_USBBANDWIDTH_enum) **newval**

Parameters :

newval either Y_USBBANDWIDTH_SIMPLE or Y_USBBANDWIDTH_DOUBLE, according to the number of USB interfaces used by the module

Returns :

YAPI_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

[module setData:]

Stores a user context provided as argument in the userData attribute of the function.

-(void) setData : (void*) **data**

This attribute is never touched by the API, and is at disposal of the caller to store a context.

Parameters :

data any kind of object to be stored

[module triggerFirmwareUpdate:]

Schedules a module reboot into special firmware update mode.

-(int) triggerFirmwareUpdate : (int) **secBeforeReboot**

Parameters :

secBeforeReboot number of seconds before rebooting

Returns :

YAPI_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

3.15. Network function interface

YNetwork objects provide access to TCP/IP parameters of Yoctopuce modules that include a built-in network interface.

In order to use the functions described here, you should include:

#import "yocto_network.h"

Global functions

yFindNetwork(func)

Retrieves a network interface for a given identifier.

yFirstNetwork()

Starts the enumeration of network interfaces currently accessible.

YNetwork methods

network→callbackLogin(username, password)

Connects to the notification callback and saves the credentials required to log in to it.

network→describe()

Returns a descriptive text that identifies the function.

network→get_adminPassword()

Returns a hash string if a password has been set for user "admin", or an empty string otherwise.

network→get_advertisedValue()

Returns the current value of the network interface (no more than 6 characters).

network→get_callbackCredentials()

Returns a hashed version of the notification callback credentials if set, or an empty string otherwise.

network→get_callbackMaxDelay()

Returns the maximum wait time between two callback notifications, in seconds.

network→get_callbackMinDelay()

Returns the minimum wait time between two callback notifications, in seconds.

network→get_callbackUrl()

Returns the callback URL to notify of significant state changes.

network→get_errorMessage()

Returns the error message of the latest error with this function.

network→get_errorType()

Returns the numerical error code of the latest error with this function.

network→get_functionDescriptor()

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

network→get_hardwareId()

Returns the unique hardware identifier of the function.

network→get_ipAddress()

Returns the IP address currently in use by the device.

network→get_logicalName()

Returns the logical name of the network interface, corresponding to the network name of the module.

network→get_macAddress()

Returns the MAC address of the network interface.

network→get_module()

Get the `YModule` object for the device on which the function is located.

network→get_module_async(callback, context)

Get the `YModule` object for the device on which the function is located (asynchronous version).

network→get_primaryDNS()

Returns the IP address of the primary name server to be used by the module.

network→get_readiness()

Returns the current established working mode of the network interface.

network→get_router()

Returns the IP address of the router on the device subnet (default gateway).

network→get_secondaryDNS()

Returns the IP address of the secondary name server to be used by the module.

network→get_subnetMask()

Returns the subnet mask currently used by the device.

network→get_userData()

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

network→get_userPassword()

Returns a hash string if a password has been set for user "user", or an empty string otherwise.

network→isOnline()

Checks if the function is currently reachable, without raising any error.

network→isOnline_async(callback, context)

Checks if the function is currently reachable, without raising any error (asynchronous version).

network→load(msValidity)

Preloads the function cache with a specified validity duration.

network→load_async(msValidity, callback, context)

Preloads the function cache with a specified validity duration (asynchronous version).

network→nextNetwork()

Continues the enumeration of network interfaces started using `yFirstNetwork()`.

network→registerValueCallback(callback)

Registers the callback function that is invoked on every change of advertised value.

network→set_adminPassword(newval)

Changes the password for the "admin" user.

network→set_callbackCredentials(newval)

Changes the credentials required to connect to the callback address.

network→set_callbackMaxDelay(newval)

Changes the maximum wait time between two callback notifications, in seconds.

network→set_callbackMinDelay(newval)

Changes the minimum wait time between two callback notifications, in seconds.

network→set_callbackUrl(newval)

Changes the callback URL to notify of significant state changes.

network→set_logicalName(newval)

Changes the logical name of the network interface, corresponding to the network name of the module.

network→set_primaryDNS(newval)

Changes the IP address of the primary name server to be used by the module.

network→set_secondaryDNS(newval)

Changes the IP address of the secondary name server to be used by the module.

network→set_userData(data)

Stores a user context provided as argument in the `userData` attribute of the function.

network→set_userPassword(newval)

Changes the password for the "user" user.

network→useDHCP(fallbackIpAddr, fallbackSubnetMaskLen, fallbackRouter)

Changes the configuration of the network interface to enable the use of an IP address received from a DHCP server.

network→useStaticIP(ipAddress, subnetMaskLen, router)

Changes the configuration of the network interface to use a static IP address.

yFindNetwork()

Retrieves a network interface for a given identifier.

`YNetwork* yFindNetwork(NSString* func)`

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the network interface is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YNetwork.isOnline()` to test if the network interface is indeed online at a given time. In case of ambiguity when looking for a network interface by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

Parameters :

func a string that uniquely characterizes the network interface

Returns :

a `YNetwork` object allowing you to drive the network interface.

yFirstNetwork()

Starts the enumeration of network interfaces currently accessible.

`YNetwork* yFirstNetwork()`

Use the method `YNetwork.nextNetwork()` to iterate on next network interfaces.

Returns :

a pointer to a `YNetwork` object, corresponding to the first network interface currently online, or a `null` pointer if there are none.

[network callbackLogin:]

Connects to the notification callback and saves the credentials required to log in to it.

`-(int) callbackLogin : (NSString*) username : (NSString*) password`

The password will not be stored into the module, only a hashed copy of the credentials will be saved. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

Parameters :

username username required to log to the callback

password password required to log to the callback

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[network describe]

Returns a descriptive text that identifies the function.

`-(NSString*) describe`

The text always includes the class name, and may include as well either the logical name of the function or its hardware identifier.

Returns :

a string that describes the function

[network adminPassword]

Returns a hash string if a password has been set for user "admin", or an empty string otherwise.

`-(NSString*) adminPassword`

Returns :

a string corresponding to a hash string if a password has been set for user "admin", or an empty string otherwise

On failure, throws an exception or returns `Y_ADMINPASSWORD_INVALID`.

[network advertisedValue]

Returns the current value of the network interface (no more than 6 characters).

`-(NSString*) advertisedValue`

Returns :

a string corresponding to the current value of the network interface (no more than 6 characters)

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

[network callbackCredentials]

Returns a hashed version of the notification callback credentials if set, or an empty string otherwise.

`-(NSString*) callbackCredentials`

Returns :

a string corresponding to a hashed version of the notification callback credentials if set, or an empty string otherwise

On failure, throws an exception or returns `Y_CALLBACKCREDENTIALS_INVALID`.

[network callbackMaxDelay]

Returns the maximum wait time between two callback notifications, in seconds.

`-(unsigned) callbackMaxDelay`

Returns :

an integer corresponding to the maximum wait time between two callback notifications, in seconds

On failure, throws an exception or returns `Y_CALLBACKMAXDELAY_INVALID`.

[network callbackMinDelay]

Returns the minimum wait time between two callback notifications, in seconds.

`-(unsigned) callbackMinDelay`

Returns :

an integer corresponding to the minimum wait time between two callback notifications, in seconds

On failure, throws an exception or returns `Y_CALLBACKMINDELAY_INVALID`.

[network callbackUrl]

Returns the callback URL to notify of significant state changes.

-(NSString*) callbackUrl

Returns :

a string corresponding to the callback URL to notify of significant state changes

On failure, throws an exception or returns Y_CALLBACKURL_INVALID.

Returns the error message of the latest error with this function.

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

Returns :

a string corresponding to the latest error message that occurred while using this function object

Returns the numerical error code of the latest error with this function.

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

Returns :

a number corresponding to the code of the latest error that occurred while using this function object

[network networkDescriptor]

Returns a unique identifier of type YFUN_DESCR corresponding to the function.

-(YFUN_DESCR) functionDescriptor

This identifier can be used to test if two instances of YFunction reference the same physical function on the same physical device.

Returns :

an identifier of type YFUN_DESCR. If the function has never been contacted, the returned value is Y_FUNCTIONDESCRIPTOR_INVALID.

Returns the unique hardware identifier of the function.

The unique hardware identifier is made of the device serial number and of the hardware identifier of the function.

Returns :

a string that uniquely identifies the function On failure, throws an exception or returns Y_HARDWAREID_INVALID.

[network ipAddress]

Returns the IP address currently in use by the device.

-(NSString*) ipAddress

The address may have been configured statically, or provided by a DHCP server.

Returns :

a string corresponding to the IP address currently in use by the device

On failure, throws an exception or returns `Y_IPADDRESS_INVALID`.

[network logicalName]

Returns the logical name of the network interface, corresponding to the network name of the module.

`-(NSString*) logicalName`

Returns :

a string corresponding to the logical name of the network interface, corresponding to the network name of the module

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

[network macAddress]

Returns the MAC address of the network interface.

`-(NSString*) macAddress`

The MAC address is also available on a sticker on the module, in both numeric and barcode forms.

Returns :

a string corresponding to the MAC address of the network interface

On failure, throws an exception or returns `Y_MACADDRESS_INVALID`.

[network module]

Get the `YModule` object for the device on which the function is located.

`-(YModule*) module`

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

Returns :

an instance of `YModule`

Get the `YModule` object for the device on which the function is located (asynchronous version).

If the function cannot be located on any module, the returned `YModule` object does not show as on-line. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

Parameters :

callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the requested `YModule` object

context caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[network primaryDNS]

Returns the IP address of the primary name server to be used by the module.

-(NSString*) primaryDNS

Returns :

a string corresponding to the IP address of the primary name server to be used by the module

On failure, throws an exception or returns Y_PRIMARYDNS_INVALID.

[network readiness]

Returns the current established working mode of the network interface.

-(Y_READINESS_enum) readiness

Level zero (DOWN_0) means that no hardware link has been detected. Either there is no signal on the network cable, or the selected wireless access point cannot be detected. Level 1 (LIVE_1) is reached when the network is detected, but is not yet connected. For a wireless network, this shows that the requested SSID is present. Level 2 (LINK_2) is reached when the hardware connection is established. For a wired network connection, level 2 means that the cable is attached on both ends. For a connection to a wireless access point, it shows that the security parameters are properly configured. For an ad-hoc wireless connection, it means that there is at least one other device connected on the ad-hoc network. Level 3 (DHCP_3) is reached when an IP address has been obtained using DHCP. Level 4 (DNS_4) is reached when the DNS server is reachable on the network. Level 5 (WWW_5) is reached when global connectivity is demonstrated by properly loading current time from an NTP server.

Returns :

a value among Y_READINESS_DOWN, Y_READINESS_EXISTS, Y_READINESS_LINKED, Y_READINESS_LAN_OK and Y_READINESS_WWW_OK corresponding to the current established working mode of the network interface

On failure, throws an exception or returns Y_READINESS_INVALID.

[network router]

Returns the IP address of the router on the device subnet (default gateway).

-(NSString*) router

Returns :

a string corresponding to the IP address of the router on the device subnet (default gateway)

On failure, throws an exception or returns Y_ROUTER_INVALID.

[network secondaryDNS]

Returns the IP address of the secondary name server to be used by the module.

-(NSString*) secondaryDNS

Returns :

a string corresponding to the IP address of the secondary name server to be used by the module

On failure, throws an exception or returns Y_SECONDARYDNS_INVALID.

[network subnetMask]

Returns the subnet mask currently used by the device.

-(NSString*) subnetMask

Returns :

a string corresponding to the subnet mask currently used by the device

On failure, throws an exception or returns `Y_SUBNETMASK_INVALID`.

[network userData]

Returns the value of the `userData` attribute, as previously stored using method `set_userdata`.

`-(void*) userData`

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

Returns :
the object stored previously by the caller.

[network userPassword]

Returns a hash string if a password has been set for user "user", or an empty string otherwise.

`-(NSString*) userPassword`

Returns :
a string corresponding to a hash string if a password has been set for user "user", or an empty string otherwise

On failure, throws an exception or returns `Y_USERPASSWORD_INVALID`.

[network isOnline]

Checks if the function is currently reachable, without raising any error.

`-(BOOL) isOnline`

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

Returns :
`true` if the function can be reached, and `false` otherwise

Checks if the function is currently reachable, without raising any error (asynchronous version).

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox Javascript VM that does not implement context switching during blocking I/O calls.

Parameters :

callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the boolean result

context caller-specific object that is passed as-is to the callback function

Returns :
nothing : the result is provided to the callback.

[network load:]

Preloads the function cache with a specified validity duration.

-(YRETCODE) **load** : (int) **msValidity**

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

Parameters :

msValidity an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

Returns :

YAPI_SUCCESS when the call succeeds. On failure, throws an exception or returns a negative error code.

Preloads the function cache with a specified validity duration (asynchronous version).

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

Parameters :

msValidity an integer corresponding to the validity of the loaded function parameters, in milliseconds

callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the error code (or YAPI_SUCCESS)

context caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[network nextNetwork]

Continues the enumeration of network interfaces started using `yFirstNetwork()`.

-(YNetwork*) **nextNetwork**

Returns :

a pointer to a YNetwork object, corresponding to a network interface currently online, or a null pointer if there are no more network interfaces to enumerate.

[network registerValueCallback:]

Registers the callback function that is invoked on every change of advertised value.

-(void) **registerValueCallback** : (YFunctionUpdateCallback) **callback**

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

Parameters :

callback the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

[network setAdminPassword:]

Changes the password for the "admin" user.

-(int) setAdminPassword : (NSString*) newval

This password becomes instantly required to perform any change of the module state. If the specified value is an empty string, a password is not required anymore. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

Parameters :

newval a string corresponding to the password for the "admin" user

Returns :

YAPI_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

[network setCallbackCredentials:]

Changes the credentials required to connect to the callback address.

-(int) setCallbackCredentials : (NSString*) newval

The credentials must be provided as returned by function `get_callbackCredentials`, in the form `username:hash`. The method used to compute the hash varies according to the authentication scheme implemented by the callback. For Basic authentication, the hash is the MD5 of the string `username:password`. For Digest authentication, the hash is the MD5 of the string `username:realm:password`. For a simpler way to configure callback credentials, use function `callbackLogin` instead. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

Parameters :

newval a string corresponding to the credentials required to connect to the callback address

Returns :

YAPI_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

[network setCallbackMaxDelay:]

Changes the maximum wait time between two callback notifications, in seconds.

-(int) setCallbackMaxDelay : (unsigned) newval

Parameters :

newval an integer corresponding to the maximum wait time between two callback notifications, in seconds

Returns :

YAPI_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

[network setCallbackMinDelay:]

Changes the minimum wait time between two callback notifications, in seconds.

`-(int) setCallbackMinDelay : (unsigned) newval`

Parameters :

newval an integer corresponding to the minimum wait time between two callback notifications, in seconds

Returns :

YAPI_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

[network setCallbackUrl:]

Changes the callback URL to notify of significant state changes.

`-(int) setCallbackUrl : (NSString*) newval`

Remember to call the `saveToFlash()` method of the module if the modification must be kept.

Parameters :

newval a string corresponding to the callback URL to notify of significant state changes

Returns :

YAPI_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

[network setLogicalName:]

Changes the logical name of the network interface, corresponding to the network name of the module.

`-(int) setLogicalName : (NSString*) newval`

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

Parameters :

newval a string corresponding to the logical name of the network interface, corresponding to the network name of the module

Returns :

YAPI_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

[network setPrimaryDNS:]

Changes the IP address of the primary name server to be used by the module.

`-(int) setPrimaryDNS : (NSString*) newval`

When using DHCP, if a value is specified, it will override the value received from the DHCP server. Remember to call the `saveToFlash()` method and then to reboot the module to apply this setting.

Parameters :

newval a string corresponding to the IP address of the primary name server to be used by the module

Returns :

YAPI_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

[network setSecondaryDNS:]

Changes the IP address of the secondary name server to be used by the module.

`-(int) setSecondaryDNS : (NSString*) newval`

When using DHCP, if a value is specified, it will override the value received from the DHCP server. Remember to call the `saveToFlash()` method and then to reboot the module to apply this setting.

Parameters :

newval a string corresponding to the IP address of the secondary name server to be used by the module

Returns :

YAPI_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

[network setUserData:]

Stores a user context provided as argument in the userData attribute of the function.

`-(void) setUserData : (void*) data`

This attribute is never touched by the API, and is at disposal of the caller to store a context.

Parameters :

data any kind of object to be stored

[network setUserPassword:]

Changes the password for the "user" user.

`-(int) setUserPassword : (NSString*) newval`

This password becomes instantly required to perform any use of the module. If the specified value is an empty string, a password is not required anymore. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

Parameters :

newval a string corresponding to the password for the "user" user

Returns :

YAPI_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

[network useDHCP:]

Changes the configuration of the network interface to enable the use of an IP address received from a DHCP server.

`-(int) useDHCP : (NSString*) fallbackIpAddr
: (int) fallbackSubnetMaskLen
: (NSString*) fallbackRouter`

Until an address is received from a DHCP server, the module will use the IP parameters specified to this function. Remember to call the `saveToFlash()` method and then to reboot the module to apply this setting.

Parameters :

fallbackIpAddr fallback IP address, to be used when no DHCP reply is received
fallbackSubnetMaskLen fallback subnet mask length when no DHCP reply is received, as an integer (eg. 24 means 255.255.255.0)
fallbackRouter fallback router IP address, to be used when no DHCP reply is received

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[network useStaticIP:]

Changes the configuration of the network interface to use a static IP address.

-(int) **useStaticIP** : (NSString*) **ipAddress**
: (int) **subnetMaskLen**
: (NSString*) **router**

Remember to call the `saveToFlash()` method and then to reboot the module to apply this setting.

Parameters :

ipAddress device IP address
subnetMaskLen subnet mask length, as an integer (eg. 24 means 255.255.255.0)
router router IP address (default gateway)

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

3.16. Pressure function interface

The Yoctopuce application programming interface allows you to read an instant measure of the sensor, as well as the minimal and maximal values observed.

In order to use the functions described here, you should include:

`#import "yocto_pressure.h"`

Global functions

yFindPressure(func)

Retrieves a pressure sensor for a given identifier.

yFirstPressure()

Starts the enumeration of pressure sensors currently accessible.

YPressure methods

pressure→calibrateFromPoints(rawValues, refValues)

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

pressure→describe()

Returns a descriptive text that identifies the function.

pressure→get_advertisedValue()

Returns the current value of the pressure sensor (no more than 6 characters).

pressure→get_currentRawValue()

Returns the unrounded and uncalibrated raw value returned by the sensor.
pressure→get_currentValue() Returns the current measured value.
pressure→get_errorMessage() Returns the error message of the latest error with this function.
pressure→get_errorType() Returns the numerical error code of the latest error with this function.
pressure→get_functionDescriptor() Returns a unique identifier of type <code>YFUN_DESCR</code> corresponding to the function.
pressure→get_hardwareId() Returns the unique hardware identifier of the function.
pressure→get_highestValue() Returns the maximal value observed.
pressure→get_logicalName() Returns the logical name of the pressure sensor.
pressure→get_lowestValue() Returns the minimal value observed.
pressure→get_module() Get the <code>YModule</code> object for the device on which the function is located.
pressure→get_module_async(callback, context) Get the <code>YModule</code> object for the device on which the function is located (asynchronous version).
pressure→get_resolution() Returns the resolution of the measured values.
pressure→get_unit() Returns the measuring unit for the measured value.
pressure→get_userData() Returns the value of the <code>userData</code> attribute, as previously stored using method <code>set_userData</code> .
pressure→isOnline() Checks if the function is currently reachable, without raising any error.
pressure→isOnline_async(callback, context) Checks if the function is currently reachable, without raising any error (asynchronous version).
pressure→load(msValidity) Preloads the function cache with a specified validity duration.
pressure→load_async(msValidity, callback, context) Preloads the function cache with a specified validity duration (asynchronous version).
pressure→nextPressure() Continues the enumeration of pressure sensors started using <code>yFirstPressure()</code> .
pressure→registerValueCallback(callback) Registers the callback function that is invoked on every change of advertised value.
pressure→set_highestValue(newval) Changes the recorded maximal value observed.
pressure→set_logicalName(newval)

Changes the logical name of the pressure sensor.

pressure→**set_lowestValue**(**newval**)

Changes the recorded minimal value observed.

pressure→**set_userData**(**data**)

Stores a user context provided as argument in the `userData` attribute of the function.

yFindPressure()

Retrieves a pressure sensor for a given identifier.

`YPressure* yFindPressure(NSString* func)`

The identifier can be specified using several formats:

- `FunctionLogicalName`
- `ModuleSerialNumber.FunctionIdentifier`
- `ModuleSerialNumber.FunctionLogicalName`
- `ModuleLogicalName.FunctionIdentifier`
- `ModuleLogicalName.FunctionLogicalName`

This function does not require that the pressure sensor is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YPressure.isOnline()` to test if the pressure sensor is indeed online at a given time. In case of ambiguity when looking for a pressure sensor by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

Parameters :

func a string that uniquely characterizes the pressure sensor

Returns :

a `YPressure` object allowing you to drive the pressure sensor.

yFirstPressure()

Starts the enumeration of pressure sensors currently accessible.

`YPressure* yFirstPressure()`

Use the method `YPressure.nextPressure()` to iterate on next pressure sensors.

Returns :

a pointer to a `YPressure` object, corresponding to the first pressure sensor currently online, or a `null` pointer if there are none.

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

It is possible to configure up to five correction points. Correction points must be provided in ascending order, and be in the range of the sensor. The device will automatically perform a lineat interpolation of the error correction between specified points. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

For more information on advanced capabilities to refine the calibration of sensors, please contact support@yoctopuce.com.

Parameters :

rawValues array of floating point numbers, corresponding to the raw values returned by the sensor for the correction points.

refValues array of floating point numbers, corresponding to the corrected values for the correction points.

Returns :

YAPI_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

[pressure describe]

Returns a descriptive text that identifies the function.

-(NSString*) **describe**

The text always includes the class name, and may include as well either the logical name of the function or its hardware identifier.

Returns :

a string that describes the function

[pressure advertisedValue]

Returns the current value of the pressure sensor (no more than 6 characters).

-(NSString*) **advertisedValue**

Returns :

a string corresponding to the current value of the pressure sensor (no more than 6 characters)

On failure, throws an exception or returns Y_ADVERTISEDVALUE_INVALID.

[pressure currentRawValue]

Returns the unrounded and uncalibrated raw value returned by the sensor.

-(double) **currentRawValue**

Returns :

a floating point number corresponding to the unrounded and uncalibrated raw value returned by the sensor

On failure, throws an exception or returns Y_CURRENTRAWVALUE_INVALID.

[pressure currentValue]

Returns the current measured value.

-(double) **currentValue**

Returns :

a floating point number corresponding to the current measured value

On failure, throws an exception or returns Y_CURRENTVALUE_INVALID.

Returns the error message of the latest error with this function.

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

Returns :

a string corresponding to the latest error message that occurred while using this function object

Returns the numerical error code of the latest error with this function.

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

Returns :

a number corresponding to the code of the latest error that occurred while using this function object

[pressure pressureDescriptor]

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

`-(YFUN_DESCR) functionDescriptor`

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

Returns :

an identifier of type `YFUN_DESCR`. If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

Returns the unique hardware identifier of the function.

The unique hardware identifier is made of the device serial number and of the hardware identifier of the function.

Returns :

a string that uniquely identifies the function. On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

[pressure highestValue]

Returns the maximal value observed.

`-(double) highestValue`

Returns :

a floating point number corresponding to the maximal value observed

On failure, throws an exception or returns `Y_HIGHESTVALUE_INVALID`.

[pressure logicalName]

Returns the logical name of the pressure sensor.

`-(NSString*) logicalName`

Returns :

a string corresponding to the logical name of the pressure sensor

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

[pressure lowestValue]

Returns the minimal value observed.

`-(double) lowestValue`

Returns :

a floating point number corresponding to the minimal value observed

On failure, throws an exception or returns `Y_LOWESTVALUE_INVALID`.

[pressure module]

Get the `YModule` object for the device on which the function is located.

`-(YModule*) module`

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

Returns :

an instance of `YModule`

Get the `YModule` object for the device on which the function is located (asynchronous version).

If the function cannot be located on any module, the returned `YModule` object does not show as on-line. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

Parameters :

callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the requested `YModule` object

context caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[pressure resolution]

Returns the resolution of the measured values.

`-(double) resolution`

The resolution corresponds to the numerical precision of the values, which is not always the same as the actual precision of the sensor.

Returns :

a floating point number corresponding to the resolution of the measured values

On failure, throws an exception or returns `Y_RESOLUTION_INVALID`.

[pressure unit]

Returns the measuring unit for the measured value.

`-(NSString*) unit`

Returns :

a string corresponding to the measuring unit for the measured value

On failure, throws an exception or returns `Y_UNIT_INVALID`.

[pressure userData]

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

-(void*) **userData**

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

Returns :
the object stored previously by the caller.

[pressure isOnline]

Checks if the function is currently reachable, without raising any error.

-(BOOL) **isOnline**

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

Returns :
`true` if the function can be reached, and `false` otherwise

Checks if the function is currently reachable, without raising any error (asynchronous version).

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox Javascript VM that does not implement context switching during blocking I/O calls.

Parameters :
callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the boolean result
context caller-specific object that is passed as-is to the callback function

Returns :
nothing : the result is provided to the callback.

[pressure load:]

Preloads the function cache with a specified validity duration.

-(YRETCODE) **load** : (int) **msValidity**

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

Parameters :
msValidity an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

Returns :
`YAPI_SUCCESS` when the call succeeds. On failure, throws an exception or returns a negative error code.

Preloads the function cache with a specified validity duration (asynchronous version).

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

Parameters :

- msValidity** an integer corresponding to the validity of the loaded function parameters, in milliseconds
- callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the error code (or `YAPI_SUCCESS`)
- context** caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[pressure nextPressure]

Continues the enumeration of pressure sensors started using `yFirstPressure()`.

-(YPressure*) **nextPressure**

Returns :

a pointer to a `YPressure` object, corresponding to a pressure sensor currently online, or a `null` pointer if there are no more pressure sensors to enumerate.

[pressure registerValueCallback:]

Registers the callback function that is invoked on every change of advertised value.

-(void) **registerValueCallback** : (YFunctionUpdateCallback) **callback**

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

Parameters :

- callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

[pressure setHighestValue:]

Changes the recorded maximal value observed.

-(int) **setHighestValue** : (double) **newval**

Parameters :

- newval** a floating point number corresponding to the recorded maximal value observed

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[pressure setLogicalName:]

Changes the logical name of the pressure sensor.

`-(int) setLogicalName : (NSString*) newval`

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

Parameters :

newval a string corresponding to the logical name of the pressure sensor

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[pressure setLowestValue:]

Changes the recorded minimal value observed.

`-(int) setLowestValue : (double) newval`

Parameters :

newval a floating point number corresponding to the recorded minimal value observed

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[pressure setUserData:]

Stores a user context provided as argument in the `userData` attribute of the function.

`-(void) setUserData : (void*) data`

This attribute is never touched by the API, and is at disposal of the caller to store a context.

Parameters :

data any kind of object to be stored

3.17. Relay function interface

The Yoctopuce application programming interface allows you to switch the relay state. This change is not persistent: the relay will automatically return to its idle position whenever power is lost or if the module is restarted. The library can also generate automatically short pulses of determined duration. On devices with two output for each relay (double throw), the two outputs are named A and B, with output A corresponding to the idle position (at power off) and the output B corresponding to the active state. If you prefer the alternate default state, simply switch your cables on the board.

In order to use the functions described here, you should include:

`#import "yocto_relay.h"`

Global functions

`yFindRelay(func)`

Retrieves a relay for a given identifier.

`yFirstRelay()`

Starts the enumeration of relays currently accessible.

YRelay methods

relay→describe()

Returns a descriptive text that identifies the function.

relay→get_advertisedValue()

Returns the current value of the relay (no more than 6 characters).

relay→get_errorMessage()

Returns the error message of the latest error with this function.

relay→get_errorType()

Returns the numerical error code of the latest error with this function.

relay→get_functionDescriptor()

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

relay→get_hardwareId()

Returns the unique hardware identifier of the function.

relay→get_logicalName()

Returns the logical name of the relay.

relay→get_module()

Get the `YModule` object for the device on which the function is located.

relay→get_module_async(callback, context)

Get the `YModule` object for the device on which the function is located (asynchronous version).

relay→get_output()

Returns the output state of the relay, when used as a simple switch (single throw).

relay→get_pulseTimer()

Returns the number of milliseconds remaining before the relay is returned to idle position (state A), during a measured pulse generation.

relay→get_state()

Returns the state of the relay (A for the idle position, B for the active position).

relay→get_userData()

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

relay→isOnline()

Checks if the function is currently reachable, without raising any error.

relay→isOnline_async(callback, context)

Checks if the function is currently reachable, without raising any error (asynchronous version).

relay→load(msValidity)

Preloads the function cache with a specified validity duration.

relay→load_async(msValidity, callback, context)

Preloads the function cache with a specified validity duration (asynchronous version).

relay→nextRelay()

Continues the enumeration of relays started using `yFirstRelay()`.

relay→pulse(ms_duration)

Sets the relay to output B (active) for a specified duration, then brings it automatically back to output A (idle state).

relay→registerValueCallback(callback)

Registers the callback function that is invoked on every change of advertised value.

relay→**set_logicalName**(**newval**)

Changes the logical name of the relay.

relay→**set_output**(**newval**)

Changes the output state of the relay, when used as a simple switch (single throw).

relay→**set_state**(**newval**)

Changes the state of the relay (A for the idle position, B for the active position).

relay→**set_userData**(**data**)

Stores a user context provided as argument in the `userData` attribute of the function.

yFindRelay()

Retrieves a relay for a given identifier.

YRelay* **yFindRelay**(**NSString*** **func**)

The identifier can be specified using several formats:

- `FunctionLogicalName`
- `ModuleSerialNumber.FunctionIdentifier`
- `ModuleSerialNumber.FunctionLogicalName`
- `ModuleLogicalName.FunctionIdentifier`
- `ModuleLogicalName.FunctionLogicalName`

This function does not require that the relay is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YRelay.isOnline()` to test if the relay is indeed online at a given time. In case of ambiguity when looking for a relay by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

Parameters :

func a string that uniquely characterizes the relay

Returns :

a `YRelay` object allowing you to drive the relay.

yFirstRelay()

Starts the enumeration of relays currently accessible.

YRelay* **yFirstRelay**()

Use the method `YRelay.nextRelay()` to iterate on next relays.

Returns :

a pointer to a `YRelay` object, corresponding to the first relay currently online, or a `null` pointer if there are none.

[relay describe]

Returns a descriptive text that identifies the function.

-(NSString*) describe

The text always includes the class name, and may include as well either the logical name of the function or its hardware identifier.

Returns :

a string that describes the function

[relay advertisedValue]

Returns the current value of the relay (no more than 6 characters).

`-(NSString*) advertisedValue`

Returns :

a string corresponding to the current value of the relay (no more than 6 characters)

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

Returns the error message of the latest error with this function.

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

Returns :

a string corresponding to the latest error message that occurred while using this function object

Returns the numerical error code of the latest error with this function.

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

Returns :

a number corresponding to the code of the latest error that occurred while using this function object

[relay relayDescriptor]

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

`-(YFUN_DESCR) functionDescriptor`

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

Returns :

an identifier of type `YFUN_DESCR`. If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

Returns the unique hardware identifier of the function.

The unique hardware identifier is made of the device serial number and of the hardware identifier of the function.

Returns :

a string that uniquely identifies the function On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

[relay logicalName]

Returns the logical name of the relay.

`-(NSString*) logicalName`

Returns :

a string corresponding to the logical name of the relay

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

[relay module]

Get the `YModule` object for the device on which the function is located.

-(YModule*) module

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

Returns :

an instance of `YModule`

Get the `YModule` object for the device on which the function is located (asynchronous version).

If the function cannot be located on any module, the returned `YModule` object does not show as on-line. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

Parameters :

callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the requested `YModule` object

context caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[relay output]

Returns the output state of the relay, when used as a simple switch (single throw).

-(Y_OUTPUT_enum) output

Returns :

either `Y_OUTPUT_OFF` or `Y_OUTPUT_ON`, according to the output state of the relay, when used as a simple switch (single throw)

On failure, throws an exception or returns `Y_OUTPUT_INVALID`.

[relay pulseTimer]

Returns the number of milliseconds remaining before the relay is returned to idle position (state A), during a measured pulse generation.

-(unsigned) pulseTimer

When there is no ongoing pulse, returns zero.

Returns :

an integer corresponding to the number of milliseconds remaining before the relay is returned to idle position (state A), during a measured pulse generation

On failure, throws an exception or returns `Y_PULSETIMER_INVALID`.

[relay state]

Returns the state of the relay (A for the idle position, B for the active position).

-(Y_STATE_enum) state

Returns :

either Y_STATE_A or Y_STATE_B, according to the state of the relay (A for the idle position, B for the active position)

On failure, throws an exception or returns Y_STATE_INVALID.

[relay userData]

Returns the value of the userData attribute, as previously stored using method set_userdata.

-(void*) userData

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

Returns :

the object stored previously by the caller.

[relay isOnline]

Checks if the function is currently reachable, without raising any error.

-(BOOL) isOnline

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

Returns :

true if the function can be reached, and false otherwise

Checks if the function is currently reachable, without raising any error (asynchronous version).

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox Javascript VM that does not implement context switching during blocking I/O calls.

Parameters :

callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the boolean result

context caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[relay load:]

Preloads the function cache with a specified validity duration.

-(YRETCODE) load : (int) msValidity

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

Parameters :

msValidity an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

Returns :

`YAPI_SUCCESS` when the call succeeds. On failure, throws an exception or returns a negative error code.

Preloads the function cache with a specified validity duration (asynchronous version).

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

Parameters :

msValidity an integer corresponding to the validity of the loaded function parameters, in milliseconds

callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the error code (or `YAPI_SUCCESS`)

context caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[relay nextRelay]

Continues the enumeration of relays started using `yFirstRelay()`.

-(YRelay*) **nextRelay**

Returns :

a pointer to a `YRelay` object, corresponding to a relay currently online, or a `null` pointer if there are no more relays to enumerate.

[relay pulse:]

Sets the relay to output B (active) for a specified duration, then brings it automatically back to output A (idle state).

-(int) **pulse** : (int) **ms_duration**

Parameters :

ms_duration pulse duration, in milliseconds

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[relay registerValueCallback:]

Registers the callback function that is invoked on every change of advertised value.

`-(void) registerValueCallback : (YFunctionUpdateCallback) callback`

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

Parameters :

callback the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

[relay setLogicalName:]

Changes the logical name of the relay.

`-(int) setLogicalName : (NSString*) newval`

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

Parameters :

newval a string corresponding to the logical name of the relay

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[relay setOutput:]

Changes the output state of the relay, when used as a simple switch (single throw).

`-(int) setOutput : (Y_OUTPUT_enum) newval`

Parameters :

newval either `Y_OUTPUT_OFF` or `Y_OUTPUT_ON`, according to the output state of the relay, when used as a simple switch (single throw)

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[relay setState:]

Changes the state of the relay (A for the idle position, B for the active position).

`-(int) setState : (Y_STATE_enum) newval`

Parameters :

newval either `Y_STATE_A` or `Y_STATE_B`, according to the state of the relay (A for the idle position, B for the active position)

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[relay setUserData:]

Stores a user context provided as argument in the `userData` attribute of the function.

-(void) setData : (void*) **data**

This attribute is never touched by the API, and is at disposal of the caller to store a context.

Parameters :

data any kind of object to be stored

3.18. Servo function interface

Yoctopuce application programming interface allows you not only to move a servo to a given position, but also to specify the time interval in which the move should be performed. This makes it possible to synchronize two servos involved in a same move.

In order to use the functions described here, you should include:

`#import "yocto_servo.h"`

Global functions

yFindServo(func)

Retrieves a servo for a given identifier.

yFirstServo()

Starts the enumeration of servos currently accessible.

YServo methods

servo→describe()

Returns a descriptive text that identifies the function.

servo→get_advertisedValue()

Returns the current value of the servo (no more than 6 characters).

servo→get_errorMessage()

Returns the error message of the latest error with this function.

servo→get_errorType()

Returns the numerical error code of the latest error with this function.

servo→get_functionDescriptor()

Returns a unique identifier of type YFUN_DESCR corresponding to the function.

servo→get_hardwareId()

Returns the unique hardware identifier of the function.

servo→get_logicalName()

Returns the logical name of the servo.

servo→get_module()

Get the YModule object for the device on which the function is located.

servo→get_module_async(callback, context)

Get the YModule object for the device on which the function is located (asynchronous version).

servo→get_neutral()

Returns the duration in microseconds of a neutral pulse for the servo.

servo→get_position()

Returns the current servo position.

servo→get_range()

Returns the current range of use of the servo.

servo→get_userData()

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

`servo→isOnline()`

Checks if the function is currently reachable, without raising any error.

`servo→isOnline_async(callback, context)`

Checks if the function is currently reachable, without raising any error (asynchronous version).

`servo→load(msValidity)`

Preloads the function cache with a specified validity duration.

`servo→load_async(msValidity, callback, context)`

Preloads the function cache with a specified validity duration (asynchronous version).

`servo→move(target, ms_duration)`

Performs a smooth move at constant speed toward a given position.

`servo→nextServo()`

Continues the enumeration of servos started using `yFirstServo()`.

`servo→registerValueCallback(callback)`

Registers the callback function that is invoked on every change of advertised value.

`servo→set_logicalName(newval)`

Changes the logical name of the servo.

`servo→set_neutral(newval)`

Changes the duration of the pulse corresponding to the neutral position of the servo.

`servo→set_position(newval)`

Changes immediately the servo driving position.

`servo→set_range(newval)`

Changes the range of use of the servo, specified in per cents.

`servo→set_userData(data)`

Stores a user context provided as argument in the `userData` attribute of the function.

`yFindServo()`

Retrieves a servo for a given identifier.

`YServo* yFindServo(NSString* func)`

The identifier can be specified using several formats:

- `FunctionLogicalName`
- `ModuleSerialNumber.FunctionIdentifier`
- `ModuleSerialNumber.FunctionLogicalName`
- `ModuleLogicalName.FunctionIdentifier`
- `ModuleLogicalName.FunctionLogicalName`

This function does not require that the servo is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YServo.isOnline()` to test if the servo is indeed online at a given time. In case of ambiguity when looking for a servo by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

Parameters :

`func` a string that uniquely characterizes the servo

Returns :

a `YServo` object allowing you to drive the servo.

yFirstServo()

Starts the enumeration of servos currently accessible.

`YServo* yFirstServo()`

Use the method `YServo.nextServo()` to iterate on next servos.

Returns :

a pointer to a `YServo` object, corresponding to the first servo currently online, or a `null` pointer if there are none.

[servo describe]

Returns a descriptive text that identifies the function.

`-(NSString*) describe`

The text always includes the class name, and may include as well either the logical name of the function or its hardware identifier.

Returns :

a string that describes the function

[servo advertisedValue]

Returns the current value of the servo (no more than 6 characters).

`-(NSString*) advertisedValue`

Returns :

a string corresponding to the current value of the servo (no more than 6 characters)

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

Returns the error message of the latest error with this function.

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

Returns :

a string corresponding to the latest error message that occurred while using this function object

Returns the numerical error code of the latest error with this function.

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

Returns :

a number corresponding to the code of the latest error that occurred while using this function object

[servo servoDescriptor]

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

`-(YFUN_DESCR) functionDescriptor`

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

Returns :

an identifier of type `YFUN_DESCR`. If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

Returns the unique hardware identifier of the function.

The unique hardware identifier is made of the device serial number and of the hardware identifier of the function.

Returns :

a string that uniquely identifies the function On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

[servo logicalName]

Returns the logical name of the servo.

`-(NSString*) logicalName`

Returns :

a string corresponding to the logical name of the servo

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

[servo module]

Get the `YModule` object for the device on which the function is located.

`-(YModule*) module`

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

Returns :

an instance of `YModule`

Get the `YModule` object for the device on which the function is located (asynchronous version).

If the function cannot be located on any module, the returned `YModule` object does not show as on-line. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

Parameters :

callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the requested `YModule` object

context caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[servo neutral]

Returns the duration in microseconds of a neutral pulse for the servo.

`-(int) neutral`

Returns :

an integer corresponding to the duration in microseconds of a neutral pulse for the servo

On failure, throws an exception or returns `Y_NEUTRAL_INVALID`.

[servo position]

Returns the current servo position.

-(int) position

Returns :

an integer corresponding to the current servo position

On failure, throws an exception or returns `Y_POSITION_INVALID`.

[servo range]

Returns the current range of use of the servo.

-(int) range

Returns :

an integer corresponding to the current range of use of the servo

On failure, throws an exception or returns `Y_RANGE_INVALID`.

[servo userData]

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

-(void*) userData

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

Returns :

the object stored previously by the caller.

[servo isOnline]

Checks if the function is currently reachable, without raising any error.

-(BOOL) isOnline

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

Returns :

`true` if the function can be reached, and `false` otherwise

Checks if the function is currently reachable, without raising any error (asynchronous version).

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox Javascript VM that does not implement context switching during blocking I/O calls.

Parameters :

- callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the boolean result
- context** caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[servo load:]

Preloads the function cache with a specified validity duration.

-(YRETCODE) **load** : (int) **msValidity**

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

Parameters :

- msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

Returns :

YAPI_SUCCESS when the call succeeds. On failure, throws an exception or returns a negative error code.

Preloads the function cache with a specified validity duration (asynchronous version).

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

Parameters :

- msValidity** an integer corresponding to the validity of the loaded function parameters, in milliseconds
- callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the error code (or YAPI_SUCCESS)
- context** caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[servo move:]

Performs a smooth move at constant speed toward a given position.

-(int) **move** : (int) **target** : (int) **ms_duration**

Parameters :

- target** new position at the end of the move
- ms_duration** total duration of the move, in milliseconds

Returns :

YAPI_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

[servo nextServo]

Continues the enumeration of servos started using `yFirstServo()`.

`-(YServo*) nextServo`

Returns :

a pointer to a `YServo` object, corresponding to a servo currently online, or a `null` pointer if there are no more servos to enumerate.

[servo registerValueCallback:]

Registers the callback function that is invoked on every change of advertised value.

`-(void) registerValueCallback : (YFunctionUpdateCallback) callback`

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

Parameters :

callback the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

[servo setLogicalName:]

Changes the logical name of the servo.

`-(int) setLogicalName : (NSString*) newval`

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

Parameters :

newval a string corresponding to the logical name of the servo

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[servo setNeutral:]

Changes the duration of the pulse corresponding to the neutral position of the servo.

`-(int) setNeutral : (int) newval`

The duration is specified in microseconds, and the standard value is 1500 [us]. This setting makes it possible to shift the range of use of the servo. Be aware that using a range higher than what is supported by the servo is likely to damage the servo.

Parameters :

newval an integer corresponding to the duration of the pulse corresponding to the neutral position of the servo

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[servo setPosition:]

Changes immediately the servo driving position.

-(int) setPosition : (int) **newval**

Parameters :

newval an integer corresponding to immediately the servo driving position

Returns :

YAPI_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

[servo setRange:]

Changes the range of use of the servo, specified in per cents.

-(int) setRange : (int) **newval**

A range of 100% corresponds to a standard control signal, that varies from 1 [ms] to 2 [ms], When using a servo that supports a double range, from 0.5 [ms] to 2.5 [ms], you can select a range of 200%. Be aware that using a range higher than what is supported by the servo is likely to damage the servo.

Parameters :

newval an integer corresponding to the range of use of the servo, specified in per cents

Returns :

YAPI_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

[servo setUserData:]

Stores a user context provided as argument in the userData attribute of the function.

-(void) setUserData : (void*) **data**

This attribute is never touched by the API, and is at disposal of the caller to store a context.

Parameters :

data any kind of object to be stored

3.19. Temperature function interface

The Yoctopuce application programming interface allows you to read an instant measure of the sensor, as well as the minimal and maximal values observed.

In order to use the functions described here, you should include:

#import "yocto_temperature.h"

Global functions

yFindTemperature(func)

Retrieves a temperature sensor for a given identifier.

yFirstTemperature()

Starts the enumeration of temperature sensors currently accessible.

YTemperature methods

temperature→calibrateFromPoints(rawValues, refValues)

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

temperature→describe()

Returns a descriptive text that identifies the function.

temperature→get_advertisedValue()

Returns the current value of the temperature sensor (no more than 6 characters).

temperature→get_currentRawValue()

Returns the uncalibrated, unrounded raw value returned by the sensor.

temperature→get_currentValue()

Returns the current measured value.

temperature→get_errorMessage()

Returns the error message of the latest error with this function.

temperature→get_errorType()

Returns the numerical error code of the latest error with this function.

temperature→get_functionDescriptor()

Returns a unique identifier of type YFUN_DESCR corresponding to the function.

temperature→get_hardwareId()

Returns the unique hardware identifier of the function.

temperature→get_highestValue()

Returns the maximal value observed.

temperature→get_logicalName()

Returns the logical name of the temperature sensor.

temperature→get_lowestValue()

Returns the minimal value observed.

temperature→get_module()

Get the YModule object for the device on which the function is located.

temperature→get_module_async(callback, context)

Get the YModule object for the device on which the function is located (asynchronous version).

temperature→get_resolution()

Returns the resolution of the measured values.

temperature→get_sensorType()

Returns the temperature sensor type.

temperature→get_unit()

Returns the measuring unit for the measured value.

temperature→get_userData()

Returns the value of the userData attribute, as previously stored using method set_userData.

temperature→isOnline()

Checks if the function is currently reachable, without raising any error.

temperature→isOnline_async(callback, context)

Checks if the function is currently reachable, without raising any error (asynchronous version).

temperature→load(msValidity)

Preloads the function cache with a specified validity duration.

temperature→**load_async**(**msValidity**, **callback**, **context**)

Preloads the function cache with a specified validity duration (asynchronous version).

temperature→**nextTemperature**()

Continues the enumeration of temperature sensors started using `yFirstTemperature()`.

temperature→**registerValueCallback**(**callback**)

Registers the callback function that is invoked on every change of advertised value.

temperature→**set_highestValue**(**newval**)

Changes the recorded maximal value observed.

temperature→**set_logicalName**(**newval**)

Changes the logical name of the temperature sensor.

temperature→**set_lowestValue**(**newval**)

Changes the recorded minimal value observed.

temperature→**set_sensorType**(**newval**)

Modify the temperature sensor type.

temperature→**set_userData**(**data**)

Stores a user context provided as argument in the `userData` attribute of the function.

yFindTemperature()

Retrieves a temperature sensor for a given identifier.

YTemperature* **yFindTemperature**(**NSString*** **func**)

The identifier can be specified using several formats:

- `FunctionLogicalName`
- `ModuleSerialNumber.FunctionIdentifier`
- `ModuleSerialNumber.FunctionLogicalName`
- `ModuleLogicalName.FunctionIdentifier`
- `ModuleLogicalName.FunctionLogicalName`

This function does not require that the temperature sensor is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YTemperature.isOnline()` to test if the temperature sensor is indeed online at a given time. In case of ambiguity when looking for a temperature sensor by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

Parameters :

func a string that uniquely characterizes the temperature sensor

Returns :

a `YTemperature` object allowing you to drive the temperature sensor.

yFirstTemperature()

Starts the enumeration of temperature sensors currently accessible.

YTemperature* **yFirstTemperature**()

Use the method `YTemperature.nextTemperature()` to iterate on next temperature sensors.

Returns :

a pointer to a `YTemperature` object, corresponding to the first temperature sensor currently online, or a `null` pointer if there are none.

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

It is possible to configure up to five correction points. Correction points must be provided in ascending order, and be in the range of the sensor. The device will automatically perform a linear interpolation of the error correction between specified points. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

For more information on advanced capabilities to refine the calibration of sensors, please contact support@yoctopuce.com.

Parameters :

rawValues array of floating point numbers, corresponding to the raw values returned by the sensor for the correction points.

refValues array of floating point numbers, corresponding to the corrected values for the correction points.

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[temperature describe]

Returns a descriptive text that identifies the function.

`-(NSString*) describe`

The text always includes the class name, and may include as well either the logical name of the function or its hardware identifier.

Returns :

a string that describes the function

[temperature advertisedValue]

Returns the current value of the temperature sensor (no more than 6 characters).

`-(NSString*) advertisedValue`

Returns :

a string corresponding to the current value of the temperature sensor (no more than 6 characters)

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

[temperature currentRawValue]

Returns the uncalibrated, unrounded raw value returned by the sensor.

`-(double) currentRawValue`

Returns :

a floating point number corresponding to the uncalibrated, unrounded raw value returned by the sensor

On failure, throws an exception or returns `Y_CURRENTRAWVALUE_INVALID`.

[temperature currentValue]

Returns the current measured value.

-(double) currentValue

Returns :

a floating point number corresponding to the current measured value

On failure, throws an exception or returns `Y_CURRENTVALUE_INVALID`.

Returns the error message of the latest error with this function.

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

Returns :

a string corresponding to the latest error message that occurred while using this function object

Returns the numerical error code of the latest error with this function.

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

Returns :

a number corresponding to the code of the latest error that occurred while using this function object

[temperature temperatureDescriptor]

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

-(YFUN_DESCR) functionDescriptor

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

Returns :

an identifier of type `YFUN_DESCR`. If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

Returns the unique hardware identifier of the function.

The unique hardware identifier is made of the device serial number and of the hardware identifier of the function.

Returns :

a string that uniquely identifies the function On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

[temperature highestValue]

Returns the maximal value observed.

-(double) highestValue

Returns :

a floating point number corresponding to the maximal value observed

On failure, throws an exception or returns `Y_HIGHESTVALUE_INVALID`.

[temperature logicalName]

Returns the logical name of the temperature sensor.

-(NSString*) logicalName

Returns :

a string corresponding to the logical name of the temperature sensor

On failure, throws an exception or returns Y_LOGICALNAME_INVALID.

[temperature lowestValue]

Returns the minimal value observed.

-(double) lowestValue

Returns :

a floating point number corresponding to the minimal value observed

On failure, throws an exception or returns Y_LOWESTVALUE_INVALID.

[temperature module]

Get the YModule object for the device on which the function is located.

-(YModule*) module

If the function cannot be located on any module, the returned instance of YModule is not shown as on-line.

Returns :

an instance of YModule

Get the YModule object for the device on which the function is located (asynchronous version).

If the function cannot be located on any module, the returned YModule object does not show as on-line. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

Parameters :

callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the requested YModule object

context caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[temperature resolution]

Returns the resolution of the measured values.

-(double) resolution

The resolution corresponds to the numerical precision of the values, which is not always the same as the actual precision of the sensor.

Returns :

a floating point number corresponding to the resolution of the measured values

On failure, throws an exception or returns `Y_RESOLUTION_INVALID`.

[temperature sensorType]

Returns the temperature sensor type.

`-(Y_SENSORTYPE_enum) sensorType`

Returns :

a value among `Y_SENSORTYPE_DIGITAL`, `Y_SENSORTYPE_TYPE_K`, `Y_SENSORTYPE_TYPE_E`, `Y_SENSORTYPE_TYPE_J`, `Y_SENSORTYPE_TYPE_N`, `Y_SENSORTYPE_TYPE_R`, `Y_SENSORTYPE_TYPE_S` and `Y_SENSORTYPE_TYPE_T` corresponding to the temperature sensor type

On failure, throws an exception or returns `Y_SENSORTYPE_INVALID`.

[temperature unit]

Returns the measuring unit for the measured value.

`-(NSString*) unit`

Returns :

a string corresponding to the measuring unit for the measured value

On failure, throws an exception or returns `Y_UNIT_INVALID`.

[temperature userData]

Returns the value of the `userData` attribute, as previously stored using method `set_userdata`.

`-(void*) userData`

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

Returns :

the object stored previously by the caller.

[temperature isOnline]

Checks if the function is currently reachable, without raising any error.

`-(BOOL) isOnline`

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

Returns :

`true` if the function can be reached, and `false` otherwise

Checks if the function is currently reachable, without raising any error (asynchronous version).

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox Javascript VM that does not implement context switching during blocking I/O calls.

Parameters :

- callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the boolean result
- context** caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[temperature load:]

Preloads the function cache with a specified validity duration.

-(YRETCODE) **load** : (int) **msValidity**

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

Parameters :

- msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

Returns :

YAPI_SUCCESS when the call succeeds. On failure, throws an exception or returns a negative error code.

Preloads the function cache with a specified validity duration (asynchronous version).

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

Parameters :

- msValidity** an integer corresponding to the validity of the loaded function parameters, in milliseconds
- callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the error code (or YAPI_SUCCESS)
- context** caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[temperature nextTemperature]

Continues the enumeration of temperature sensors started using `yFirstTemperature()`.

-(YTemperature*) **nextTemperature**

Returns :

a pointer to a YTemperature object, corresponding to a temperature sensor currently online, or a null pointer if there are no more temperature sensors to enumerate.

[temperature registerValueCallback:]

Registers the callback function that is invoked on every change of advertised value.

-(void) **registerValueCallback** : (YFunctionUpdateCallback) **callback**

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

Parameters :

callback the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

[temperature setHighestValue:]

Changes the recorded maximal value observed.

-(int) **setHighestValue** : (double) **newval**

Parameters :

newval a floating point number corresponding to the recorded maximal value observed

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[temperature setLogicalName:]

Changes the logical name of the temperature sensor.

-(int) **setLogicalName** : (NSString*) **newval**

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

Parameters :

newval a string corresponding to the logical name of the temperature sensor

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[temperature setLowestValue:]

Changes the recorded minimal value observed.

-(int) **setLowestValue** : (double) **newval**

Parameters :

newval a floating point number corresponding to the recorded minimal value observed

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[temperature setSensorType:]

Modify the temperature sensor type.

-(int) setSensorType : (Y_SENSORTYPE_enum) **newval**

This function is used to to define the type of thermo couple (K,E...) used with the device. This will have no effect if module is using a digital sensor. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

Parameters :

newval a value among Y_SENSORTYPE_DIGITAL, Y_SENSORTYPE_TYPE_K, Y_SENSORTYPE_TYPE_E, Y_SENSORTYPE_TYPE_J, Y_SENSORTYPE_TYPE_N, Y_SENSORTYPE_TYPE_R, Y_SENSORTYPE_TYPE_S and Y_SENSORTYPE_TYPE_T

Returns :

YAPI_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

[temperature setUserData:]

Stores a user context provided as argument in the userData attribute of the function.

-(void) setUserData : (void*) **data**

This attribute is never touched by the API, and is at disposal of the caller to store a context.

Parameters :

data any kind of object to be stored

3.20. Voltage function interface

The Yoctopuce application programming interface allows you to read an instant measure of the sensor, as well as the minimal and maximal values observed.

In order to use the functions described here, you should include:

`#import "yocto_voltage.h"`

Global functions

yFindVoltage(func)

Retrieves a voltage sensor for a given identifier.

yFirstVoltage()

Starts the enumeration of voltage sensors currently accessible.

YVoltage methods

voltage→calibrateFromPoints(rawValues, refValues)

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

voltage→describe()

Returns a descriptive text that identifies the function.

voltage→get_advertisedValue()

Returns the current value of the voltage sensor (no more than 6 characters).

voltage→get_currentRawValue()

Returns the uncalibrated, unrounded raw value returned by the sensor.

voltage→get_currentValue()

Returns the current measured value.
voltage→get_errorMessage() Returns the error message of the latest error with this function.
voltage→get_errorType() Returns the numerical error code of the latest error with this function.
voltage→get_functionDescriptor() Returns a unique identifier of type <code>YFUN_DESCR</code> corresponding to the function.
voltage→get_hardwareId() Returns the unique hardware identifier of the function.
voltage→get_highestValue() Returns the maximal value observed.
voltage→get_logicalName() Returns the logical name of the voltage sensor.
voltage→get_lowestValue() Returns the minimal value observed.
voltage→get_module() Get the <code>YModule</code> object for the device on which the function is located.
voltage→get_module_async(callback, context) Get the <code>YModule</code> object for the device on which the function is located (asynchronous version).
voltage→get_resolution() Returns the resolution of the measured values.
voltage→get_unit() Returns the measuring unit for the measured value.
voltage→get_userData() Returns the value of the <code>userData</code> attribute, as previously stored using method <code>set_userData</code> .
voltage→isOnline() Checks if the function is currently reachable, without raising any error.
voltage→isOnline_async(callback, context) Checks if the function is currently reachable, without raising any error (asynchronous version).
voltage→load(msValidity) Preloads the function cache with a specified validity duration.
voltage→load_async(msValidity, callback, context) Preloads the function cache with a specified validity duration (asynchronous version).
voltage→nextVoltage() Continues the enumeration of voltage sensors started using <code>yFirstVoltage()</code> .
voltage→registerValueCallback(callback) Registers the callback function that is invoked on every change of advertised value.
voltage→set_highestValue(newval) Changes the recorded maximal value observed.
voltage→set_logicalName(newval) Changes the logical name of the voltage sensor.
voltage→set_lowestValue(newval)

Changes the recorded minimal value observed.

voltage→**set_userdata(data)**

Stores a user context provided as argument in the `userData` attribute of the function.

yFindVoltage()

Retrieves a voltage sensor for a given identifier.

`YVoltage* yFindVoltage(NSString* func)`

The identifier can be specified using several formats:

- `FunctionLogicalName`
- `ModuleSerialNumber.FunctionIdentifier`
- `ModuleSerialNumber.FunctionLogicalName`
- `ModuleLogicalName.FunctionIdentifier`
- `ModuleLogicalName.FunctionLogicalName`

This function does not require that the voltage sensor is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YVoltage.isOnline()` to test if the voltage sensor is indeed online at a given time. In case of ambiguity when looking for a voltage sensor by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

Parameters :

func a string that uniquely characterizes the voltage sensor

Returns :

a `YVoltage` object allowing you to drive the voltage sensor.

yFirstVoltage()

Starts the enumeration of voltage sensors currently accessible.

`YVoltage* yFirstVoltage()`

Use the method `YVoltage.nextVoltage()` to iterate on next voltage sensors.

Returns :

a pointer to a `YVoltage` object, corresponding to the first voltage sensor currently online, or a `null` pointer if there are none.

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

It is possible to configure up to five correction points. Correction points must be provided in ascending order, and be in the range of the sensor. The device will automatically perform a lineat interpolation of the error correction between specified points. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

For more information on advanced capabilities to refine the calibration of sensors, please contact support@yoctopuce.com.

Parameters :

rawValues array of floating point numbers, corresponding to the raw values returned by the sensor for the correction points.

refValues array of floating point numbers, corresponding to the corrected values for the correction points.

Returns :

YAPI_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

[voltage describe]

Returns a descriptive text that identifies the function.

-(NSString*) **describe**

The text always includes the class name, and may include as well either the logical name of the function or its hardware identifier.

Returns :

a string that describes the function

[voltage advertisedValue]

Returns the current value of the voltage sensor (no more than 6 characters).

-(NSString*) **advertisedValue**

Returns :

a string corresponding to the current value of the voltage sensor (no more than 6 characters)

On failure, throws an exception or returns Y_ADVERTISEDVALUE_INVALID.

[voltage currentRawValue]

Returns the uncalibrated, unrounded raw value returned by the sensor.

-(double) **currentRawValue**

Returns :

a floating point number corresponding to the uncalibrated, unrounded raw value returned by the sensor

On failure, throws an exception or returns Y_CURRENTRAWVALUE_INVALID.

[voltage currentValue]

Returns the current measured value.

-(double) **currentValue**

Returns :

a floating point number corresponding to the current measured value

On failure, throws an exception or returns Y_CURRENTVALUE_INVALID.

Returns the error message of the latest error with this function.

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

Returns :

a string corresponding to the latest error message that occurred while using this function object

Returns the numerical error code of the latest error with this function.

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

Returns :

a number corresponding to the code of the latest error that occurred while using this function object

[voltage voltageDescriptor]

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

`-(YFUN_DESCR) functionDescriptor`

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

Returns :

an identifier of type `YFUN_DESCR`. If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

Returns the unique hardware identifier of the function.

The unique hardware identifier is made of the device serial number and of the hardware identifier of the function.

Returns :

a string that uniquely identifies the function. On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

[voltage highestValue]

Returns the maximal value observed.

`-(double) highestValue`

Returns :

a floating point number corresponding to the maximal value observed

On failure, throws an exception or returns `Y_HIGHESTVALUE_INVALID`.

[voltage logicalName]

Returns the logical name of the voltage sensor.

`-(NSString*) logicalName`

Returns :

a string corresponding to the logical name of the voltage sensor

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

[voltage lowestValue]

Returns the minimal value observed.

`-(double) lowestValue`

Returns :

a floating point number corresponding to the minimal value observed

On failure, throws an exception or returns `Y_LOWESTVALUE_INVALID`.

[voltage module]

Get the `YModule` object for the device on which the function is located.

`-(YModule*) module`

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

Returns :

an instance of `YModule`

Get the `YModule` object for the device on which the function is located (asynchronous version).

If the function cannot be located on any module, the returned `YModule` object does not show as on-line. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

Parameters :

callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the requested `YModule` object

context caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[voltage resolution]

Returns the resolution of the measured values.

`-(double) resolution`

The resolution corresponds to the numerical precision of the values, which is not always the same as the actual precision of the sensor.

Returns :

a floating point number corresponding to the resolution of the measured values

On failure, throws an exception or returns `Y_RESOLUTION_INVALID`.

[voltage unit]

Returns the measuring unit for the measured value.

`-(NSString*) unit`

Returns :

a string corresponding to the measuring unit for the measured value

On failure, throws an exception or returns `Y_UNIT_INVALID`.

[voltage userData]

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

`-(void*) userData`

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

Returns :
the object stored previously by the caller.

[voltage isOnline]

Checks if the function is currently reachable, without raising any error.

-(BOOL) isOnline

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

Returns :
`true` if the function can be reached, and `false` otherwise

Checks if the function is currently reachable, without raising any error (asynchronous version).

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox Javascript VM that does not implement context switching during blocking I/O calls.

Parameters :
callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the boolean result
context caller-specific object that is passed as-is to the callback function

Returns :
nothing : the result is provided to the callback.

[voltage load:]

Preloads the function cache with a specified validity duration.

-(YRETCODE) load : (int) msValidity

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

Parameters :
msValidity an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

Returns :
`YAPI_SUCCESS` when the call succeeds. On failure, throws an exception or returns a negative error code.

Preloads the function cache with a specified validity duration (asynchronous version).

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

Parameters :

- msValidity** an integer corresponding to the validity of the loaded function parameters, in milliseconds
- callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the error code (or `YAPI_SUCCESS`)
- context** caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[voltage nextVoltage]

Continues the enumeration of voltage sensors started using `yFirstVoltage()`.

-(YVoltage*) **nextVoltage**

Returns :

a pointer to a `YVoltage` object, corresponding to a voltage sensor currently online, or a null pointer if there are no more voltage sensors to enumerate.

[voltage registerValueCallback:]

Registers the callback function that is invoked on every change of advertised value.

-(void) **registerValueCallback** : (YFunctionUpdateCallback) **callback**

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

Parameters :

- callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

[voltage setHighestValue:]

Changes the recorded maximal value observed.

-(int) **setHighestValue** : (double) **newval**

Parameters :

- newval** a floating point number corresponding to the recorded maximal value observed

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[voltage setLogicalName:]

Changes the logical name of the voltage sensor.

`-(int) setLogicalName : (NSString*) newval`

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

Parameters :

newval a string corresponding to the logical name of the voltage sensor

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[voltage setLowestValue:]

Changes the recorded minimal value observed.

`-(int) setLowestValue : (double) newval`

Parameters :

newval a floating point number corresponding to the recorded minimal value observed

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[voltage setUserData:]

Stores a user context provided as argument in the `userData` attribute of the function.

`-(void) setUserData : (void*) data`

This attribute is never touched by the API, and is at disposal of the caller to store a context.

Parameters :

data any kind of object to be stored

3.21. Voltage source function interface

Yoctopuce application programming interface allows you to control the module voltage output. You affect absolute output values or make transitions

In order to use the functions described here, you should include:

`#import "yocto_vsource.h"`

Global functions

yFindVSource(func)

Retrieves a voltage source for a given identifier.

yFirstVSource()

Starts the enumeration of voltage sources currently accessible.

YVSource methods

vsource→describe()

Returns a descriptive text that identifies the function.

vsource→get_advertisedValue()

Returns the current value of the voltage source (no more than 6 characters).

vsource→get_errorMessage()

Returns the error message of the latest error with this function.
vsource → get_errorType() Returns the numerical error code of the latest error with this function.
vsource → get_extPowerFailure() Return true if external power supply voltage is too low.
vsource → get_failure() Return true if the module is in failure mode.
vsource → get_functionDescriptor() Returns a unique identifier of type <code>YFUN_DESCR</code> corresponding to the function.
vsource → get_hardwareId() Returns the unique hardware identifier of the function.
vsource → get_logicalName() Returns the logical name of the voltage source.
vsource → get_module() Get the <code>YModule</code> object for the device on which the function is located.
vsource → get_module_async(callback, context) Get the <code>YModule</code> object for the device on which the function is located (asynchronous version).
vsource → get_overCurrent() Return true if the appliance connected to the device is too greedy .
vsource → get_overHeat() Return TRUE if the module is overheating.
vsource → get_overLoad() Return true if the device is not able to maintaint the requested voltage output .
vsource → get_regulationFailure() Return true if the voltage output is too high regarding the requested voltage .
vsource → get_unit() Returns the measuring unit for the voltage.
vsource → get_userData() Returns the value of the <code>userData</code> attribute, as previously stored using method <code>set_userData</code> .
vsource → get_voltage() Returns the voltage output command (mV)
vsource → isOnline() Checks if the function is currently reachable, without raising any error.
vsource → isOnline_async(callback, context) Checks if the function is currently reachable, without raising any error (asynchronous version).
vsource → load(msValidity) Preloads the function cache with a specified validity duration.
vsource → load_async(msValidity, callback, context) Preloads the function cache with a specified validity duration (asynchronous version).
vsource → nextVSource() Continues the enumeration of voltage sources started using <code>yFirstVSource()</code> .
vsource → pulse(voltage, ms_duration)

Sets device output to a specific volatage, for a specified duration, then brings it automatically to 0V.

`vsource→registerValueCallback(callback)`

Registers the callback function that is invoked on every change of advertised value.

`vsource→reset()`

Resets the device Output.

`vsource→set_logicalName(newval)`

Changes the logical name of the voltage source.

`vsource→set_userData(data)`

Stores a user context provided as argument in the `userData` attribute of the function.

`vsource→set_voltage(newval)`

Tunes the device output voltage (milliVolts).

`vsource→voltageMove(target, ms_duration)`

Performs a smooth move at constant speed toward a given value.

yFindVSource()

Retrieves a voltage source for a given identifier.

`YVSource* yFindVSource(NSString* func)`

The identifier can be specified using several formats:

- `FunctionLogicalName`
- `ModuleSerialNumber.FunctionIdentifier`
- `ModuleSerialNumber.FunctionLogicalName`
- `ModuleLogicalName.FunctionIdentifier`
- `ModuleLogicalName.FunctionLogicalName`

This function does not require that the voltage source is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YVSource.isOnline()` to test if the voltage source is indeed online at a given time. In case of ambiguity when looking for a voltage source by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

Parameters :

`func` a string that uniquely characterizes the voltage source

Returns :

a `YVSource` object allowing you to drive the voltage source.

yFirstVSource()

Starts the enumeration of voltage sources currently accessible.

`YVSource* yFirstVSource()`

Use the method `YVSource.nextVSource()` to iterate on next voltage sources.

Returns :

a pointer to a `YVSource` object, corresponding to the first voltage source currently online, or a `null` pointer if there are none.

[vsource describe]

Returns a descriptive text that identifies the function.

`-(NSString*) describe`

The text always includes the class name, and may include as well either the logical name of the function or its hardware identifier.

Returns :
a string that describes the function

[vsource advertisedValue]

Returns the current value of the voltage source (no more than 6 characters).

`-(NSString*) advertisedValue`

Returns :
a string corresponding to the current value of the voltage source (no more than 6 characters)

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

Returns the error message of the latest error with this function.

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

Returns :
a string corresponding to the latest error message that occurred while using this function object

Returns the numerical error code of the latest error with this function.

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

Returns :
a number corresponding to the code of the latest error that occurred while using this function object

[vsource extPowerFailure]

Return true if external power supply voltage is too low.

`-(Y_EXTPOWERFAILURE_enum) extPowerFailure`

Returns :
either `Y_EXTPOWERFAILURE_FALSE` or `Y_EXTPOWERFAILURE_TRUE`

On failure, throws an exception or returns `Y_EXTPOWERFAILURE_INVALID`.

[vsource failure]

Return true if the module is in failure mode.

`-(Y_FAILURE_enum) failure`

More information can be obtained by testing `get_overheat`, `get_overcurrent` etc... When a error condition is met, the output voltage is set to zéro and cannot be changed until the `reset()` function is called.

Returns :
either `Y_FAILURE_FALSE` or `Y_FAILURE_TRUE`

On failure, throws an exception or returns `Y_FAILURE_INVALID`.

[vsource vsourceDescriptor]

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

`-(YFUN_DESCR) functionDescriptor`

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

Returns :

an identifier of type `YFUN_DESCR`. If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

Returns the unique hardware identifier of the function.

The unique hardware identifier is made of the device serial number and of the hardware identifier of the function.

Returns :

a string that uniquely identifies the function On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

[vsource logicalName]

Returns the logical name of the voltage source.

`-(NSString*) logicalName`

Returns :

a string corresponding to the logical name of the voltage source

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

[vsource module]

Get the `YModule` object for the device on which the function is located.

`-(YModule*) module`

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

Returns :

an instance of `YModule`

Get the `YModule` object for the device on which the function is located (asynchronous version).

If the function cannot be located on any module, the returned `YModule` object does not show as on-line. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

Parameters :

callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the requested `YModule` object

context caller-specific object that is passed as-is to the callback function

Returns :
nothing : the result is provided to the callback.

[vsource overCurrent]

Return true if the appliance connected to the device is too greedy .

[-\(Y_OVERCURRENT_enum\) overCurrent](#)

Returns :
either Y_OVERCURRENT_FALSE or Y_OVERCURRENT_TRUE
On failure, throws an exception or returns Y_OVERCURRENT_INVALID.

[vsource overHeat]

Return TRUE if the module is overheating.

[-\(Y_OVERHEAT_enum\) overHeat](#)

Returns :
either Y_OVERHEAT_FALSE or Y_OVERHEAT_TRUE
On failure, throws an exception or returns Y_OVERHEAT_INVALID.

[vsource overLoad]

Return true if the device is not able to maintaint the requested voltage output .

[-\(Y_OVERLOAD_enum\) overLoad](#)

Returns :
either Y_OVERLOAD_FALSE or Y_OVERLOAD_TRUE
On failure, throws an exception or returns Y_OVERLOAD_INVALID.

[vsource regulationFailure]

Return true if the voltage output is too high regarding the requested voltage .

[-\(Y_REGULATIONFAILURE_enum\) regulationFailure](#)

Returns :
either Y_REGULATIONFAILURE_FALSE or Y_REGULATIONFAILURE_TRUE
On failure, throws an exception or returns Y_REGULATIONFAILURE_INVALID.

[vsource unit]

Returns the measuring unit for the voltage.

[-\(NSString*\) unit](#)

Returns :
a string corresponding to the measuring unit for the voltage
On failure, throws an exception or returns Y_UNIT_INVALID.

[vsource userData]

Returns the value of the userData attribute, as previously stored using method set_userdata.

-(void*) userData

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

Returns :
the object stored previously by the caller.

[vsource voltage]

Returns the voltage output command (mV)

-(int) voltage

Returns :
an integer corresponding to the voltage output command (mV)
On failure, throws an exception or returns `Y_VOLTAGE_INVALID`.

[vsource isOnline]

Checks if the function is currently reachable, without raising any error.

-(BOOL) isOnline

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

Returns :
`true` if the function can be reached, and `false` otherwise

Checks if the function is currently reachable, without raising any error (asynchronous version).

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox Javascript VM that does not implement context switching during blocking I/O calls.

Parameters :
callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the boolean result
context caller-specific object that is passed as-is to the callback function

Returns :
nothing : the result is provided to the callback.

[vsource load:]

Preloads the function cache with a specified validity duration.

-(YRETCODE) load : (int) msValidity

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

Parameters :

msValidity an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

Returns :

`YAPI_SUCCESS` when the call succeeds. On failure, throws an exception or returns a negative error code.

Preloads the function cache with a specified validity duration (asynchronous version).

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

Parameters :

msValidity an integer corresponding to the validity of the loaded function parameters, in milliseconds

callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the error code (or `YAPI_SUCCESS`)

context caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[vsource nextVSource]

Continues the enumeration of voltage sources started using `yFirstVSource()`.

-(YVSource*) **nextVSource**

Returns :

a pointer to a `YVSource` object, corresponding to a voltage source currently online, or a null pointer if there are no more voltage sources to enumerate.

[vsource pulse:]

Sets device output to a specific volatage, for a specified duration, then brings it automatically to 0V.

-(int) **pulse** : (int) **voltage** : (int) **ms_duration**

Parameters :

voltage pulse voltage, in millivolts

ms_duration pulse duration, in milliseconds

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[vsource registerValueCallback:]

Registers the callback function that is invoked on every change of advertised value.

-(void) **registerValueCallback** : (YFunctionUpdateCallback) **callback**

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

Parameters :

callback the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

[vsource reset]

Resets the device Output.

`-(int) reset`

This function must be called after any error condition. After an error condition, voltage output will be set to none and cannot be changed until this function is called.

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[vsource setLogicalName:]

Changes the logical name of the voltage source.

`-(int) setLogicalName : (NSString*) newval`

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

Parameters :

newval a string corresponding to the logical name of the voltage source

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[vsource setUserData:]

Stores a user context provided as argument in the `userData` attribute of the function.

`-(void) setUserData : (void*) data`

This attribute is never touched by the API, and is at disposal of the caller to store a context.

Parameters :

data any kind of object to be stored

[vsource setVoltage:]

Tunes the device output voltage (milliVolts).

`-(int) setVoltage : (int) newval`

Parameters :

newval an integer

Returns :

YAPI_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

[vsource voltageMove:]

Performs a smooth move at constant speed toward a given value.

-(int) **voltageMove** : (int) **target** : (int) **ms_duration**

Parameters :

target new output value at end of transition, in millivolts.

ms_duration transition duration, in milliseconds

Returns :

YAPI_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

3.22. Wireless function interface

In order to use the functions described here, you should include:

```
#import "yocto_wireless.h"
```

Global functions**yFindWireless(func)**

Retrieves a wireless lan interface for a given identifier.

yFirstWireless()

Starts the enumeration of wireless lan interfaces currently accessible.

YWireless methods**wireless→adhocNetwork(ssid, securityKey)**

Changes the configuration of the wireless lan interface to create an ad-hoc wireless network, without using an access point.

wireless→describe()

Returns a descriptive text that identifies the function.

wireless→get_advertisedValue()

Returns the current value of the wireless lan interface (no more than 6 characters).

wireless→get_channel()

Returns the 802.

wireless→get_errorMessage()

Returns the error message of the latest error with this function.

wireless→get_errorType()

Returns the numerical error code of the latest error with this function.

wireless→get_functionDescriptor()

Returns a unique identifier of type YFUN_DESCR corresponding to the function.

wireless→get_hardwareId()

Returns the unique hardware identifier of the function.

wireless→get_linkQuality()

Returns the link quality, expressed in per cents.

wireless→get_logicalName()

Returns the logical name of the wireless lan interface.

wireless→get_module()

Get the `YModule` object for the device on which the function is located.

wireless→get_module_async(callback, context)

Get the `YModule` object for the device on which the function is located (asynchronous version).

wireless→get_security()

Returns the security algorithm used by the selected wireless network.

wireless→get_ssid()

Returns the wireless network name (SSID).

wireless→get_userData()

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

wireless→isOnline()

Checks if the function is currently reachable, without raising any error.

wireless→isOnline_async(callback, context)

Checks if the function is currently reachable, without raising any error (asynchronous version).

wireless→joinNetwork(ssid, securityKey)

Changes the configuration of the wireless lan interface to connect to an existing access point (infrastructure mode).

wireless→load(msValidity)

Preloads the function cache with a specified validity duration.

wireless→load_async(msValidity, callback, context)

Preloads the function cache with a specified validity duration (asynchronous version).

wireless→nextWireless()

Continues the enumeration of wireless lan interfaces started using `yFirstWireless()`.

wireless→registerValueCallback(callback)

Registers the callback function that is invoked on every change of advertised value.

wireless→set_logicalName(newval)

Changes the logical name of the wireless lan interface.

wireless→set_userData(data)

Stores a user context provided as argument in the `userData` attribute of the function.

yFindWireless()

Retrieves a wireless lan interface for a given identifier.

`YWireless* yFindWireless(NSString* func)`

The identifier can be specified using several formats:

- `FunctionLogicalName`
- `ModuleSerialNumber.FunctionIdentifier`
- `ModuleSerialNumber.FunctionLogicalName`
- `ModuleLogicalName.FunctionIdentifier`
- `ModuleLogicalName.FunctionLogicalName`

This function does not require that the wireless lan interface is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YWireless.isOnline()` to test if the wireless lan interface is indeed online at a given time. In case of ambiguity when looking

for a wireless lan interface by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

Parameters :

func a string that uniquely characterizes the wireless lan interface

Returns :

a `YWireless` object allowing you to drive the wireless lan interface.

yFirstWireless()

Starts the enumeration of wireless lan interfaces currently accessible.

`YWireless* yFirstWireless()`

Use the method `YWireless.nextWireless()` to iterate on next wireless lan interfaces.

Returns :

a pointer to a `YWireless` object, corresponding to the first wireless lan interface currently online, or a `null` pointer if there are none.

[wireless adhocNetwork:]

Changes the configuration of the wireless lan interface to create an ad-hoc wireless network, without using an access point.

`-(int) adhocNetwork : (NSString*) ssid : (NSString*) securityKey`

If a security key is specified, the network will be protected by WEP128, since WPA is not standardized for ad-hoc networks. Remember to call the `saveToFlash()` method and then to reboot the module to apply this setting.

Parameters :

ssid the name of the network to connect to
securityKey the network key, as a character string

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[wireless describe]

Returns a descriptive text that identifies the function.

`-(NSString*) describe`

The text always includes the class name, and may include as well either the logical name of the function or its hardware identifier.

Returns :

a string that describes the function

[wireless advertisedValue]

Returns the current value of the wireless lan interface (no more than 6 characters).

`-(NSString*) advertisedValue`

Returns :

a string corresponding to the current value of the wireless lan interface (no more than 6 characters)

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

[wireless channel]

Returns the 802.

-(unsigned) channel

11 channel currently used, or 0 when the selected network has not been found.

Returns :

an integer corresponding to the 802

On failure, throws an exception or returns `Y_CHANNEL_INVALID`.

Returns the error message of the latest error with this function.

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

Returns :

a string corresponding to the latest error message that occurred while using this function object

Returns the numerical error code of the latest error with this function.

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

Returns :

a number corresponding to the code of the latest error that occurred while using this function object

[wireless wirelessDescriptor]

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

-(YFUN_DESCR) functionDescriptor

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

Returns :

an identifier of type `YFUN_DESCR`. If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

Returns the unique hardware identifier of the function.

The unique hardware identifier is made of the device serial number and of the hardware identifier of the function.

Returns :

a string that uniquely identifies the function On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

[wireless linkQuality]

Returns the link quality, expressed in per cents.

-(int) linkQuality

Returns :

an integer corresponding to the link quality, expressed in per cents

On failure, throws an exception or returns `Y_LINKQUALITY_INVALID`.

[wireless logicalName]

Returns the logical name of the wireless lan interface.

-(NSString*) logicalName

Returns :

a string corresponding to the logical name of the wireless lan interface

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

[wireless module]

Get the `YModule` object for the device on which the function is located.

-(YModule*) module

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

Returns :

an instance of `YModule`

Get the `YModule` object for the device on which the function is located (asynchronous version).

If the function cannot be located on any module, the returned `YModule` object does not show as on-line. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

Parameters :

callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the requested `YModule` object

context caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[wireless security]

Returns the security algorithm used by the selected wireless network.

-(Y_SECURITY_enum) security

Returns :

a value among `Y_SECURITY_UNKNOWN`, `Y_SECURITY_OPEN`, `Y_SECURITY_WEP`, `Y_SECURITY_WPA` and `Y_SECURITY_WPA2` corresponding to the security algorithm used by the selected wireless network

On failure, throws an exception or returns `Y_SECURITY_INVALID`.

[wireless ssid]

Returns the wireless network name (SSID).

-(NSString*) ssid

Returns :

a string corresponding to the wireless network name (SSID)

On failure, throws an exception or returns `Y_SSID_INVALID`.

[wireless userData]

Returns the value of the `userData` attribute, as previously stored using method `set_userdata`.

-(void*) **userData**

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

Returns :

the object stored previously by the caller.

[wireless isOnline]

Checks if the function is currently reachable, without raising any error.

-(BOOL) **isOnline**

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

Returns :

`true` if the function can be reached, and `false` otherwise

Checks if the function is currently reachable, without raising any error (asynchronous version).

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox Javascript VM that does not implement context switching during blocking I/O calls.

Parameters :

callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the boolean result

context caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[wireless joinNetwork:]

Changes the configuration of the wireless lan interface to connect to an existing access point (infrastructure mode).

-(int) **joinNetwork** : (NSString*) **ssid** : (NSString*) **securityKey**

Remember to call the `saveToFlash()` method and then to reboot the module to apply this setting.

Parameters :

ssid the name of the network to connect to
securityKey the network key, as a character string

Returns :

YAPI_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

[wireless load:]

Preloads the function cache with a specified validity duration.

-(YRETCODE) **load** : (int) **msValidity**

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

Parameters :

msValidity an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

Returns :

YAPI_SUCCESS when the call succeeds. On failure, throws an exception or returns a negative error code.

Preloads the function cache with a specified validity duration (asynchronous version).

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

Parameters :

msValidity an integer corresponding to the validity of the loaded function parameters, in milliseconds

callback callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the error code (or YAPI_SUCCESS)

context caller-specific object that is passed as-is to the callback function

Returns :

nothing : the result is provided to the callback.

[wireless nextWireless]

Continues the enumeration of wireless lan interfaces started using `yFirstWireless()`.

-(YWireless*) **nextWireless**

Returns :

a pointer to a YWireless object, corresponding to a wireless lan interface currently online, or a null pointer if there are no more wireless lan interfaces to enumerate.

[wireless registerValueCallback:]

Registers the callback function that is invoked on every change of advertised value.

`-(void) registerValueCallback : (YFunctionUpdateCallback) callback`

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

Parameters :

callback the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

[wireless setLogicalName:]

Changes the logical name of the wireless lan interface.

`-(int) setLogicalName : (NSString*) newval`

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

Parameters :

newval a string corresponding to the logical name of the wireless lan interface

Returns :

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

[wireless setUserData:]

Stores a user context provided as argument in the `userData` attribute of the function.

`-(void) setUserData : (void*) data`

This attribute is never touched by the API, and is at disposal of the caller to store a context.

Parameters :

data any kind of object to be stored

4. Index

A	
adhocNetwork	174
API	9
C	
calibrate	94
calibrateFromPoints	26
callbackLogin	113
CheckLogicalName	10
D	
describe	17
DisableExceptions	10
E	
EnableExceptions	10
EnableUSBHost	11
F	
FindAnButton	17
FindCarbonDioxide	26
FindColorLed	34
FindCurrent	42
FindDataLogger	50
FindDualPower	64
FindHubPort	71
FindHumidity	78
FindLed	85
FindLightSensor	93
FindModule	102
FindNetwork	112
FindPressure	125
FindRelay	133
FindServo	140
FindTemperature	148
FindVoltage	157
FindVSource	165
FindWireless	173
FirstAnButton	17
FirstCarbonDioxide	26
FirstColorLed	34
FirstCurrent	42
FirstDataLogger	51
FirstDualPower	64
FirstHubPort	71
FirstHumidity	78
FirstLed	86

FirstLightSensor	93
FirstModule	102
FirstNetwork	113
FirstPressure	125
FirstRelay	133
FirstServo	141
FirstTemperature	148
FirstVoltage	157
FirstVSource	165
FirstWireless	174
forgetAllDataStreams	51
FreeAPI	11
functionCount	102
functionId	103
functionName	103
functionValue	103
G	
get_adminPassword	114
get_advertisedValue	17
get_analogCalibration	18
get_autoStart	51
get_averageValue	58
get_baudRate	72
get_beacon	103
get_blinking	86
get_calibratedValue	18
get_calibrationMax	18
get_calibrationMin	18
get_callbackCredentials	114
get_callbackMaxDelay	114
get_callbackMinDelay	114
get_callbackUrl	114
get_channel	175
get_columnCount	60
get_columnNames	61
get_currentRawValue	27
get_currentRunIndex	52
get_currentValue	27
get_data	61
get_dataRows	61
get_dataRun	52
get_dataSamplesInterval	61
get_dataStreams	52
get_duration	58
get_enabled	72
get_errorMessage	18
get_errorType	19
get_extPowerFailure	166
get_extVoltage	65
get_failure	166
get_firmwareRelease	104
get_functionDescriptor	19
get_hardwareId	19
get_highestValue	28
get_hslColor	35
get_icon2d	104
get_ipAddress	115
get_isPressed	19
get_lastTimePressed	19
get_lastTimeReleased	20
get_linkQuality	175
get_logicalName	20
get_lowestValue	29
get_luminosity	88

get_macAddress	116
get_maxValue	58
get_measureNames	53
get_minValue	59
get_module	20
get_module_async	20
get_neutral	142
get_oldestRunIndex	54
get_output	135
get_overCurrent	168
get_overHeat	168
get_overLoad	168
get_persistentSettings	105
get_portState	73
get_position	143
get_power	88
get_powerControl	66
get_powerState	67
get_primaryDNS	116
get_productId	105
get_productName	105
get_productRelease	105
get_pulseTimer	135
get_range	143
get_rawValue	20
get_readiness	117
get_rebootCountdown	106
get_recording	54
get_regulationFailure	168
get_resolution	29
get_rgbColor	36
get_rgbColorAtPowerOn	37
get_router	117
get_rowCount	62
get_runIndex	62
get_secondaryDNS	117
get_security	176
get_sensitivity	21
get_sensorType	152
get_serialNumber	106
get_ssid	176
get_startTime	62
get_startTimeUTC	59
get_state	135
get_subnetMask	117
get_timeUTC	54
get_unit	29
get_upTime	106
get_usbBandwidth	106
get_usbCurrent	106
get_userData	21
get_userPassword	118
get_valueCount	59
get_valueInterval	59
get_voltage	169
GetAPIVersion	11
GetTickCount	11
H	
HandleEvents	11
hslMove	37
I	
InitAPI	12
isOnline	21
isOnline_async	21

J	
joinNetwork	177
L	
load	22
load_async	22
M	
move	144
N	
nextAnButton	22
nextCarbonDioxide	31
nextColorLed	38
nextCurrent	47
nextDataLogger	56
nextDualPower	68
nextHubPort	75
nextHumidity	83
nextLed	90
nextLightSensor	98
nextModule	108
nextNetwork	119
nextPressure	130
nextRelay	137
nextServo	145
nextTemperature	153
nextVoltage	162
nextVSource	170
nextWireless	178
P	
pulse	137
R	
reboot	108
RegisterDeviceArrivalCallback	12
RegisterDeviceRemovalCallback	12
RegisterHub	13
RegisterLogFunction	13
registerValueCallback	22
reset	171
revertFromFlash	108
rgbMove	39
S	
saveToFlash	109
set_adminPassword	120
set_analogCalibration	23
set_autoStart	56
set_beacon	109
set_blinking	90
set_calibrationMax	23
set_calibrationMin	23
set_callbackCredentials	120
set_callbackMaxDelay	120
set_callbackMinDelay	120
set_callbackUrl	121
set_enabled	75
set_highestValue	31
set_hslColor	39
set_logicalName	23
set_lowestValue	32
set_luminosity	91
set_neutral	145
set_output	138
set_position	146
set_power	91
set_powerControl	69
set_primaryDNS	121

set_range	146
set_recording	57
set_rgbColor	40
set_rgbColorAtPowerOn	40
set_secondaryDNS	122
set_sensitivity	24
set_sensorType	154
set_state	138
set_timeUTC	57
set_usbBandwidth	110
set_userData	24
set_userPassword	122
set_valueInterval	60
set_voltage	171
SetDelegate	13
SetTimeout	13
Sleep	14
T	
triggerFirmwareUpdate	110
U	
UnregisterHub	14
UpdateDeviceList	14
UpdateDeviceList_async	15
useDHCP	122
useStaticIP	123
V	
voltageMove	172
Y	
YAnButton	15
YCarbonDioxide	24
YColorLed	32
YCurrent	40
YDataLogger	48
YDataRun	58
YDataStream	60
YDualPower	63
YHubPort	69
YHumidity	76
YLed	84
YLightSensor	91
YModule	100
YNetwork	110
YPressure	123
YRelay	131
YServo	139
YTemperature	146
YVoltage	155
YVSource	163
YWireless	172