



# PYTHON API Reference

# Table of contents

<b>Introduction</b>	<b>3</b>
<b>Using the Yocto—Demo with Python</b>	<b>4</b>
Source files	4
Dynamic library	4
Control of the Led function	4
Control of the module part	6
Error handling	8
<b>Reference</b>	<b>9</b>
General functions	9
AnButton function interface	15
CarbonDioxide function interface	24
ColorLed function interface	33
Current function interface	41
DataLogger function interface	49
Formatted data sequence	58
Recorded data sequence	60
External power supply control interface	63
Yocto-hub port interface	70
Humidity function interface	77
Led function interface	85
LightSensor function interface	92
Module control interface	101
Network function interface	111
Pressure function interface	124
Relay function interface	133
Servo function interface	140
Temperature function interface	148
Voltage function interface	157
Voltage source function interface	165
Wireless function interface	173
<b>Index</b>	<b>182</b>

# 1. Introduction

This manual is intended to be used as a reference for Yoctopuce Python library, in order to interface your code with USB sensors and controllers.

The next chapter is taken from the free USB device Yocto—Demo, in order to provide a concrete examples of how the library is used within a program.

The remaining part of the manual is a function-by-function, class-by-class documentation of the API. The first section describes all general-purpose global function, while the forthcoming sections describe the various classes that you may have to use depending on the Yoctopuce device beeing used. For more informations regarding the purpose and the usage of a given device attribute, please refer to the extended discussion provided in the device-specific user manual.

## 2. Using the Yocto—Demo with Python

Python is an interpreted object oriented language developed by Guido van Rossum. Among its advantages is the fact that it is free, and the fact that it is available for most platforms, Windows as well as UNIX. It is an ideal language to write small scripts on a napkin. The Yoctopuce library is compatible with Python 2.6+ and 3+. It works under Windows, Mac OS X, and Linux, Intel as well as ARM. The library was tested with Python 2.6 and Python 3.2. Python interpreters are available on the Python web site<sup>1</sup>.

### 2.1. Source files

The Yoctopuce library classes<sup>2</sup> for Python that you will use are provided as source files. Copy all the content of the *Sources* directory in the directory of your choice and add this directory to the *PYTHONPATH* environment variable. If you use an IDE to program in Python, refer to its documentation to configure it so that it automatically finds the API source files.

### 2.2. Dynamic library

A section of the low-level library is written in C, but you should not need to interact directly with it: it is provided as a DLL under Windows, as a *.so* files under UNIX, and as a *.dylib* file under Mac OS X. Everything was done to ensure the simplest possible interaction from Python: the distinct versions of the dynamic library corresponding to the distinct operating systems and architectures are stored in the *cdll* directory. The API automatically loads the correct file during its initialization. You should not have to worry about it.

If you ever need to recompile the dynamic library, its complete source code is located in the Yoctopuce C++ library.

In order to keep them simple, all the examples provided in this documentation are console applications. Naturally, the libraries function in a strictly identical manner if you integrate them in an application with a graphical interface.

### 2.3. Control of the Led function

A few lines of code are enough to use a Yocto—Demo. Here is the skeleton of a Python code snippet to use the Led function.

```
[...]  
  
errmsg=YRefParam()  
#Get access to your device, connected locally on USB for instance  
YAPI.RegisterHub("usb",errmsg)
```

---

<sup>1</sup> <http://www.python.org/download/>

<sup>2</sup> [www.yoctopuce.com/EN/libraries.php](http://www.yoctopuce.com/EN/libraries.php)

```

led = YLed.FindLed("YCTOPOC1-123456.led")

# Hot-plug is easy: just check that the device is online
if led.isOnline():
    #Use led.set_power()
    ...

[...]
```

Let's look at these lines in more details.

## YAPI.RegisterHub

The `yAPI.RegisterHub` function initializes the Yoctopuce API and indicates where the modules should be looked for. When used with the parameter `"usb"`, it will use the modules locally connected to the computer running the library. If the initialization does not succeed, this function returns a value different from `YAPI.SUCCESS` and `errmsg` contains the error message.

## YLed.FindLed

The `YLed.FindLed` function allows you to find a led from the serial number of the module on which it resides and from its function name. You can use logical names as well, as long as you have initialized them. Let us imagine a Yocto-Demo module with serial number `YCTOPOC1-123456` which you have named `"MyModule"`, and for which you have given the `led` function the name `"MyFunction"`. The following five calls are strictly equivalent, as long as `"MyFunction"` is defined only once.

```

led = YLed.FindLed("YCTOPOC1-123456.led")
led = YLed.FindLed("YCTOPOC1-123456.MyFunction")
led = YLed.FindLed("MyModule.led")
led = YLed.FindLed("MyModule.MyFunction")
led = YLed.FindLed("MyFunction")
```

`YLed.FindLed` returns an object which you can then use at will to control the led.

## isOnline

The `isOnline()` method of the object returned by `YLed.FindLed` allows you to know if the corresponding module is present and in working order.

## set\_power

The `set_power()` function of the object returned by `YLed.FindLed` allows you to turn on and off the led. The argument is `YLed.POWER_ON` or `YLed.POWER_OFF`. In the reference on the programming interface, you will find more methods to precisely control the luminosity and make the led blink automatically.

## A real example

Launch Python and open the corresponding sample script provided in the directory **Examples/Doc-GettingStarted-Yocto-Demo** of the Yoctopuce library.

In this example, you will recognize the functions explained above, but this time used with all side materials needed to make it work nicely as a small demo.

```

import os
import sys
from yocto_api import *
from yocto_led import *

def usage():
    scriptname = os.path.basename(sys.argv[0])
    print("Usage:")
    print(scriptname+' <serial_number>')
    print(scriptname+' <logical_name>')
    print(scriptname+' any ')
    sys.exit()

def die(msg):
    sys.exit(msg+' (check USB cable)')

def setLedState(led, state):
    if led.isOnline():
```

```

        if state :
            led.set_power(YLed.POWER_ON)
        else:
            led.set_power(YLed.POWER_OFF)
    else:
        print('Module not connected (check identification and USB cable)')

errmsg=YRefParam()

if len(sys.argv)<2 :  usage()

target=sys.argv[1]

# Setup the API to use local USB devices
if YAPI.RegisterHub("usb", errmsg) != YAPI.SUCCESS:
    sys.exit("init error"+errmsg.value)

if target=='any':
    # retrieve any RGB led
    led = YLed.FirstLed()
    if led is None :
        die('No module connected')
else:
    led= YLed.FindLed(target + '.led')

if not(led.isOnline()):die('device not connected')

print('0: turn test led OFF')
print('1: turn test led ON')
print('x: exit')

try: input = raw_input  # python 2.x fix
except: pass

c= input("command:")

while c!='x':
    if c=='0' :  setLedState(led,False);
    elif c=='1' :setLedState(led,True);
    c= input("command:")

```

## 2.4. Control of the module part

Each module can be controlled in a similar manner, you can find below a simple sample program displaying the main parameters of the module and enabling you to activate the localization beacon.

```

#!/usr/bin/python
# -*- coding: utf-8 -*-
import os,sys
from yocto_api import *

def usage():
    sys.exit("usage: demo <serial or logical name> [ON/OFF]")

errmsg =YRefParam()
if YAPI.RegisterHub("usb", errmsg) != YAPI.SUCCESS:
    sys.exit("RegisterHub error: " + str(errmsg))

if len(sys.argv)<2 : usage()

m = YModule.FindModule(sys.argv[1]) ## use serial or logical name

if m.isOnline():
    if len(sys.argv) > 2:
        if sys.argv[2].upper() == "ON" : m.set_beacon(YModule.BEACON_ON)
        if sys.argv[2].upper() == "OFF" : m.set_beacon(YModule.BEACON_OFF)

    print("serial:      " + m.get_serialNumber())
    print("logical name: " + m.get_logicalName())
    print("luminosity:   " + str(m.get_luminosity()))
    if m.get_beacon() == YModule.BEACON_ON:
        print("beacon:      ON")
    else:
        print("beacon:      OFF")
else:
    print(sys.argv[1] + " not connected (check identification and USB cable)")

```

Each property `xxx` of the module can be read thanks to a method of type `YModule.get_xxxx()`, and properties which are not read-only can be modified with the help of the `YModule.set_xxx()` method. For more details regarding the used functions, refer to the [API](#) chapters.

## Changing the module settings

When you want to modify the settings of a module, you only need to call the corresponding `YModule.set_xxx()` function. However, this modification is performed only in the random access memory (RAM) of the module: if the module is restarted, the modifications are lost. To memorize them persistently, it is necessary to ask the module to save its current configuration in its permanent memory. To do so, use the `YModule.saveToFlash()` method. Inversely, it is possible to force the module to forget its current settings by using the `YModule.revertFromFlash()` method. The short example below allows you to modify the logical name of a module.

```
#!/usr/bin/python
# -*- coding: utf-8 -*-
import os,sys
from yocto_api import *

def usage():
    sys.exit("usage: demo <serial or logical name> <new logical name>")

if len(sys.argv) != 3 : usage()

errmsg=YRefParam()
if YAPI.RegisterHub("usb", errmsg) != YAPI.SUCCESS:
    sys.exit("RegisterHub error: " + str(errmsg))

m = YModule.FindModule(sys.argv[1]) # use serial or logical name

if m.isOnline():
    newname = sys.argv[2]
    if not YAPI.CheckLogicalName(newname):
        sys.exit("Invalid name (" + newname + ")")
    m.set_logicalName(newname)
    m.saveToFlash() # do not forget this
    print ("Module: serial= " + m.get_serialNumber()+" / name= " + m.get_logicalName()
    )
else:
    sys.exit("not connected (check identification and USB cable)")
```

Warning: the number of write cycles of the nonvolatile memory of the module is limited. When this limit is reached, nothing guaranties that the saving process is performed correctly. This limit, linked to the technology employed by the module micro-processor, is located at about 100000 cycles. In short, you can use the `YModule.saveToFlash()` function only 100000 times in the life of the module. Make sure you do not call this function within a loop.

## Listing the modules

Obtaining the list of the connected modules is performed with the `YModule.yFirstModule()` function which returns the first module found. Then, you only need to call the `nextModule()` function of this object to find the following modules, and this as long as the returned value is not null. Below a short example listing the connected modules.

```
#!/usr/bin/python
# -*- coding: utf-8 -*-
import os,sys

from yocto_api import *

errmsg=YRefParam()

# Setup the API to use local USB devices
if YAPI.RegisterHub("usb", errmsg) != YAPI.SUCCESS:
    sys.exit("init error"+str(errmsg))

print('Device list')
```

```
module = YModule.FirstModule()
while module is not None:
    print(module.get_serialNumber()+' ('+module.get_productName()+')')
    module = module.nextModule()
```

## 2.5. Error handling

When you implement a program which must interact with USB modules, you cannot disregard error handling. Inevitably, there will be a time when a user will have unplugged the device, either before running the software, or even while the software is running. The Yoctopuce library is designed to help you support this kind of behavior, but your code must nevertheless be conceived to interpret in the best possible way the errors indicated by the library.

The simplest way to work around the problem is the one used in the short examples provided in this chapter: before accessing a module, check that it is online with the `isOnline` function, and then hope that it will stay so during the fraction of a second necessary for the following code lines to run. This method is not perfect, but it can be sufficient in some cases. You must however be aware that you cannot completely exclude an error which would occur after the call to `isOnline` and which could crash the software. The only way to prevent this is to implement one of the two error handling techniques described below.

The method recommended by most programming languages for unpredictable error handling is the use of exceptions. By default, it is the behavior of the Yoctopuce library. If an error happens while you try to access a module, the library throws an exception. In this case, there are three possibilities:

- If your code catches the exception and handles it, everything goes well.
- If your program is running in debug mode, you can relatively easily determine where the problem happened and view the explanatory message linked to the exception.
- Otherwise... the exception makes your program crash, bang!

As this latest situation is not the most desirable, the Yoctopuce library offers another possibility for error handling, allowing you to create a robust program without needing to catch exceptions at every line of code. You simply need to call the `yDisableExceptions()` function to commute the library to a mode where exceptions for all the functions are systematically replaced by specific return values, which can be tested by the caller when necessary. For each function, the name of each return value in case of error is systematically documented in the [library reference](#). The name always follows the same logic: a `get_state()` method returns a `Y_STATE_INVALID` value, a `get_currentValue` method returns a `Y_CURRENTVALUE_INVALID` value, and so on. In any case, the returned value is of the expected type and is not a null pointer which would risk crashing your program. At worst, if you display the value without testing it, it will be outside the expected bounds for the returned value. In the case of functions which do not normally return information, the return value is `YAPI_SUCCESS` if everything went well, and a different error code in case of failure.

When you work without exceptions, you can obtain an error code and an error message explaining the source of the error. You can request them from the object which returned the error, calling the `errType()` and `errMessage()` methods. Their returned values contain the same information as in the exceptions when they are active.



## 3. Reference

### 3.1. General functions

These general functions should be used to initialize and configure the Yoctopuce library. In most cases, a simple call to function `yRegisterHub()` should be enough. The module-specific functions `yFind...()` or `yFirst...()` should then be used to retrieve an object that provides interaction with the module.

In order to use the functions described here, you should include:

```
from yocto_api import *
```

#### Global functions

##### `yCheckLogicalName(name)`

Checks if a given string is valid as logical name for a module or a function.

##### `yDisableExceptions()`

Disables the use of exceptions to report runtime errors.

##### `yEnableExceptions()`

Re-enables the use of exceptions for runtime error handling.

##### `yEnableUSBHost(osContext)`

This function is used only on Android.

##### `yFreeAPI()`

Frees dynamically allocated memory blocks used by the Yoctopuce library.

##### `yGetAPIVersion()`

Returns the version identifier for the Yoctopuce library in use.

##### `yGetTickCount()`

Returns the current value of a monotone millisecond-based time counter.

##### `yHandleEvents(errmsg)`

Maintains the device-to-library communication channel.

##### `yInitAPI(mode, errmsg)`

Initializes the Yoctopuce programming library explicitly.

##### `yRegisterDeviceArrivalCallback(arrivalCallback)`

Register a callback function, to be called each time a device is plugged.

##### `yRegisterDeviceRemovalCallback(removalCallback)`

Register a callback function, to be called each time a device is unplugged.

**yRegisterHub(url, errmsg)**

Setup the Yoctopuce library to use modules connected on a given machine.

**yRegisterLogFunction(logfun)**

Register a log callback function.

**ySetDelegate(object)**

(Objective-C only) Register an object that must follow the protocol YDeviceHotPlug.

**ySetTimeout(callback, ms\_timeout, optional\_arguments)**

Invoke the specified callback function after a given timeout.

**ySleep(ms\_duration, errmsg)**

Pauses the execution flow for a specified duration.

**yUnregisterHub(url)**

Setup the Yoctopuce library to no more use modules connected on a previously registered machine with RegisterHub.

**yUpdateDeviceList(errmsg)**

Triggers a (re)detection of connected Yoctopuce modules.

**yUpdateDeviceList\_async(callback, context)**

Triggers a (re)detection of connected Yoctopuce modules.

## YAPI.CheckLogicalName()

Checks if a given string is valid as logical name for a module or a function.

**def CheckLogicalName( name)**

A valid logical name has a maximum of 19 characters, all among A..Z, a..z, 0..9, \_, and -. If you try to configure a logical name with an incorrect string, the invalid characters are ignored.

**Parameters :**

**name** a string containing the name to check.

**Returns :**

`true` if the name is valid, `false` otherwise.

## YAPI.DisableExceptions()

Disables the use of exceptions to report runtime errors.

**def DisableExceptions( )**

When exceptions are disabled, every function returns a specific error value which depends on its type and which is documented in this reference manual.

## YAPI.EnableExceptions()

Re-enables the use of exceptions for runtime error handling.

**def EnableExceptions( )**

Be aware than when exceptions are enabled, every function that fails triggers an exception. If the exception is not caught by the user code, it either fires the debugger or aborts (i.e. crash) the program. On failure, throws an exception or returns a negative error code.

---

This function is used only on Android.

Before calling `yRegisterHub("usb")` you need to activate the USB host port of the system. This function takes as argument, an object of class `android.content.Context` (or any subclass). It is not necessary to call this function to reach modules through the network.

**Parameters :**

**osContext** an object of class `android.content.Context` (or any subclass).  
On failure, throws an exception.

---

## YAPI.FreeAPI()

Frees dynamically allocated memory blocks used by the Yoctopuce library.

def **FreeAPI**( )

It is generally not required to call this function, unless you want to free all dynamically allocated memory blocks in order to track a memory leak for instance. You should not call any other library function after calling `yFreeAPI()`, or your program will crash.

---

## YAPI.GetAPIVersion()

Returns the version identifier for the Yoctopuce library in use.

def **GetAPIVersion**( )

The version is a string in the form "Major.Minor.Build", for instance "1.01.5535". For languages using an external DLL (for instance C#, VisualBasic or Delphi), the character string includes as well the DLL version, for instance "1.01.5535 (1.01.5439)".

If you want to verify in your code that the library version is compatible with the version that you have used during development, verify that the major number is strictly equal and that the minor number is greater or equal. The build number is not relevant with respect to the library compatibility.

**Returns :**

a character string describing the library version.

---

## YAPI.GetTickCount()

Returns the current value of a monotone millisecond-based time counter.

def **GetTickCount**( )

This counter can be used to compute delays in relation with Yoctopuce devices, which also uses the millisecond as timebase.

**Returns :**

a long integer corresponding to the millisecond counter.

---

## YAPI.HandleEvents()

Maintains the device-to-library communication channel.

def **HandleEvents**( **errmsg**=None)

If your program includes significant loops, you may want to include a call to this function to make sure that the library takes care of the information pushed by the modules on the

---

communication channels. This is not strictly necessary, but it may improve the reactivity of the library for the following commands.

This function may signal an error in case there is a communication problem while contacting a module.

**Parameters :**

**errmsg** a string passed by reference to receive any error message.

**Returns :**

`YAPI_SUCCESS` when the call succeeds. On failure, throws an exception or returns a negative error code.

---

## YAPI.InitAPI()

Initializes the Yoctopuce programming library explicitly.

```
def InitAPI( mode, errmsg=None)
```

It is not strictly needed to call `yInitAPI()`, as the library is automatically initialized when calling `yRegisterHub()` for the first time.

When `Y_DETECT_NONE` is used as detection mode, you must explicitly use `yRegisterHub()` to point the API to the VirtualHub on which your devices are connected before trying to access them.

**Parameters :**

**mode** an integer corresponding to the type of automatic device detection to use. Possible values are `Y_DETECT_NONE`, `Y_DETECT_USB`, `Y_DETECT_NET`, and `Y_DETECT_ALL`.

**errmsg** a string passed by reference to receive any error message.

**Returns :**

`YAPI_SUCCESS` when the call succeeds. On failure, throws an exception or returns a negative error code.

---

## YAPI.RegisterDeviceArrivalCallback()

Register a callback function, to be called each time a device is plugged.

```
def RegisterDeviceArrivalCallback( arrivalCallback)
```

This callback will be invoked while `yUpdateDeviceList` is running. You will have to call this function on a regular basis.

**Parameters :**

**arrivalCallback** a procedure taking a `YModule` parameter, or `null` to unregister a previously registered callback.

---

## YAPI.RegisterDeviceRemovalCallback()

Register a callback function, to be called each time a device is unplugged.

```
def RegisterDeviceRemovalCallback( removalCallback)
```

This callback will be invoked while `yUpdateDeviceList` is running. You will have to call this function on a regular basis.

**Parameters :**

**removalCallback** a procedure taking a `YModule` parameter, or `null` to unregister a previously registered callback.

---

## YAPI.RegisterHub()

Setup the Yoctopuce library to use modules connected on a given machine.

```
def RegisterHub( url, errmsg=None)
```

When using Yoctopuce modules through the VirtualHub gateway, you should provide as parameter the address of the machine on which the VirtualHub software is running (typically "http://127.0.0.1:4444", which represents the local machine). When you use a language which has direct access to the USB hardware, you can use the pseudo-URL "usb" instead.

Be aware that only one application can use direct USB access at a given time on a machine. Multiple access would cause conflicts while trying to access the USB modules. In particular, this means that you must stop the VirtualHub software before starting an application that uses direct USB access. The workaround for this limitation is to setup the library to use the VirtualHub rather than direct USB access. If access control has been activated on the VirtualHub you want to reach, the URL parameter should look like: `http://username:password@adresse:port`

### Parameters :

- url** a string containing either "usb" or the root URL of the hub to monitor
- errmsg** a string passed by reference to receive any error message.

### Returns :

YAPI\_SUCCESS when the call succeeds. On failure, throws an exception or returns a negative error code.

---

## YAPI.RegisterLogFunction()

Register a log callback function.

```
def RegisterLogFunction( logfun)
```

This callback will be called each time the API have something to say. Quite usefull to debug the API.

### Parameters :

- logfun** a procedure taking a string parameter, or null to unregister a previously registered callback.

---

(Objective-C only) Register an object that must follow the protocol YDeviceHotPlug.

The methodes `yDeviceArrival` and `yDeviceRemoval` will be invoked while `yUpdateDeviceList` is running. You will have to call this function on a regular basis.

### Parameters :

- object** an object that must follow the protocol YAPIDelegate, or nil to unregister a previously registered object.

---

Invoke the specified callback function after a given timeout.

This function behaves more or less like Javascript `setTimeout`, but during the waiting time, it will call `yHandleEvents` and `yUpdateDeviceList` periodically, in order to keep the API up-to-date with current devices.

### Parameters :

- callback** the function to call after the timeout occurs. On Microsoft Internet Explorer, the callback must be provided as a string to be evaluated.

**ms\_timeout** an integer corresponding to the duration of the timeout, in milliseconds.  
**optional\_arguments** additional arguments to be passed to the callback function can be provided, if needed (not supported on Microsoft Internet Explorer).

**Returns :**

YAPI\_SUCCESS when the call succeeds. On failure, throws an exception or returns a negative error code.

---

## YAPI.Sleep()

Pauses the execution flow for a specified duration.

```
def Sleep( ms_duration, errmsg=None)
```

This function implements a passive waiting loop, meaning that it does not consume CPU cycles significantly. The processor is left available for other threads and processes. During the pause, the library nevertheless reads from time to time information from the Yoctopuce modules by calling `yHandleEvents()`, in order to stay up-to-date.

This function may signal an error in case there is a communication problem while contacting a module.

**Parameters :**

**ms\_duration** an integer corresponding to the duration of the pause, in milliseconds.  
**errmsg** a string passed by reference to receive any error message.

**Returns :**

YAPI\_SUCCESS when the call succeeds. On failure, throws an exception or returns a negative error code.

---

## YAPI.UnregisterHub()

Setup the Yoctopuce library to no more use modules connected on a previously registered machine with RegisterHub.

```
def UnregisterHub( url)
```

**Parameters :**

**url** a string containing either "usb" or the root URL of the hub to monitor

---

## YAPI.UpdateDeviceList()

Triggers a (re)detection of connected Yoctopuce modules.

```
def UpdateDeviceList( errmsg=None)
```

The library searches the machines or USB ports previously registered using `yRegisterHub()`, and invokes any user-defined callback function in case a change in the list of connected devices is detected.

This function can be called as frequently as desired to refresh the device list and to make the application aware of hot-plug events.

**Parameters :**

**errmsg** a string passed by reference to receive any error message.

**Returns :**

YAPI\_SUCCESS when the call succeeds. On failure, throws an exception or returns a negative error code.

---

Triggers a (re)detection of connected Yoctopuce modules.

The library searches the machines or USB ports previously registered using `yRegisterHub()`, and invokes any user-defined callback function in case a change in the list of connected devices is detected.

This function can be called as frequently as desired to refresh the device list and to make the application aware of hot-plug events.

This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox Javascript VM that does not implement context switching during blocking I/O calls.

**Parameters :**

**callback** callback function that is invoked when the result is known. The callback function receives two arguments: the caller-specific context object and the result code (`YAPI_SUCCESS` if the operation completes successfully).

**context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

## 3.2. AnButton function interface

Yoctopuce application programming interface allows you to measure the state of a simple button as well as to read an analog potentiometer (variable resistance). This can be use for instance with a continuous rotating knob, a throttle grip or a joystick. The module is capable to calibrate itself on min and max values, in order to compute a calibrated value that varies proportionally with the potentiometer position, regardless of its total resistance.

In order to use the functions described here, you should include:

```
from yocto_anbutton import *
```

Global functions	
<b>yFindAnButton(func)</b>	Retrieves an analog input for a given identifier.
<b>yFirstAnButton()</b>	Starts the enumeration of analog inputs currently accessible.
YAnButton methods	
<b>anbutton→describe()</b>	Returns a descriptive text that identifies the function.
<b>anbutton→get_advertisedValue()</b>	Returns the current value of the analog input (no more than 6 characters).
<b>anbutton→get_analogCalibration()</b>	Tells if a calibration process is currently ongoing.
<b>anbutton→get_calibratedValue()</b>	Returns the current calibrated input value (between 0 and 1000, included).
<b>anbutton→get_calibrationMax()</b>	Returns the maximal value measured during the calibration (between 0 and 4095, included).
<b>anbutton→get_calibrationMin()</b>	Returns the minimal value measured during the calibration (between 0 and 4095, included).
<b>anbutton→get_errorMessage()</b>	Returns the error message of the latest error with this function.
<b>anbutton→get_errorType()</b>	Returns the numerical error code of the latest error with this function.

<b>anbutton→get_functionDescriptor()</b>	Returns a unique identifier of type <code>YFUN_DESCR</code> corresponding to the function.
<b>anbutton→get_hardwareId()</b>	Returns the unique hardware identifier of the function.
<b>anbutton→get_isPressed()</b>	Returns true if the input (considered as binary) is active (closed contact), and false otherwise.
<b>anbutton→get_lastTimePressed()</b>	Returns the number of elapsed milliseconds between the module power on and the last time the input button was pressed (the input contact transitionned from open to closed).
<b>anbutton→get_lastTimeReleased()</b>	Returns the number of elapsed milliseconds between the module power on and the last time the input button was released (the input contact transitionned from closed to open).
<b>anbutton→get_logicalName()</b>	Returns the logical name of the analog input.
<b>anbutton→get_module()</b>	Get the <code>YModule</code> object for the device on which the function is located.
<b>anbutton→get_module_async(callback, context)</b>	Get the <code>YModule</code> object for the device on which the function is located (asynchronous version).
<b>anbutton→get_rawValue()</b>	Returns the current measured input value as-is (between 0 and 4095, included).
<b>anbutton→get_sensitivity()</b>	Returns the sensibility for the input (between 1 and 255, included) for triggering user callbacks.
<b>anbutton→get_userData()</b>	Returns the value of the <code>userData</code> attribute, as previously stored using method <code>set_userData</code> .
<b>anbutton→isOnline()</b>	Checks if the function is currently reachable, without raising any error.
<b>anbutton→isOnline_async(callback, context)</b>	Checks if the function is currently reachable, without raising any error (asynchronous version).
<b>anbutton→load(msValidity)</b>	Preloads the function cache with a specified validity duration.
<b>anbutton→load_async(msValidity, callback, context)</b>	Preloads the function cache with a specified validity duration (asynchronous version).
<b>anbutton→nextAnButton()</b>	Continues the enumeration of analog inputs started using <code>yFirstAnButton()</code> .
<b>anbutton→registerValueCallback(callback)</b>	Registers the callback function that is invoked on every change of advertised value.
<b>anbutton→set_analogCalibration(newval)</b>	Starts or stops the calibration process.
<b>anbutton→set_calibrationMax(newval)</b>	Changes the maximal calibration value for the input (between 0 and 4095, included), without actually starting the automated calibration.
<b>anbutton→set_calibrationMin(newval)</b>	Changes the minimal calibration value for the input (between 0 and 4095, included), without actually starting the automated calibration.
<b>anbutton→set_logicalName(newval)</b>	



Changes the logical name of the analog input.

**anbutton**→**set\_sensitivity**(newval)

Changes the sensibility for the input (between 1 and 255, included) for triggering user callbacks.

**anbutton**→**set\_userData**(data)

Stores a user context provided as argument in the userData attribute of the function.

---

## **YAnButton.FindAnButton()**

Retrieves an analog input for a given identifier.

def **FindAnButton**( func)

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the analog input is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YAnButton.isOnline()` to test if the analog input is indeed online at a given time. In case of ambiguity when looking for an analog input by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

### **Parameters :**

**func** a string that uniquely characterizes the analog input

### **Returns :**

a `YAnButton` object allowing you to drive the analog input.

---

## **YAnButton.FirstAnButton()**

Starts the enumeration of analog inputs currently accessible.

def **FirstAnButton**( )

Use the method `YAnButton.nextAnButton()` to iterate on next analog inputs.

### **Returns :**

a pointer to a `YAnButton` object, corresponding to the first analog input currently online, or a `null` pointer if there are none.

---

## **anbutton.describe()**

Returns a descriptive text that identifies the function.

def **describe**( )

The text always includes the class name, and may include as well either the logical name of the function or its hardware identifier.

### **Returns :**

a string that describes the function

---

## **anbutton.get\_advertisedValue()**

Returns the current value of the analog input (no more than 6 characters).

**def get\_advertisedValue( )**

**Returns :**

a string corresponding to the current value of the analog input (no more than 6 characters)

On failure, throws an exception or returns Y\_ADVERTISEDVALUE\_INVALID.

---

**anbutton.get\_analogCalibration()**

Tells if a calibration process is currently ongoing.

**def get\_analogCalibration( )**

**Returns :**

either Y\_ANALOGCALIBRATION\_OFF or Y\_ANALOGCALIBRATION\_ON

On failure, throws an exception or returns Y\_ANALOGCALIBRATION\_INVALID.

---

**anbutton.get\_calibratedValue()**

Returns the current calibrated input value (between 0 and 1000, included).

**def get\_calibratedValue( )**

**Returns :**

an integer corresponding to the current calibrated input value (between 0 and 1000, included)

On failure, throws an exception or returns Y\_CALIBRATEDVALUE\_INVALID.

---

**anbutton.get\_calibrationMax()**

Returns the maximal value measured during the calibration (between 0 and 4095, included).

**def get\_calibrationMax( )**

**Returns :**

an integer corresponding to the maximal value measured during the calibration (between 0 and 4095, included)

On failure, throws an exception or returns Y\_CALIBRATIONMAX\_INVALID.

---

**anbutton.get\_calibrationMin()**

Returns the minimal value measured during the calibration (between 0 and 4095, included).

**def get\_calibrationMin( )**

**Returns :**

an integer corresponding to the minimal value measured during the calibration (between 0 and 4095, included)

On failure, throws an exception or returns Y\_CALIBRATIONMIN\_INVALID.

---

**anbutton.get\_errorMessage()**

Returns the error message of the latest error with this function.

**def get\_errorMessage( )**

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using this function object

---

### **anbutton.get\_errorType()**

Returns the numerical error code of the latest error with this function.

**def get\_errorType( )**

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using this function object

---

### **anbutton.get\_anbuttonDescriptor()**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

**def get\_functionDescriptor( )**

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`. If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

---

Returns the unique hardware identifier of the function.

The unique hardware identifier is made of the device serial number and of the hardware identifier of the function.

**Returns :**

a string that uniquely identifies the function. On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

---

### **anbutton.get\_isPressed()**

Returns true if the input (considered as binary) is active (closed contact), and false otherwise.

**def get\_isPressed( )**

**Returns :**

either `Y_ISPRESSED_FALSE` or `Y_ISPRESSED_TRUE`, according to true if the input (considered as binary) is active (closed contact), and false otherwise

On failure, throws an exception or returns `Y_ISPRESSED_INVALID`.

---

### **anbutton.get\_lastTimePressed()**

Returns the number of elapsed milliseconds between the module power on and the last time the input button was pressed (the input contact transitioned from open to closed).

**def get\_lastTimePressed( )**

**Returns :**

an integer corresponding to the number of elapsed milliseconds between the module power on and the last time the input button was pressed (the input contact transitioned from open to closed)

---

On failure, throws an exception or returns `Y_LASTTIMEPRESSED_INVALID`.

---

### **anbutton.get\_lastTimeReleased()**

Returns the number of elapsed milliseconds between the module power on and the last time the input button was released (the input contact transitionned from closed to open).

**def get\_lastTimeReleased( )**

**Returns :**

an integer corresponding to the number of elapsed milliseconds between the module power on and the last time the input button was released (the input contact transitionned from closed to open)

On failure, throws an exception or returns `Y_LASTTIMERELEASED_INVALID`.

---

### **anbutton.get\_logicalName()**

Returns the logical name of the analog input.

**def get\_logicalName( )**

**Returns :**

a string corresponding to the logical name of the analog input

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

---

### **anbutton.get\_module()**

Get the `YModule` object for the device on which the function is located.

**def get\_module( )**

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

**Returns :**

an instance of `YModule`

---

Get the `YModule` object for the device on which the function is located (asynchronous version).

If the function cannot be located on any module, the returned `YModule` object does not show as on-line. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

**Parameters :**

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the requested `YModule` object

**context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

---

### **anbutton.get\_rawValue()**

Returns the current measured input value as-is (between 0 and 4095, included).

---

**def `get_rawValue()`**

**Returns :**

an integer corresponding to the current measured input value as-is (between 0 and 4095, included)

On failure, throws an exception or returns `Y_RAWVALUE_INVALID`.

---

**`anbutton.get_sensitivity()`**

Returns the sensibility for the input (between 1 and 255, included) for triggering user callbacks.

**def `get_sensitivity()`**

**Returns :**

an integer corresponding to the sensibility for the input (between 1 and 255, included) for triggering user callbacks

On failure, throws an exception or returns `Y_SENSITIVITY_INVALID`.

---

**`anbutton.get_userData()`**

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

**def `get_userData()`**

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

---

**`anbutton.isOnline()`**

Checks if the function is currently reachable, without raising any error.

**def `isOnline()`**

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

**Returns :**

`true` if the function can be reached, and `false` otherwise

---

Checks if the function is currently reachable, without raising any error (asynchronous version).

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox Javascript VM that does not implement context switching during blocking I/O calls.

**Parameters :**

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the boolean result

---

**context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

---

## **anbutton.load()**

Preloads the function cache with a specified validity duration.

def **load**( **msValidity** )

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds. On failure, throws an exception or returns a negative error code.

---

Preloads the function cache with a specified validity duration (asynchronous version).

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

**Parameters :**

**msValidity** an integer corresponding to the validity of the loaded function parameters, in milliseconds

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the error code (or YAPI\_SUCCESS)

**context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

---

## **anbutton.nextAnButton()**

Continues the enumeration of analog inputs started using `yFirstAnButton()`.

def **nextAnButton**( )

**Returns :**

a pointer to a `YAnButton` object, corresponding to an analog input currently online, or a null pointer if there are no more analog inputs to enumerate.

---

## **anbutton.registerValueCallback()**

Registers the callback function that is invoked on every change of advertised value.

def **registerValueCallback**( **callback** )

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness,

---

remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

---

## **anbutton.set\_analogCalibration()**

Starts or stops the calibration process.

**def set\_analogCalibration( newval)**

Remember to call the `saveToFlash()` method of the module at the end of the calibration if the modification must be kept.

**Parameters :**

**newval** either `Y_ANALOGCALIBRATION_OFF` or `Y_ANALOGCALIBRATION_ON`

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **anbutton.set\_calibrationMax()**

Changes the maximal calibration value for the input (between 0 and 4095, included), without actually starting the automated calibration.

**def set\_calibrationMax( newval)**

Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** an integer corresponding to the maximal calibration value for the input (between 0 and 4095, included), without actually starting the automated calibration

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **anbutton.set\_calibrationMin()**

Changes the minimal calibration value for the input (between 0 and 4095, included), without actually starting the automated calibration.

**def set\_calibrationMin( newval)**

Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** an integer corresponding to the minimal calibration value for the input (between 0 and 4095, included), without actually starting the automated calibration

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **anbutton.set\_logicalName()**

Changes the logical name of the analog input.

```
def set_logicalName( newval)
```

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

### **Parameters :**

**newval** a string corresponding to the logical name of the analog input

### **Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **anbutton.set\_sensitivity()**

Changes the sensibility for the input (between 1 and 255, included) for triggering user callbacks.

```
def set_sensitivity( newval)
```

Remember to call the `saveToFlash()` method of the module if the modification must be kept.

### **Parameters :**

**newval** an integer corresponding to the sensibility for the input (between 1 and 255, included) for triggering user callbacks

### **Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **anbutton.set\_userData()**

Stores a user context provided as argument in the `userData` attribute of the function.

```
def set_userData( data)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

### **Parameters :**

**data** any kind of object to be stored

## **3.3. CarbonDioxide function interface**

The Yoctopuce application programming interface allows you to read an instant measure of the sensor, as well as the minimal and maximal values observed.

In order to use the functions described here, you should include:

```
from yocto_carbondioxide import *
```

### **Global functions**

```
yFindCarbonDioxide(func)
```

Retrieves a CO2 sensor for a given identifier.

```
yFirstCarbonDioxide()
```



Starts the enumeration of CO2 sensors currently accessible.

#### **YCarbonDioxide methods**

##### **carbondioxide→calibrateFromPoints(rawValues, refValues)**

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

##### **carbondioxide→describe()**

Returns a descriptive text that identifies the function.

##### **carbondioxide→get\_advertisedValue()**

Returns the current value of the CO2 sensor (no more than 6 characters).

##### **carbondioxide→get\_currentRawValue()**

Returns the uncalibrated, unrounded raw value returned by the sensor.

##### **carbondioxide→get\_currentValue()**

Returns the current measured value.

##### **carbondioxide→get\_errorMessage()**

Returns the error message of the latest error with this function.

##### **carbondioxide→get\_errorType()**

Returns the numerical error code of the latest error with this function.

##### **carbondioxide→get\_functionDescriptor()**

Returns a unique identifier of type YFUN\_DESCR corresponding to the function.

##### **carbondioxide→get\_hardwareId()**

Returns the unique hardware identifier of the function.

##### **carbondioxide→get\_highestValue()**

Returns the maximal value observed.

##### **carbondioxide→get\_logicalName()**

Returns the logical name of the CO2 sensor.

##### **carbondioxide→get\_lowestValue()**

Returns the minimal value observed.

##### **carbondioxide→get\_module()**

Get the YModule object for the device on which the function is located.

##### **carbondioxide→get\_module\_async(callback, context)**

Get the YModule object for the device on which the function is located (asynchronous version).

##### **carbondioxide→get\_resolution()**

Returns the resolution of the measured values.

##### **carbondioxide→get\_unit()**

Returns the measuring unit for the measured value.

##### **carbondioxide→get\_userData()**

Returns the value of the userData attribute, as previously stored using method set\_userData.

##### **carbondioxide→isOnline()**

Checks if the function is currently reachable, without raising any error.

##### **carbondioxide→isOnline\_async(callback, context)**

Checks if the function is currently reachable, without raising any error (asynchronous version).

##### **carbondioxide→load(msValidity)**

Preloads the function cache with a specified validity duration.

**carbondioxide→load\_async(msValidity, callback, context)**

Preloads the function cache with a specified validity duration (asynchronous version).

**carbondioxide→nextCarbonDioxide()**

Continues the enumeration of CO2 sensors started using `yFirstCarbonDioxide()`.

**carbondioxide→registerValueCallback(callback)**

Registers the callback function that is invoked on every change of advertised value.

**carbondioxide→set\_highestValue(newval)**

Changes the recorded maximal value observed.

**carbondioxide→set\_logicalName(newval)**

Changes the logical name of the CO2 sensor.

**carbondioxide→set\_lowestValue(newval)**

Changes the recorded minimal value observed.

**carbondioxide→set\_userData(data)**

Stores a user context provided as argument in the `userData` attribute of the function.

## **YCarbonDioxide.FindCarbonDioxide()**

Retrieves a CO2 sensor for a given identifier.

**def FindCarbonDioxide( func)**

The identifier can be specified using several formats:

- `FunctionLogicalName`
- `ModuleSerialNumber.FunctionIdentifier`
- `ModuleSerialNumber.FunctionLogicalName`
- `ModuleLogicalName.FunctionIdentifier`
- `ModuleLogicalName.FunctionLogicalName`

This function does not require that the CO2 sensor is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YCarbonDioxide.isOnline()` to test if the CO2 sensor is indeed online at a given time. In case of ambiguity when looking for a CO2 sensor by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

### **Parameters :**

**func** a string that uniquely characterizes the CO2 sensor

### **Returns :**

a `YCarbonDioxide` object allowing you to drive the CO2 sensor.

## **YCarbonDioxide.FirstCarbonDioxide()**

Starts the enumeration of CO2 sensors currently accessible.

**def FirstCarbonDioxide( )**

Use the method `YCarbonDioxide.nextCarbonDioxide()` to iterate on next CO2 sensors.

### **Returns :**

a pointer to a `YCarbonDioxide` object, corresponding to the first CO2 sensor currently online, or a `null` pointer if there are none.

---

## carbondioxide.calibrateFromPoints()

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

```
def calibrateFromPoints( rawValues, refValues)
```

It is possible to configure up to five correction points. Correction points must be provided in ascending order, and be in the range of the sensor. The device will automatically perform a lineat interpolation of the error correction between specified points. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

For more information on advanced capabilities to refine the calibration of sensors, please contact [support@yoctopuce.com](mailto:support@yoctopuce.com).

### Parameters :

**rawValues** array of floating point numbers, corresponding to the raw values returned by the sensor for the correction points.

**refValues** array of floating point numbers, corresponding to the corrected values for the correction points.

### Returns :

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## carbondioxide.describe()

Returns a descriptive text that identifies the function.

```
def describe( )
```

The text always includes the class name, and may include as well either the logical name of the function or its hardware identifier.

### Returns :

a string that describes the function

---

## carbondioxide.get\_advertisedValue()

Returns the current value of the CO2 sensor (no more than 6 characters).

```
def get_advertisedValue( )
```

### Returns :

a string corresponding to the current value of the CO2 sensor (no more than 6 characters)

On failure, throws an exception or returns Y\_ADVERTISEDVALUE\_INVALID.

---

## carbondioxide.get\_currentRawValue()

Returns the uncalibrated, unrounded raw value returned by the sensor.

```
def get_currentRawValue( )
```

### Returns :

a floating point number corresponding to the uncalibrated, unrounded raw value returned by the sensor

On failure, throws an exception or returns Y\_CURRENTRAWVALUE\_INVALID.

---

### **carbondioxide.get\_currentValue()**

Returns the current measured value.

**def get\_currentValue( )**

**Returns :**

a floating point number corresponding to the current measured value

On failure, throws an exception or returns `Y_CURRENTVALUE_INVALID`.

---

### **carbondioxide.get\_errorMessage()**

Returns the error message of the latest error with this function.

**def get\_errorMessage( )**

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using this function object

---

### **carbondioxide.get\_errorType()**

Returns the numerical error code of the latest error with this function.

**def get\_errorType( )**

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using this function object

---

### **carbondioxide.get\_carbondioxideDescriptor()**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

**def get\_functionDescriptor( )**

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`. If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

---

Returns the unique hardware identifier of the function.

The unique hardware identifier is made of the device serial number and of the hardware identifier of the function.

**Returns :**

a string that uniquely identifies the function On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

---

### **carbondioxide.get\_highestValue()**

Returns the maximal value observed.

**def `get_highestValue()`**

**Returns :**

a floating point number corresponding to the maximal value observed

On failure, throws an exception or returns `Y_HIGHESTVALUE_INVALID`.

---

**`carbondioxide.get_logicalName()`**

Returns the logical name of the CO2 sensor.

**def `get_logicalName()`**

**Returns :**

a string corresponding to the logical name of the CO2 sensor

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

---

**`carbondioxide.get_lowestValue()`**

Returns the minimal value observed.

**def `get_lowestValue()`**

**Returns :**

a floating point number corresponding to the minimal value observed

On failure, throws an exception or returns `Y_LOWESTVALUE_INVALID`.

---

**`carbondioxide.get_module()`**

Get the `YModule` object for the device on which the function is located.

**def `get_module()`**

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

**Returns :**

an instance of `YModule`

---

Get the `YModule` object for the device on which the function is located (asynchronous version).

If the function cannot be located on any module, the returned `YModule` object does not show as on-line. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

**Parameters :**

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the requested `YModule` object

**context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

---

**`carbondioxide.get_resolution()`**

Returns the resolution of the measured values.

---

```
def get_resolution( )
```

The resolution corresponds to the numerical precision of the values, which is not always the same as the actual precision of the sensor.

**Returns :**

a floating point number corresponding to the resolution of the measured values

On failure, throws an exception or returns `Y_RESOLUTION_INVALID`.

---

### **carbondioxide.get\_unit()**

Returns the measuring unit for the measured value.

```
def get_unit( )
```

**Returns :**

a string corresponding to the measuring unit for the measured value

On failure, throws an exception or returns `Y_UNIT_INVALID`.

---

### **carbondioxide.get\_userData()**

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

```
def get_userData( )
```

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

---

### **carbondioxide.isOnline()**

Checks if the function is currently reachable, without raising any error.

```
def isOnline( )
```

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

**Returns :**

`true` if the function can be reached, and `false` otherwise

---

Checks if the function is currently reachable, without raising any error (asynchronous version).

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox Javascript VM that does not implement context switching during blocking I/O calls.

**Parameters :**

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the boolean result

**context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

---

## **carbondioxide.load()**

Preloads the function cache with a specified validity duration.

**def load( msValidity )**

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds. On failure, throws an exception or returns a negative error code.

---

Preloads the function cache with a specified validity duration (asynchronous version).

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

**Parameters :**

**msValidity** an integer corresponding to the validity of the loaded function parameters, in milliseconds

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the error code (or YAPI\_SUCCESS)

**context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

---

## **carbondioxide.nextCarbonDioxide()**

Continues the enumeration of CO2 sensors started using `yFirstCarbonDioxide()`.

**def nextCarbonDioxide( )**

**Returns :**

a pointer to a `YCarbonDioxide` object, corresponding to a CO2 sensor currently online, or a `null` pointer if there are no more CO2 sensors to enumerate.

---

## **carbondioxide.registerValueCallback()**

Registers the callback function that is invoked on every change of advertised value.

**def registerValueCallback( callback )**

---

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

---

## **carbondioxide.set\_highestValue()**

Changes the recorded maximal value observed.

```
def set_highestValue( newval)
```

**Parameters :**

**newval** a floating point number corresponding to the recorded maximal value observed

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **carbondioxide.set\_logicalName()**

Changes the logical name of the CO2 sensor.

```
def set_logicalName( newval)
```

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the CO2 sensor

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **carbondioxide.set\_lowestValue()**

Changes the recorded minimal value observed.

```
def set_lowestValue( newval)
```

**Parameters :**

**newval** a floating point number corresponding to the recorded minimal value observed

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **carbondioxide.set\_userData()**

Stores a user context provided as argument in the `userData` attribute of the function.

```
def set_userData( data)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.



**Parameters :****data** any kind of object to be stored

## 3.4. ColorLed function interface

Yoctopuce application programming interface allows you to drive a color led using RGB coordinates as well as HSL coordinates. The module performs all conversions from RGB to HSL automatically. It is then self-evident to turn on a led with a given hue and to progressively vary its saturation or lightness. If needed, you can find more information on the difference between RGB and HSL in the section following this one.

In order to use the functions described here, you should include:

```
from yocto_colorled import *
```

Global functions	
<b>yFindColorLed(func)</b>	Retrieves an RGB led for a given identifier.
<b>yFirstColorLed()</b>	Starts the enumeration of RGB leds currently accessible.
YColorLed methods	
<b>colorled→describe()</b>	Returns a descriptive text that identifies the function.
<b>colorled→get_advertisedValue()</b>	Returns the current value of the RGB led (no more than 6 characters).
<b>colorled→get_errorMessage()</b>	Returns the error message of the latest error with this function.
<b>colorled→get_errorType()</b>	Returns the numerical error code of the latest error with this function.
<b>colorled→get_functionDescriptor()</b>	Returns a unique identifier of type YFUN_DESCR corresponding to the function.
<b>colorled→get_hardwareId()</b>	Returns the unique hardware identifier of the function.
<b>colorled→get_hslColor()</b>	Returns the current HSL color of the led.
<b>colorled→get_logicalName()</b>	Returns the logical name of the RGB led.
<b>colorled→get_module()</b>	Get the YModule object for the device on which the function is located.
<b>colorled→get_module_async(callback, context)</b>	Get the YModule object for the device on which the function is located (asynchronous version).
<b>colorled→get_rgbColor()</b>	Returns the current RGB color of the led.
<b>colorled→get_rgbColorAtPowerOn()</b>	Returns the configured color to be displayed when the module is turned on.
<b>colorled→get_userData()</b>	Returns the value of the userData attribute, as previously stored using method set_userData.
<b>colorled→hslMove(hsl_target, ms_duration)</b>	

Performs a smooth transition in the HSL color space between the current color and a target color.

**colorled→isOnline()**

Checks if the function is currently reachable, without raising any error.

**colorled→isOnline\_async(callback, context)**

Checks if the function is currently reachable, without raising any error (asynchronous version).

**colorled→load(msValidity)**

Preloads the function cache with a specified validity duration.

**colorled→load\_async(msValidity, callback, context)**

Preloads the function cache with a specified validity duration (asynchronous version).

**colorled→nextColorLed()**

Continues the enumeration of RGB leds started using `yFirstColorLed()`.

**colorled→registerValueCallback(callback)**

Registers the callback function that is invoked on every change of advertised value.

**colorled→rgbMove(rgb\_target, ms\_duration)**

Performs a smooth transition in the RGB color space between the current color and a target color.

**colorled→set\_hslColor(newval)**

Changes the current color of the led, using a color HSL.

**colorled→set\_logicalName(newval)**

Changes the logical name of the RGB led.

**colorled→set\_rgbColor(newval)**

Changes the current color of the led, using a RGB color.

**colorled→set\_rgbColorAtPowerOn(newval)**

Changes the color that the led will display by default when the module is turned on.

**colorled→set\_userData(data)**

Stores a user context provided as argument in the `userData` attribute of the function.

## YColorLed.FindColorLed()

Retrieves an RGB led for a given identifier.

**def FindColorLed( func)**

The identifier can be specified using several formats:

- `FunctionLogicalName`
- `ModuleSerialNumber.FunctionIdentifier`
- `ModuleSerialNumber.FunctionLogicalName`
- `ModuleLogicalName.FunctionIdentifier`
- `ModuleLogicalName.FunctionLogicalName`

This function does not require that the RGB led is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YColorLed.isOnline()` to test if the RGB led is indeed online at a given time. In case of ambiguity when looking for an RGB led by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

**Parameters :**

**func** a string that uniquely characterizes the RGB led

**Returns :**

a `YColorLed` object allowing you to drive the RGB led.

---

## **YColorLed.FirstColorLed()**

Starts the enumeration of RGB leds currently accessible.

def **FirstColorLed**( )

Use the method `YColorLed.nextColorLed()` to iterate on next RGB leds.

**Returns :**

a pointer to a `YColorLed` object, corresponding to the first RGB led currently online, or a `null` pointer if there are none.

---

## **colorled.describe()**

Returns a descriptive text that identifies the function.

def **describe**( )

The text always includes the class name, and may include as well either the logical name of the function or its hardware identifier.

**Returns :**

a string that describes the function

---

## **colorled.get\_advertisedValue()**

Returns the current value of the RGB led (no more than 6 characters).

def **get\_advertisedValue**( )

**Returns :**

a string corresponding to the current value of the RGB led (no more than 6 characters)

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

---

## **colorled.get\_errorMessage()**

Returns the error message of the latest error with this function.

def **get\_errorMessage**( )

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using this function object

---

## **colorled.get\_errorType()**

Returns the numerical error code of the latest error with this function.

def **get\_errorType**( )

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using this function object

---

## **colorled.get\_colorledDescriptor()**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

**def get\_functionDescriptor( )**

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`. If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

---

Returns the unique hardware identifier of the function.

The unique hardware identifier is made of the device serial number and of the hardware identifier of the function.

**Returns :**

a string that uniquely identifies the function On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

---

**colorled.get\_hslColor()**

Returns the current HSL color of the led.

**def get\_hslColor( )**

**Returns :**

an integer corresponding to the current HSL color of the led

On failure, throws an exception or returns `Y_HSLCOLOR_INVALID`.

---

**colorled.get\_logicalName()**

Returns the logical name of the RGB led.

**def get\_logicalName( )**

**Returns :**

a string corresponding to the logical name of the RGB led

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

---

**colorled.get\_module()**

Get the `YModule` object for the device on which the function is located.

**def get\_module( )**

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

**Returns :**

an instance of `YModule`

---

Get the `YModule` object for the device on which the function is located (asynchronous version).

If the function cannot be located on any module, the returned `YModule` object does not show as on-line. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context

switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

**Parameters :**

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the requested `YModule` object

**context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

---

## **colorled.get\_rgbColor()**

Returns the current RGB color of the led.

**def get\_rgbColor( )**

**Returns :**

an integer corresponding to the current RGB color of the led

On failure, throws an exception or returns `Y_RGBCOLOR_INVALID`.

---

## **colorled.get\_rgbColorAtPowerOn()**

Returns the configured color to be displayed when the module is turned on.

**def get\_rgbColorAtPowerOn( )**

**Returns :**

an integer corresponding to the configured color to be displayed when the module is turned on

On failure, throws an exception or returns `Y_RGBCOLORATPOWERON_INVALID`.

---

## **colorled.get\_userData()**

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

**def get\_userData( )**

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

---

## **colorled.hslMove()**

Performs a smooth transition in the HSL color space between the current color and a target color.

**def hslMove( hsl\_target, ms\_duration)**

**Parameters :**

**hsl\_target** desired HSL color at the end of the transition

**ms\_duration** duration of the transition, in millisecond

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

---

## colorled.isOnline()

Checks if the function is currently reachable, without raising any error.

**def isOnline( )**

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

**Returns :**

`true` if the function can be reached, and `false` otherwise

---

Checks if the function is currently reachable, without raising any error (asynchronous version).

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox Javascript VM that does not implement context switching during blocking I/O calls.

**Parameters :**

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the boolean result

**context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

---

## colorled.load()

Preloads the function cache with a specified validity duration.

**def load( msValidity)**

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

`YAPI_SUCCESS` when the call succeeds. On failure, throws an exception or returns a negative error code.

---

Preloads the function cache with a specified validity duration (asynchronous version).

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

**Parameters :**

**msValidity** an integer corresponding to the validity of the loaded function parameters, in milliseconds

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the error code (or `YAPI_SUCCESS`)

**context** caller-specific object that is passed as-is to the callback function

**Returns :**  
nothing : the result is provided to the callback.

---

## **colorled.nextColorLed()**

Continues the enumeration of RGB leds started using `yFirstColorLed()`.

**def nextColorLed( )**

**Returns :**  
a pointer to a `YColorLed` object, corresponding to an RGB led currently online, or a `null` pointer if there are no more RGB leds to enumerate.

---

## **colorled.registerValueCallback()**

Registers the callback function that is invoked on every change of advertised value.

**def registerValueCallback( callback)**

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**  
**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

---

## **colorled.rgbMove()**

Performs a smooth transition in the RGB color space between the current color and a target color.

**def rgbMove( rgb\_target, ms\_duration)**

**Parameters :**  
**rgb\_target** desired RGB color at the end of the transition  
**ms\_duration** duration of the transition, in millisecond

**Returns :**  
`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **colorled.set\_hslColor()**

Changes the current color of the led, using a color HSL.

**def set\_hslColor( newval)**

Encoding is done as follows: 0xHHSSLL.

**Parameters :**

---

**newval** an integer corresponding to the current color of the led, using a color HSL

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **colorled.set\_logicalName()**

Changes the logical name of the RGB led.

**def set\_logicalName( newval)**

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the RGB led

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **colorled.set\_rgbColor()**

Changes the current color of the led, using a RGB color.

**def set\_rgbColor( newval)**

Encoding is done as follows: 0xRRGGBB.

**Parameters :**

**newval** an integer corresponding to the current color of the led, using a RGB color

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **colorled.set\_rgbColorAtPowerOn()**

Changes the color that the led will display by default when the module is turned on.

**def set\_rgbColorAtPowerOn( newval)**

This color will be displayed as soon as the module is powered on. Remember to call the `saveToFlash()` method of the module if the change should be kept.

**Parameters :**

**newval** an integer corresponding to the color that the led will display by default when the module is turned on

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **colorled.set\_userData()**

Stores a user context provided as argument in the `userData` attribute of the function.

---



```
def set_userData( data)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

## 3.5. Current function interface

The Yoctopuce application programming interface allows you to read an instant measure of the sensor, as well as the minimal and maximal values observed.

In order to use the functions described here, you should include:

```
from yocto_current import *
```

### Global functions

**yFindCurrent(func)**

Retrieves a current sensor for a given identifier.

**yFirstCurrent()**

Starts the enumeration of current sensors currently accessible.

### YCurrent methods

**current→calibrateFromPoints(rawValues, refValues)**

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

**current→describe()**

Returns a descriptive text that identifies the function.

**current→get\_advertisedValue()**

Returns the current value of the current sensor (no more than 6 characters).

**current→get\_currentRawValue()**

Returns the uncalibrated, unrounded raw value returned by the sensor.

**current→get\_currentValue()**

Returns the current measured value.

**current→get\_errorMessage()**

Returns the error message of the latest error with this function.

**current→get\_errorType()**

Returns the numerical error code of the latest error with this function.

**current→get\_functionDescriptor()**

Returns a unique identifier of type YFUN\_DESCR corresponding to the function.

**current→get\_hardwareId()**

Returns the unique hardware identifier of the function.

**current→get\_highestValue()**

Returns the maximal value observed.

**current→get\_logicalName()**

Returns the logical name of the current sensor.

**current→get\_lowestValue()**

Returns the minimal value observed.

**current→get\_module()**

Get the YModule object for the device on which the function is located.

<b>current→get_module_async(callback, context)</b>
Get the YModule object for the device on which the function is located (asynchronous version).
<b>current→get_resolution()</b>
Returns the resolution of the measured values.
<b>current→get_unit()</b>
Returns the measuring unit for the measured value.
<b>current→get_userData()</b>
Returns the value of the userData attribute, as previously stored using method set_userData.
<b>current→isOnline()</b>
Checks if the function is currently reachable, without raising any error.
<b>current→isOnline_async(callback, context)</b>
Checks if the function is currently reachable, without raising any error (asynchronous version).
<b>current→load(msValidity)</b>
Preloads the function cache with a specified validity duration.
<b>current→load_async(msValidity, callback, context)</b>
Preloads the function cache with a specified validity duration (asynchronous version).
<b>current→nextCurrent()</b>
Continues the enumeration of current sensors started using yFirstCurrent().
<b>current→registerValueCallback(callback)</b>
Registers the callback function that is invoked on every change of advertised value.
<b>current→set_highestValue(newval)</b>
Changes the recorded maximal value observed.
<b>current→set_logicalName(newval)</b>
Changes the logical name of the current sensor.
<b>current→set_lowestValue(newval)</b>
Changes the recorded minimal value observed.
<b>current→set_userData(data)</b>
Stores a user context provided as argument in the userData attribute of the function.

## YCurrent.FindCurrent()

Retrieves a current sensor for a given identifier.

**def FindCurrent( func)**

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the current sensor is online at the time it is invoked. The returned object is nevertheless valid. Use the method YCurrent.isOnline() to test if the current sensor is indeed online at a given time. In case of ambiguity when looking for a current sensor by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

**Parameters :**

**func** a string that uniquely characterizes the current sensor

**Returns :**

a `YCurrent` object allowing you to drive the current sensor.

---

## **YCurrent.FirstCurrent()**

Starts the enumeration of current sensors currently accessible.

def **FirstCurrent**( )

Use the method `YCurrent.nextCurrent()` to iterate on next current sensors.

**Returns :**

a pointer to a `YCurrent` object, corresponding to the first current sensor currently online, or a `null` pointer if there are none.

---

## **current.calibrateFromPoints()**

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

def **calibrateFromPoints**( **rawValues**, **refValues** )

It is possible to configure up to five correction points. Correction points must be provided in ascending order, and be in the range of the sensor. The device will automatically perform a linear interpolation of the error correction between specified points. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

For more information on advanced capabilities to refine the calibration of sensors, please contact [support@yoctopuce.com](mailto:support@yoctopuce.com).

**Parameters :**

**rawValues** array of floating point numbers, corresponding to the raw values returned by the sensor for the correction points.

**refValues** array of floating point numbers, corresponding to the corrected values for the correction points.

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **current.describe()**

Returns a descriptive text that identifies the function.

def **describe**( )

The text always includes the class name, and may include as well either the logical name of the function or its hardware identifier.

**Returns :**

a string that describes the function

---

## **current.get\_advertisedValue()**

Returns the current value of the current sensor (no more than 6 characters).

def **get\_advertisedValue**( )

**Returns :**

a string corresponding to the current value of the current sensor (no more than 6 characters)

---

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

---

### **current.get\_currentRawValue()**

Returns the uncalibrated, unrounded raw value returned by the sensor.

**def get\_currentRawValue( )**

**Returns :**

a floating point number corresponding to the uncalibrated, unrounded raw value returned by the sensor

On failure, throws an exception or returns `Y_CURRENTRAWVALUE_INVALID`.

---

### **current.get\_currentValue()**

Returns the current measured value.

**def get\_currentValue( )**

**Returns :**

a floating point number corresponding to the current measured value

On failure, throws an exception or returns `Y_CURRENTVALUE_INVALID`.

---

### **current.get\_errorMessage()**

Returns the error message of the latest error with this function.

**def get\_errorMessage( )**

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using this function object

---

### **current.get\_errorType()**

Returns the numerical error code of the latest error with this function.

**def get\_errorType( )**

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using this function object

---

### **current.get\_currentDescriptor()**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

**def get\_functionDescriptor( )**

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`. If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

---

Returns the unique hardware identifier of the function.

The unique hardware identifier is made of the device serial number and of the hardware identifier of the function.

**Returns :**

a string that uniquely identifies the function On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

---

**current.get\_highestValue()**

Returns the maximal value observed.

**def get\_highestValue( )**

**Returns :**

a floating point number corresponding to the maximal value observed

On failure, throws an exception or returns `Y_HIGHESTVALUE_INVALID`.

---

**current.get\_logicalName()**

Returns the logical name of the current sensor.

**def get\_logicalName( )**

**Returns :**

a string corresponding to the logical name of the current sensor

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

---

**current.get\_lowestValue()**

Returns the minimal value observed.

**def get\_lowestValue( )**

**Returns :**

a floating point number corresponding to the minimal value observed

On failure, throws an exception or returns `Y_LOWESTVALUE_INVALID`.

---

**current.get\_module()**

Get the `YModule` object for the device on which the function is located.

**def get\_module( )**

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

**Returns :**

an instance of `YModule`

---

Get the `YModule` object for the device on which the function is located (asynchronous version).

If the function cannot be located on any module, the returned `YModule` object does not show as on-line. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context

---

switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

**Parameters :**

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the requested `YModule` object

**context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

---

## **current.get\_resolution()**

Returns the resolution of the measured values.

### **def get\_resolution( )**

The resolution corresponds to the numerical precision of the values, which is not always the same as the actual precision of the sensor.

**Returns :**

a floating point number corresponding to the resolution of the measured values

On failure, throws an exception or returns `Y_RESOLUTION_INVALID`.

---

## **current.get\_unit()**

Returns the measuring unit for the measured value.

### **def get\_unit( )**

**Returns :**

a string corresponding to the measuring unit for the measured value

On failure, throws an exception or returns `Y_UNIT_INVALID`.

---

## **current.get\_userData()**

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

### **def getUserData( )**

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

---

## **current.isOnline()**

Checks if the function is currently reachable, without raising any error.

### **def isOnline( )**

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

**Returns :**

`true` if the function can be reached, and `false` otherwise

---

---

Checks if the function is currently reachable, without raising any error (asynchronous version).

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox Javascript VM that does not implement context switching during blocking I/O calls.

**Parameters :**

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the boolean result

**context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

---

## **current.load()**

Preloads the function cache with a specified validity duration.

**def load( msValidity )**

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds. On failure, throws an exception or returns a negative error code.

---

Preloads the function cache with a specified validity duration (asynchronous version).

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

**Parameters :**

**msValidity** an integer corresponding to the validity of the loaded function parameters, in milliseconds

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the error code (or YAPI\_SUCCESS)

**context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

---

## **current.nextCurrent()**

Continues the enumeration of current sensors started using `yFirstCurrent()`.

---

def **nextCurrent**( )

**Returns :**

a pointer to a `YCurrent` object, corresponding to a current sensor currently online, or a `null` pointer if there are no more current sensors to enumerate.

---

## **current.registerValueCallback()**

Registers the callback function that is invoked on every change of advertised value.

def **registerValueCallback**( **callback**)

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

---

## **current.set\_highestValue()**

Changes the recorded maximal value observed.

def **set\_highestValue**( **newval**)

**Parameters :**

**newval** a floating point number corresponding to the recorded maximal value observed

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **current.set\_logicalName()**

Changes the logical name of the current sensor.

def **set\_logicalName**( **newval**)

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the current sensor

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **current.set\_lowestValue()**

Changes the recorded minimal value observed.

def **set\_lowestValue**( **newval**)

**Parameters :**



**newval** a floating point number corresponding to the recorded minimal value observed

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## current.set\_userData()

Stores a user context provided as argument in the userData attribute of the function.

def **set\_userData**( **data**)

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

## 3.6. DataLogger function interface

Yoctopuce sensors include a non-volatile memory capable of storing ongoing measured data automatically, without requiring a permanent connection to a computer. The Yoctopuce application programming interface includes functions to control how this internal data logger works. Because the sensors do not include a battery, they do not have an absolute time reference. Therefore, measures are simply indexed by the absolute run number and time relative to the start of the run. Every new power up starts a new run. It is however possible to setup an absolute UTC time by software at a given time, so that the data logger keeps track of it until it is next powered off.

In order to use the functions described here, you should include:

```
from yocto_datalogger import *
```

### Global functions

#### yFindDataLogger(func)

Retrieves a data logger for a given identifier.

#### yFirstDataLogger()

Starts the enumeration of data loggers currently accessible.

### YDataLogger methods

#### datalogger→describe()

Returns a descriptive text that identifies the function.

#### datalogger→forgetAllDataStreams()

Clears the data logger memory and discards all recorded data streams.

#### datalogger→get\_advertisedValue()

Returns the current value of the data logger (no more than 6 characters).

#### datalogger→get\_autoStart()

Returns the default activation state of the data logger on power up.

#### datalogger→get\_currentRunIndex()

Returns the current run number, corresponding to the number of times the module was powered on with the dataLogger enabled at some point.

#### datalogger→get\_dataRun(runIdx)

Returns a data run object holding all measured data for a given period during which the module was turned on (a run).

#### datalogger→get\_dataStreams(v)

Builds a list of all data streams hold by the data logger.

<b><code>datalogger→get_errorMessage()</code></b>
Returns the error message of the latest error with this function.
<b><code>datalogger→get_errorType()</code></b>
Returns the numerical error code of the latest error with this function.
<b><code>datalogger→get_functionDescriptor()</code></b>
Returns a unique identifier of type <code>YFUN_DESCR</code> corresponding to the function.
<b><code>datalogger→get_hardwareId()</code></b>
Returns the unique hardware identifier of the function.
<b><code>datalogger→get_logicalName()</code></b>
Returns the logical name of the data logger.
<b><code>datalogger→get_measureNames()</code></b>
Returns the names of the measures recorded by the data logger.
<b><code>datalogger→get_module()</code></b>
Get the <code>YModule</code> object for the device on which the function is located.
<b><code>datalogger→get_module_async(callback, context)</code></b>
Get the <code>YModule</code> object for the device on which the function is located (asynchronous version).
<b><code>datalogger→get_oldestRunIndex()</code></b>
Returns the index of the oldest run for which the non-volatile memory still holds recorded data.
<b><code>datalogger→get_recording()</code></b>
Returns the current activation state of the data logger.
<b><code>datalogger→get_timeUTC()</code></b>
Returns the Unix timestamp for current UTC time, if known.
<b><code>datalogger→get_userData()</code></b>
Returns the value of the <code>userData</code> attribute, as previously stored using method <code>set_userData</code> .
<b><code>datalogger→isOnline()</code></b>
Checks if the function is currently reachable, without raising any error.
<b><code>datalogger→isOnline_async(callback, context)</code></b>
Checks if the function is currently reachable, without raising any error (asynchronous version).
<b><code>datalogger→load(msValidity)</code></b>
Preloads the function cache with a specified validity duration.
<b><code>datalogger→load_async(msValidity, callback, context)</code></b>
Preloads the function cache with a specified validity duration (asynchronous version).
<b><code>datalogger→nextDataLogger()</code></b>
Continues the enumeration of data loggers started using <code>yFirstDataLogger()</code> .
<b><code>datalogger→registerValueCallback(callback)</code></b>
Registers the callback function that is invoked on every change of advertised value.
<b><code>datalogger→set_autoStart(newval)</code></b>
Changes the default activation state of the data logger on power up.
<b><code>datalogger→set_logicalName(newval)</code></b>
Changes the logical name of the data logger.
<b><code>datalogger→set_recording(newval)</code></b>
Changes the activation state of the data logger to start/stop recording data.
<b><code>datalogger→set_timeUTC(newval)</code></b>

Changes the current UTC time reference used for recorded data.

**datalogger**→**set\_userdata**(data)

Stores a user context provided as argument in the `userData` attribute of the function.

---

## **YDataLogger.FindDataLogger()**

Retrieves a data logger for a given identifier.

def **FindDataLogger**( func)

The identifier can be specified using several formats:

- `FunctionLogicalName`
- `ModuleSerialNumber.FunctionIdentifier`
- `ModuleSerialNumber.FunctionLogicalName`
- `ModuleLogicalName.FunctionIdentifier`
- `ModuleLogicalName.FunctionLogicalName`

This function does not require that the data logger is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YDataLogger.isOnline()` to test if the data logger is indeed online at a given time. In case of ambiguity when looking for a data logger by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

### **Parameters :**

**func** a string that uniquely characterizes the data logger

### **Returns :**

a `YDataLogger` object allowing you to drive the data logger.

---

## **YDataLogger.FirstDataLogger()**

Starts the enumeration of data loggers currently accessible.

def **FirstDataLogger**( )

Use the method `YDataLogger.nextDataLogger()` to iterate on next data loggers.

### **Returns :**

a pointer to a `YDataLogger` object, corresponding to the first data logger currently online, or a `null` pointer if there are none.

---

## **datalogger.describe()**

Returns a descriptive text that identifies the function.

def **describe**( )

The text always includes the class name, and may include as well either the logical name of the function or its hardware identifier.

### **Returns :**

a string that describes the function

---

## **datalogger.forgetAllDataStreams()**

Clears the data logger memory and discards all recorded data streams.

def **forgetAllDataStreams**( )

This method also resets the current run index to zero.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**datalogger.get\_advertisedValue()**

Returns the current value of the data logger (no more than 6 characters).

```
def get_advertisedValue( )
```

**Returns :**

a string corresponding to the current value of the data logger (no more than 6 characters)

On failure, throws an exception or returns Y\_ADVERTISEDVALUE\_INVALID.

---

**datalogger.get\_autoStart()**

Returns the default activation state of the data logger on power up.

```
def get_autoStart( )
```

**Returns :**

either Y\_AUTOSTART\_OFF or Y\_AUTOSTART\_ON, according to the default activation state of the data logger on power up

On failure, throws an exception or returns Y\_AUTOSTART\_INVALID.

---

**datalogger.get\_currentRunIndex()**

Returns the current run number, corresponding to the number of times the module was powered on with the data logger enabled at some point.

```
def get_currentRunIndex( )
```

**Returns :**

an integer corresponding to the current run number, corresponding to the number of times the module was powered on with the data logger enabled at some point

On failure, throws an exception or returns Y\_CURRENTRUNINDEX\_INVALID.

---

**datalogger.get\_dataRun()**

Returns a data run object holding all measured data for a given period during which the module was turned on (a run).

```
def get_dataRun( runIdx)
```

This object can then be used to retrieve measures (min, average and max) at a desired data rate.

**Parameters :**

**runIdx** the index of the desired run

**Returns :**

an YDataRun object

On failure, throws an exception or returns null.

---

**datalogger.get\_dataStreams()**

Builds a list of all data streams hold by the data logger.

---

**def get\_dataStreams( v )**

The caller must pass by reference an empty array to hold YDataStream objects, and the function fills it with objects describing available data sequences.

**Parameters :**

**v** an array of YDataStream objects to be filled in

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**datalogger.getErrorMessage()**

Returns the error message of the latest error with this function.

**def get\_errorMessage( )**

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using this function object

---

**datalogger.getErrorType()**

Returns the numerical error code of the latest error with this function.

**def get\_errorType( )**

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using this function object

---

**datalogger.get\_dataloggerDescriptor()**

Returns a unique identifier of type YFUN\_DESCR corresponding to the function.

**def get\_functionDescriptor( )**

This identifier can be used to test if two instances of YFunction reference the same physical function on the same physical device.

**Returns :**

an identifier of type YFUN\_DESCR. If the function has never been contacted, the returned value is Y\_FUNCTIONDESCRIPTOR\_INVALID.

---

Returns the unique hardware identifier of the function.

The unique hardware identifier is made of the device serial number and of the hardware identifier of the function.

**Returns :**

a string that uniquely identifies the function On failure, throws an exception or returns Y\_HARDWAREID\_INVALID.

---

**datalogger.get\_logicalName()**

Returns the logical name of the data logger.

---

**def `get_logicalName( )`**

**Returns :**

a string corresponding to the logical name of the data logger

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

---

Returns the names of the measures recorded by the data logger.

In most case, the measure names match the hardware identifier of the sensor that produced the data.

**Returns :**

a list of strings (the measure names) On failure, throws an exception or returns an empty array.

---

## **`datalogger.get_module()`**

Get the `YModule` object for the device on which the function is located.

**def `get_module( )`**

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

**Returns :**

an instance of `YModule`

---

Get the `YModule` object for the device on which the function is located (asynchronous version).

If the function cannot be located on any module, the returned `YModule` object does not show as on-line. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

**Parameters :**

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the requested `YModule` object

**context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

---

## **`datalogger.get_oldestRunIndex()`**

Returns the index of the oldest run for which the non-volatile memory still holds recorded data.

**def `get_oldestRunIndex( )`**

**Returns :**

an integer corresponding to the index of the oldest run for which the non-volatile memory still holds recorded data

On failure, throws an exception or returns `Y_OLDESTRUNINDEX_INVALID`.

---

## **`datalogger.get_recording()`**

Returns the current activation state of the data logger.

---

`def get_recording( )`

**Returns :**

either `Y_RECORDING_OFF` or `Y_RECORDING_ON`, according to the current activation state of the data logger

On failure, throws an exception or returns `Y_RECORDING_INVALID`.

---

## **`datalogger.getTimeUTC()`**

Returns the Unix timestamp for current UTC time, if known.

`def getTimeUTC( )`

**Returns :**

an integer corresponding to the Unix timestamp for current UTC time, if known

On failure, throws an exception or returns `Y_TIMEUTC_INVALID`.

---

## **`datalogger.getUserData()`**

Returns the value of the `userData` attribute, as previously stored using method `set_userdata`.

`def getUserData( )`

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

---

## **`datalogger.isOnline()`**

Checks if the function is currently reachable, without raising any error.

`def isOnline( )`

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

**Returns :**

`true` if the function can be reached, and `false` otherwise

---

Checks if the function is currently reachable, without raising any error (asynchronous version).

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox Javascript VM that does not implement context switching during blocking I/O calls.

**Parameters :**

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the boolean result

---

**context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

---

## **datalogger.load()**

Preloads the function cache with a specified validity duration.

def **load**( **msValidity** )

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds. On failure, throws an exception or returns a negative error code.

---

Preloads the function cache with a specified validity duration (asynchronous version).

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

**Parameters :**

**msValidity** an integer corresponding to the validity of the loaded function parameters, in milliseconds

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the error code (or YAPI\_SUCCESS)

**context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

---

## **datalogger.nextDataLogger()**

Continues the enumeration of data loggers started using `yFirstDataLogger()`.

def **nextDataLogger**( )

**Returns :**

a pointer to a `YDataLogger` object, corresponding to a data logger currently online, or a null pointer if there are no more data loggers to enumerate.

---

## **datalogger.registerValueCallback()**

Registers the callback function that is invoked on every change of advertised value.

def **registerValueCallback**( **callback** )

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness,



remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

---

## **datalogger.set\_autoStart()**

Changes the default activation state of the data logger on power up.

```
def set_autoStart( newval)
```

Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** either `Y_AUTOSTART_OFF` or `Y_AUTOSTART_ON`, according to the default activation state of the data logger on power up

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **datalogger.set\_logicalName()**

Changes the logical name of the data logger.

```
def set_logicalName( newval)
```

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the data logger

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **datalogger.set\_recording()**

Changes the activation state of the data logger to start/stop recording data.

```
def set_recording( newval)
```

**Parameters :**

**newval** either `Y_RECORDING_OFF` or `Y_RECORDING_ON`, according to the activation state of the data logger to start/stop recording data

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **datalogger.set\_timeUTC()**

Changes the current UTC time reference used for recorded data.

---

```
def set_timeUTC( newval)
```

**Parameters :**

**newval** an integer corresponding to the current UTC time reference used for recorded data

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **datalogger.set\_userData()**

Stores a user context provided as argument in the userData attribute of the function.

```
def set_userData( data)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

## **3.7. Formatted data sequence**

A run is a continuous interval of time during which a module was powered on. A data run provides easy access to all data collected during a given run, providing on-the-fly resampling at the desired reporting rate.

In order to use the functions described here, you should include:

```
from yocto_datalogger import *
```

### **YDataRun methods**

**datarun→get\_averageValue(measureName, pos)**

Returns the average value of the measure observed at the specified time period.

**datarun→get\_duration()**

Returns the duration (in seconds) of the data run.

**datarun→get\_maxValue(measureName, pos)**

Returns the maximal value of the measure observed at the specified time period.

**datarun→get\_measureNames()**

Returns the names of the measures recorded by the data logger.

**datarun→get\_minValue(measureName, pos)**

Returns the minimal value of the measure observed at the specified time period.

**datarun→get\_startTimeUTC()**

Returns the start time of the data run, relative to the Jan 1, 1970.

**datarun→get\_valueCount()**

Returns the number of values accessible in this run, given the selected data samples interval.

**datarun→get\_valueInterval()**

Returns the number of seconds covered by each value in this run.

**datarun→set\_valueInterval(valueInterval)**

Changes the number of seconds covered by each value in this run.

---

## **datarun.get\_averageValue()**

Returns the average value of the measure observed at the specified time period.

```
def get_averageValue( measureName, pos)
```

**Parameters :**

**measureName** the name of the desired measure (one of the names returned by `get_measureNames`)  
**pos** the position index, between 0 and the value returned by `get_valueCount`

**Returns :**

a floating point number (the average value)

On failure, throws an exception or returns `Y_AVERAGEVALUE_INVALID`.

---

## **datarun.get\_duration()**

Returns the duration (in seconds) of the data run.

```
def get_duration( )
```

When the datalogger is actively recording and the specified run is the current run, calling this method reloads last sequence(s) from device to make sure it includes the latest recorded data.

**Returns :**

an unsigned number corresponding to the number of seconds between the beginning of the run (when the module was powered up) and the last recorded measure.

---

## **datarun.get\_maxValue()**

Returns the maximal value of the measure observed at the specified time period.

```
def get_maxValue( measureName, pos)
```

**Parameters :**

**measureName** the name of the desired measure (one of the names returned by `get_measureNames`)  
**pos** the position index, between 0 and the value returned by `get_valueCount`

**Returns :**

a floating point number (the maximal value)

On failure, throws an exception or returns `Y_MAXVALUE_INVALID`.

---

## **datarun.get\_measureNames()**

Returns the names of the measures recorded by the data logger.

```
def get_measureNames( )
```

In most case, the measure names match the hardware identifier of the sensor that produced the data.

**Returns :**

a list of strings (the measure names) On failure, throws an exception or returns an empty array.

---

## **datarun.get\_minValue()**

Returns the minimal value of the measure observed at the specified time period.

```
def get_minValue( measureName, pos)
```

**Parameters :**

**measureName** the name of the desired measure (one of the names returned by `get_measureNames`)  
**pos** the position index, between 0 and the value returned by `get_valueCount`

**Returns :**

a floating point number (the minimal value)

On failure, throws an exception or returns Y\_MINVALUE\_INVALID.

---

Returns the start time of the data run, relative to the Jan 1, 1970.

If the UTC time was not set in the datalogger at any time during the recording of this data run, and if this is not the current run, this method returns 0.

**Returns :**

an unsigned number corresponding to the number of seconds between the Jan 1, 1970 and the beginning of this data run (i.e. Unix time representation of the absolute time).

---

### **datarun.get\_valueCount()**

Returns the number of values accessible in this run, given the selected data samples interval.

`def get_valueCount( )`

When the datalogger is actively recording and the specified run is the current run, calling this method reloads last sequence(s) from device to make sure it includes the latest recorded data.

**Returns :**

an unsigned number corresponding to the run duration divided by the samples interval.

---

### **datarun.get\_valueInterval()**

Returns the number of seconds covered by each value in this run.

`def get_valueInterval( )`

By default, the value interval is set to the coarsest data rate archived in the data logger flash for this run. The value interval can however be configured at will to a different rate when desired.

**Returns :**

an unsigned number corresponding to a number of seconds covered by each data sample in the Run.

---

### **datarun.set\_valueInterval()**

Changes the number of seconds covered by each value in this run.

`def set_valueInterval( valueInterval)`

By default, the value interval is set to the coarsest data rate archived in the data logger flash for this run. The value interval can however be configured at will to a different rate when desired.

**Parameters :**

**valueInterval** an integer number of seconds.

**Returns :**

nothing

---

## **3.8. Recorded data sequence**

DataStream objects represent a recorded measure sequence. They are returned by the data logger present on Yoctopuce sensors.

In order to use the functions described here, you should include:

```
from yocto_datalogger import *
```

## **YDataStream methods**

### **datastream→get\_columnCount()**

Returns the number of data columns present in this stream.

### **datastream→get\_columnNames()**

Returns the title (or meaning) of each data column present in this stream.

### **datastream→get\_data(row, col)**

Returns a single measure from the data stream, specified by its row and column index.

### **datastream→get\_dataRows()**

Returns the whole data set contained in the stream, as a bidimensional table of numbers.

### **datastream→get\_dataSamplesInterval()**

Returns the number of seconds elapsed between two consecutive rows of this data stream.

### **datastream→get\_rowCount()**

Returns the number of data rows present in this stream.

### **datastream→get\_runIndex()**

Returns the run index of the data stream.

### **datastream→get\_startTime()**

Returns the start time of the data stream, relative to the beginning of the run.

### **datastream→get\_startTimeUTC()**

Returns the start time of the data stream, relative to the Jan 1, 1970.

## **datastream.get\_columnCount()**

Returns the number of data columns present in this stream.

```
def get_columnCount( )
```

The meaning of the values present in each column can be obtained using the method `get_columnNames()`.

This method fetches the whole data stream from the device, if not yet done.

### **Returns :**

an unsigned number corresponding to the number of rows. On failure, throws an exception or returns zero.

## **datastream.get\_columnNames()**

Returns the title (or meaning) of each data column present in this stream.

```
def get_columnNames( )
```

In most case, the title of the data column is the hardware identifier of the sensor that produced the data. For archived streams created by summarizing a high-resolution data stream, there can be a suffix appended to the sensor identifier, such as `_min` for the minimum value, `_avg` for the average value and `_max` for the maximal value.

This method fetches the whole data stream from the device, if not yet done.

### **Returns :**

a list containing as many strings as there are columns in the data stream. On failure, throws an exception or returns an empty array.

## **datastream.get\_data()**

Returns a single measure from the data stream, specified by its row and column index.

```
def get_data( row, col)
```

The meaning of the values present in each column can be obtained using the method `get_columnNames()`.

This method fetches the whole data stream from the device, if not yet done.

**Parameters :**

**row** row index

**col** column index

**Returns :**

a floating-point number On failure, throws an exception or returns `Y_DATA_INVALID`.

---

## **datastream.get\_dataRows()**

Returns the whole data set contained in the stream, as a bidimensional table of numbers.

```
def get_dataRows( )
```

The meaning of the values present in each column can be obtained using the method `get_columnNames()`.

This method fetches the whole data stream from the device, if not yet done.

**Returns :**

a list containing as many elements as there are rows in the data stream. Each row itself is a list of floating-point numbers. On failure, throws an exception or returns an empty array.

---

## **datastream.get\_dataSamplesInterval()**

Returns the number of seconds elapsed between two consecutive rows of this data stream.

```
def get_dataSamplesInterval( )
```

By default, the data logger records one row per second, but there might be alternative streams at lower resolution created by summarizing the original stream for archiving purposes.

This method does not cause any access to the device, as the value is preloaded in the object at instantiation time.

**Returns :**

an unsigned number corresponding to a number of seconds.

---

## **datastream.get\_rowCount()**

Returns the number of data rows present in this stream.

```
def get_rowCount( )
```

This method fetches the whole data stream from the device, if not yet done.

**Returns :**

an unsigned number corresponding to the number of rows. On failure, throws an exception or returns zero.

---

## **datastream.get\_runIndex()**

Returns the run index of the data stream.

---

```
def get_runIndex( )
```

A run can be made of multiple datastreams, for different time intervals. This method does not cause any access to the device, as the value is preloaded in the object at instantiation time.

**Returns :**

an unsigned number corresponding to the run index.

---

## **datastream.get\_startTime()**

Returns the start time of the data stream, relative to the beginning of the run.

```
def get_startTime( )
```

If you need an absolute time, use `get_startTimeUTC()`.

This method does not cause any access to the device, as the value is preloaded in the object at instantiation time.

**Returns :**

an unsigned number corresponding to the number of seconds between the start of the run and the beginning of this data stream.

---

## **datastream.get\_startTimeUTC()**

Returns the start time of the data stream, relative to the Jan 1, 1970.

```
def get_startTimeUTC( )
```

If the UTC time was not set in the datalogger at the time of the recording of this data stream, this method returns 0.

This method does not cause any access to the device, as the value is preloaded in the object at instantiation time.

**Returns :**

an unsigned number corresponding to the number of seconds between the Jan 1, 1970 and the beginning of this data stream (i.e. Unix time representation of the absolute time).

## **3.9. External power supply control interface**

Yoctopuce application programming interface allows you to control the power source to use for module functions that require high current. The module can also automatically disconnect the external power when a voltage drop is observed on the external power source (external battery running out of power).

In order to use the functions described here, you should include:

```
from yocto_dualpower import *
```

### **Global functions**

```
yFindDualPower(func)
```

Retrieves a dual power control for a given identifier.

```
yFirstDualPower()
```

Starts the enumeration of dual power controls currently accessible.

### **YDualPower methods**

```
dualpower→describe()
```

Returns a descriptive text that identifies the function.

```
dualpower→get_advertisedValue()
```

Returns the current value of the power control (no more than 6 characters).

<b>dualpower→get_errorMessage()</b>
Returns the error message of the latest error with this function.
<b>dualpower→get_errorType()</b>
Returns the numerical error code of the latest error with this function.
<b>dualpower→get_extVoltage()</b>
Returns the measured voltage on the external power source, in millivolts.
<b>dualpower→get_functionDescriptor()</b>
Returns a unique identifier of type <code>YFUN_DESCR</code> corresponding to the function.
<b>dualpower→get_hardwareId()</b>
Returns the unique hardware identifier of the function.
<b>dualpower→get_logicalName()</b>
Returns the logical name of the power control.
<b>dualpower→get_module()</b>
Get the <code>YModule</code> object for the device on which the function is located.
<b>dualpower→get_module_async(callback, context)</b>
Get the <code>YModule</code> object for the device on which the function is located (asynchronous version).
<b>dualpower→get_powerControl()</b>
Returns the selected power source for module functions that require lots of current.
<b>dualpower→get_powerState()</b>
Returns the current power source for module functions that require lots of current.
<b>dualpower→get_userData()</b>
Returns the value of the <code>userData</code> attribute, as previously stored using method <code>set_userData</code> .
<b>dualpower→isOnline()</b>
Checks if the function is currently reachable, without raising any error.
<b>dualpower→isOnline_async(callback, context)</b>
Checks if the function is currently reachable, without raising any error (asynchronous version).
<b>dualpower→load(msValidity)</b>
Preloads the function cache with a specified validity duration.
<b>dualpower→load_async(msValidity, callback, context)</b>
Preloads the function cache with a specified validity duration (asynchronous version).
<b>dualpower→nextDualPower()</b>
Continues the enumeration of dual power controls started using <code>yFirstDualPower()</code> .
<b>dualpower→registerValueCallback(callback)</b>
Registers the callback function that is invoked on every change of advertised value.
<b>dualpower→set_logicalName(newval)</b>
Changes the logical name of the power control.
<b>dualpower→set_powerControl(newval)</b>
Changes the selected power source for module functions that require lots of current.
<b>dualpower→set_userData(data)</b>
Stores a user context provided as argument in the <code>userData</code> attribute of the function.

## YDualPower.FindDualPower()

Retrieves a dual power control for a given identifier.



```
def FindDualPower( func)
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the power control is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YDualPower.isOnline()` to test if the power control is indeed online at a given time. In case of ambiguity when looking for a dual power control by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

**Parameters :**

**func** a string that uniquely characterizes the power control

**Returns :**

a `YDualPower` object allowing you to drive the power control.

---

## **YDualPower.FirstDualPower()**

Starts the enumeration of dual power controls currently accessible.

```
def FirstDualPower( )
```

Use the method `YDualPower.nextDualPower()` to iterate on next dual power controls.

**Returns :**

a pointer to a `YDualPower` object, corresponding to the first dual power control currently online, or a `null` pointer if there are none.

---

## **dualpower.describe()**

Returns a descriptive text that identifies the function.

```
def describe( )
```

The text always includes the class name, and may include as well either the logical name of the function or its hardware identifier.

**Returns :**

a string that describes the function

---

## **dualpower.get\_advertisedValue()**

Returns the current value of the power control (no more than 6 characters).

```
def get_advertisedValue( )
```

**Returns :**

a string corresponding to the current value of the power control (no more than 6 characters)

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

---

## **dualpower.get\_errorMessage()**

Returns the error message of the latest error with this function.

---

```
def get_errorMessage( )
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using this function object

---

## **dualpower.get\_errorType()**

Returns the numerical error code of the latest error with this function.

```
def get_errorType( )
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using this function object

---

## **dualpower.get\_extVoltage()**

Returns the measured voltage on the external power source, in millivolts.

```
def get_extVoltage( )
```

**Returns :**

an integer corresponding to the measured voltage on the external power source, in millivolts

On failure, throws an exception or returns `Y_EXTVOLTAGE_INVALID`.

---

## **dualpower.get\_dualpowerDescriptor()**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

```
def get_functionDescriptor( )
```

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`. If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

---

Returns the unique hardware identifier of the function.

The unique hardware identifier is made of the device serial number and of the hardware identifier of the function.

**Returns :**

a string that uniquely identifies the function On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

---

## **dualpower.get\_logicalName()**

Returns the logical name of the power control.

```
def get_logicalName( )
```

**Returns :**

a string corresponding to the logical name of the power control

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

---

---

## dualpower.get\_module()

Get the `YModule` object for the device on which the function is located.

```
def get_module( )
```

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

**Returns :**  
an instance of `YModule`

---

Get the `YModule` object for the device on which the function is located (asynchronous version).

If the function cannot be located on any module, the returned `YModule` object does not show as on-line. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

**Parameters :**

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the requested `YModule` object

**context** caller-specific object that is passed as-is to the callback function

**Returns :**  
nothing : the result is provided to the callback.

---

## dualpower.get\_powerControl()

Returns the selected power source for module functions that require lots of current.

```
def get_powerControl( )
```

**Returns :**

a value among `Y_POWERCONTROL_AUTO`, `Y_POWERCONTROL_FROM_USB`, `Y_POWERCONTROL_FROM_EXT` and `Y_POWERCONTROL_OFF` corresponding to the selected power source for module functions that require lots of current

On failure, throws an exception or returns `Y_POWERCONTROL_INVALID`.

---

## dualpower.get\_powerState()

Returns the current power source for module functions that require lots of current.

```
def get_powerState( )
```

**Returns :**

a value among `Y_POWERSTATE_OFF`, `Y_POWERSTATE_FROM_USB` and `Y_POWERSTATE_FROM_EXT` corresponding to the current power source for module functions that require lots of current

On failure, throws an exception or returns `Y_POWERSTATE_INVALID`.

---

## dualpower.get\_userData()

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

**def `getUserData()`**

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**  
the object stored previously by the caller.

---

## **dualpower.isOnline()**

Checks if the function is currently reachable, without raising any error.

**def `isOnline()`**

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

**Returns :**  
`true` if the function can be reached, and `false` otherwise

---

Checks if the function is currently reachable, without raising any error (asynchronous version).

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox Javascript VM that does not implement context switching during blocking I/O calls.

**Parameters :**  
**`callback`** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the boolean result  
**`context`** caller-specific object that is passed as-is to the callback function

**Returns :**  
nothing : the result is provided to the callback.

---

## **dualpower.load()**

Preloads the function cache with a specified validity duration.

**def `load(msValidity)`**

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**  
**`msValidity`** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**  
`YAPI_SUCCESS` when the call succeeds. On failure, throws an exception or returns a negative error code.

---

Preloads the function cache with a specified validity duration (asynchronous version).

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

**Parameters :**

- msValidity** an integer corresponding to the validity of the loaded function parameters, in milliseconds
- callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the error code (or `YAPI_SUCCESS`)
- context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

---

## **dualpower.nextDualPower()**

Continues the enumeration of dual power controls started using `yFirstDualPower()`.

```
def nextDualPower( )
```

**Returns :**

a pointer to a `YDualPower` object, corresponding to a dual power control currently online, or a null pointer if there are no more dual power controls to enumerate.

---

## **dualpower.registerValueCallback()**

Registers the callback function that is invoked on every change of advertised value.

```
def registerValueCallback( callback)
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

- callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

---

## **dualpower.set\_logicalName()**

Changes the logical name of the power control.

```
def set_logicalName( newval)
```

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

- newval** a string corresponding to the logical name of the power control

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## dualpower.set\_powerControl()

Changes the selected power source for module functions that require lots of current.

```
def set_powerControl( newval)
```

### Parameters :

**newval** a value among Y\_POWERCONTROL\_AUTO, Y\_POWERCONTROL\_FROM\_USB, Y\_POWERCONTROL\_FROM\_EXT and Y\_POWERCONTROL\_OFF corresponding to the selected power source for module functions that require lots of current

### Returns :

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## dualpower.set\_userData()

Stores a user context provided as argument in the userData attribute of the function.

```
def set_userData( data)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

### Parameters :

**data** any kind of object to be stored

## 3.10. Yocto-hub port interface

In order to use the functions described here, you should include:

```
from yocto_hubport import *
```

### Global functions

#### yFindHubPort(func)

Retrieves a Yocto-hub port for a given identifier.

#### yFirstHubPort()

Starts the enumeration of Yocto-hub ports currently accessible.

### YHubPort methods

#### hubport→describe()

Returns a descriptive text that identifies the function.

#### hubport→get\_advertisedValue()

Returns the current value of the Yocto-hub port (no more than 6 characters).

#### hubport→get\_baudRate()

Returns the current baud rate used by this Yocto-hub port, in kbps.

#### hubport→get\_enabled()

Returns true if the Yocto-hub port is powered, false otherwise.

#### hubport→get\_errorMessage()

Returns the error message of the latest error with this function.

#### hubport→get\_errorType()

Returns the numerical error code of the latest error with this function.

#### hubport→get\_functionDescriptor()

Returns a unique identifier of type YFUN\_DESCR corresponding to the function.

#### hubport→get\_hardwareId()

Returns the unique hardware identifier of the function.

**hubport→get\_logicalName()**

Returns the logical name of the Yocto-hub port, which is always the serial number of the connected module.

**hubport→get\_module()**

Get the `YModule` object for the device on which the function is located.

**hubport→get\_module\_async(callback, context)**

Get the `YModule` object for the device on which the function is located (asynchronous version).

**hubport→get\_portState()**

Returns the current state of the Yocto-hub port.

**hubport→get\_userData()**

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

**hubport→isOnline()**

Checks if the function is currently reachable, without raising any error.

**hubport→isOnline\_async(callback, context)**

Checks if the function is currently reachable, without raising any error (asynchronous version).

**hubport→load(msValidity)**

Preloads the function cache with a specified validity duration.

**hubport→load\_async(msValidity, callback, context)**

Preloads the function cache with a specified validity duration (asynchronous version).

**hubport→nextHubPort()**

Continues the enumeration of Yocto-hub ports started using `yFirstHubPort()`.

**hubport→registerValueCallback(callback)**

Registers the callback function that is invoked on every change of advertised value.

**hubport→set\_enabled(newval)**

Changes the activation of the Yocto-hub port.

**hubport→set\_logicalName(newval)**

It is not possible to configure the logical name of a Yocto-hub port.

**hubport→set\_userData(data)**

Stores a user context provided as argument in the `userData` attribute of the function.

## **YHubPort.FindHubPort()**

Retrieves a Yocto-hub port for a given identifier.

**def FindHubPort( func )**

The identifier can be specified using several formats:

- `FunctionLogicalName`
- `ModuleSerialNumber.FunctionIdentifier`
- `ModuleSerialNumber.FunctionLogicalName`
- `ModuleLogicalName.FunctionIdentifier`
- `ModuleLogicalName.FunctionLogicalName`

This function does not require that the Yocto-hub port is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YHubPort.isOnline()` to test if the Yocto-hub port is indeed online at a given time. In case of ambiguity when looking for a Yocto-

hub port by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

**Parameters :**

**func** a string that uniquely characterizes the Yocto-hub port

**Returns :**

a `YHubPort` object allowing you to drive the Yocto-hub port.

---

## **YHubPort.FirstHubPort()**

Starts the enumeration of Yocto-hub ports currently accessible.

**def FirstHubPort( )**

Use the method `YHubPort.nextHubPort()` to iterate on next Yocto-hub ports.

**Returns :**

a pointer to a `YHubPort` object, corresponding to the first Yocto-hub port currently online, or a `null` pointer if there are none.

---

## **hubport.describe()**

Returns a descriptive text that identifies the function.

**def describe( )**

The text always includes the class name, and may include as well either the logical name of the function or its hardware identifier.

**Returns :**

a string that describes the function

---

## **hubport.get\_advertisedValue()**

Returns the current value of the Yocto-hub port (no more than 6 characters).

**def get\_advertisedValue( )**

**Returns :**

a string corresponding to the current value of the Yocto-hub port (no more than 6 characters)

On failure, throws an exception or returns `Y__ADVERTISEDVALUE__INVALID`.

---

## **hubport.get\_baudRate()**

Returns the current baud rate used by this Yocto-hub port, in kbps.

**def get\_baudRate( )**

The default value is 1000 kbps, but a slower rate may be used if communication problems are hit.

**Returns :**

an integer corresponding to the current baud rate used by this Yocto-hub port, in kbps

On failure, throws an exception or returns `Y__BAUDRATE__INVALID`.

---

## **hubport.get\_enabled()**

Returns true if the Yocto-hub port is powered, false otherwise.



**def get\_enabled( )**

**Returns :**

either `Y_ENABLED_FALSE` or `Y_ENABLED_TRUE`, according to true if the Yocto-hub port is powered, false otherwise

On failure, throws an exception or returns `Y_ENABLED_INVALID`.

---

## **hubport.get\_errorMessage()**

Returns the error message of the latest error with this function.

**def get\_errorMessage( )**

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using this function object

---

## **hubport.get\_errorType()**

Returns the numerical error code of the latest error with this function.

**def get\_errorType( )**

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using this function object

---

## **hubport.get\_hubportDescriptor()**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

**def get\_functionDescriptor( )**

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`. If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

---

Returns the unique hardware identifier of the function.

The unique hardware identifier is made of the device serial number and of the hardware identifier of the function.

**Returns :**

a string that uniquely identifies the function On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

---

## **hubport.get\_logicalName()**

Returns the logical name of the Yocto-hub port, which is always the serial number of the connected module.

**def get\_logicalName( )**

**Returns :**

a string corresponding to the logical name of the Yocto-hub port, which is always the serial number of the connected module

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

---

## hubport.get\_module()

Get the `YModule` object for the device on which the function is located.

`def get_module( )`

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

**Returns :**  
an instance of `YModule`

---

Get the `YModule` object for the device on which the function is located (asynchronous version).

If the function cannot be located on any module, the returned `YModule` object does not show as on-line. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

**Parameters :**  
**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the requested `YModule` object  
**context** caller-specific object that is passed as-is to the callback function

**Returns :**  
nothing : the result is provided to the callback.

---

## hubport.get\_portState()

Returns the current state of the Yocto-hub port.

`def get_portState( )`

**Returns :**  
a value among `Y_PORTSTATE_OFF`, `Y_PORTSTATE_ON` and `Y_PORTSTATE_RUN` corresponding to the current state of the Yocto-hub port

On failure, throws an exception or returns `Y_PORTSTATE_INVALID`.

---

## hubport.get\_userData()

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

`def get_userData( )`

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**  
the object stored previously by the caller.

---

## hubport.isOnline()

Checks if the function is currently reachable, without raising any error.

**def isOnline( )**

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

**Returns :**

`true` if the function can be reached, and `false` otherwise

---

Checks if the function is currently reachable, without raising any error (asynchronous version).

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox Javascript VM that does not implement context switching during blocking I/O calls.

**Parameters :**

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the boolean result

**context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

---

## hubport.load()

Preloads the function cache with a specified validity duration.

**def load( msValidity )**

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

`YAPI_SUCCESS` when the call succeeds. On failure, throws an exception or returns a negative error code.

---

Preloads the function cache with a specified validity duration (asynchronous version).

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

**Parameters :**

**msValidity** an integer corresponding to the validity of the loaded function parameters, in milliseconds

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the error code (or `YAPI_SUCCESS`)

**context** caller-specific object that is passed as-is to the callback function

**Returns :**  
nothing : the result is provided to the callback.

---

## **hubport.nextHubPort()**

Continues the enumeration of Yocto-hub ports started using `yFirstHubPort()`.

**def nextHubPort()**

**Returns :**  
a pointer to a `YHubPort` object, corresponding to a Yocto-hub port currently online, or a `null` pointer if there are no more Yocto-hub ports to enumerate.

---

## **hubport.registerValueCallback()**

Registers the callback function that is invoked on every change of advertised value.

**def registerValueCallback( callback )**

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**  
**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

---

## **hubport.set\_enabled()**

Changes the activation of the Yocto-hub port.

**def set\_enabled( newval )**

If the port is enabled, the \* connected module will be powered. Otherwise, port power will be shut down.

**Parameters :**  
**newval** either `Y_ENABLED_FALSE` or `Y_ENABLED_TRUE`, according to the activation of the Yocto-hub port

**Returns :**  
`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **hubport.set\_logicalName()**

It is not possible to configure the logical name of a Yocto-hub port.

**def set\_logicalName( newval )**

The logical name is automatically set to the serial number of the connected module.

**Parameters :**

---

**newval** a string

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## hubport.set\_userdata()

Stores a user context provided as argument in the userData attribute of the function.

def **set\_userdata( data)**

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

## 3.11. Humidity function interface

The Yoctopuce application programming interface allows you to read an instant measure of the sensor, as well as the minimal and maximal values observed.

In order to use the functions described here, you should include:

```
from yocto_humidity import *
```

### Global functions

#### yFindHumidity(func)

Retrieves a humidity sensor for a given identifier.

#### yFirstHumidity()

Starts the enumeration of humidity sensors currently accessible.

### YHumidity methods

#### humidity→calibrateFromPoints(rawValues, refValues)

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

#### humidity→describe()

Returns a descriptive text that identifies the function.

#### humidity→get\_advertisedValue()

Returns the current value of the humidity sensor (no more than 6 characters).

#### humidity→get\_currentRawValue()

Returns the unrounded and uncalibrated raw value returned by the sensor.

#### humidity→get\_currentValue()

Returns the current measured value.

#### humidity→get\_errorMessage()

Returns the error message of the latest error with this function.

#### humidity→get\_errorType()

Returns the numerical error code of the latest error with this function.

#### humidity→get\_functionDescriptor()

Returns a unique identifier of type YFUN\_DESCR corresponding to the function.

#### humidity→get\_hardwareId()

Returns the unique hardware identifier of the function.

#### humidity→get\_highestValue()

Returns the maximal value observed.
<b>humidity→get_logicalName()</b> Returns the logical name of the humidity sensor.
<b>humidity→get_lowestValue()</b> Returns the minimal value observed.
<b>humidity→get_module()</b> Get the <code>YModule</code> object for the device on which the function is located.
<b>humidity→get_module_async(callback, context)</b> Get the <code>YModule</code> object for the device on which the function is located (asynchronous version).
<b>humidity→get_resolution()</b> Returns the resolution of the measured values.
<b>humidity→get_unit()</b> Returns the measuring unit for the measured value.
<b>humidity→get_userData()</b> Returns the value of the <code>userData</code> attribute, as previously stored using method <code>set_userData</code> .
<b>humidity→isOnline()</b> Checks if the function is currently reachable, without raising any error.
<b>humidity→isOnline_async(callback, context)</b> Checks if the function is currently reachable, without raising any error (asynchronous version).
<b>humidity→load(msValidity)</b> Preloads the function cache with a specified validity duration.
<b>humidity→load_async(msValidity, callback, context)</b> Preloads the function cache with a specified validity duration (asynchronous version).
<b>humidity→nextHumidity()</b> Continues the enumeration of humidity sensors started using <code>yFirstHumidity()</code> .
<b>humidity→registerValueCallback(callback)</b> Registers the callback function that is invoked on every change of advertised value.
<b>humidity→set_highestValue(newval)</b> Changes the recorded maximal value observed.
<b>humidity→set_logicalName(newval)</b> Changes the logical name of the humidity sensor.
<b>humidity→set_lowestValue(newval)</b> Changes the recorded minimal value observed.
<b>humidity→set_userData(data)</b> Stores a user context provided as argument in the <code>userData</code> attribute of the function.

## YHumidity.FindHumidity()

Retrieves a humidity sensor for a given identifier.

```
def FindHumidity( func)
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the humidity sensor is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YHumidity.isOnline()` to test if the humidity sensor is indeed online at a given time. In case of ambiguity when looking for a humidity sensor by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

**Parameters :**

**func** a string that uniquely characterizes the humidity sensor

**Returns :**

a `YHumidity` object allowing you to drive the humidity sensor.

---

## **YHumidity.FirstHumidity()**

Starts the enumeration of humidity sensors currently accessible.

def **FirstHumidity**( )

Use the method `YHumidity.nextHumidity()` to iterate on next humidity sensors.

**Returns :**

a pointer to a `YHumidity` object, corresponding to the first humidity sensor currently online, or a `null` pointer if there are none.

---

## **humidity.calibrateFromPoints()**

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

def **calibrateFromPoints**( **rawValues**, **refValues** )

It is possible to configure up to five correction points. Correction points must be provided in ascending order, and be in the range of the sensor. The device will automatically perform a lineat interpolation of the error correction between specified points. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

For more information on advanced capabilities to refine the calibration of sensors, please contact [support@yoctopuce.com](mailto:support@yoctopuce.com).

**Parameters :**

**rawValues** array of floating point numbers, corresponding to the raw values returned by the sensor for the correction points.

**refValues** array of floating point numbers, corresponding to the corrected values for the correction points.

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **humidity.describe()**

Returns a descriptive text that identifies the function.

def **describe**( )

The text always includes the class name, and may include as well either the logical name of the function or its hardware identifier.

**Returns :**

a string that describes the function

---

### **humidity.get\_advertisedValue()**

Returns the current value of the humidity sensor (no more than 6 characters).

`def get_advertisedValue( )`

**Returns :**

a string corresponding to the current value of the humidity sensor (no more than 6 characters)

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

---

### **humidity.get\_currentRawValue()**

Returns the unrounded and uncalibrated raw value returned by the sensor.

`def get_currentRawValue( )`

**Returns :**

a floating point number corresponding to the unrounded and uncalibrated raw value returned by the sensor

On failure, throws an exception or returns `Y_CURRENTRAWVALUE_INVALID`.

---

### **humidity.get\_currentValue()**

Returns the current measured value.

`def get_currentValue( )`

**Returns :**

a floating point number corresponding to the current measured value

On failure, throws an exception or returns `Y_CURRENTVALUE_INVALID`.

---

### **humidity.get\_errorMessage()**

Returns the error message of the latest error with this function.

`def get_errorMessage( )`

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using this function object

---

### **humidity.get\_errorType()**

Returns the numerical error code of the latest error with this function.

`def get_errorType( )`

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using this function object



---

## humidity.get\_humidityDescriptor()

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

```
def get_functionDescriptor( )
```

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`. If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

---

Returns the unique hardware identifier of the function.

The unique hardware identifier is made of the device serial number and of the hardware identifier of the function.

**Returns :**

a string that uniquely identifies the function On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

---

## humidity.get\_highestValue()

Returns the maximal value observed.

```
def get_highestValue( )
```

**Returns :**

a floating point number corresponding to the maximal value observed

On failure, throws an exception or returns `Y_HIGHESTVALUE_INVALID`.

---

## humidity.get\_logicalName()

Returns the logical name of the humidity sensor.

```
def get_logicalName( )
```

**Returns :**

a string corresponding to the logical name of the humidity sensor

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

---

## humidity.get\_lowestValue()

Returns the minimal value observed.

```
def get_lowestValue( )
```

**Returns :**

a floating point number corresponding to the minimal value observed

On failure, throws an exception or returns `Y_LOWESTVALUE_INVALID`.

---

## humidity.get\_module()

Get the `YModule` object for the device on which the function is located.

`def get_module( )`

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

**Returns :**  
an instance of `YModule`

---

Get the `YModule` object for the device on which the function is located (asynchronous version).

If the function cannot be located on any module, the returned `YModule` object does not show as on-line. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

**Parameters :**  
**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the requested `YModule` object  
**context** caller-specific object that is passed as-is to the callback function

**Returns :**  
nothing : the result is provided to the callback.

---

## **humidity.get\_resolution()**

Returns the resolution of the measured values.

`def get_resolution( )`

The resolution corresponds to the numerical precision of the values, which is not always the same as the actual precision of the sensor.

**Returns :**  
a floating point number corresponding to the resolution of the measured values

On failure, throws an exception or returns `Y_RESOLUTION_INVALID`.

---

## **humidity.get\_unit()**

Returns the measuring unit for the measured value.

`def get_unit( )`

**Returns :**  
a string corresponding to the measuring unit for the measured value

On failure, throws an exception or returns `Y_UNIT_INVALID`.

---

## **humidity.get\_userData()**

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

`def get_userData( )`

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

---

## humidity.isOnline()

Checks if the function is currently reachable, without raising any error.

**def isOnline( )**

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

**Returns :**

`true` if the function can be reached, and `false` otherwise

---

Checks if the function is currently reachable, without raising any error (asynchronous version).

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox Javascript VM that does not implement context switching during blocking I/O calls.

**Parameters :**

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the boolean result

**context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

---

## humidity.load()

Preloads the function cache with a specified validity duration.

**def load( msValidity )**

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

`YAPI_SUCCESS` when the call succeeds. On failure, throws an exception or returns a negative error code.

---

Preloads the function cache with a specified validity duration (asynchronous version).

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

**Parameters :**

- msValidity** an integer corresponding to the validity of the loaded function parameters, in milliseconds
- callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the error code (or `YAPI_SUCCESS`)
- context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

**humidity.nextHumidity()**

Continues the enumeration of humidity sensors started using `yFirstHumidity()`.

```
def nextHumidity( )
```

**Returns :**

a pointer to a `YHumidity` object, corresponding to a humidity sensor currently online, or a `null` pointer if there are no more humidity sensors to enumerate.

**humidity.registerValueCallback()**

Registers the callback function that is invoked on every change of advertised value.

```
def registerValueCallback( callback)
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

- callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

**humidity.set\_highestValue()**

Changes the recorded maximal value observed.

```
def set_highestValue( newval)
```

**Parameters :**

- newval** a floating point number corresponding to the recorded maximal value observed

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

**humidity.set\_logicalName()**

Changes the logical name of the humidity sensor.

```
def set_logicalName( newval)
```

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the humidity sensor

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## humidity.set\_lowestValue()

Changes the recorded minimal value observed.

def **set\_lowestValue**( **newval**)

**Parameters :**

**newval** a floating point number corresponding to the recorded minimal value observed

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## humidity.set\_userData()

Stores a user context provided as argument in the userData attribute of the function.

def **set\_userData**( **data**)

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

## 3.12. Led function interface

Yoctopuce application programming interface allows you not only to drive the intensity of the led, but also to have it blink at various preset frequencies.

In order to use the functions described here, you should include:

```
from yocto_led import *
```

### Global functions

**yFindLed**(**func**)

Retrieves a led for a given identifier.

**yFirstLed**()

Starts the enumeration of leds currently accessible.

### YLed methods

**led→describe**()

Returns a descriptive text that identifies the function.

**led→get\_advertisedValue**()

Returns the current value of the led (no more than 6 characters).

**led→get\_blinking**()

Returns the current led signaling mode.

**led→get\_errorMessage**()

Returns the error message of the latest error with this function.

**led→get\_errorType**()

Returns the numerical error code of the latest error with this function.
<b>led→get_functionDescriptor()</b> Returns a unique identifier of type <code>YFUN_DESCR</code> corresponding to the function.
<b>led→get_hardwareId()</b> Returns the unique hardware identifier of the function.
<b>led→get_logicalName()</b> Returns the logical name of the led.
<b>led→get_luminosity()</b> Returns the current led intensity (in per cent).
<b>led→get_module()</b> Get the <code>YModule</code> object for the device on which the function is located.
<b>led→get_module_async(callback, context)</b> Get the <code>YModule</code> object for the device on which the function is located (asynchronous version).
<b>led→get_power()</b> Returns the current led state.
<b>led→get_userData()</b> Returns the value of the <code>userData</code> attribute, as previously stored using method <code>set_userData</code> .
<b>led→isOnline()</b> Checks if the function is currently reachable, without raising any error.
<b>led→isOnline_async(callback, context)</b> Checks if the function is currently reachable, without raising any error (asynchronous version).
<b>led→load(msValidity)</b> Preloads the function cache with a specified validity duration.
<b>led→load_async(msValidity, callback, context)</b> Preloads the function cache with a specified validity duration (asynchronous version).
<b>led→nextLed()</b> Continues the enumeration of leds started using <code>yFirstLed()</code> .
<b>led→registerValueCallback(callback)</b> Registers the callback function that is invoked on every change of advertised value.
<b>led→set_blinking(newval)</b> Changes the current led signaling mode.
<b>led→set_logicalName(newval)</b> Changes the logical name of the led.
<b>led→set_luminosity(newval)</b> Changes the current led intensity (in per cent).
<b>led→set_power(newval)</b> Changes the state of the led.
<b>led→set_userData(data)</b> Stores a user context provided as argument in the <code>userData</code> attribute of the function.

## YLed.FindLed()

Retrieves a led for a given identifier.

def **FindLed**( **func**)

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the led is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YLed.isOnline()` to test if the led is indeed online at a given time. In case of ambiguity when looking for a led by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

**Parameters :**

**func** a string that uniquely characterizes the led

**Returns :**

a `YLed` object allowing you to drive the led.

---

## **YLed.FirstLed()**

Starts the enumeration of leds currently accessible.

def **FirstLed**( )

Use the method `YLed.nextLed()` to iterate on next leds.

**Returns :**

a pointer to a `YLed` object, corresponding to the first led currently online, or a `null` pointer if there are none.

---

## **led.describe()**

Returns a descriptive text that identifies the function.

def **describe**( )

The text always includes the class name, and may include as well either the logical name of the function or its hardware identifier.

**Returns :**

a string that describes the function

---

## **led.get\_advertisedValue()**

Returns the current value of the led (no more than 6 characters).

def **get\_advertisedValue**( )

**Returns :**

a string corresponding to the current value of the led (no more than 6 characters)

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

---

## **led.get\_blinking()**

Returns the current led signaling mode.

def **get\_blinking**( )

**Returns :**

a value among `Y_BLINKING_STILL`, `Y_BLINKING_RELAX`, `Y_BLINKING_AWARE`, `Y_BLINKING_RUN`, `Y_BLINKING_CALL` and `Y_BLINKING_PANIC` corresponding to the current led signaling mode

On failure, throws an exception or returns `Y_BLINKING_INVALID`.

---

**led.get\_errorMessage()**

Returns the error message of the latest error with this function.

`def get_errorMessage( )`

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using this function object

---

**led.get\_errorType()**

Returns the numerical error code of the latest error with this function.

`def get_errorType( )`

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using this function object

---

**led.get\_ledDescriptor()**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

`def get_functionDescriptor( )`

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`. If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

---

Returns the unique hardware identifier of the function.

The unique hardware identifier is made of the device serial number and of the hardware identifier of the function.

**Returns :**

a string that uniquely identifies the function On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

---

**led.get\_logicalName()**

Returns the logical name of the led.

`def get_logicalName( )`

**Returns :**

a string corresponding to the logical name of the led

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

---



---

## led.get\_luminosity()

Returns the current led intensity (in per cent).

```
def get_luminosity( )
```

**Returns :**

an integer corresponding to the current led intensity (in per cent)

On failure, throws an exception or returns `Y_LUMINOSITY_INVALID`.

---

## led.get\_module()

Get the `YModule` object for the device on which the function is located.

```
def get_module( )
```

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

**Returns :**

an instance of `YModule`

---

Get the `YModule` object for the device on which the function is located (asynchronous version).

If the function cannot be located on any module, the returned `YModule` object does not show as on-line. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

**Parameters :**

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the requested `YModule` object

**context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

---

## led.get\_power()

Returns the current led state.

```
def get_power( )
```

**Returns :**

either `Y_POWER_OFF` or `Y_POWER_ON`, according to the current led state

On failure, throws an exception or returns `Y_POWER_INVALID`.

---

## led.get\_userData()

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

```
def get_userData( )
```

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**  
the object stored previously by the caller.

---

## led.isOnline()

Checks if the function is currently reachable, without raising any error.

**def isOnline( )**

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

**Returns :**  
`true` if the function can be reached, and `false` otherwise

---

Checks if the function is currently reachable, without raising any error (asynchronous version).

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox Javascript VM that does not implement context switching during blocking I/O calls.

**Parameters :**

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the boolean result

**context** caller-specific object that is passed as-is to the callback function

**Returns :**  
nothing : the result is provided to the callback.

---

## led.load()

Preloads the function cache with a specified validity duration.

**def load( msValidity )**

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**  
`YAPI_SUCCESS` when the call succeeds. On failure, throws an exception or returns a negative error code.

---

Preloads the function cache with a specified validity duration (asynchronous version).

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox

javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

**Parameters :**

- msValidity** an integer corresponding to the validity of the loaded function parameters, in milliseconds
- callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the error code (or `YAPI_SUCCESS`)
- context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

---

## led.nextLed()

Continues the enumeration of leds started using `yFirstLed()`.

def `nextLed()`

**Returns :**

a pointer to a `YLed` object, corresponding to a led currently online, or a `null` pointer if there are no more leds to enumerate.

---

## led.registerValueCallback()

Registers the callback function that is invoked on every change of advertised value.

def `registerValueCallback( callback )`

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

- callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

---

## led.set\_blinking()

Changes the current led signaling mode.

def `set_blinking( newval )`

**Parameters :**

- newval** a value among `Y_BLINKING_STILL`, `Y_BLINKING_RELAX`, `Y_BLINKING_AWARE`, `Y_BLINKING_RUN`, `Y_BLINKING_CALL` and `Y_BLINKING_PANIC` corresponding to the current led signaling mode

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## led.set\_logicalName()

Changes the logical name of the led.

def `set_logicalName( newval )`

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the led

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

### **led.set\_luminosity()**

Changes the current led intensity (in per cent).

```
def set_luminosity( newval)
```

**Parameters :**

**newval** an integer corresponding to the current led intensity (in per cent)

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

### **led.set\_power()**

Changes the state of the led.

```
def set_power( newval)
```

**Parameters :**

**newval** either `Y_POWER_OFF` or `Y_POWER_ON`, according to the state of the led

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

### **led.set\_userData()**

Stores a user context provided as argument in the `userData` attribute of the function.

```
def set_userData( data)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

## **3.13. LightSensor function interface**

The Yoctopuce application programming interface allows you to read an instant measure of the sensor, as well as the minimal and maximal values observed.

In order to use the functions described here, you should include:

```
from yocto_lightsensor import *
```

#### **Global functions**

```
yFindLightSensor(func)
```

Retrieves a light sensor for a given identifier.

#### **yFirstLightSensor()**

Starts the enumeration of light sensors currently accessible.

#### **YLightSensor methods**

##### **lightsensor→calibrate(calibratedVal)**

Changes the sensor-specific calibration parameter so that the current value matches a desired target (linear scaling).

##### **lightsensor→calibrateFromPoints(rawValues, refValues)**

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

##### **lightsensor→describe()**

Returns a descriptive text that identifies the function.

##### **lightsensor→get\_advertisedValue()**

Returns the current value of the light sensor (no more than 6 characters).

##### **lightsensor→get\_currentRawValue()**

Returns the unrounded and uncalibrated raw value returned by the sensor.

##### **lightsensor→get\_currentValue()**

Returns the current measured value.

##### **lightsensor→get\_errorMessage()**

Returns the error message of the latest error with this function.

##### **lightsensor→get\_errorType()**

Returns the numerical error code of the latest error with this function.

##### **lightsensor→get\_functionDescriptor()**

Returns a unique identifier of type YFUN\_DESCR corresponding to the function.

##### **lightsensor→get\_hardwareId()**

Returns the unique hardware identifier of the function.

##### **lightsensor→get\_highestValue()**

Returns the maximal value observed.

##### **lightsensor→get\_logicalName()**

Returns the logical name of the light sensor.

##### **lightsensor→get\_lowestValue()**

Returns the minimal value observed.

##### **lightsensor→get\_module()**

Get the YModule object for the device on which the function is located.

##### **lightsensor→get\_module\_async(callback, context)**

Get the YModule object for the device on which the function is located (asynchronous version).

##### **lightsensor→get\_resolution()**

Returns the resolution of the measured values.

##### **lightsensor→get\_unit()**

Returns the measuring unit for the measured value.

##### **lightsensor→get\_userData()**

Returns the value of the userData attribute, as previously stored using method set\_userData.

##### **lightsensor→isOnline()**

Checks if the function is currently reachable, without raising any error.

**lightsensor→isOnline\_async(callback, context)**

Checks if the function is currently reachable, without raising any error (asynchronous version).

**lightsensor→load(msValidity)**

Preloads the function cache with a specified validity duration.

**lightsensor→load\_async(msValidity, callback, context)**

Preloads the function cache with a specified validity duration (asynchronous version).

**lightsensor→nextLightSensor()**

Continues the enumeration of light sensors started using `yFirstLightSensor()`.

**lightsensor→registerValueCallback(callback)**

Registers the callback function that is invoked on every change of advertised value.

**lightsensor→set\_highestValue(newval)**

Changes the recorded maximal value observed.

**lightsensor→set\_logicalName(newval)**

Changes the logical name of the light sensor.

**lightsensor→set\_lowestValue(newval)**

Changes the recorded minimal value observed.

**lightsensor→set\_userData(data)**

Stores a user context provided as argument in the `userData` attribute of the function.

## YLightSensor.FindLightSensor()

Retrieves a light sensor for a given identifier.

**def FindLightSensor( func )**

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the light sensor is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YLightSensor.isOnline()` to test if the light sensor is indeed online at a given time. In case of ambiguity when looking for a light sensor by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

**Parameters :**

**func** a string that uniquely characterizes the light sensor

**Returns :**

a `YLightSensor` object allowing you to drive the light sensor.

## YLightSensor.FirstLightSensor()

Starts the enumeration of light sensors currently accessible.

**def FirstLightSensor( )**

Use the method `YLightSensor.nextLightSensor()` to iterate on next light sensors.

**Returns :**

a pointer to a `YLightSensor` object, corresponding to the first light sensor currently online, or a `null` pointer if there are none.

---

**lightsensor.calibrate()**

Changes the sensor-specific calibration parameter so that the current value matches a desired target (linear scaling).

**def** `calibrate( calibratedVal )`

**Parameters :**

**calibratedVal** the desired target value.

Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**lightsensor.calibrateFromPoints()**

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

**def** `calibrateFromPoints( rawValues, refValues )`

It is possible to configure up to five correction points. Correction points must be provided in ascending order, and be in the range of the sensor. The device will automatically perform a linear interpolation of the error correction between specified points. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

For more information on advanced capabilities to refine the calibration of sensors, please contact [support@yoctopuce.com](mailto:support@yoctopuce.com).

**Parameters :**

**rawValues** array of floating point numbers, corresponding to the raw values returned by the sensor for the correction points.

**refValues** array of floating point numbers, corresponding to the corrected values for the correction points.

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**lightsensor.describe()**

Returns a descriptive text that identifies the function.

**def** `describe( )`

The text always includes the class name, and may include as well either the logical name of the function or its hardware identifier.

**Returns :**

a string that describes the function

---

**lightsensor.get\_advertisedValue()**

Returns the current value of the light sensor (no more than 6 characters).

**def get\_advertisedValue( )**

**Returns :**

a string corresponding to the current value of the light sensor (no more than 6 characters)

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

---

**lightsensor.get\_currentRawValue()**

Returns the unrounded and uncalibrated raw value returned by the sensor.

**def get\_currentRawValue( )**

**Returns :**

a floating point number corresponding to the unrounded and uncalibrated raw value returned by the sensor

On failure, throws an exception or returns `Y_CURRENTRAWVALUE_INVALID`.

---

**lightsensor.get\_currentValue()**

Returns the current measured value.

**def get\_currentValue( )**

**Returns :**

a floating point number corresponding to the current measured value

On failure, throws an exception or returns `Y_CURRENTVALUE_INVALID`.

---

**lightsensor.get\_errorMessage()**

Returns the error message of the latest error with this function.

**def get\_errorMessage( )**

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using this function object

---

**lightsensor.get\_errorType()**

Returns the numerical error code of the latest error with this function.

**def get\_errorType( )**

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using this function object

---

**lightsensor.get\_lightsensorDescriptor()**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

**def get\_functionDescriptor( )**

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**



an identifier of type `YFUN_DESCR`. If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

---

Returns the unique hardware identifier of the function.

The unique hardware identifier is made of the device serial number and of the hardware identifier of the function.

**Returns :**

a string that uniquely identifies the function On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

---

### **lightsensor.get\_highestValue()**

Returns the maximal value observed.

**def get\_highestValue( )**

**Returns :**

a floating point number corresponding to the maximal value observed

On failure, throws an exception or returns `Y_HIGHESTVALUE_INVALID`.

---

### **lightsensor.get\_logicalName()**

Returns the logical name of the light sensor.

**def get\_logicalName( )**

**Returns :**

a string corresponding to the logical name of the light sensor

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

---

### **lightsensor.get\_lowestValue()**

Returns the minimal value observed.

**def get\_lowestValue( )**

**Returns :**

a floating point number corresponding to the minimal value observed

On failure, throws an exception or returns `Y_LOWESTVALUE_INVALID`.

---

### **lightsensor.get\_module()**

Get the `YModule` object for the device on which the function is located.

**def get\_module( )**

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

**Returns :**

an instance of `YModule`

---

Get the `YModule` object for the device on which the function is located (asynchronous version).

---

If the function cannot be located on any module, the returned `YModule` object does not show as on-line. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

**Parameters :**

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the requested `YModule` object

**context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

---

## **lightsensor.get\_resolution()**

Returns the resolution of the measured values.

**def get\_resolution( )**

The resolution corresponds to the numerical precision of the values, which is not always the same as the actual precision of the sensor.

**Returns :**

a floating point number corresponding to the resolution of the measured values

On failure, throws an exception or returns `Y_RESOLUTION_INVALID`.

---

## **lightsensor.get\_unit()**

Returns the measuring unit for the measured value.

**def get\_unit( )**

**Returns :**

a string corresponding to the measuring unit for the measured value

On failure, throws an exception or returns `Y_UNIT_INVALID`.

---

## **lightsensor.get\_userData()**

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

**def get\_userData( )**

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

---

## **lightsensor.isOnline()**

Checks if the function is currently reachable, without raising any error.

**def isOnline( )**

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

**Returns :**

`true` if the function can be reached, and `false` otherwise

---

Checks if the function is currently reachable, without raising any error (asynchronous version).

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox Javascript VM that does not implement context switching during blocking I/O calls.

**Parameters :**

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the boolean result

**context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

---

**lightsensor.load()**

Preloads the function cache with a specified validity duration.

**def load( msValidity )**

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

`YAPI_SUCCESS` when the call succeeds. On failure, throws an exception or returns a negative error code.

---

Preloads the function cache with a specified validity duration (asynchronous version).

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

**Parameters :**

**msValidity** an integer corresponding to the validity of the loaded function parameters, in milliseconds

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the error code (or `YAPI_SUCCESS`)

**context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

---

---

## lightsensor.nextLightSensor()

Continues the enumeration of light sensors started using `yFirstLightSensor()`.

def `nextLightSensor()`

**Returns :**

a pointer to a `YLightSensor` object, corresponding to a light sensor currently online, or a null pointer if there are no more light sensors to enumerate.

---

## lightsensor.registerValueCallback()

Registers the callback function that is invoked on every change of advertised value.

def `registerValueCallback( callback)`

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

---

## lightsensor.set\_highestValue()

Changes the recorded maximal value observed.

def `set_highestValue( newval)`

**Parameters :**

**newval** a floating point number corresponding to the recorded maximal value observed

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## lightsensor.set\_logicalName()

Changes the logical name of the light sensor.

def `set_logicalName( newval)`

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the light sensor

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## lightsensor.set\_lowestValue()

Changes the recorded minimal value observed.

```
def set_lowestValue( newval)
```

**Parameters :**

**newval** a floating point number corresponding to the recorded minimal value observed

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## lightsensor.set\_userData()

Stores a user context provided as argument in the userData attribute of the function.

```
def set_userData( data)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

## 3.14. Module control interface

This interface is identical for all Yoctopuce USB modules. It can be used to control the module global parameters, and to enumerate the functions provided by each module.

In order to use the functions described here, you should include:

```
from yocto_api import *
```

### Global functions

#### yFindModule(func)

Allows you to find a module from its serial number or from its logical name.

#### yFirstModule()

Starts the enumeration of modules currently accessible.

### YModule methods

#### module→describe()

Returns a descriptive text that identifies the module.

#### module→functionCount()

Returns the number of functions (beside the "module" interface) available on the module.

#### module→functionId(functionIndex)

Retrieves the hardware identifier of the *n*th function on the module.

#### module→functionName(functionIndex)

Retrieves the logical name of the *n*th function on the module.

#### module→functionValue(functionIndex)

Retrieves the advertised value of the *n*th function on the module.

#### module→get\_beacon()

Returns the state of the localization beacon.

#### module→get\_errorMessage()

Returns the error message of the last error with this module object.

#### module→get\_errorType()

Returns the numerical error code of the last error with this module object.

#### module→get\_firmwareRelease()

Returns the version of the firmware embedded in the module.
<b>module→get_functionDescriptor()</b> Returns a unique identifier of type <code>YFUN_DESCR</code> corresponding to the function.
<b>module→get_hardwareId()</b> Returns the unique hardware identifier of the module.
<b>module→get_icon2d()</b> Returns the icon of the module.
<b>module→get_logicalName()</b> Returns the logical name of the module.
<b>module→get_luminosity()</b> Returns the luminosity of the module informative leds (from 0 to 100).
<b>module→get_persistentSettings()</b> Returns the current state of persistent module settings.
<b>module→get_productId()</b> Returns the USB device identifier of the module.
<b>module→get_productName()</b> Returns the commercial name of the module, as set by the factory.
<b>module→get_productRelease()</b> Returns the hardware release version of the module.
<b>module→get_rebootCountdown()</b> Returns the remaining number of seconds before the module restarts, or zero when no reboot has been scheduled.
<b>module→get_serialNumber()</b> Returns the serial number of the module, as set by the factory.
<b>module→get_upTime()</b> Returns the number of milliseconds spent since the module was powered on.
<b>module→get_usbBandwidth()</b> Returns the number of USB interfaces used by the module.
<b>module→get_usbCurrent()</b> Returns the current consumed by the module on the USB bus, in milli-amps.
<b>module→get_userData()</b> Returns the value of the <code>userData</code> attribute, as previously stored using method <code>set_userData</code> .
<b>module→isOnline()</b> Checks if the module is currently reachable, without raising any error.
<b>module→isOnline_async(callback, context)</b> Checks if the module is currently reachable, without raising any error.
<b>module→load(msValidity)</b> Preloads the module cache with a specified validity duration.
<b>module→load_async(msValidity, callback, context)</b> Preloads the module cache with a specified validity duration (asynchronous version).
<b>module→nextModule()</b> Continues the module enumeration started using <code>yFirstModule()</code> .
<b>module→reboot(secBeforeReboot)</b>

Schedules a simple module reboot after the given number of seconds.

**module→revertFromFlash()**

Reloads the settings stored in the nonvolatile memory, as when the module is powered on.

**module→saveToFlash()**

Saves current settings in the nonvolatile memory of the module.

**module→set\_beacon(newval)**

Turns on or off the module localization beacon.

**module→set\_logicalName(newval)**

Changes the logical name of the module.

**module→set\_luminosity(newval)**

Changes the luminosity of the module informative leds.

**module→set\_usbBandwidth(newval)**

Changes the number of USB interfaces used by the module.

**module→set\_userData(data)**

Stores a user context provided as argument in the userData attribute of the function.

**module→triggerFirmwareUpdate(secBeforeReboot)**

Schedules a module reboot into special firmware update mode.

## **YModule.FindModule()**

Allows you to find a module from its serial number or from its logical name.

**def FindModule( func)**

This function does not require that the module is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YModule.isOnline()` to test if the module is indeed online at a given time. In case of ambiguity when looking for a module by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

**Parameters :**

**func** a string containing either the serial number or the logical name of the desired module

**Returns :**

a `YModule` object allowing you to drive the module or get additional information on the module.

## **YModule.FirstModule()**

Starts the enumeration of modules currently accessible.

**def FirstModule( )**

Use the method `YModule.nextModule()` to iterate on the next modules.

**Returns :**

a pointer to a `YModule` object, corresponding to the first module currently online, or a `null` pointer if there are none.

## **module.describe()**

Returns a descriptive text that identifies the module.

**def describe( )**

The text may include either the logical name or the serial number of the module.

**Returns :**

a string that describes the module

---

## **module.functionCount()**

Returns the number of functions (beside the "module" interface) available on the module.

def **functionCount**( )

**Returns :**

the number of functions on the module

On failure, throws an exception or returns a negative error code.

---

## **module.functionId()**

Retrieves the hardware identifier of the *n*th function on the module.

def **functionId**( **functionIndex**)

**Parameters :**

**functionIndex** the index of the function for which the information is desired, starting at 0 for the first function.

**Returns :**

a string corresponding to the unambiguous hardware identifier of the requested module function

On failure, throws an exception or returns an empty string.

---

## **module.functionName()**

Retrieves the logical name of the *n*th function on the module.

def **functionName**( **functionIndex**)

**Parameters :**

**functionIndex** the index of the function for which the information is desired, starting at 0 for the first function.

**Returns :**

a string corresponding to the logical name of the requested module function

On failure, throws an exception or returns an empty string.

---

## **module.functionValue()**

Retrieves the advertised value of the *n*th function on the module.

def **functionValue**( **functionIndex**)

**Parameters :**

**functionIndex** the index of the function for which the information is desired, starting at 0 for the first function.

**Returns :**

a short string (up to 6 characters) corresponding to the advertised value of the requested module function

On failure, throws an exception or returns an empty string.

---



---

## **module.get\_beacon()**

Returns the state of the localization beacon.

**def get\_beacon( )**

**Returns :**

either `Y_BEACON_OFF` or `Y_BEACON_ON`, according to the state of the localization beacon

On failure, throws an exception or returns `Y_BEACON_INVALID`.

---

## **module.get\_errorMessage()**

Returns the error message of the last error with this module object.

**def get\_errorMessage( )**

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the last error message that occurred while using this module object

---

## **module.getErrorType()**

Returns the numerical error code of the last error with this module object.

**def get\_errorType( )**

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the last error that occurred while using this module object

---

## **module.get\_firmwareRelease()**

Returns the version of the firmware embedded in the module.

**def get\_firmwareRelease( )**

**Returns :**

a string corresponding to the version of the firmware embedded in the module

On failure, throws an exception or returns `Y_FIRMWARERELEASE_INVALID`.

---

## **module.get\_moduleDescriptor()**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

**def get\_functionDescriptor( )**

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`. If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

---

Returns the unique hardware identifier of the module.

---

The unique hardware identifier is made of the device serial number followed by string ".module".

**Returns :**

a string that uniquely identifies the module

---

Returns the icon of the module.

The icon is a png image and does not exceeds 1024 bytes.

**Returns :**

a binary buffer with module icon, in png format.

---

### **module.get\_logicalName()**

Returns the logical name of the module.

**def get\_logicalName( )**

**Returns :**

a string corresponding to the logical name of the module

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

---

### **module.get\_luminosity()**

Returns the luminosity of the module informative leds (from 0 to 100).

**def get\_luminosity( )**

**Returns :**

an integer corresponding to the luminosity of the module informative leds (from 0 to 100)

On failure, throws an exception or returns `Y_LUMINOSITY_INVALID`.

---

### **module.get\_persistentSettings()**

Returns the current state of persistent module settings.

**def get\_persistentSettings( )**

**Returns :**

a value among `Y_PERSISTENTSETTINGS_LOADED`, `Y_PERSISTENTSETTINGS_SAVED` and `Y_PERSISTENTSETTINGS_MODIFIED` corresponding to the current state of persistent module settings

On failure, throws an exception or returns `Y_PERSISTENTSETTINGS_INVALID`.

---

### **module.get\_productId()**

Returns the USB device identifier of the module.

**def get\_productId( )**

**Returns :**

an integer corresponding to the USB device identifier of the module

On failure, throws an exception or returns `Y_PRODUCTID_INVALID`.

---

---

### **module.get\_productName()**

Returns the commercial name of the module, as set by the factory.

**def get\_productName( )**

**Returns :**

a string corresponding to the commercial name of the module, as set by the factory

On failure, throws an exception or returns Y\_PRODUCTNAME\_INVALID.

---

### **module.get\_productRelease()**

Returns the hardware release version of the module.

**def get\_productRelease( )**

**Returns :**

an integer corresponding to the hardware release version of the module

On failure, throws an exception or returns Y\_PRODUCTRELEASE\_INVALID.

---

### **module.get\_rebootCountdown()**

Returns the remaining number of seconds before the module restarts, or zero when no reboot has been scheduled.

**def get\_rebootCountdown( )**

**Returns :**

an integer corresponding to the remaining number of seconds before the module restarts, or zero when no reboot has been scheduled

On failure, throws an exception or returns Y\_REBOOTCOUNTDOWN\_INVALID.

---

### **module.get\_serialNumber()**

Returns the serial number of the module, as set by the factory.

**def get\_serialNumber( )**

**Returns :**

a string corresponding to the serial number of the module, as set by the factory

On failure, throws an exception or returns Y\_SERIALNUMBER\_INVALID.

---

### **module.get\_upTime()**

Returns the number of milliseconds spent since the module was powered on.

**def get\_upTime( )**

**Returns :**

an integer corresponding to the number of milliseconds spent since the module was powered on

On failure, throws an exception or returns Y\_UPTIME\_INVALID.

---

### **module.get\_usbBandwidth()**

Returns the number of USB interfaces used by the module.

**def get\_usbBandwidth( )**

**Returns :**

either `Y_USBBANDWIDTH_SIMPLE` or `Y_USBBANDWIDTH_DOUBLE`, according to the number of USB interfaces used by the module

On failure, throws an exception or returns `Y_USBBANDWIDTH_INVALID`.

---

**module.get\_usbCurrent()**

Returns the current consumed by the module on the USB bus, in milli-amps.

**def get\_usbCurrent( )**

**Returns :**

an integer corresponding to the current consumed by the module on the USB bus, in milli-amps

On failure, throws an exception or returns `Y_USBCURRENT_INVALID`.

---

**module.get\_userData()**

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

**def get\_userData( )**

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

---

**module.isOnline()**

Checks if the module is currently reachable, without raising any error.

**def isOnline( )**

If there are valid cached values for the module, that have not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the requested module.

**Returns :**

`true` if the module can be reached, and `false` otherwise

---

Checks if the module is currently reachable, without raising any error.

If there are valid cached values for the module, that have not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the requested module.

This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox Javascript VM that does not implement context switching during blocking I/O calls.

**Parameters :**

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving module object and the boolean result

**context** caller-specific object that is passed as-is to the callback function

**Returns :**

---

nothing : the result is provided to the callback.

---

## module.load()

Preloads the module cache with a specified validity duration.

def **load**( **msValidity** )

By default, whenever accessing a device, all module attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded module parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds. On failure, throws an exception or returns a negative error code.

---

Preloads the module cache with a specified validity duration (asynchronous version).

By default, whenever accessing a device, all module attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

**Parameters :**

**msValidity** an integer corresponding to the validity of the loaded module parameters, in milliseconds  
**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving module object and the error code (or YAPI\_SUCCESS)  
**context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

---

## module.nextModule()

Continues the module enumeration started using `yFirstModule()`.

def **nextModule**( )

**Returns :**

a pointer to a YModule object, corresponding to the next module found, or a null pointer if there are no more modules to enumerate.

---

## module.reboot()

Schedules a simple module reboot after the given number of seconds.

def **reboot**( **secBeforeReboot** )

**Parameters :**

**secBeforeReboot** number of seconds before rebooting

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **module.revertFromFlash()**

Reloads the settings stored in the nonvolatile memory, as when the module is powered on.

def **revertFromFlash**( )

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **module.saveToFlash()**

Saves current settings in the nonvolatile memory of the module.

def **saveToFlash**( )

Warning: the number of allowed save operations during a module life is limited (about 100000 cycles). Do not call this function within a loop.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **module.set\_beacon()**

Turns on or off the module localization beacon.

def **set\_beacon**( newval)

**Parameters :**

**newval** either Y\_BEACON\_OFF or Y\_BEACON\_ON

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **module.set\_logicalName()**

Changes the logical name of the module.

def **set\_logicalName**( newval)

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the module

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **module.set\_luminosity()**

Changes the luminosity of the module informative leds.

---

```
def set_luminosity( newval)
```

The parameter is a value between 0 and 100. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** an integer corresponding to the luminosity of the module informative leds

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **module.set\_usbBandwidth()**

Changes the number of USB interfaces used by the module.

```
def set_usbBandwidth( newval)
```

**Parameters :**

**newval** either `Y_USBBANDWIDTH_SIMPLE` or `Y_USBBANDWIDTH_DOUBLE`, according to the number of USB interfaces used by the module

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **module.set\_userData()**

Stores a user context provided as argument in the `userData` attribute of the function.

```
def set_userData( data)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

---

## **module.triggerFirmwareUpdate()**

Schedules a module reboot into special firmware update mode.

```
def triggerFirmwareUpdate( secBeforeReboot)
```

**Parameters :**

**secBeforeReboot** number of seconds before rebooting

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **3.15. Network function interface**

`YNetwork` objects provide access to TCP/IP parameters of Yoctopuce modules that include a built-in network interface.

In order to use the functions described here, you should include:

```
from yocto_network import *
```

## Global functions

### **yFindNetwork(func)**

Retrieves a network interface for a given identifier.

### **yFirstNetwork()**

Starts the enumeration of network interfaces currently accessible.

## YNetwork methods

### **network→callbackLogin(username, password)**

Connects to the notification callback and saves the credentials required to log in to it.

### **network→describe()**

Returns a descriptive text that identifies the function.

### **network→get\_adminPassword()**

Returns a hash string if a password has been set for user "admin", or an empty string otherwise.

### **network→get\_advertisedValue()**

Returns the current value of the network interface (no more than 6 characters).

### **network→get\_callbackCredentials()**

Returns a hashed version of the notification callback credentials if set, or an empty string otherwise.

### **network→get\_callbackMaxDelay()**

Returns the maximum wait time between two callback notifications, in seconds.

### **network→get\_callbackMinDelay()**

Returns the minimum wait time between two callback notifications, in seconds.

### **network→get\_callbackUrl()**

Returns the callback URL to notify of significant state changes.

### **network→get\_errorMessage()**

Returns the error message of the latest error with this function.

### **network→get\_errorType()**

Returns the numerical error code of the latest error with this function.

### **network→get\_functionDescriptor()**

Returns a unique identifier of type YFUN\_DESCR corresponding to the function.

### **network→get\_hardwareId()**

Returns the unique hardware identifier of the function.

### **network→get\_ipAddress()**

Returns the IP address currently in use by the device.

### **network→get\_logicalName()**

Returns the logical name of the network interface, corresponding to the network name of the module.

### **network→get\_macAddress()**

Returns the MAC address of the network interface.

### **network→get\_module()**

Get the YModule object for the device on which the function is located.

### **network→get\_module\_async(callback, context)**

Get the YModule object for the device on which the function is located (asynchronous version).

### **network→get\_primaryDNS()**

Returns the IP address of the primary name server to be used by the module.

### **network→get\_readiness()**



Returns the current established working mode of the network interface.
<b>network→get_router()</b> Returns the IP address of the router on the device subnet (default gateway).
<b>network→get_secondaryDNS()</b> Returns the IP address of the secondary name server to be used by the module.
<b>network→get_subnetMask()</b> Returns the subnet mask currently used by the device.
<b>network→get_userData()</b> Returns the value of the userData attribute, as previously stored using method <code>set_userData</code> .
<b>network→get_userPassword()</b> Returns a hash string if a password has been set for user "user", or an empty string otherwise.
<b>network→isOnline()</b> Checks if the function is currently reachable, without raising any error.
<b>network→isOnline_async(callback, context)</b> Checks if the function is currently reachable, without raising any error (asynchronous version).
<b>network→load(msValidity)</b> Preloads the function cache with a specified validity duration.
<b>network→load_async(msValidity, callback, context)</b> Preloads the function cache with a specified validity duration (asynchronous version).
<b>network→nextNetwork()</b> Continues the enumeration of network interfaces started using <code>yFirstNetwork()</code> .
<b>network→registerValueCallback(callback)</b> Registers the callback function that is invoked on every change of advertised value.
<b>network→set_adminPassword(newval)</b> Changes the password for the "admin" user.
<b>network→set_callbackCredentials(newval)</b> Changes the credentials required to connect to the callback address.
<b>network→set_callbackMaxDelay(newval)</b> Changes the maximum wait time between two callback notifications, in seconds.
<b>network→set_callbackMinDelay(newval)</b> Changes the minimum wait time between two callback notifications, in seconds.
<b>network→set_callbackUrl(newval)</b> Changes the callback URL to notify of significant state changes.
<b>network→set_logicalName(newval)</b> Changes the logical name of the network interface, corresponding to the network name of the module.
<b>network→set_primaryDNS(newval)</b> Changes the IP address of the primary name server to be used by the module.
<b>network→set_secondaryDNS(newval)</b> Changes the IP address of the secondary name server to be used by the module.
<b>network→set_userData(data)</b> Stores a user context provided as argument in the userData attribute of the function.
<b>network→set_userPassword(newval)</b>

Changes the password for the "user" user.

**network**→**useDHCP**(**fallbackIpAddr**, **fallbackSubnetMaskLen**, **fallbackRouter**)

Changes the configuration of the network interface to enable the use of an IP address received from a DHCP server.

**network**→**useStaticIP**(**ipAddress**, **subnetMaskLen**, **router**)

Changes the configuration of the network interface to use a static IP address.

---

## YNetwork.FindNetwork()

Retrieves a network interface for a given identifier.

def **FindNetwork**( **func**)

The identifier can be specified using several formats:

- `FunctionLogicalName`
- `ModuleSerialNumber.FunctionIdentifier`
- `ModuleSerialNumber.FunctionLogicalName`
- `ModuleLogicalName.FunctionIdentifier`
- `ModuleLogicalName.FunctionLogicalName`

This function does not require that the network interface is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YNetwork.isOnline()` to test if the network interface is indeed online at a given time. In case of ambiguity when looking for a network interface by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

### Parameters :

**func** a string that uniquely characterizes the network interface

### Returns :

a `YNetwork` object allowing you to drive the network interface.

---

## YNetwork.FirstNetwork()

Starts the enumeration of network interfaces currently accessible.

def **FirstNetwork**( )

Use the method `YNetwork.nextNetwork()` to iterate on next network interfaces.

### Returns :

a pointer to a `YNetwork` object, corresponding to the first network interface currently online, or a `null` pointer if there are none.

---

## network.callbackLogin()

Connects to the notification callback and saves the credentials required to log in to it.

def **callbackLogin**( **username**, **password**)

The password will not be stored into the module, only a hashed copy of the credentials will be saved. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

### Parameters :

**username** username required to log to the callback

**password** password required to log to the callback

### Returns :

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

### **network.describe()**

Returns a descriptive text that identifies the function.

**def describe( )**

The text always includes the class name, and may include as well either the logical name of the function or its hardware identifier.

**Returns :**

a string that describes the function

---

### **network.get\_adminPassword()**

Returns a hash string if a password has been set for user "admin", or an empty string otherwise.

**def get\_adminPassword( )**

**Returns :**

a string corresponding to a hash string if a password has been set for user "admin", or an empty string otherwise

On failure, throws an exception or returns Y\_ADMINPASSWORD\_INVALID.

---

### **network.get\_advertisedValue()**

Returns the current value of the network interface (no more than 6 characters).

**def get\_advertisedValue( )**

**Returns :**

a string corresponding to the current value of the network interface (no more than 6 characters)

On failure, throws an exception or returns Y\_ADVERTISEDVALUE\_INVALID.

---

### **network.get\_callbackCredentials()**

Returns a hashed version of the notification callback credentials if set, or an empty string otherwise.

**def get\_callbackCredentials( )**

**Returns :**

a string corresponding to a hashed version of the notification callback credentials if set, or an empty string otherwise

On failure, throws an exception or returns Y\_CALLBACKCREDENTIALS\_INVALID.

---

### **network.get\_callbackMaxDelay()**

Returns the maximum wait time between two callback notifications, in seconds.

**def get\_callbackMaxDelay( )**

**Returns :**

an integer corresponding to the maximum wait time between two callback notifications, in seconds

---

On failure, throws an exception or returns `Y_CALLBACKMAXDELAY_INVALID`.

---

### **network.get\_callbackMinDelay()**

Returns the minimum wait time between two callback notifications, in seconds.

**def get\_callbackMinDelay( )**

**Returns :**

an integer corresponding to the minimum wait time between two callback notifications, in seconds

On failure, throws an exception or returns `Y_CALLBACKMINDELAY_INVALID`.

---

### **network.get\_callbackUrl()**

Returns the callback URL to notify of significant state changes.

**def get\_callbackUrl( )**

**Returns :**

a string corresponding to the callback URL to notify of significant state changes

On failure, throws an exception or returns `Y_CALLBACKURL_INVALID`.

---

### **network.get\_errorMessage()**

Returns the error message of the latest error with this function.

**def get\_errorMessage( )**

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using this function object

---

### **network.get\_errorType()**

Returns the numerical error code of the latest error with this function.

**def get\_errorType( )**

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using this function object

---

### **network.get\_networkDescriptor()**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

**def get\_functionDescriptor( )**

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`. If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

Returns the unique hardware identifier of the function.

The unique hardware identifier is made of the device serial number and of the hardware identifier of the function.

**Returns :**

a string that uniquely identifies the function On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

---

## **network.get\_ipAddress()**

Returns the IP address currently in use by the device.

`def get_ipAddress( )`

The adress may have been configured statically, or provided by a DHCP server.

**Returns :**

a string corresponding to the IP address currently in use by the device

On failure, throws an exception or returns `Y_IPADDRESS_INVALID`.

---

## **network.get\_logicalName()**

Returns the logical name of the network interface, corresponding to the network name of the module.

`def get_logicalName( )`

**Returns :**

a string corresponding to the logical name of the network interface, corresponding to the network name of the module

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

---

## **network.get\_macAddress()**

Returns the MAC address of the network interface.

`def get_macAddress( )`

The MAC address is also available on a sticker on the module, in both numeric and barcode forms.

**Returns :**

a string corresponding to the MAC address of the network interface

On failure, throws an exception or returns `Y_MACADDRESS_INVALID`.

---

## **network.get\_module()**

Get the `YModule` object for the device on which the function is located.

`def get_module( )`

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

**Returns :**

an instance of `YModule`

---

Get the `YModule` object for the device on which the function is located (asynchronous version).

---

If the function cannot be located on any module, the returned `YModule` object does not show as on-line. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

**Parameters :**

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the requested `YModule` object

**context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

---

## **network.get\_primaryDNS()**

Returns the IP address of the primary name server to be used by the module.

**def get\_primaryDNS( )**

**Returns :**

a string corresponding to the IP address of the primary name server to be used by the module

On failure, throws an exception or returns `Y_PRIMARYDNS_INVALID`.

---

## **network.get\_readiness()**

Returns the current established working mode of the network interface.

**def get\_readiness( )**

Level zero (`DOWN_0`) means that no hardware link has been detected. Either there is no signal on the network cable, or the selected wireless access point cannot be detected. Level 1 (`LIVE_1`) is reached when the network is detected, but is not yet connected, For a wireless network, this shows that the requested SSID is present. Level 2 (`LINK_2`) is reached when the hardware connection is established. For a wired network connection, level 2 means that the cable is attached on both ends. For a connection to a wireless access point, it shows that the security parameters are properly configured. For an ad-hoc wireless connection, it means that there is at least one other device connected on the ad-hoc network. Level 3 (`DHCP_3`) is reached when an IP address has been obtained using DHCP. Level 4 (`DNS_4`) is reached when the DNS server is reachable on the network. Level 5 (`WWW_5`) is reached when global connectivity is demonstrated by properly loading current time from an NTP server.

**Returns :**

a value among `Y_READINESS_DOWN`, `Y_READINESS_EXISTS`, `Y_READINESS_LINKED`, `Y_READINESS_LAN_OK` and `Y_READINESS_WWW_OK` corresponding to the current established working mode of the network interface

On failure, throws an exception or returns `Y_READINESS_INVALID`.

---

## **network.get\_router()**

Returns the IP address of the router on the device subnet (default gateway).

**def get\_router( )**

**Returns :**

a string corresponding to the IP address of the router on the device subnet (default gateway)

On failure, throws an exception or returns `Y_ROUTER_INVALID`.

---

## **network.get\_secondaryDNS()**

Returns the IP address of the secondary name server to be used by the module.

**def get\_secondaryDNS( )**

**Returns :**

a string corresponding to the IP address of the secondary name server to be used by the module

On failure, throws an exception or returns `Y_SECONDARYDNS_INVALID`.

---

## **network.get\_subnetMask()**

Returns the subnet mask currently used by the device.

**def get\_subnetMask( )**

**Returns :**

a string corresponding to the subnet mask currently used by the device

On failure, throws an exception or returns `Y_SUBNETMASK_INVALID`.

---

## **network.getUserData()**

Returns the value of the `userData` attribute, as previously stored using method `set_userdata`.

**def getUserData( )**

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

---

## **network.getUserPassword()**

Returns a hash string if a password has been set for user "user", or an empty string otherwise.

**def getUserPassword( )**

**Returns :**

a string corresponding to a hash string if a password has been set for user "user", or an empty string otherwise

On failure, throws an exception or returns `Y_USERPASSWORD_INVALID`.

---

## **network.isOnline()**

Checks if the function is currently reachable, without raising any error.

**def isOnline( )**

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

**Returns :**

`true` if the function can be reached, and `false` otherwise

---

---

Checks if the function is currently reachable, without raising any error (asynchronous version).

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox Javascript VM that does not implement context switching during blocking I/O calls.

**Parameters :**

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the boolean result

**context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

---

## **network.load()**

Preloads the function cache with a specified validity duration.

**def load( msValidity )**

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds. On failure, throws an exception or returns a negative error code.

---

Preloads the function cache with a specified validity duration (asynchronous version).

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

**Parameters :**

**msValidity** an integer corresponding to the validity of the loaded function parameters, in milliseconds

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the error code (or YAPI\_SUCCESS)

**context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

---

## **network.nextNetwork()**

Continues the enumeration of network interfaces started using `yFirstNetwork()`.

---



def **nextNetwork**( )

**Returns :**

a pointer to a `YNetwork` object, corresponding to a network interface currently online, or a `null` pointer if there are no more network interfaces to enumerate.

---

## **network.registerValueCallback()**

Registers the callback function that is invoked on every change of advertised value.

def **registerValueCallback**( **callback** )

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

---

## **network.set\_adminPassword()**

Changes the password for the "admin" user.

def **set\_adminPassword**( **newval** )

This password becomes instantly required to perform any change of the module state. If the specified value is an empty string, a password is not required anymore. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the password for the "admin" user

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **network.set\_callbackCredentials()**

Changes the credentials required to connect to the callback address.

def **set\_callbackCredentials**( **newval** )

The credentials must be provided as returned by function `get_callbackCredentials`, in the form `username:hash`. The method used to compute the hash varies according to the authentication scheme implemented by the callback. For Basic authentication, the hash is the MD5 of the string `username:password`. For Digest authentication, the hash is the MD5 of the string `username:realm:password`. For a simpler way to configure callback credentials, use function `callbackLogin` instead. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the credentials required to connect to the callback address

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

---

## network.set\_callbackMaxDelay()

Changes the maximum wait time between two callback notifications, in seconds.

```
def set_callbackMaxDelay( newval)
```

**Parameters :**

**newval** an integer corresponding to the maximum wait time between two callback notifications, in seconds

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## network.set\_callbackMinDelay()

Changes the minimum wait time between two callback notifications, in seconds.

```
def set_callbackMinDelay( newval)
```

**Parameters :**

**newval** an integer corresponding to the minimum wait time between two callback notifications, in seconds

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## network.set\_callbackUrl()

Changes the callback URL to notify of significant state changes.

```
def set_callbackUrl( newval)
```

Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the callback URL to notify of significant state changes

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## network.set\_logicalName()

Changes the logical name of the network interface, corresponding to the network name of the module.

```
def set_logicalName( newval)
```

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the network interface, corresponding to the network name of the module

**Returns :**

---

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## network.set\_primaryDNS()

Changes the IP address of the primary name server to be used by the module.

```
def set_primaryDNS( newval)
```

When using DHCP, if a value is specified, it will override the value received from the DHCP server. Remember to call the `saveToFlash()` method and then to reboot the module to apply this setting.

### Parameters :

**newval** a string corresponding to the IP address of the primary name server to be used by the module

### Returns :

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## network.set\_secondaryDNS()

Changes the IP address of the secondary name server to be used by the module.

```
def set_secondaryDNS( newval)
```

When using DHCP, if a value is specified, it will override the value received from the DHCP server. Remember to call the `saveToFlash()` method and then to reboot the module to apply this setting.

### Parameters :

**newval** a string corresponding to the IP address of the secondary name server to be used by the module

### Returns :

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## network.set\_userData()

Stores a user context provided as argument in the `userData` attribute of the function.

```
def set_userData( data)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

### Parameters :

**data** any kind of object to be stored

---

## network.set\_userPassword()

Changes the password for the "user" user.

```
def set_userPassword( newval)
```

This password becomes instantly required to perform any use of the module. If the specified value is an empty string, a password is not required anymore. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

---

**Parameters :**

**newval** a string corresponding to the password for the "user" user

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**network.useDHCP()**

Changes the configuration of the network interface to enable the use of an IP address received from a DHCP server.

```
def useDHCP( fallbackIpAddr, fallbackSubnetMaskLen, fallbackRouter)
```

Until an address is received from a DHCP server, the module will use the IP parameters specified to this function. Remember to call the `saveToFlash()` method and then to reboot the module to apply this setting.

**Parameters :**

**fallbackIpAddr** fallback IP address, to be used when no DHCP reply is received  
**fallbackSubnetMaskLen** fallback subnet mask length when no DHCP reply is received, as an integer (eg. 24 means 255.255.255.0)  
**fallbackRouter** fallback router IP address, to be used when no DHCP reply is received

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**network.useStaticIP()**

Changes the configuration of the network interface to use a static IP address.

```
def useStaticIP( ipAddress, subnetMaskLen, router)
```

Remember to call the `saveToFlash()` method and then to reboot the module to apply this setting.

**Parameters :**

**ipAddress** device IP address  
**subnetMaskLen** subnet mask length, as an integer (eg. 24 means 255.255.255.0)  
**router** router IP address (default gateway)

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

## 3.16. Pressure function interface

The Yoctopuce application programming interface allows you to read an instant measure of the sensor, as well as the minimal and maximal values observed.

In order to use the functions described here, you should include:

```
from yocto_pressure import *
```

**Global functions****yFindPressure(func)**

Retrieves a pressure sensor for a given identifier.

**yFirstPressure()**

Starts the enumeration of pressure sensors currently accessible.

### **YPressure methods**

#### **pressure→calibrateFromPoints(rawValues, refValues)**

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

#### **pressure→describe()**

Returns a descriptive text that identifies the function.

#### **pressure→get\_advertisedValue()**

Returns the current value of the pressure sensor (no more than 6 characters).

#### **pressure→get\_currentRawValue()**

Returns the unrounded and uncalibrated raw value returned by the sensor.

#### **pressure→get\_currentValue()**

Returns the current measured value.

#### **pressure→get\_errorMessage()**

Returns the error message of the latest error with this function.

#### **pressure→get\_errorType()**

Returns the numerical error code of the latest error with this function.

#### **pressure→get\_functionDescriptor()**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

#### **pressure→get\_hardwareId()**

Returns the unique hardware identifier of the function.

#### **pressure→get\_highestValue()**

Returns the maximal value observed.

#### **pressure→get\_logicalName()**

Returns the logical name of the pressure sensor.

#### **pressure→get\_lowestValue()**

Returns the minimal value observed.

#### **pressure→get\_module()**

Get the `YModule` object for the device on which the function is located.

#### **pressure→get\_module\_async(callback, context)**

Get the `YModule` object for the device on which the function is located (asynchronous version).

#### **pressure→get\_resolution()**

Returns the resolution of the measured values.

#### **pressure→get\_unit()**

Returns the measuring unit for the measured value.

#### **pressure→get\_userData()**

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

#### **pressure→isOnline()**

Checks if the function is currently reachable, without raising any error.

#### **pressure→isOnline\_async(callback, context)**

Checks if the function is currently reachable, without raising any error (asynchronous version).

#### **pressure→load(msValidity)**

Preloads the function cache with a specified validity duration.

**pressure→load\_async(msValidity, callback, context)**

Preloads the function cache with a specified validity duration (asynchronous version).

**pressure→nextPressure()**

Continues the enumeration of pressure sensors started using `yFirstPressure()`.

**pressure→registerValueCallback(callback)**

Registers the callback function that is invoked on every change of advertised value.

**pressure→set\_highestValue(newval)**

Changes the recorded maximal value observed.

**pressure→set\_logicalName(newval)**

Changes the logical name of the pressure sensor.

**pressure→set\_lowestValue(newval)**

Changes the recorded minimal value observed.

**pressure→set\_userData(data)**

Stores a user context provided as argument in the `userData` attribute of the function.

## **YPressure.FindPressure()**

Retrieves a pressure sensor for a given identifier.

**def FindPressure( func)**

The identifier can be specified using several formats:

- `FunctionLogicalName`
- `ModuleSerialNumber.FunctionIdentifier`
- `ModuleSerialNumber.FunctionLogicalName`
- `ModuleLogicalName.FunctionIdentifier`
- `ModuleLogicalName.FunctionLogicalName`

This function does not require that the pressure sensor is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YPressure.isOnline()` to test if the pressure sensor is indeed online at a given time. In case of ambiguity when looking for a pressure sensor by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

### **Parameters :**

**func** a string that uniquely characterizes the pressure sensor

### **Returns :**

a `YPressure` object allowing you to drive the pressure sensor.

## **YPressure.FirstPressure()**

Starts the enumeration of pressure sensors currently accessible.

**def FirstPressure( )**

Use the method `YPressure.nextPressure()` to iterate on next pressure sensors.

### **Returns :**

a pointer to a `YPressure` object, corresponding to the first pressure sensor currently online, or a `null` pointer if there are none.

## **pressure.calibrateFromPoints()**

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

```
def calibrateFromPoints( rawValues, refValues)
```

It is possible to configure up to five correction points. Correction points must be provided in ascending order, and be in the range of the sensor. The device will automatically perform a lineat interpolation of the error correction between specified points. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

For more information on advanced capabilities to refine the calibration of sensors, please contact [support@yoctopuce.com](mailto:support@yoctopuce.com).

**Parameters :**

**rawValues** array of floating point numbers, corresponding to the raw values returned by the sensor for the correction points.

**refValues** array of floating point numbers, corresponding to the corrected values for the correction points.

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **pressure.describe()**

Returns a descriptive text that identifies the function.

```
def describe( )
```

The text always includes the class name, and may include as well either the logical name of the function or its hardware identifier.

**Returns :**

a string that describes the function

---

## **pressure.get\_advertisedValue()**

Returns the current value of the pressure sensor (no more than 6 characters).

```
def get_advertisedValue( )
```

**Returns :**

a string corresponding to the current value of the pressure sensor (no more than 6 characters)

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

---

## **pressure.get\_currentRawValue()**

Returns the unrounded and uncalibrated raw value returned by the sensor.

```
def get_currentRawValue( )
```

**Returns :**

a floating point number corresponding to the unrounded and uncalibrated raw value returned by the sensor

On failure, throws an exception or returns `Y_CURRENTRAWVALUE_INVALID`.

---

## **pressure.get\_currentValue()**

Returns the current measured value.

```
def get_currentValue( )
```

---

**Returns :**

a floating point number corresponding to the current measured value

On failure, throws an exception or returns `Y_CURRENTVALUE_INVALID`.

---

**pressure.get\_errorMessage()**

Returns the error message of the latest error with this function.

`def get_errorMessage( )`

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using this function object

---

**pressure.get\_errorType()**

Returns the numerical error code of the latest error with this function.

`def get_errorType( )`

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using this function object

---

**pressure.get\_pressureDescriptor()**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

`def get_functionDescriptor( )`

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`. If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

---

Returns the unique hardware identifier of the function.

The unique hardware identifier is made of the device serial number and of the hardware identifier of the function.

**Returns :**

a string that uniquely identifies the function On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

---

**pressure.get\_highestValue()**

Returns the maximal value observed.

`def get_highestValue( )`

**Returns :**

a floating point number corresponding to the maximal value observed

On failure, throws an exception or returns `Y_HIGHESTVALUE_INVALID`.

---



---

## **pressure.get\_logicalName()**

Returns the logical name of the pressure sensor.

**def get\_logicalName( )**

**Returns :**

a string corresponding to the logical name of the pressure sensor

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

---

## **pressure.get\_lowestValue()**

Returns the minimal value observed.

**def get\_lowestValue( )**

**Returns :**

a floating point number corresponding to the minimal value observed

On failure, throws an exception or returns `Y_LOWESTVALUE_INVALID`.

---

## **pressure.get\_module()**

Get the `YModule` object for the device on which the function is located.

**def get\_module( )**

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

**Returns :**

an instance of `YModule`

---

Get the `YModule` object for the device on which the function is located (asynchronous version).

If the function cannot be located on any module, the returned `YModule` object does not show as on-line. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

**Parameters :**

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the requested `YModule` object

**context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

---

## **pressure.get\_resolution()**

Returns the resolution of the measured values.

**def get\_resolution( )**

The resolution corresponds to the numerical precision of the values, which is not always the same as the actual precision of the sensor.

**Returns :**

a floating point number corresponding to the resolution of the measured values

On failure, throws an exception or returns `Y_RESOLUTION_INVALID`.

---

**pressure.get\_unit()**

Returns the measuring unit for the measured value.

```
def get_unit( )
```

**Returns :**

a string corresponding to the measuring unit for the measured value

On failure, throws an exception or returns `Y_UNIT_INVALID`.

---

**pressure.getUserData()**

Returns the value of the `userData` attribute, as previously stored using method `set_userdata`.

```
def getUserData( )
```

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

---

**pressure.isOnline()**

Checks if the function is currently reachable, without raising any error.

```
def isOnline( )
```

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

**Returns :**

`true` if the function can be reached, and `false` otherwise

---

Checks if the function is currently reachable, without raising any error (asynchronous version).

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox Javascript VM that does not implement context switching during blocking I/O calls.

**Parameters :**

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the boolean result

**context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

---

---

## pressure.load()

Preloads the function cache with a specified validity duration.

```
def load( msValidity)
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

### Parameters :

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

### Returns :

YAPI\_SUCCESS when the call succeeds. On failure, throws an exception or returns a negative error code.

---

Preloads the function cache with a specified validity duration (asynchronous version).

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

### Parameters :

**msValidity** an integer corresponding to the validity of the loaded function parameters, in milliseconds

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the error code (or YAPI\_SUCCESS)

**context** caller-specific object that is passed as-is to the callback function

### Returns :

nothing : the result is provided to the callback.

---

## pressure.nextPressure()

Continues the enumeration of pressure sensors started using yFirstPressure().

```
def nextPressure( )
```

### Returns :

a pointer to a YPressure object, corresponding to a pressure sensor currently online, or a null pointer if there are no more pressure sensors to enumerate.

---

## pressure.registerValueCallback()

Registers the callback function that is invoked on every change of advertised value.

```
def registerValueCallback( callback)
```

The callback is invoked only during the execution of ySleep or yHandleEvents. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

### Parameters :

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

---

## **pressure.set\_highestValue()**

Changes the recorded maximal value observed.

```
def set_highestValue( newval)
```

**Parameters :**

**newval** a floating point number corresponding to the recorded maximal value observed

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **pressure.set\_logicalName()**

Changes the logical name of the pressure sensor.

```
def set_logicalName( newval)
```

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the pressure sensor

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **pressure.set\_lowestValue()**

Changes the recorded minimal value observed.

```
def set_lowestValue( newval)
```

**Parameters :**

**newval** a floating point number corresponding to the recorded minimal value observed

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **pressure.set\_userData()**

Stores a user context provided as argument in the `userData` attribute of the function.

```
def set_userData( data)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

---

## 3.17. Relay function interface

The Yoctopuce application programming interface allows you to switch the relay state. This change is not persistent: the relay will automatically return to its idle position whenever power is lost or if the module is restarted. The library can also generate automatically short pulses of determined duration. On devices with two output for each relay (double throw), the two outputs are named A and B, with output A corresponding to the idle position (at power off) and the output B corresponding to the active state. If you prefer the alternate default state, simply switch your cables on the board.

In order to use the functions described here, you should include:

```
from yocto_relay import *
```

### Global functions

#### **yFindRelay(func)**

Retrieves a relay for a given identifier.

#### **yFirstRelay()**

Starts the enumeration of relays currently accessible.

### YRelay methods

#### **relay→describe()**

Returns a descriptive text that identifies the function.

#### **relay→get\_advertisedValue()**

Returns the current value of the relay (no more than 6 characters).

#### **relay→get\_errorMessage()**

Returns the error message of the latest error with this function.

#### **relay→get\_errorType()**

Returns the numerical error code of the latest error with this function.

#### **relay→get\_functionDescriptor()**

Returns a unique identifier of type YFUN\_DESCR corresponding to the function.

#### **relay→get\_hardwareId()**

Returns the unique hardware identifier of the function.

#### **relay→get\_logicalName()**

Returns the logical name of the relay.

#### **relay→get\_module()**

Get the YModule object for the device on which the function is located.

#### **relay→get\_module\_async(callback, context)**

Get the YModule object for the device on which the function is located (asynchronous version).

#### **relay→get\_output()**

Returns the output state of the relay, when used as a simple switch (single throw).

#### **relay→get\_pulseTimer()**

Returns the number of milliseconds remaining before the relay is returned to idle position (state A), during a measured pulse generation.

#### **relay→get\_state()**

Returns the state of the relay (A for the idle position, B for the active position).

#### **relay→get\_userData()**

Returns the value of the userData attribute, as previously stored using method set\_userData.

#### **relay→isOnline()**

Checks if the function is currently reachable, without raising any error.

<b>relay→isOnline_async(callback, context)</b>
Checks if the function is currently reachable, without raising any error (asynchronous version).
<b>relay→load(msValidity)</b>
Preloads the function cache with a specified validity duration.
<b>relay→load_async(msValidity, callback, context)</b>
Preloads the function cache with a specified validity duration (asynchronous version).
<b>relay→nextRelay()</b>
Continues the enumeration of relays started using <code>yFirstRelay()</code> .
<b>relay→pulse(ms_duration)</b>
Sets the relay to output B (active) for a specified duration, then brings it automatically back to output A (idle state).
<b>relay→registerValueCallback(callback)</b>
Registers the callback function that is invoked on every change of advertised value.
<b>relay→set_logicalName(newval)</b>
Changes the logical name of the relay.
<b>relay→set_output(newval)</b>
Changes the output state of the relay, when used as a simple switch (single throw).
<b>relay→set_state(newval)</b>
Changes the state of the relay (A for the idle position, B for the active position).
<b>relay→set_userData(data)</b>
Stores a user context provided as argument in the <code>userData</code> attribute of the function.

## YRelay.FindRelay()

Retrieves a relay for a given identifier.

```
def FindRelay( func)
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the relay is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YRelay.isOnline()` to test if the relay is indeed online at a given time. In case of ambiguity when looking for a relay by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

### Parameters :

**func** a string that uniquely characterizes the relay

### Returns :

a `YRelay` object allowing you to drive the relay.

## YRelay.FirstRelay()

Starts the enumeration of relays currently accessible.

```
def FirstRelay( )
```

Use the method `YRelay.nextRelay()` to iterate on next relays.

**Returns :**

a pointer to a `YRelay` object, corresponding to the first relay currently online, or a `null` pointer if there are none.

---

## **relay.describe()**

Returns a descriptive text that identifies the function.

**def describe( )**

The text always includes the class name, and may include as well either the logical name of the function or its hardware identifier.

**Returns :**

a string that describes the function

---

## **relay.get\_advertisedValue()**

Returns the current value of the relay (no more than 6 characters).

**def get\_advertisedValue( )**

**Returns :**

a string corresponding to the current value of the relay (no more than 6 characters)

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

---

## **relay.get\_errorMessage()**

Returns the error message of the latest error with this function.

**def get\_errorMessage( )**

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using this function object

---

## **relay.get\_errorType()**

Returns the numerical error code of the latest error with this function.

**def get\_errorType( )**

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using this function object

---

## **relay.get\_relayDescriptor()**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

**def get\_functionDescriptor( )**

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`. If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

---

---

Returns the unique hardware identifier of the function.

The unique hardware identifier is made of the device serial number and of the hardware identifier of the function.

**Returns :**

a string that uniquely identifies the function On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

---

## **relay.get\_logicalName()**

Returns the logical name of the relay.

### **def get\_logicalName( )**

**Returns :**

a string corresponding to the logical name of the relay

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

---

## **relay.get\_module()**

Get the `YModule` object for the device on which the function is located.

### **def get\_module( )**

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

**Returns :**

an instance of `YModule`

---

Get the `YModule` object for the device on which the function is located (asynchronous version).

If the function cannot be located on any module, the returned `YModule` object does not show as on-line. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

**Parameters :**

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the requested `YModule` object

**context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

---

## **relay.get\_output()**

Returns the output state of the relay, when used as a simple switch (single throw).

### **def get\_output( )**

**Returns :**

either `Y_OUTPUT_OFF` or `Y_OUTPUT_ON`, according to the output state of the relay, when used as a simple switch (single throw)

---



On failure, throws an exception or returns `Y_OUTPUT_INVALID`.

---

### **relay.get\_pulseTimer()**

Returns the number of milliseconds remaining before the relay is returned to idle position (state A), during a measured pulse generation.

`def get_pulseTimer( )`

When there is no ongoing pulse, returns zero.

**Returns :**

an integer corresponding to the number of milliseconds remaining before the relay is returned to idle position (state A), during a measured pulse generation

On failure, throws an exception or returns `Y_PULSETIMER_INVALID`.

---

### **relay.get\_state()**

Returns the state of the relay (A for the idle position, B for the active position).

`def get_state( )`

**Returns :**

either `Y_STATE_A` or `Y_STATE_B`, according to the state of the relay (A for the idle position, B for the active position)

On failure, throws an exception or returns `Y_STATE_INVALID`.

---

### **relay.getUserData()**

Returns the value of the `userData` attribute, as previously stored using method `set_userdata`.

`def getUserData( )`

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

---

### **relay.isOnline()**

Checks if the function is currently reachable, without raising any error.

`def isOnline( )`

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

**Returns :**

`true` if the function can be reached, and `false` otherwise

---

Checks if the function is currently reachable, without raising any error (asynchronous version).

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox Javascript VM that does not implement context switching during blocking I/O calls.

**Parameters :**

- callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the boolean result
- context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

---

## relay.load()

Preloads the function cache with a specified validity duration.

**def load( msValidity )**

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

- msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds. On failure, throws an exception or returns a negative error code.

---

Preloads the function cache with a specified validity duration (asynchronous version).

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

**Parameters :**

- msValidity** an integer corresponding to the validity of the loaded function parameters, in milliseconds
- callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the error code (or YAPI\_SUCCESS)
- context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

---

## relay.nextRelay()

Continues the enumeration of relays started using `yFirstRelay()`.

**def nextRelay( )**

**Returns :**

a pointer to a YRelay object, corresponding to a relay currently online, or a null pointer if there are no more relays to enumerate.

---

## relay.pulse()

Sets the relay to output B (active) for a specified duration, then brings it automatically back to output A (idle state).

```
def pulse( ms_duration)
```

**Parameters :**

**ms\_duration** pulse duration, in milliseconds

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## relay.registerValueCallback()

Registers the callback function that is invoked on every change of advertised value.

```
def registerValueCallback( callback)
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

---

## relay.set\_logicalName()

Changes the logical name of the relay.

```
def set_logicalName( newval)
```

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the relay

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## relay.set\_output()

Changes the output state of the relay, when used as a simple switch (single throw).

```
def set_output( newval)
```

**Parameters :**

**newval** either `Y_OUTPUT_OFF` or `Y_OUTPUT_ON`, according to the output state of the relay, when used as a simple switch (single throw)

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

---

## relay.set\_state()

Changes the state of the relay (A for the idle position, B for the active position).

```
def set_state( newval)
```

### Parameters :

**newval** either Y\_STATE\_A or Y\_STATE\_B, according to the state of the relay (A for the idle position, B for the active position)

### Returns :

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## relay.set\_userdata()

Stores a user context provided as argument in the userData attribute of the function.

```
def set_userdata( data)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

### Parameters :

**data** any kind of object to be stored

## 3.18. Servo function interface

Yoctopuce application programming interface allows you not only to move a servo to a given position, but also to specify the time interval in which the move should be performed. This makes it possible to synchronize two servos involved in a same move.

In order to use the functions described here, you should include:

```
from yocto_servo import *
```

### Global functions

#### yFindServo(func)

Retrieves a servo for a given identifier.

#### yFirstServo()

Starts the enumeration of servos currently accessible.

### YServo methods

#### servo→describe()

Returns a descriptive text that identifies the function.

#### servo→get\_advertisedValue()

Returns the current value of the servo (no more than 6 characters).

#### servo→get\_errorMessage()

Returns the error message of the latest error with this function.

#### servo→get\_errorType()

Returns the numerical error code of the latest error with this function.

#### servo→get\_functionDescriptor()

Returns a unique identifier of type YFUN\_DESCR corresponding to the function.

#### servo→get\_hardwareId()

Returns the unique hardware identifier of the function.

#### servo→get\_logicalName()

Returns the logical name of the servo.
<b>servo→get_module()</b> Get the YModule object for the device on which the function is located.
<b>servo→get_module_async(callback, context)</b> Get the YModule object for the device on which the function is located (asynchronous version).
<b>servo→get_neutral()</b> Returns the duration in microseconds of a neutral pulse for the servo.
<b>servo→get_position()</b> Returns the current servo position.
<b>servo→get_range()</b> Returns the current range of use of the servo.
<b>servo→get_userData()</b> Returns the value of the userData attribute, as previously stored using method set_userData.
<b>servo→isOnline()</b> Checks if the function is currently reachable, without raising any error.
<b>servo→isOnline_async(callback, context)</b> Checks if the function is currently reachable, without raising any error (asynchronous version).
<b>servo→load(msValidity)</b> Preloads the function cache with a specified validity duration.
<b>servo→load_async(msValidity, callback, context)</b> Preloads the function cache with a specified validity duration (asynchronous version).
<b>servo→move(target, ms_duration)</b> Performs a smooth move at constant speed toward a given position.
<b>servo→nextServo()</b> Continues the enumeration of servos started using yFirstServo().
<b>servo→registerValueCallback(callback)</b> Registers the callback function that is invoked on every change of advertised value.
<b>servo→set_logicalName(newval)</b> Changes the logical name of the servo.
<b>servo→set_neutral(newval)</b> Changes the duration of the pulse corresponding to the neutral position of the servo.
<b>servo→set_position(newval)</b> Changes immediately the servo driving position.
<b>servo→set_range(newval)</b> Changes the range of use of the servo, specified in per cents.
<b>servo→set_userData(data)</b> Stores a user context provided as argument in the userData attribute of the function.

## YServo.FindServo()

Retrieves a servo for a given identifier.

def FindServo( func)

The identifier can be specified using several formats:

- `FunctionLogicalName`
- `ModuleSerialNumber.FunctionIdentifier`
- `ModuleSerialNumber.FunctionLogicalName`
- `ModuleLogicalName.FunctionIdentifier`
- `ModuleLogicalName.FunctionLogicalName`

This function does not require that the servo is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YServo.isOnline()` to test if the servo is indeed online at a given time. In case of ambiguity when looking for a servo by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

**Parameters :**

**func** a string that uniquely characterizes the servo

**Returns :**

a `YServo` object allowing you to drive the servo.

---

## **YServo.FirstServo()**

Starts the enumeration of servos currently accessible.

def **FirstServo**( )

Use the method `YServo.nextServo()` to iterate on next servos.

**Returns :**

a pointer to a `YServo` object, corresponding to the first servo currently online, or a `null` pointer if there are none.

---

## **servo.describe()**

Returns a descriptive text that identifies the function.

def **describe**( )

The text always includes the class name, and may include as well either the logical name of the function or its hardware identifier.

**Returns :**

a string that describes the function

---

## **servo.get\_advertisedValue()**

Returns the current value of the servo (no more than 6 characters).

def **get\_advertisedValue**( )

**Returns :**

a string corresponding to the current value of the servo (no more than 6 characters)

On failure, throws an exception or returns `Y__ADVERTISEDVALUE__INVALID`.

---

## **servo.get\_errorMessage()**

Returns the error message of the latest error with this function.

def **get\_errorMessage**( )

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

---

a string corresponding to the latest error message that occurred while using this function object

---

### **servo.get\_errorType()**

Returns the numerical error code of the latest error with this function.

**def get\_errorType( )**

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using this function object

---

### **servo.get\_servoDescriptor()**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

**def get\_functionDescriptor( )**

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`. If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

---

Returns the unique hardware identifier of the function.

The unique hardware identifier is made of the device serial number and of the hardware identifier of the function.

**Returns :**

a string that uniquely identifies the function. On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

---

### **servo.get\_logicalName()**

Returns the logical name of the servo.

**def get\_logicalName( )**

**Returns :**

a string corresponding to the logical name of the servo

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

---

### **servo.get\_module()**

Get the `YModule` object for the device on which the function is located.

**def get\_module( )**

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

**Returns :**

an instance of `YModule`

---

Get the `YModule` object for the device on which the function is located (asynchronous version).

If the function cannot be located on any module, the returned `YModule` object does not show as on-line. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

**Parameters :**

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the requested `YModule` object

**context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

---

## **servo.get\_neutral()**

Returns the duration in microseconds of a neutral pulse for the servo.

**def get\_neutral( )**

**Returns :**

an integer corresponding to the duration in microseconds of a neutral pulse for the servo

On failure, throws an exception or returns `Y_NEUTRAL_INVALID`.

---

## **servo.get\_position()**

Returns the current servo position.

**def get\_position( )**

**Returns :**

an integer corresponding to the current servo position

On failure, throws an exception or returns `Y_POSITION_INVALID`.

---

## **servo.get\_range()**

Returns the current range of use of the servo.

**def get\_range( )**

**Returns :**

an integer corresponding to the current range of use of the servo

On failure, throws an exception or returns `Y_RANGE_INVALID`.

---

## **servo.get\_userData()**

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

**def get\_userData( )**

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.



---

## **servo.isOnline()**

Checks if the function is currently reachable, without raising any error.

**def isOnline( )**

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

**Returns :**

`true` if the function can be reached, and `false` otherwise

---

Checks if the function is currently reachable, without raising any error (asynchronous version).

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox Javascript VM that does not implement context switching during blocking I/O calls.

**Parameters :**

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the boolean result

**context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

---

## **servo.load()**

Preloads the function cache with a specified validity duration.

**def load( msValidity )**

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

`YAPI_SUCCESS` when the call succeeds. On failure, throws an exception or returns a negative error code.

---

Preloads the function cache with a specified validity duration (asynchronous version).

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

**Parameters :**

**msValidity** an integer corresponding to the validity of the loaded function parameters, in milliseconds

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the error code (or `YAPI_SUCCESS`)

**context** caller-specific object that is passed as-is to the callback function

**Returns :**  
nothing : the result is provided to the callback.

---

## **servo.move()**

Performs a smooth move at constant speed toward a given position.

**def move( target, ms\_duration)**

**Parameters :**

**target** new position at the end of the move  
**ms\_duration** total duration of the move, in milliseconds

**Returns :**  
`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **servo.nextServo()**

Continues the enumeration of servos started using `yFirstServo()`.

**def nextServo( )**

**Returns :**  
a pointer to a `YServo` object, corresponding to a servo currently online, or a `null` pointer if there are no more servos to enumerate.

---

## **servo.registerValueCallback()**

Registers the callback function that is invoked on every change of advertised value.

**def registerValueCallback( callback)**

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

---

## **servo.set\_logicalName()**

Changes the logical name of the servo.

**def set\_logicalName( newval)**

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

---

**newval** a string corresponding to the logical name of the servo

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **servo.set\_neutral()**

Changes the duration of the pulse corresponding to the neutral position of the servo.

**def set\_neutral( newval)**

The duration is specified in microseconds, and the standard value is 1500 [us]. This setting makes it possible to shift the range of use of the servo. Be aware that using a range higher than what is supported by the servo is likely to damage the servo.

**Parameters :**

**newval** an integer corresponding to the duration of the pulse corresponding to the neutral position of the servo

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **servo.set\_position()**

Changes immediately the servo driving position.

**def set\_position( newval)**

**Parameters :**

**newval** an integer corresponding to immediately the servo driving position

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **servo.set\_range()**

Changes the range of use of the servo, specified in per cents.

**def set\_range( newval)**

A range of 100% corresponds to a standard control signal, that varies from 1 [ms] to 2 [ms], When using a servo that supports a double range, from 0.5 [ms] to 2.5 [ms], you can select a range of 200%. Be aware that using a range higher than what is supported by the servo is likely to damage the servo.

**Parameters :**

**newval** an integer corresponding to the range of use of the servo, specified in per cents

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **servo.set\_userdata()**

Stores a user context provided as argument in the userData attribute of the function.

---

```
def set_userData( data)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

## 3.19. Temperature function interface

The Yoctopuce application programming interface allows you to read an instant measure of the sensor, as well as the minimal and maximal values observed.

In order to use the functions described here, you should include:

```
from yocto_temperature import *
```

### Global functions

#### yFindTemperature(func)

Retrieves a temperature sensor for a given identifier.

#### yFirstTemperature()

Starts the enumeration of temperature sensors currently accessible.

### YTemperature methods

#### temperature→calibrateFromPoints(rawValues, refValues)

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

#### temperature→describe()

Returns a descriptive text that identifies the function.

#### temperature→get\_advertisedValue()

Returns the current value of the temperature sensor (no more than 6 characters).

#### temperature→get\_currentRawValue()

Returns the uncalibrated, unrounded raw value returned by the sensor.

#### temperature→get\_currentValue()

Returns the current measured value.

#### temperature→get\_errorMessage()

Returns the error message of the latest error with this function.

#### temperature→get\_errorType()

Returns the numerical error code of the latest error with this function.

#### temperature→get\_functionDescriptor()

Returns a unique identifier of type YFUN\_DESCR corresponding to the function.

#### temperature→get\_hardwareId()

Returns the unique hardware identifier of the function.

#### temperature→get\_highestValue()

Returns the maximal value observed.

#### temperature→get\_logicalName()

Returns the logical name of the temperature sensor.

#### temperature→get\_lowestValue()

Returns the minimal value observed.

#### temperature→get\_module()

Get the YModule object for the device on which the function is located.

<b>temperature→get_module_async(callback, context)</b>
Get the YModule object for the device on which the function is located (asynchronous version).
<b>temperature→get_resolution()</b>
Returns the resolution of the measured values.
<b>temperature→get_sensorType()</b>
Returns the temperature sensor type.
<b>temperature→get_unit()</b>
Returns the measuring unit for the measured value.
<b>temperature→get_userData()</b>
Returns the value of the userData attribute, as previously stored using method set_userData.
<b>temperature→isOnline()</b>
Checks if the function is currently reachable, without raising any error.
<b>temperature→isOnline_async(callback, context)</b>
Checks if the function is currently reachable, without raising any error (asynchronous version).
<b>temperature→load(msValidity)</b>
Preloads the function cache with a specified validity duration.
<b>temperature→load_async(msValidity, callback, context)</b>
Preloads the function cache with a specified validity duration (asynchronous version).
<b>temperature→nextTemperature()</b>
Continues the enumeration of temperature sensors started using yFirstTemperature().
<b>temperature→registerValueCallback(callback)</b>
Registers the callback function that is invoked on every change of advertised value.
<b>temperature→set_highestValue(newval)</b>
Changes the recorded maximal value observed.
<b>temperature→set_logicalName(newval)</b>
Changes the logical name of the temperature sensor.
<b>temperature→set_lowestValue(newval)</b>
Changes the recorded minimal value observed.
<b>temperature→set_sensorType(newval)</b>
Modify the temperature sensor type.
<b>temperature→set_userData(data)</b>
Stores a user context provided as argument in the userData attribute of the function.

## YTemperature.FindTemperature()

Retrieves a temperature sensor for a given identifier.

```
def FindTemperature( func)
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the temperature sensor is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YTemperature.isOnline()` to test if the temperature sensor is indeed online at a given time. In case of ambiguity when looking for a temperature sensor by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

**Parameters :**

**func** a string that uniquely characterizes the temperature sensor

**Returns :**

a `YTemperature` object allowing you to drive the temperature sensor.

---

## **YTemperature.FirstTemperature()**

Starts the enumeration of temperature sensors currently accessible.

**def FirstTemperature( )**

Use the method `YTemperature.nextTemperature()` to iterate on next temperature sensors.

**Returns :**

a pointer to a `YTemperature` object, corresponding to the first temperature sensor currently online, or a `null` pointer if there are none.

---

## **temperature.calibrateFromPoints()**

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

**def calibrateFromPoints( rawValues, refValues)**

It is possible to configure up to five correction points. Correction points must be provided in ascending order, and be in the range of the sensor. The device will automatically perform a linear interpolation of the error correction between specified points. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

For more information on advanced capabilities to refine the calibration of sensors, please contact [support@yoctopuce.com](mailto:support@yoctopuce.com).

**Parameters :**

**rawValues** array of floating point numbers, corresponding to the raw values returned by the sensor for the correction points.

**refValues** array of floating point numbers, corresponding to the corrected values for the correction points.

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **temperature.describe()**

Returns a descriptive text that identifies the function.

**def describe( )**

The text always includes the class name, and may include as well either the logical name of the function or its hardware identifier.

**Returns :**

a string that describes the function

---

### **temperature.get\_advertisedValue()**

Returns the current value of the temperature sensor (no more than 6 characters).

**def get\_advertisedValue( )**

**Returns :**

a string corresponding to the current value of the temperature sensor (no more than 6 characters)

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

---

### **temperature.get\_currentRawValue()**

Returns the uncalibrated, unrounded raw value returned by the sensor.

**def get\_currentRawValue( )**

**Returns :**

a floating point number corresponding to the uncalibrated, unrounded raw value returned by the sensor

On failure, throws an exception or returns `Y_CURRENTRAWVALUE_INVALID`.

---

### **temperature.get\_currentValue()**

Returns the current measured value.

**def get\_currentValue( )**

**Returns :**

a floating point number corresponding to the current measured value

On failure, throws an exception or returns `Y_CURRENTVALUE_INVALID`.

---

### **temperature.get\_errorMessage()**

Returns the error message of the latest error with this function.

**def get\_errorMessage( )**

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using this function object

---

### **temperature.get\_errorType()**

Returns the numerical error code of the latest error with this function.

**def get\_errorType( )**

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using this function object

---

### **temperature.get\_temperatureDescriptor()**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

---

**def get\_functionDescriptor( )**

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`. If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

---

Returns the unique hardware identifier of the function.

The unique hardware identifier is made of the device serial number and of the hardware identifier of the function.

**Returns :**

a string that uniquely identifies the function On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

---

**temperature.get\_highestValue()**

Returns the maximal value observed.

**def get\_highestValue( )**

**Returns :**

a floating point number corresponding to the maximal value observed

On failure, throws an exception or returns `Y_HIGHESTVALUE_INVALID`.

---

**temperature.get\_logicalName()**

Returns the logical name of the temperature sensor.

**def get\_logicalName( )**

**Returns :**

a string corresponding to the logical name of the temperature sensor

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

---

**temperature.get\_lowestValue()**

Returns the minimal value observed.

**def get\_lowestValue( )**

**Returns :**

a floating point number corresponding to the minimal value observed

On failure, throws an exception or returns `Y_LOWESTVALUE_INVALID`.

---

**temperature.get\_module()**

Get the `YModule` object for the device on which the function is located.

**def get\_module( )**

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

**Returns :**



an instance of `YModule`

---

Get the `YModule` object for the device on which the function is located (asynchronous version).

If the function cannot be located on any module, the returned `YModule` object does not show as on-line. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

**Parameters :**

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the requested `YModule` object

**context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

---

### **temperature.get\_resolution()**

Returns the resolution of the measured values.

**def get\_resolution( )**

The resolution corresponds to the numerical precision of the values, which is not always the same as the actual precision of the sensor.

**Returns :**

a floating point number corresponding to the resolution of the measured values

On failure, throws an exception or returns `Y_RESOLUTION_INVALID`.

---

### **temperature.get\_sensorType()**

Returns the temperature sensor type.

**def get\_sensorType( )**

**Returns :**

a value among `Y_SENSORTYPE_DIGITAL`, `Y_SENSORTYPE_TYPE_K`, `Y_SENSORTYPE_TYPE_E`, `Y_SENSORTYPE_TYPE_J`, `Y_SENSORTYPE_TYPE_N`, `Y_SENSORTYPE_TYPE_R`, `Y_SENSORTYPE_TYPE_S` and `Y_SENSORTYPE_TYPE_T` corresponding to the temperature sensor type

On failure, throws an exception or returns `Y_SENSORTYPE_INVALID`.

---

### **temperature.get\_unit()**

Returns the measuring unit for the measured value.

**def get\_unit( )**

**Returns :**

a string corresponding to the measuring unit for the measured value

On failure, throws an exception or returns `Y_UNIT_INVALID`.

---

---

## temperature.getUserData()

Returns the value of the `userData` attribute, as previously stored using method `set_userdata`.

```
def getUserData( )
```

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**  
the object stored previously by the caller.

---

## temperature.isOnline()

Checks if the function is currently reachable, without raising any error.

```
def isOnline( )
```

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

**Returns :**  
`true` if the function can be reached, and `false` otherwise

---

Checks if the function is currently reachable, without raising any error (asynchronous version).

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox Javascript VM that does not implement context switching during blocking I/O calls.

**Parameters :**  
**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the boolean result  
**context** caller-specific object that is passed as-is to the callback function

**Returns :**  
nothing : the result is provided to the callback.

---

## temperature.load()

Preloads the function cache with a specified validity duration.

```
def load( msValidity)
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**  
**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**  
`YAPI_SUCCESS` when the call succeeds. On failure, throws an exception or returns a negative error code.

---

Preloads the function cache with a specified validity duration (asynchronous version).

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

**Parameters :**

- msValidity** an integer corresponding to the validity of the loaded function parameters, in milliseconds
- callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the error code (or `YAPI_SUCCESS`)
- context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

---

## **temperature.nextTemperature()**

Continues the enumeration of temperature sensors started using `yFirstTemperature()`.

def **nextTemperature()**

**Returns :**

a pointer to a `YTemperature` object, corresponding to a temperature sensor currently online, or a null pointer if there are no more temperature sensors to enumerate.

---

## **temperature.registerValueCallback()**

Registers the callback function that is invoked on every change of advertised value.

def **registerValueCallback( callback)**

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

- callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

---

## **temperature.set\_highestValue()**

Changes the recorded maximal value observed.

def **set\_highestValue( newval)**

**Parameters :**

- newval** a floating point number corresponding to the recorded maximal value observed

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## temperature.set\_logicalName()

Changes the logical name of the temperature sensor.

```
def set_logicalName( newval)
```

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

### Parameters :

**newval** a string corresponding to the logical name of the temperature sensor

### Returns :

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## temperature.set\_lowestValue()

Changes the recorded minimal value observed.

```
def set_lowestValue( newval)
```

### Parameters :

**newval** a floating point number corresponding to the recorded minimal value observed

### Returns :

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## temperature.set\_sensorType()

Modify the temperature sensor type.

```
def set_sensorType( newval)
```

This function is used to to define the type of thermo couple (K,E...) used with the device. This will have no effect if module is using a digital sensor. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

### Parameters :

**newval** a value among Y\_SENSORTYPE\_DIGITAL, Y\_SENSORTYPE\_TYPE\_K,  
Y\_SENSORTYPE\_TYPE\_E, Y\_SENSORTYPE\_TYPE\_J,  
Y\_SENSORTYPE\_TYPE\_N, Y\_SENSORTYPE\_TYPE\_R,  
Y\_SENSORTYPE\_TYPE\_S and Y\_SENSORTYPE\_TYPE\_T

### Returns :

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## temperature.set\_userData()

Stores a user context provided as argument in the userData attribute of the function.

```
def set_userData( data)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

### Parameters :

**data** any kind of object to be stored

## 3.20. Voltage function interface

The Yoctopuce application programming interface allows you to read an instant measure of the sensor, as well as the minimal and maximal values observed.

In order to use the functions described here, you should include:

```
from yocto_voltage import *
```

Global functions	
<b>yFindVoltage(func)</b>	Retrieves a voltage sensor for a given identifier.
<b>yFirstVoltage()</b>	Starts the enumeration of voltage sensors currently accessible.
YVoltage methods	
<b>voltage→calibrateFromPoints(rawValues, refValues)</b>	Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.
<b>voltage→describe()</b>	Returns a descriptive text that identifies the function.
<b>voltage→get_advertisedValue()</b>	Returns the current value of the voltage sensor (no more than 6 characters).
<b>voltage→get_currentRawValue()</b>	Returns the uncalibrated, unrounded raw value returned by the sensor.
<b>voltage→get_currentValue()</b>	Returns the current measured value.
<b>voltage→get_errorMessage()</b>	Returns the error message of the latest error with this function.
<b>voltage→get_errorType()</b>	Returns the numerical error code of the latest error with this function.
<b>voltage→get_functionDescriptor()</b>	Returns a unique identifier of type YFUN_DESCR corresponding to the function.
<b>voltage→get_hardwareId()</b>	Returns the unique hardware identifier of the function.
<b>voltage→get_highestValue()</b>	Returns the maximal value observed.
<b>voltage→get_logicalName()</b>	Returns the logical name of the voltage sensor.
<b>voltage→get_lowestValue()</b>	Returns the minimal value observed.
<b>voltage→get_module()</b>	Get the YModule object for the device on which the function is located.
<b>voltage→get_module_async(callback, context)</b>	Get the YModule object for the device on which the function is located (asynchronous version).
<b>voltage→get_resolution()</b>	

Returns the resolution of the measured values.
<b>voltage→get_unit()</b> Returns the measuring unit for the measured value.
<b>voltage→get_userData()</b> Returns the value of the userData attribute, as previously stored using method <code>set_userData</code> .
<b>voltage→isOnline()</b> Checks if the function is currently reachable, without raising any error.
<b>voltage→isOnline_async(callback, context)</b> Checks if the function is currently reachable, without raising any error (asynchronous version).
<b>voltage→load(msValidity)</b> Preloads the function cache with a specified validity duration.
<b>voltage→load_async(msValidity, callback, context)</b> Preloads the function cache with a specified validity duration (asynchronous version).
<b>voltage→nextVoltage()</b> Continues the enumeration of voltage sensors started using <code>yFirstVoltage()</code> .
<b>voltage→registerValueCallback(callback)</b> Registers the callback function that is invoked on every change of advertised value.
<b>voltage→set_highestValue(newval)</b> Changes the recorded maximal value observed.
<b>voltage→set_logicalName(newval)</b> Changes the logical name of the voltage sensor.
<b>voltage→set_lowestValue(newval)</b> Changes the recorded minimal value observed.
<b>voltage→set_userData(data)</b> Stores a user context provided as argument in the userData attribute of the function.

## YVoltage.FindVoltage()

Retrieves a voltage sensor for a given identifier.

**def FindVoltage( func)**

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the voltage sensor is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YVoltage.isOnline()` to test if the voltage sensor is indeed online at a given time. In case of ambiguity when looking for a voltage sensor by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

### Parameters :

**func** a string that uniquely characterizes the voltage sensor

### Returns :

a `YVoltage` object allowing you to drive the voltage sensor.

---

## YVoltage.FirstVoltage()

Starts the enumeration of voltage sensors currently accessible.

def **FirstVoltage**( )

Use the method `YVoltage.nextVoltage()` to iterate on next voltage sensors.

**Returns :**

a pointer to a `YVoltage` object, corresponding to the first voltage sensor currently online, or a `null` pointer if there are none.

---

## voltage.calibrateFromPoints()

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

def **calibrateFromPoints**( **rawValues**, **refValues**)

It is possible to configure up to five correction points. Correction points must be provided in ascending order, and be in the range of the sensor. The device will automatically perform a linear interpolation of the error correction between specified points. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

For more information on advanced capabilities to refine the calibration of sensors, please contact [support@yoctopuce.com](mailto:support@yoctopuce.com).

**Parameters :**

**rawValues** array of floating point numbers, corresponding to the raw values returned by the sensor for the correction points.

**refValues** array of floating point numbers, corresponding to the corrected values for the correction points.

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## voltage.describe()

Returns a descriptive text that identifies the function.

def **describe**( )

The text always includes the class name, and may include as well either the logical name of the function or its hardware identifier.

**Returns :**

a string that describes the function

---

## voltage.get\_advertisedValue()

Returns the current value of the voltage sensor (no more than 6 characters).

def **get\_advertisedValue**( )

**Returns :**

a string corresponding to the current value of the voltage sensor (no more than 6 characters)

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

---

## **voltage.get\_currentRawValue()**

Returns the uncalibrated, unrounded raw value returned by the sensor.

**def get\_currentRawValue( )**

**Returns :**

a floating point number corresponding to the uncalibrated, unrounded raw value returned by the sensor

On failure, throws an exception or returns `Y_CURRENTRAWVALUE_INVALID`.

---

## **voltage.get\_currentValue()**

Returns the current measured value.

**def get\_currentValue( )**

**Returns :**

a floating point number corresponding to the current measured value

On failure, throws an exception or returns `Y_CURRENTVALUE_INVALID`.

---

## **voltage.get\_errorMessage()**

Returns the error message of the latest error with this function.

**def get\_errorMessage( )**

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using this function object

---

## **voltage.get\_errorType()**

Returns the numerical error code of the latest error with this function.

**def get\_errorType( )**

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using this function object

---

## **voltage.get\_voltageDescriptor()**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

**def get\_functionDescriptor( )**

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`. If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

Returns the unique hardware identifier of the function.



The unique hardware identifier is made of the device serial number and of the hardware identifier of the function.

**Returns :**

a string that uniquely identifies the function On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

---

**voltage.get\_highestValue()**

Returns the maximal value observed.

`def get_highestValue( )`

**Returns :**

a floating point number corresponding to the maximal value observed

On failure, throws an exception or returns `Y_HIGHESTVALUE_INVALID`.

---

**voltage.get\_logicalName()**

Returns the logical name of the voltage sensor.

`def get_logicalName( )`

**Returns :**

a string corresponding to the logical name of the voltage sensor

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

---

**voltage.get\_lowestValue()**

Returns the minimal value observed.

`def get_lowestValue( )`

**Returns :**

a floating point number corresponding to the minimal value observed

On failure, throws an exception or returns `Y_LOWESTVALUE_INVALID`.

---

**voltage.get\_module()**

Get the `YModule` object for the device on which the function is located.

`def get_module( )`

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

**Returns :**

an instance of `YModule`

---

Get the `YModule` object for the device on which the function is located (asynchronous version).

If the function cannot be located on any module, the returned `YModule` object does not show as on-line. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

**Parameters :**

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the requested `YModule` object

**context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

---

## **voltage.get\_resolution()**

Returns the resolution of the measured values.

**def get\_resolution( )**

The resolution corresponds to the numerical precision of the values, which is not always the same as the actual precision of the sensor.

**Returns :**

a floating point number corresponding to the resolution of the measured values

On failure, throws an exception or returns `Y_RESOLUTION_INVALID`.

---

## **voltage.get\_unit()**

Returns the measuring unit for the measured value.

**def get\_unit( )**

**Returns :**

a string corresponding to the measuring unit for the measured value

On failure, throws an exception or returns `Y_UNIT_INVALID`.

---

## **voltage.getUserData()**

Returns the value of the `userData` attribute, as previously stored using method `set_userdata`.

**def getUserData( )**

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

---

## **voltage.isOnline()**

Checks if the function is currently reachable, without raising any error.

**def isOnline( )**

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

**Returns :**

`true` if the function can be reached, and `false` otherwise

---

Checks if the function is currently reachable, without raising any error (asynchronous version).

---

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox Javascript VM that does not implement context switching during blocking I/O calls.

**Parameters :**

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the boolean result

**context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

---

## **voltage.load()**

Preloads the function cache with a specified validity duration.

**def load( msValidity )**

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds. On failure, throws an exception or returns a negative error code.

---

Preloads the function cache with a specified validity duration (asynchronous version).

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

**Parameters :**

**msValidity** an integer corresponding to the validity of the loaded function parameters, in milliseconds

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the error code (or YAPI\_SUCCESS)

**context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

---

## **voltage.nextVoltage()**

Continues the enumeration of voltage sensors started using `yFirstVoltage()`.

**def nextVoltage( )**

**Returns :**

a pointer to a `YVoltage` object, corresponding to a voltage sensor currently online, or a `null` pointer if there are no more voltage sensors to enumerate.

---

## **voltage.registerValueCallback()**

Registers the callback function that is invoked on every change of advertised value.

```
def registerValueCallback( callback)
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

### **Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

---

## **voltage.set\_highestValue()**

Changes the recorded maximal value observed.

```
def set_highestValue( newval)
```

### **Parameters :**

**newval** a floating point number corresponding to the recorded maximal value observed

### **Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **voltage.set\_logicalName()**

Changes the logical name of the voltage sensor.

```
def set_logicalName( newval)
```

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

### **Parameters :**

**newval** a string corresponding to the logical name of the voltage sensor

### **Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **voltage.set\_lowestValue()**

Changes the recorded minimal value observed.

```
def set_lowestValue( newval)
```

### **Parameters :**

**newval** a floating point number corresponding to the recorded minimal value observed

### **Returns :**

`YAPI_SUCCESS` if the call succeeds.

---

On failure, throws an exception or returns a negative error code.

## **voltage.set\_userData()**

Stores a user context provided as argument in the userData attribute of the function.

```
def set_userData( data)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

## **3.21. Voltage source function interface**

Yoctopuce application programming interface allows you to control the module voltage output. You affect absolute output values or make transitions

In order to use the functions described here, you should include:

```
from yocto_vsource import *
```

### **Global functions**

**yFindVSource(func)**

Retrieves a voltage source for a given identifier.

**yFirstVSource()**

Starts the enumeration of voltage sources currently accessible.

### **YVSource methods**

**vsource→describe()**

Returns a descriptive text that identifies the function.

**vsource→get\_advertisedValue()**

Returns the current value of the voltage source (no more than 6 characters).

**vsource→get\_errorMessage()**

Returns the error message of the latest error with this function.

**vsource→get\_errorType()**

Returns the numerical error code of the latest error with this function.

**vsource→get\_extPowerFailure()**

Return true if external power supply voltage is too low.

**vsource→get\_failure()**

Return true if the module is in failure mode.

**vsource→get\_functionDescriptor()**

Returns a unique identifier of type YFUN\_DESCR corresponding to the function.

**vsource→get\_hardwareId()**

Returns the unique hardware identifier of the function.

**vsource→get\_logicalName()**

Returns the logical name of the voltage source.

**vsource→get\_module()**

Get the YModule object for the device on which the function is located.

**vsource→get\_module\_async(callback, context)**

Get the YModule object for the device on which the function is located (asynchronous version).

<b>vsourcesrc→get_overCurrent()</b>
Return true if the appliance connected to the device is too greedy .
<b>vsourcesrc→get_overHeat()</b>
Return TRUE if the module is overheating.
<b>vsourcesrc→get_overLoad()</b>
Return true if the device is not able to maintain the requested voltage output .
<b>vsourcesrc→get_regulationFailure()</b>
Return true if the voltage output is too high regarding the requested voltage .
<b>vsourcesrc→get_unit()</b>
Returns the measuring unit for the voltage.
<b>vsourcesrc→get_userData()</b>
Returns the value of the userData attribute, as previously stored using method <code>set_userData</code> .
<b>vsourcesrc→get_voltage()</b>
Returns the voltage output command (mV)
<b>vsourcesrc→isOnline()</b>
Checks if the function is currently reachable, without raising any error.
<b>vsourcesrc→isOnline_async(callback, context)</b>
Checks if the function is currently reachable, without raising any error (asynchronous version).
<b>vsourcesrc→load(msValidity)</b>
Preloads the function cache with a specified validity duration.
<b>vsourcesrc→load_async(msValidity, callback, context)</b>
Preloads the function cache with a specified validity duration (asynchronous version).
<b>vsourcesrc→nextVSource()</b>
Continues the enumeration of voltage sources started using <code>yFirstVSource()</code> .
<b>vsourcesrc→pulse(voltage, ms_duration)</b>
Sets device output to a specific voltage, for a specified duration, then brings it automatically to 0V.
<b>vsourcesrc→registerValueCallback(callback)</b>
Registers the callback function that is invoked on every change of advertised value.
<b>vsourcesrc→reset()</b>
Resets the device Output.
<b>vsourcesrc→set_logicalName(newval)</b>
Changes the logical name of the voltage source.
<b>vsourcesrc→set_userData(data)</b>
Stores a user context provided as argument in the userData attribute of the function.
<b>vsourcesrc→set_voltage(newval)</b>
Tunes the device output voltage (milliVolts).
<b>vsourcesrc→voltageMove(target, ms_duration)</b>
Performs a smooth move at constant speed toward a given value.

## YVSource.FindVSource()

Retrieves a voltage source for a given identifier.

```
def FindVSource( func)
```

The identifier can be specified using several formats:

- `FunctionLogicalName`
- `ModuleSerialNumber.FunctionIdentifier`
- `ModuleSerialNumber.FunctionLogicalName`
- `ModuleLogicalName.FunctionIdentifier`
- `ModuleLogicalName.FunctionLogicalName`

This function does not require that the voltage source is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YVSource.isOnline()` to test if the voltage source is indeed online at a given time. In case of ambiguity when looking for a voltage source by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

**Parameters :**

**func** a string that uniquely characterizes the voltage source

**Returns :**

a `YVSource` object allowing you to drive the voltage source.

---

## **`YVSource.FirstVSource()`**

Starts the enumeration of voltage sources currently accessible.

def **`FirstVSource()`** ( )

Use the method `YVSource.nextVSource()` to iterate on next voltage sources.

**Returns :**

a pointer to a `YVSource` object, corresponding to the first voltage source currently online, or a `null` pointer if there are none.

---

## **`vsource.describe()`**

Returns a descriptive text that identifies the function.

def **`describe()`** ( )

The text always includes the class name, and may include as well either the logical name of the function or its hardware identifier.

**Returns :**

a string that describes the function

---

## **`vsource.get_advertisedValue()`**

Returns the current value of the voltage source (no more than 6 characters).

def **`get_advertisedValue()`** ( )

**Returns :**

a string corresponding to the current value of the voltage source (no more than 6 characters)

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

---

## **`vsource.get_errorMessage()`**

Returns the error message of the latest error with this function.

def **`get_errorMessage()`** ( )

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using this function object

---

### **`vsource.get_errorType()`**

Returns the numerical error code of the latest error with this function.

**`def get_errorType( )`**

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using this function object

---

### **`vsource.get_extPowerFailure()`**

Return true if external power supply voltage is too low.

**`def get_extPowerFailure( )`**

**Returns :**

either `Y_EXTPOWERFAILURE_FALSE` or `Y_EXTPOWERFAILURE_TRUE`

On failure, throws an exception or returns `Y_EXTPOWERFAILURE_INVALID`.

---

### **`vsource.get_failure()`**

Return true if the module is in failure mode.

**`def get_failure( )`**

More information can be obtained by testing `get_overheat`, `get_overcurrent` etc... When a error condition is met, the output voltage is set to zéro and cannot be changed until the `reset()` function is called.

**Returns :**

either `Y_FAILURE_FALSE` or `Y_FAILURE_TRUE`

On failure, throws an exception or returns `Y_FAILURE_INVALID`.

---

### **`vsource.get_vsourceDescriptor()`**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

**`def get_functionDescriptor( )`**

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`. If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

---

Returns the unique hardware identifier of the function.

The unique hardware identifier is made of the device serial number and of the hardware identifier of the function.

**Returns :**

a string that uniquely identifies the function On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.



---

## **vsource.get\_logicalName()**

Returns the logical name of the voltage source.

**def get\_logicalName( )**

**Returns :**

a string corresponding to the logical name of the voltage source

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

---

## **vsource.get\_module()**

Get the `YModule` object for the device on which the function is located.

**def get\_module( )**

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

**Returns :**

an instance of `YModule`

---

Get the `YModule` object for the device on which the function is located (asynchronous version).

If the function cannot be located on any module, the returned `YModule` object does not show as on-line. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

**Parameters :**

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the requested `YModule` object

**context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

---

## **vsource.get\_overCurrent()**

Return true if the appliance connected to the device is too greedy .

**def get\_overCurrent( )**

**Returns :**

either `Y_OVERCURRENT_FALSE` or `Y_OVERCURRENT_TRUE`

On failure, throws an exception or returns `Y_OVERCURRENT_INVALID`.

---

## **vsource.get\_overHeat()**

Return TRUE if the module is overheating.

**def get\_overHeat( )**

**Returns :**

either `Y_OVERHEAT_FALSE` or `Y_OVERHEAT_TRUE`

On failure, throws an exception or returns `Y_OVERHEAT_INVALID`.

---

### **`vsource.get_overLoad()`**

Return true if the device is not able to maintain the requested voltage output .

**`def get_overLoad( )`**

**Returns :**

either `Y_OVERLOAD_FALSE` or `Y_OVERLOAD_TRUE`

On failure, throws an exception or returns `Y_OVERLOAD_INVALID`.

---

### **`vsource.get_regulationFailure()`**

Return true if the voltage output is too high regarding the requested voltage .

**`def get_regulationFailure( )`**

**Returns :**

either `Y_REGULATIONFAILURE_FALSE` or `Y_REGULATIONFAILURE_TRUE`

On failure, throws an exception or returns `Y_REGULATIONFAILURE_INVALID`.

---

### **`vsource.get_unit()`**

Returns the measuring unit for the voltage.

**`def get_unit( )`**

**Returns :**

a string corresponding to the measuring unit for the voltage

On failure, throws an exception or returns `Y_UNIT_INVALID`.

---

### **`vsource.get_userData()`**

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

**`def get_userData( )`**

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

---

### **`vsource.get_voltage()`**

Returns the voltage output command (mV)

**`def get_voltage( )`**

**Returns :**

an integer corresponding to the voltage output command (mV)

On failure, throws an exception or returns `Y_VOLTAGE_INVALID`.

---

### **`vsource.isOnline()`**

Checks if the function is currently reachable, without raising any error.

---

**def isOnline( )**

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

**Returns :**

`true` if the function can be reached, and `false` otherwise

---

Checks if the function is currently reachable, without raising any error (asynchronous version).

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox Javascript VM that does not implement context switching during blocking I/O calls.

**Parameters :**

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the boolean result

**context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

---

## **vsource.load()**

Preloads the function cache with a specified validity duration.

**def load( msValidity)**

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

`YAPI_SUCCESS` when the call succeeds. On failure, throws an exception or returns a negative error code.

---

Preloads the function cache with a specified validity duration (asynchronous version).

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

**Parameters :**

**msValidity** an integer corresponding to the validity of the loaded function parameters, in milliseconds

---

- callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the error code (or `YAPI_SUCCESS`)
- context** caller-specific object that is passed as-is to the callback function

**Returns :**  
nothing : the result is provided to the callback.

---

## **vsource.nextVSource()**

Continues the enumeration of voltage sources started using `yFirstVSource()`.

**def nextVSource( )**

**Returns :**  
a pointer to a `YVSource` object, corresponding to a voltage source currently online, or a `null` pointer if there are no more voltage sources to enumerate.

---

## **vsource.pulse()**

Sets device output to a specific voltage, for a specified duration, then brings it automatically to 0V.

**def pulse( voltage, ms\_duration)**

**Parameters :**  
**voltage** pulse voltage, in millivolts  
**ms\_duration** pulse duration, in milliseconds

**Returns :**  
`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **vsource.registerValueCallback()**

Registers the callback function that is invoked on every change of advertised value.

**def registerValueCallback( callback)**

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**  
**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

---

## **vsource.reset()**

Resets the device Output.

**def reset( )**

This function must be called after any error condition. After an error condition, voltage output will be set to none and cannot be changed until this function is called.

**Returns :**  
`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

---

## **vsource.set\_logicalName()**

Changes the logical name of the voltage source.

```
def set_logicalName( newval)
```

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

### **Parameters :**

**newval** a string corresponding to the logical name of the voltage source

### **Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **vsource.set\_userData()**

Stores a user context provided as argument in the `userData` attribute of the function.

```
def set_userData( data)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

### **Parameters :**

**data** any kind of object to be stored

---

## **vsource.set\_voltage()**

Tunes the device output voltage (milliVolts).

```
def set_voltage( newval)
```

### **Parameters :**

**newval** an integer

### **Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **vsource.voltageMove()**

Performs a smooth move at constant speed toward a given value.

```
def voltageMove( target, ms_duration)
```

### **Parameters :**

**target** new output value at end of transition, in milliVolts.

**ms\_duration** transition duration, in milliseconds

### **Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

## **3.22. Wireless function interface**

In order to use the functions described here, you should include:

from yocto\_wireless import \*

## Global functions

### yFindWireless(func)

Retrieves a wireless lan interface for a given identifier.

### yFirstWireless()

Starts the enumeration of wireless lan interfaces currently accessible.

## YWireless methods

### wireless→adhocNetwork(ssid, securityKey)

Changes the configuration of the wireless lan interface to create an ad-hoc wireless network, without using an access point.

### wireless→describe()

Returns a descriptive text that identifies the function.

### wireless→get\_advertisedValue()

Returns the current value of the wireless lan interface (no more than 6 characters).

### wireless→get\_channel()

Returns the 802.

### wireless→get\_errorMessage()

Returns the error message of the latest error with this function.

### wireless→get\_errorType()

Returns the numerical error code of the latest error with this function.

### wireless→get\_functionDescriptor()

Returns a unique identifier of type YFUN\_DESCR corresponding to the function.

### wireless→get\_hardwareId()

Returns the unique hardware identifier of the function.

### wireless→get\_linkQuality()

Returns the link quality, expressed in per cents.

### wireless→get\_logicalName()

Returns the logical name of the wireless lan interface.

### wireless→get\_module()

Get the YModule object for the device on which the function is located.

### wireless→get\_module\_async(callback, context)

Get the YModule object for the device on which the function is located (asynchronous version).

### wireless→get\_security()

Returns the security algorithm used by the selected wireless network.

### wireless→get\_ssid()

Returns the wireless network name (SSID).

### wireless→get\_userData()

Returns the value of the userData attribute, as previously stored using method set\_userData.

### wireless→isOnline()

Checks if the function is currently reachable, without raising any error.

### wireless→isOnline\_async(callback, context)

Checks if the function is currently reachable, without raising any error (asynchronous version).

### wireless→joinNetwork(ssid, securityKey)

Changes the configuration of the wireless lan interface to connect to an existing access point (infrastructure mode).

**wireless→load(msValidity)**

Preloads the function cache with a specified validity duration.

**wireless→load\_async(msValidity, callback, context)**

Preloads the function cache with a specified validity duration (asynchronous version).

**wireless→nextWireless()**

Continues the enumeration of wireless lan interfaces started using `yFirstWireless()`.

**wireless→registerValueCallback(callback)**

Registers the callback function that is invoked on every change of advertised value.

**wireless→set\_logicalName(newval)**

Changes the logical name of the wireless lan interface.

**wireless→set\_userData(data)**

Stores a user context provided as argument in the `userData` attribute of the function.

## YWireless.FindWireless()

Retrieves a wireless lan interface for a given identifier.

**def FindWireless( func)**

The identifier can be specified using several formats:

- `FunctionLogicalName`
- `ModuleSerialNumber.FunctionIdentifier`
- `ModuleSerialNumber.FunctionLogicalName`
- `ModuleLogicalName.FunctionIdentifier`
- `ModuleLogicalName.FunctionLogicalName`

This function does not require that the wireless lan interface is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YWireless.isOnline()` to test if the wireless lan interface is indeed online at a given time. In case of ambiguity when looking for a wireless lan interface by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

**Parameters :**

**func** a string that uniquely characterizes the wireless lan interface

**Returns :**

a `YWireless` object allowing you to drive the wireless lan interface.

## YWireless.FirstWireless()

Starts the enumeration of wireless lan interfaces currently accessible.

**def FirstWireless( )**

Use the method `YWireless.nextWireless()` to iterate on next wireless lan interfaces.

**Returns :**

a pointer to a `YWireless` object, corresponding to the first wireless lan interface currently online, or a `null` pointer if there are none.

## wireless.adhocNetwork()

Changes the configuration of the wireless lan interface to create an ad-hoc wireless network, without using an access point.

```
def adhocNetwork( ssid, securityKey)
```

If a security key is specified, the network will be protected by WEP128, since WPA is not standardized for ad-hoc networks. Remember to call the `saveToFlash()` method and then to reboot the module to apply this setting.

**Parameters :**

**ssid** the name of the network to connect to  
**securityKey** the network key, as a character string

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **wireless.describe()**

Returns a descriptive text that identifies the function.

```
def describe( )
```

The text always includes the class name, and may include as well either the logical name of the function or its hardware identifier.

**Returns :**

a string that describes the function

---

## **wireless.get\_advertisedValue()**

Returns the current value of the wireless lan interface (no more than 6 characters).

```
def get_advertisedValue( )
```

**Returns :**

a string corresponding to the current value of the wireless lan interface (no more than 6 characters)

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

---

## **wireless.get\_channel()**

Returns the 802.

```
def get_channel( )
```

11 channel currently used, or 0 when the selected network has not been found.

**Returns :**

an integer corresponding to the 802

On failure, throws an exception or returns `Y_CHANNEL_INVALID`.

---

## **wireless.get\_errorMessage()**

Returns the error message of the latest error with this function.

```
def get_errorMessage( )
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using this function object

---



---

## wireless.get\_errorType()

Returns the numerical error code of the latest error with this function.

`def get_errorType( )`

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using this function object

---

## wireless.get\_wirelessDescriptor()

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

`def get_functionDescriptor( )`

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`. If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

---

Returns the unique hardware identifier of the function.

The unique hardware identifier is made of the device serial number and of the hardware identifier of the function.

**Returns :**

a string that uniquely identifies the function. On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

---

## wireless.get\_linkQuality()

Returns the link quality, expressed in per cents.

`def get_linkQuality( )`

**Returns :**

an integer corresponding to the link quality, expressed in per cents

On failure, throws an exception or returns `Y_LINKQUALITY_INVALID`.

---

## wireless.get\_logicalName()

Returns the logical name of the wireless lan interface.

`def get_logicalName( )`

**Returns :**

a string corresponding to the logical name of the wireless lan interface

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

---

## wireless.get\_module()

Get the `YModule` object for the device on which the function is located.

---

**def get\_module( )**

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

**Returns :**

an instance of `YModule`

---

Get the `YModule` object for the device on which the function is located (asynchronous version).

If the function cannot be located on any module, the returned `YModule` object does not show as on-line. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

**Parameters :**

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the requested `YModule` object

**context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

---

## **wireless.get\_security()**

Returns the security algorithm used by the selected wireless network.

**def get\_security( )**

**Returns :**

a value among `Y_SECURITY_UNKNOWN`, `Y_SECURITY_OPEN`, `Y_SECURITY_WEP`, `Y_SECURITY_WPA` and `Y_SECURITY_WPA2` corresponding to the security algorithm used by the selected wireless network

On failure, throws an exception or returns `Y_SECURITY_INVALID`.

---

## **wireless.get\_ssid()**

Returns the wireless network name (SSID).

**def get\_ssid( )**

**Returns :**

a string corresponding to the wireless network name (SSID)

On failure, throws an exception or returns `Y_SSID_INVALID`.

---

## **wireless.getUserData()**

Returns the value of the `userData` attribute, as previously stored using method `set_userdata`.

**def getUserData( )**

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

---

---

## wireless.isOnline()

Checks if the function is currently reachable, without raising any error.

**def isOnline( )**

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

**Returns :**

`true` if the function can be reached, and `false` otherwise

---

Checks if the function is currently reachable, without raising any error (asynchronous version).

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox Javascript VM that does not implement context switching during blocking I/O calls.

**Parameters :**

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the boolean result

**context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

---

## wireless.joinNetwork()

Changes the configuration of the wireless lan interface to connect to an existing access point (infrastructure mode).

**def joinNetwork( ssid, securityKey)**

Remember to call the `saveToFlash()` method and then to reboot the module to apply this setting.

**Parameters :**

**ssid** the name of the network to connect to

**securityKey** the network key, as a character string

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## wireless.load()

Preloads the function cache with a specified validity duration.

**def load( msValidity)**

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

`YAPI_SUCCESS` when the call succeeds. On failure, throws an exception or returns a negative error code.

Preloads the function cache with a specified validity duration (asynchronous version).

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance. This asynchronous version exists only in Javascript. It uses a callback instead of a return value in order to avoid blocking Firefox javascript VM that does not implement context switching during blocking I/O calls. See the documentation section on asynchronous Javascript calls for more details.

**Parameters :**

**msValidity** an integer corresponding to the validity of the loaded function parameters, in milliseconds

**callback** callback function that is invoked when the result is known. The callback function receives three arguments: the caller-specific context object, the receiving function object and the error code (or `YAPI_SUCCESS`)

**context** caller-specific object that is passed as-is to the callback function

**Returns :**

nothing : the result is provided to the callback.

**wireless.nextWireless()**

Continues the enumeration of wireless lan interfaces started using `yFirstWireless()`.

def `nextWireless( )`

**Returns :**

a pointer to a `YWireless` object, corresponding to a wireless lan interface currently online, or a null pointer if there are no more wireless lan interfaces to enumerate.

**wireless.registerValueCallback()**

Registers the callback function that is invoked on every change of advertised value.

def `registerValueCallback( callback)`

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

**wireless.set\_logicalName()**

Changes the logical name of the wireless lan interface.

def `set_logicalName( newval)`

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the wireless lan interface

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

## **wireless.set\_userdata()**

Stores a user context provided as argument in the `userData` attribute of the function.

def **set\_userdata( data)**

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

## 4. Index

A	
adhocNetwork	175
API	9
C	
calibrate	95
calibrateFromPoints	26
callbackLogin	114
CheckLogicalName	10
D	
describe	17
DisableExceptions	10
E	
EnableExceptions	10
EnableUSBHost	11
F	
FindAnButton	17
FindCarbonDioxide	26
FindColorLed	34
FindCurrent	42
FindDataLogger	51
FindDualPower	64
FindHubPort	71
FindHumidity	78
FindLed	86
FindLightSensor	94
FindModule	103
FindNetwork	114
FindPressure	126
FindRelay	134
FindServo	141
FindTemperature	149
FindVoltage	158
FindVSource	166
FindWireless	175
FirstAnButton	17
FirstCarbonDioxide	26
FirstColorLed	35
FirstCurrent	43
FirstDataLogger	51
FirstDualPower	65
FirstHubPort	72
FirstHumidity	79
FirstLed	87

FirstLightSensor	94
FirstModule	103
FirstNetwork	114
FirstPressure	126
FirstRelay	134
FirstServo	142
FirstTemperature	150
FirstVoltage	159
FirstVSource	167
FirstWireless	175
forgetAllDataStreams	51
FreeAPI	11
functionCount	104
functionId	104
functionName	104
functionValue	104
G	
get_adminPassword	115
get_advertisedValue	17
get_analogCalibration	18
get_autoStart	52
get_averageValue	58
get_baudRate	72
get_beacon	104
get_blinking	87
get_calibratedValue	18
get_calibrationMax	18
get_calibrationMin	18
get_callbackCredentials	115
get_callbackMaxDelay	115
get_callbackMinDelay	116
get_callbackUrl	116
get_channel	176
get_columnCount	61
get_columnNames	61
get_currentRawValue	27
get_currentRunIndex	52
get_currentValue	27
get_data	61
get_dataRows	62
get_dataRun	52
get_dataSamplesInterval	62
get_dataStreams	52
get_duration	59
get_enabled	72
get_errorMessage	18
get_errorType	19
get_extPowerFailure	168
get_extVoltage	66
get_failure	168
get_firmwareRelease	105
get_functionDescriptor	19
get_hardwareId	19
get_highestValue	28
get_hslColor	36
get_icon2d	106
get_ipAddress	117
get_isPressed	19
get_lastTimePressed	19
get_lastTimeReleased	20
get_linkQuality	177
get_logicalName	20
get_lowestValue	29
get_luminosity	89

get_macAddress	117
get_maxValue	59
get_measureNames	54
get_minValue	59
get_module	20
get_module_async	20
get_neutral	144
get_oldestRunIndex	54
get_output	136
get_overCurrent	169
get_overHeat	169
get_overLoad	170
get_persistentSettings	106
get_portState	74
get_position	144
get_power	89
get_powerControl	67
get_powerState	67
get_primaryDNS	118
get_productId	106
get_productName	106
get_productRelease	107
get_pulseTimer	137
get_range	144
get_rawValue	20
get_readiness	118
get_rebootCountdown	107
get_recording	54
get_regulationFailure	170
get_resolution	29
get_rgbColor	37
get_rgbColorAtPowerOn	37
get_router	118
get_rowCount	62
get_runIndex	62
get_secondaryDNS	118
get_security	178
get_sensitivity	21
get_sensorType	153
get_serialNumber	107
get_ssid	178
get_startTime	63
get_startTimeUTC	60
get_state	137
get_subnetMask	119
get_timeUTC	55
get_unit	30
get_upTime	107
get_usbBandwidth	107
get_usbCurrent	108
get_userData	21
get_userPassword	119
get_valueCount	60
get_valueInterval	60
get_voltage	170
GetAPIVersion	11
GetTickCount	11
H	
HandleEvents	11
hslMove	37
I	
InitAPI	12
isOnline	21
isOnline_async	21



J	
joinNetwork	179
L	
load	22
load_async	22
M	
move	146
N	
nextAnButton	22
nextCarbonDioxide	31
nextColorLed	39
nextCurrent	47
nextDataLogger	56
nextDualPower	69
nextHubPort	76
nextHumidity	84
nextLed	91
nextLightSensor	99
nextModule	109
nextNetwork	120
nextPressure	131
nextRelay	138
nextServo	146
nextTemperature	155
nextVoltage	163
nextVSource	172
nextWireless	180
P	
pulse	138
R	
reboot	109
RegisterDeviceArrivalCallback	12
RegisterDeviceRemovalCallback	12
RegisterHub	13
RegisterLogFunction	13
registerValueCallback	22
reset	172
revertFromFlash	110
rgbMove	39
S	
saveToFlash	110
set_adminPassword	121
set_analogCalibration	23
set_autoStart	57
set_beacon	110
set_blinking	91
set_calibrationMax	23
set_calibrationMin	23
set_callbackCredentials	121
set_callbackMaxDelay	121
set_callbackMinDelay	122
set_callbackUrl	122
set_enabled	76
set_highestValue	32
set_hslColor	39
set_logicalName	23
set_lowestValue	32
set_luminosity	92
set_neutral	147
set_output	139
set_position	147
set_power	92
set_powerControl	69
set_primaryDNS	123

set_range	147
set_recording	57
set_rgbColor	40
set_rgbColorAtPowerOn	40
set_secondaryDNS	123
set_sensitivity	24
set_sensorType	156
set_state	140
set_timeUTC	57
set_usbBandwidth	111
set_userData	24
set_userPassword	123
set_valueInterval	60
set_voltage	173
SetDelegate	13
SetTimeout	13
Sleep	14
T	
triggerFirmwareUpdate	111
U	
UnregisterHub	14
UpdateDeviceList	14
UpdateDeviceList_async	14
useDHCP	124
useStaticIP	124
V	
voltageMove	173
Y	
YAnButton	15
YCarbonDioxide	24
YColorLed	33
YCurrent	41
YDataLogger	49
YDataRun	58
YDataStream	60
YDualPower	63
YHubPort	70
YHumidity	77
YLed	85
YLightSensor	92
YModule	101
YNetwork	111
YPressure	124
YRelay	133
YServo	140
YTemperature	148
YVoltage	157
YVSource	165
YWireless	173