



# VisualBasic .NET API Reference

---



# Table of contents

<b>1. Introduction</b> .....	<b>1</b>
<b>2. Using Yocto-Demo with Visual Basic .NET</b> .....	<b>3</b>
2.1. Installation .....	3
2.2. Using the Yoctopuce API in a Visual Basic project .....	3
2.3. Control of the Led function .....	4
2.4. Control of the module part .....	5
2.5. Error handling .....	8
Blueprint .....	10
<b>3. Reference</b> .....	<b>10</b>
3.1. General functions .....	11
3.2. Accelerometer function interface .....	31
3.3. Altitude function interface .....	72
3.4. AnButton function interface .....	113
3.5. CarbonDioxide function interface .....	150
3.6. ColorLed function interface .....	188
3.7. Compass function interface .....	216
3.8. Current function interface .....	255
3.9. DataLogger function interface .....	293
3.10. Formatted data sequence .....	326
3.11. Recorded data sequence .....	328
3.12. Unformatted data sequence .....	340
3.13. Digital IO function interface .....	355
3.14. Display function interface .....	398
3.15. DisplayLayer object interface .....	444
3.16. External power supply control interface .....	476
3.17. Files function interface .....	500
3.18. GenericSensor function interface .....	527
3.19. Gyroscope function interface .....	575
3.20. Yocto-hub port interface .....	625
3.21. Humidity function interface .....	649
3.22. Led function interface .....	687
3.23. LightSensor function interface .....	713
3.24. Magnetometer function interface .....	754

3.25. Measured value .....	795
3.26. Module control interface .....	801
3.27. Motor function interface .....	848
3.28. Network function interface .....	888
3.29. OS control .....	944
3.30. Power function interface .....	966
3.31. Pressure function interface .....	1008
3.32. PwmInput function interface .....	1046
3.33. Pwm function interface .....	1093
3.34. PwmPowerSource function interface .....	1130
3.35. Quaternion interface .....	1152
3.36. Real Time Clock function interface .....	1190
3.37. Reference frame configuration .....	1216
3.38. Relay function interface .....	1251
3.39. Sensor function interface .....	1286
3.40. SerialPort function interface .....	1324
3.41. Servo function interface .....	1380
3.42. Temperature function interface .....	1414
3.43. Tilt function interface .....	1454
3.44. Voc function interface .....	1492
3.45. Voltage function interface .....	1530
3.46. Voltage source function interface .....	1568
3.47. WakeUpMonitor function interface .....	1599
3.48. WakeUpSchedule function interface .....	1633
3.49. Watchdog function interface .....	1669
3.50. Wireless function interface .....	1713

<b>Index .....</b>	<b>1743</b>
--------------------	-------------

# 1. Introduction

This manual is intended to be used as a reference for Yoctopuce VisualBasic .NET library, in order to interface your code with USB sensors and controllers.

The next chapter is taken from the free USB device Yocto-Demo, in order to provide a concrete examples of how the library is used within a program.

The remaining part of the manual is a function-by-function, class-by-class documentation of the API. The first section describes all general-purpose global function, while the forthcoming sections describe the various classes that you may have to use depending on the Yoctopuce device beeing used. For more informations regarding the purpose and the usage of a given device attribute, please refer to the extended discussion provided in the device-specific user manual.



## 2. Using Yocto-Demo with Visual Basic .NET

VisualBasic has long been the most favored entrance path to the Microsoft world. Therefore, we had to provide our library for this language, even if the new trend is shifting to C#. All the examples and the project models are tested with Microsoft VisualBasic 2010 Express, freely available on the Microsoft web site<sup>1</sup>.

### 2.1. Installation

Download the Visual Basic Yoctopuce library from the Yoctopuce web site<sup>2</sup>. There is no setup program, simply copy the content of the zip file into the directory of your choice. You mostly need the content of the `Sources` directory. The other directories contain the documentation and a few sample programs. All sample projects are Visual Basic 2010, projects, if you are using a previous version, you may have to recreate the projects structure from scratch.

### 2.2. Using the Yoctopuce API in a Visual Basic project

The Visual Basic.NET Yoctopuce library is composed of a DLL and of source files in Visual Basic. The DLL is not a .NET DLL, but a classic DLL, written in C, which manages the low level communications with the modules<sup>3</sup>. The source files in Visual Basic manage the high level part of the API. Therefore, you need both this DLL and the .vb files of the `sources` directory to create a project managing Yoctopuce modules.

#### Configuring a Visual Basic project

The following indications are provided for Visual Studio Express 2010, but the process is similar for other versions. Start by creating your project. Then, on the *Solution Explorer* panel, right click on your project, and select "Add" and then "Add an existing item".

A file selection window opens. Select the `yocto_api.vb` file and the files corresponding to the functions of the Yoctopuce modules that your project is going to manage. If in doubt, select all the files.

You then have the choice between simply adding these files to your project, or to add them as links (the **Add** button is in fact a scroll-down menu). In the first case, Visual Studio copies the selected files into your project. In the second case, Visual Studio simply keeps a link on the original files. We recommend you to use links, which makes updates of the library much easier.

---

<sup>1</sup> <http://www.microsoft.com/visualstudio/en-us/products/2010-editions/visual-basic-express>

<sup>2</sup> [www.yoctopuce.com/EN/libraries.php](http://www.yoctopuce.com/EN/libraries.php)

<sup>3</sup> The sources of this DLL are available in the C++ API

Then add in the same manner the `yapi.dll` DLL, located in the `Sources/dll` directory<sup>4</sup>. Then, from the **Solution Explorer** window, right click on the DLL, select **Properties** and in the **Properties** panel, set the **Copy to output folder** to **always**. You are now ready to use your Yoctopuce modules from Visual Studio.

In order to keep them simple, all the examples provided in this documentation are console applications. Naturally, the libraries function in a strictly identical manner if you integrate them in an application with a graphical interface.

### 2.3. Control of the Led function

A few lines of code are enough to use a Yocto-Demo. Here is the skeleton of a Visual Basic code snippet to use the Led function.

```
[...]
Dim errmsg As String errmsg
Dim led As YLed

REM Get access to your device, connected locally on USB for instance
yRegisterHub("usb", errmsg)
led = yFindLed("YCTOPOC1-123456.led")

REM Hot-plug is easy: just check that the device is online
If (led.isOnline()) Then
    REM Use led.set_power(), ...
End If
```

Let's look at these lines in more details.

#### yRegisterHub

The `yRegisterHub` function initializes the Yoctopuce API and indicates where the modules should be looked for. When used with the parameter `"usb"`, it will use the modules locally connected to the computer running the library. If the initialization does not succeed, this function returns a value different from `YAPI_SUCCESS` and `errmsg` contains the error message.

#### yFindLed

The `yFindLed` function allows you to find a led from the serial number of the module on which it resides and from its function name. You can use logical names as well, as long as you have initialized them. Let us imagine a Yocto-Demo module with serial number `YCTOPOC1-123456` which you have named `"MyModule"`, and for which you have given the `led` function the name `"MyFunction"`. The following five calls are strictly equivalent, as long as `"MyFunction"` is defined only once.

```
led = yFindLed("YCTOPOC1-123456.led")
led = yFindLed("YCTOPOC1-123456.MyFunction")
led = yFindLed("MyModule.led")
led = yFindLed("MyModule.MyFunction")
led = yFindLed("MyFunction")
```

`yFindLed` returns an object which you can then use at will to control the led.

#### isOnline

The `isOnline()` method of the object returned by `yFindLed` allows you to know if the corresponding module is present and in working order.

#### set\_power

The `set_power()` function of the object returned by `yFindLed` allows you to turn on and off the led. The argument is `Y_POWER_ON` or `Y_POWER_OFF`. In the reference on the programming

<sup>4</sup> Remember to change the filter of the selection window, otherwise the DLL will not show.



interface, you will find more methods to precisely control the luminosity and make the led blink automatically.

## A real example

Launch Microsoft VisualBasic and open the corresponding sample project provided in the directory **Examples/Doc-GettingStarted-Yocto-Demo** of the Yoctopuce library.

In this example, you will recognize the functions explained above, but this time used with all side materials needed to make it work nicely as a small demo.

```
Module Module1

    Private Sub Usage()
        Dim execname = System.AppDomain.CurrentDomain.FriendlyName
        Console.WriteLine("Usage:")
        Console.WriteLine(execname+" <serial_number> [ on | off ]")
        Console.WriteLine(execname+" <logical_name> [ on | off ]")
        Console.WriteLine(execname+" any [ on | off ] ")
        System.Threading.Thread.Sleep(2500)
    End Sub

    Sub Main()
        Dim argv() As String = System.Environment.GetCommandLineArgs()
        Dim errmsg As String = ""
        Dim target As String
        Dim led As YLed

        Dim on_off As String

        If argv.Length < 3 Then Usage()

        target = argv(1)
        on_off = argv(2).ToUpper()

        REM Setup the API to use local USB devices
        If (yRegisterHub("usb", errmsg) <> YAPI_SUCCESS) Then
            Console.WriteLine("RegisterHub error: " + errmsg)
        End If

        If target = "any" Then
            led = yFirstLed()
            If led Is Nothing Then
                Console.WriteLine("No module connected (check USB cable) ")
            End If
        Else
            led = yFindLed(target + ".led")
        End If

        If (led.isOnline()) Then
            If on_off = "ON" Then led.set_power(Y_POWER_ON) Else led.set_power(Y_POWER_OFF)
        Else
            Console.WriteLine("Module not connected (check identification and USB cable)")
        End If
    End Sub

End Module
```

## 2.4. Control of the module part

Each module can be controlled in a similar manner, you can find below a simple sample program displaying the main parameters of the module and enabling you to activate the localization beacon.

```

Imports System.IO
Imports System.Environment

Module Module1

    Sub usage ()
        Console.WriteLine("usage: demo <serial or logical name> [ON/OFF]")
    End
End Sub

Sub Main ()
    Dim argv() As String = System.Environment.GetCommandLineArgs ()
    Dim errmsg As String = ""
    Dim m As ymodule

    If (yRegisterHub("usb", errmsg) <> YAPI_SUCCESS) Then
        Console.WriteLine("RegisterHub error:" + errmsg)
    End
End If

    If argv.Length < 2 Then usage ()

    m = yFindModule(argv(1)) REM use serial or logical name

    If (m.isOnline ()) Then
        If argv.Length > 2 Then
            If argv(2) = "ON" Then m.set_beacon(Y_BEACON_ON)
            If argv(2) = "OFF" Then m.set_beacon(Y_BEACON_OFF)
        End If
        Console.WriteLine("serial:          " + m.get_serialNumber ())
        Console.WriteLine("logical name:  " + m.get_logicalName ())
        Console.WriteLine("luminosity:   " + Str(m.get_luminosity ()))
        Console.WriteLine("beacon:       ")
        If (m.get_beacon () = Y_BEACON_ON) Then
            Console.WriteLine("ON")
        Else
            Console.WriteLine("OFF")
        End If
        Console.WriteLine("upTime:       " + Str(m.get_upTime () / 1000) + " sec")
        Console.WriteLine("USB current:  " + Str(m.get_usbCurrent ()) + " mA")
        Console.WriteLine("Logs:")
        Console.WriteLine(m.get_lastLogs ())
    Else
        Console.WriteLine(argv(1) + " not connected (check identification and USB cable)")
    End If

End Sub

End Module

```

Each property `xxx` of the module can be read thanks to a method of type `get_xxxx()`, and properties which are not read-only can be modified with the help of the `set_xxx()` method. For more details regarding the used functions, refer to the API chapters.

## Changing the module settings

When you want to modify the settings of a module, you only need to call the corresponding `set_xxx()` function. However, this modification is performed only in the random access memory (RAM) of the module: if the module is restarted, the modifications are lost. To memorize them persistently, it is necessary to ask the module to save its current configuration in its permanent memory. To do so, use the `saveToFlash()` method. Inversely, it is possible to force the module to forget its current settings by using the `revertFromFlash()` method. The short example below allows you to modify the logical name of a module.

```

Module Module1

    Sub usage ()

        Console.WriteLine("usage: demo <serial or logical name> <new logical name>")
    End

```

```

End Sub

Sub Main()
    Dim argv() As String = System.Environment.GetCommandLineArgs()
    Dim errmsg As String = ""
    Dim newname As String
    Dim m As YModule

    If (argv.Length <> 3) Then usage()

    REM Setup the API to use local USB devices
    If yRegisterHub("usb", errmsg) <> YAPI_SUCCESS Then
        Console.WriteLine("RegisterHub error: " + errmsg)
    End If

    m = yFindModule(argv(1)) REM use serial or logical name
    If m.isOnline() Then

        newname = argv(2)
        If (Not yCheckLogicalName(newname)) Then
            Console.WriteLine("Invalid name (" + newname + ")")
        End If
        m.set_logicalName(newname)
        m.saveToFlash() REM do not forget this

        Console.WriteLine("Module: serial= " + m.get_serialNumber())
        Console.WriteLine(" / name= " + m.get_logicalName())
    Else
        Console.WriteLine("not connected (check identification and USB cable)")
    End If

End Sub

End Module

```

Warning: the number of write cycles of the nonvolatile memory of the module is limited. When this limit is reached, nothing guaranties that the saving process is performed correctly. This limit, linked to the technology employed by the module micro-processor, is located at about 100000 cycles. In short, you can use the `saveToFlash()` function only 100000 times in the life of the module. Make sure you do not call this function within a loop.

## Listing the modules

Obtaining the list of the connected modules is performed with the `yFirstModule()` function which returns the first module found. Then, you only need to call the `nextModule()` function of this object to find the following modules, and this as long as the returned value is not `Nothing`. Below a short example listing the connected modules.

```

Module Module1

Sub Main()
    Dim M As ymodule
    Dim errmsg As String = ""

    REM Setup the API to use local USB devices
    If yRegisterHub("usb", errmsg) <> YAPI_SUCCESS Then
        Console.WriteLine("RegisterHub error: " + errmsg)
    End If

    Console.WriteLine("Device list")
    M = yFirstModule()
    While M IsNot Nothing
        Console.WriteLine(M.get_serialNumber() + " (" + M.get_productName() + ")")
        M = M.nextModule()
    End While

End Sub

End Module

```

## 2.5. Error handling

When you implement a program which must interact with USB modules, you cannot disregard error handling. Inevitably, there will be a time when a user will have unplugged the device, either before running the software, or even while the software is running. The Yoctopuce library is designed to help you support this kind of behavior, but your code must nevertheless be conceived to interpret in the best possible way the errors indicated by the library.

The simplest way to work around the problem is the one used in the short examples provided in this chapter: before accessing a module, check that it is online with the `isOnline` function, and then hope that it will stay so during the fraction of a second necessary for the following code lines to run. This method is not perfect, but it can be sufficient in some cases. You must however be aware that you cannot completely exclude an error which would occur after the call to `isOnline` and which could crash the software. The only way to prevent this is to implement one of the two error handling techniques described below.

The method recommended by most programming languages for unpredictable error handling is the use of exceptions. By default, it is the behavior of the Yoctopuce library. If an error happens while you try to access a module, the library throws an exception. In this case, there are three possibilities:

- If your code catches the exception and handles it, everything goes well.
- If your program is running in debug mode, you can relatively easily determine where the problem happened and view the explanatory message linked to the exception.
- Otherwise... the exception makes your program crash, bang!

As this latest situation is not the most desirable, the Yoctopuce library offers another possibility for error handling, allowing you to create a robust program without needing to catch exceptions at every line of code. You simply need to call the `yDisableExceptions()` function to commute the library to a mode where exceptions for all the functions are systematically replaced by specific return values, which can be tested by the caller when necessary. For each function, the name of each return value in case of error is systematically documented in the library reference. The name always follows the same logic: a `get_state()` method returns a `Y_STATE_INVALID` value, a `get_currentValue` method returns a `Y_CURRENTVALUE_INVALID` value, and so on. In any case, the returned value is of the expected type and is not a null pointer which would risk crashing your program. At worst, if you display the value without testing it, it will be outside the expected bounds for the returned value. In the case of functions which do not normally return information, the return value is `YAPI_SUCCESS` if everything went well, and a different error code in case of failure.

When you work without exceptions, you can obtain an error code and an error message explaining the source of the error. You can request them from the object which returned the error, calling the `errType()` and `errMessage()` methods. Their returned values contain the same information as in the exceptions when they are active.



### **3. Reference**

## 3.1. General functions

These general functions should be used to initialize and configure the Yoctopuce library. In most cases, a simple call to function `yRegisterHub()` should be enough. The module-specific functions `yFind...()` or `yFirst...()` should then be used to retrieve an object that provides interaction with the module.

In order to use the functions described here, you should include:

js	<code>&lt;script type='text/javascript' src='yocto_api.js'&gt;&lt;/script&gt;</code>
nodejs	<code>var yoctolib = require('yoctolib'); var YAPI = yoctolib.YAPI; var YModule = yoctolib.YModule;</code>
php	<code>require_once('yocto_api.php');</code>
cpp	<code>#include "yocto_api.h"</code>
m	<code>#import "yocto_api.h"</code>
pas	<code>uses yocto_api;</code>
vb	<code>yocto_api.vb</code>
cs	<code>yocto_api.cs</code>
java	<code>import com.yoctopuce.YoctoAPI.YModule;</code>
py	<code>from yocto_api import *</code>

### Global functions

#### **yCheckLogicalName(name)**

Checks if a given string is valid as logical name for a module or a function.

#### **yDisableExceptions()**

Disables the use of exceptions to report runtime errors.

#### **yEnableExceptions()**

Re-enables the use of exceptions for runtime error handling.

#### **yEnableUSBHost(osContext)**

This function is used only on Android.

#### **yFreeAPI()**

Frees dynamically allocated memory blocks used by the Yoctopuce library.

#### **yGetAPIVersion()**

Returns the version identifier for the Yoctopuce library in use.

#### **yGetTickCount()**

Returns the current value of a monotone millisecond-based time counter.

#### **yHandleEvents(errmsg)**

Maintains the device-to-library communication channel.

#### **yInitAPI(mode, errmsg)**

Initializes the Yoctopuce programming library explicitly.

#### **yPreregisterHub(url, errmsg)**

Fault-tolerant alternative to `RegisterHub()`.

#### **yRegisterDeviceArrivalCallback(arrivalCallback)**

Register a callback function, to be called each time a device is plugged.

#### **yRegisterDeviceRemovalCallback(removalCallback)**

Register a callback function, to be called each time a device is unplugged.

#### **yRegisterHub(url, errmsg)**

Setup the Yoctopuce library to use modules connected on a given machine.

#### **yRegisterHubDiscoveryCallback(hubDiscoveryCallback)**

### 3. Reference

Register a callback function, to be called each time an Network Hub send an SSDP message.

#### **yRegisterLogFunction(logfun)**

Registers a log callback function.

#### **ySelectArchitecture(arch)**

Select the architecture or the library to be loaded to access to USB.

#### **ySetDelegate(object)**

(Objective-C only) Register an object that must follow the protocol YDeviceHotPlug.

#### **ySetTimeout(callback, ms\_timeout, arguments)**

Invoke the specified callback function after a given timeout.

#### **ySleep(ms\_duration, errmsg)**

Pauses the execution flow for a specified duration.

#### **yTriggerHubDiscovery(errmsg)**

Force a hub discovery, if a callback as been registered with `yRegisterDeviceRemovalCallback` it will be called for each net work hub that will respond to the discovery.

#### **yUnregisterHub(url)**

Setup the Yoctopuce library to no more use modules connected on a previously registered machine with `RegisterHub`.

#### **yUpdateDeviceList(errmsg)**

Triggers a (re)detection of connected Yoctopuce modules.

#### **yUpdateDeviceList\_async(callback, context)**

Triggers a (re)detection of connected Yoctopuce modules.



---

**YAPI.CheckLogicalName()**  
**yCheckLogicalName()yCheckLogicalName()**

---

YAPI

Checks if a given string is valid as logical name for a module or a function.

```
function yCheckLogicalName( ByVal name As String) As Boolean
```

A valid logical name has a maximum of 19 characters, all among A . . Z, a . . z, 0 . . 9, `_`, and `-`. If you try to configure a logical name with an incorrect string, the invalid characters are ignored.

**Parameters :**

**name** a string containing the name to check.

**Returns :**

`true` if the name is valid, `false` otherwise.

## YAPI.DisableExceptions()

YAPI

### yDisableExceptions()yDisableExceptions()

---

Disables the use of exceptions to report runtime errors.

procedure **yDisableExceptions**( )

When exceptions are disabled, every function returns a specific error value which depends on its type and which is documented in this reference manual.

---

**YAPI.EnableExceptions()  
yEnableExceptions()yEnableExceptions()**

---

**YAPI**

Re-enables the use of exceptions for runtime error handling.

procedure **yEnableExceptions( )**

Be aware than when exceptions are enabled, every function that fails triggers an exception. If the exception is not caught by the user code, it either fires the debugger or aborts (i.e. crash) the program. On failure, throws an exception or returns a negative error code.

**YAPI.FreeAPI()  
yFreeAPI(yFreeAPI())**

---

**YAPI**

Frees dynamically allocated memory blocks used by the Yoctopuce library.

procedure **yFreeAPI( )**

It is generally not required to call this function, unless you want to free all dynamically allocated memory blocks in order to track a memory leak for instance. You should not call any other library function after calling `yFreeAPI( )`, or your program will crash.

---

**YAPI.GetAPIVersion()  
yGetAPIVersion()yGetAPIVersion()**

---

**YAPI**

Returns the version identifier for the Yoctopuce library in use.

```
function yGetAPIVersion( ) As String
```

The version is a string in the form "Major.Minor.Build", for instance "1.01.5535". For languages using an external DLL (for instance C#, VisualBasic or Delphi), the character string includes as well the DLL version, for instance "1.01.5535 (1.01.5439)".

If you want to verify in your code that the library version is compatible with the version that you have used during development, verify that the major number is strictly equal and that the minor number is greater or equal. The build number is not relevant with respect to the library compatibility.

**Returns :**

a character string describing the library version.

## YAPI.GetTickCount()

YAPI

### yGetTickCount()yGetTickCount()

---

Returns the current value of a monotone millisecond-based time counter.

```
function yGetTickCount( ) As Long
```

This counter can be used to compute delays in relation with Yoctopuce devices, which also uses the millisecond as timebase.

**Returns :**

a long integer corresponding to the millisecond counter.

## YAPI.HandleEvents() yHandleEvents()yHandleEvents()

YAPI

Maintains the device-to-library communication channel.

```
function yHandleEvents( ByRef errmsg As String) As YRETCODE
```

If your program includes significant loops, you may want to include a call to this function to make sure that the library takes care of the information pushed by the modules on the communication channels. This is not strictly necessary, but it may improve the reactivity of the library for the following commands.

This function may signal an error in case there is a communication problem while contacting a module.

**Parameters :**

**errmsg** a string passed by reference to receive any error message.

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

## YAPI.InitAPI() yInitAPI()yInitAPI()

YAPI

Initializes the Yoctopuce programming library explicitly.

```
function yInitAPI( ByVal mode As Integer, ByRef errmsg As String) As Integer
```

It is not strictly needed to call `yInitAPI()`, as the library is automatically initialized when calling `yRegisterHub()` for the first time.

When `Y_DETECT_NONE` is used as detection mode, you must explicitly use `yRegisterHub()` to point the API to the VirtualHub on which your devices are connected before trying to access them.

### Parameters :

**mode** an integer corresponding to the type of automatic device detection to use. Possible values are `Y_DETECT_NONE`, `Y_DETECT_USB`, `Y_DETECT_NET`, and `Y_DETECT_ALL`.

**errmsg** a string passed by reference to receive any error message.

### Returns :

`YAPI_SUCCESS` when the call succeeds.

On failure, throws an exception or returns a negative error code.



## YAPI.PreregisterHub() yPreregisterHub(yPreregisterHub())

YAPI

Fault-tolerant alternative to RegisterHub().

```
function yPreregisterHub( ByVal url As String,  
                          ByRef errmsg As String) As Integer
```

This function has the same purpose and same arguments as RegisterHub(), but does not trigger an error when the selected hub is not available at the time of the function call. This makes it possible to register a network hub independently of the current connectivity, and to try to contact it only when a device is actively needed.

### Parameters :

**url** a string containing either "usb", "callback" or the root URL of the hub to monitor  
**errmsg** a string passed by reference to receive any error message.

### Returns :

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

**YAPI.RegisterDeviceArrivalCallback()**  
**yRegisterDeviceArrivalCallback()**  
**yRegisterDeviceArrivalCallback()**

---

YAPI

Register a callback function, to be called each time a device is plugged.

```
procedure yRegisterDeviceArrivalCallback( ByVal arrivalCallback As yDeviceUpdateFunc)
```

This callback will be invoked while `yUpdateDeviceList` is running. You will have to call this function on a regular basis.

**Parameters :**

**arrivalCallback** a procedure taking a `YModule` parameter, or null

---

**YAPI.RegisterDeviceRemovalCallback()**  
**yRegisterDeviceRemovalCallback()**  
**yRegisterDeviceRemovalCallback()**

---

**YAPI**

Register a callback function, to be called each time a device is unplugged.

```
procedure yRegisterDeviceRemovalCallback( ByVal removalCallback As yDeviceUpdateFunc)
```

This callback will be invoked while `yUpdateDeviceList` is running. You will have to call this function on a regular basis.

**Parameters :**

**removalCallback** a procedure taking a `YModule` parameter, or `null`

## YAPI.RegisterHub() yRegisterHub()yRegisterHub()

YAPI

Setup the Yoctopuce library to use modules connected on a given machine.

```
function yRegisterHub( ByVal url As String,
                      ByRef errmsg As String) As Integer
```

The parameter will determine how the API will work. Use the following values:

**usb**: When the **usb** keyword is used, the API will work with devices connected directly to the USB bus. Some programming languages such as Javascript, PHP, and Java don't provide direct access to USB hardware, so **usb** will not work with these. In this case, use a VirtualHub or a networked YoctoHub (see below).

**x.x.x.x** or **hostname**: The API will use the devices connected to the host with the given IP address or hostname. That host can be a regular computer running a VirtualHub, or a networked YoctoHub such as YoctoHub-Ethernet or YoctoHub-Wireless. If you want to use the VirtualHub running on your local computer, use the IP address 127.0.0.1.

**callback**: that keyword makes the API run in "*HTTP Callback*" mode. This is a special mode allowing to take control of Yoctopuce devices through a NAT filter when using a VirtualHub or a networked YoctoHub. You only need to configure your hub to call your server script on a regular basis. This mode is currently available for PHP and Node.JS only.

Be aware that only one application can use direct USB access at a given time on a machine. Multiple access would cause conflicts while trying to access the USB modules. In particular, this means that you must stop the VirtualHub software before starting an application that uses direct USB access. The workaround for this limitation is to setup the library to use the VirtualHub rather than direct USB access.

If access control has been activated on the hub, virtual or not, you want to reach, the URL parameter should look like:

```
http://username:password@address:port
```

You can call *RegisterHub* several times to connect to several machines.

### Parameters :

- url** a string containing either "**usb**", "**callback**" or the root URL of the hub to monitor
- errmsg** a string passed by reference to receive any error message.

### Returns :

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**YAPI.RegisterHubDiscoveryCallback()  
yRegisterHubDiscoveryCallback()  
yRegisterHubDiscoveryCallback()**

---

**YAPI**

Register a callback function, to be called each time an Network Hub send an SSDP message.

```
procedure yRegisterHubDiscoveryCallback( ByVal hubDiscoveryCallback As YHubDiscoveryCallback)
```

The callback has two string parameter, the first one contain the serial number of the hub and the second contain the URL of the network hub (this URL can be passed to RegisterHub). This callback will be invoked while yUpdateDeviceList is running. You will have to call this function on a regular basis.

**Parameters :**

**hubDiscoveryCallback** a procedure taking two string parameter, or null

## YAPI.RegisterLogFunction()

YAPI

### yRegisterLogFunction()yRegisterLogFunction()

---

Registers a log callback function.

```
procedure yRegisterLogFunction( ByVal logfun As yLogFunc)
```

This callback will be called each time the API have something to say. Quite useful to debug the API.

#### Parameters :

**logfun** a procedure taking a string parameter, or null

## YAPI.Sleep() ySleep()ySleep()

YAPI

Pauses the execution flow for a specified duration.

```
function ySleep( ByVal ms_duration As Integer,  
                ByRef errmsg As String) As Integer
```

This function implements a passive waiting loop, meaning that it does not consume CPU cycles significantly. The processor is left available for other threads and processes. During the pause, the library nevertheless reads from time to time information from the Yoctopuce modules by calling `yHandleEvents()`, in order to stay up-to-date.

This function may signal an error in case there is a communication problem while contacting a module.

### Parameters :

- ms\_duration** an integer corresponding to the duration of the pause, in milliseconds.
- errmsg** a string passed by reference to receive any error message.

### Returns :

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

**YAPI.TriggerHubDiscovery()**

YAPI

**yTriggerHubDiscovery()**

Force a hub discovery, if a callback as been registered with `yRegisterDeviceRemovalCallback` it will be called for each net work hub that will respond to the discovery.

```
function yTriggerHubDiscovery( ByRef errmsg As String) As Integer
```

**Parameters :**

**errmsg** a string passed by reference to receive any error message.

**Returns :**

YAPI\_SUCCESS when the call succeeds. On failure, throws an exception or returns a negative error code.



---

**YAPI.UnregisterHub()  
yUnregisterHub()yUnregisterHub()**

---

**YAPI**

Setup the Yoctopuce library to no more use modules connected on a previously registered machine with RegisterHub.

```
procedure yUnregisterHub( ByVal url As String)
```

**Parameters :**

**url** a string containing either "**usb**" or the

## YAPI.UpdateDeviceList() yUpdateDeviceList(yUpdateDeviceList())

YAPI

Triggers a (re)detection of connected Yoctopuce modules.

```
function yUpdateDeviceList( ByRef errmsg As String) As YRETCODE
```

The library searches the machines or USB ports previously registered using `yRegisterHub()`, and invokes any user-defined callback function in case a change in the list of connected devices is detected.

This function can be called as frequently as desired to refresh the device list and to make the application aware of hot-plug events.

**Parameters :**

**errmsg** a string passed by reference to receive any error message.

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

## 3.2. Accelerometer function interface

The Yoctopuce application programming interface allows you to read an instant measure of the sensor, as well as the minimal and maximal values observed.

In order to use the functions described here, you should include:

js	<script type='text/javascript' src='yocto_accelerometer.js'></script>
nodejs	var yoctolib = require('yoctolib'); var YAccelerometer = yoctolib.YAccelerometer;
php	require_once('yocto_accelerometer.php');
c++	#include "yocto_accelerometer.h"
m	#import "yocto_accelerometer.h"
pas	uses yocto_accelerometer;
vb	yocto_accelerometer.vb
cs	yocto_accelerometer.cs
java	import com.yoctopuce.YoctoAPI.YAccelerometer;
py	from yocto_accelerometer import *

### Global functions

#### **yFindAccelerometer(func)**

Retrieves an accelerometer for a given identifier.

#### **yFirstAccelerometer()**

Starts the enumeration of accelerometers currently accessible.

### YAccelerometer methods

#### **accelerometer→calibrateFromPoints(rawValues, refValues)**

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

#### **accelerometer→describe()**

Returns a short text that describes unambiguously the instance of the accelerometer in the form `TYPE ( NAME ) = SERIAL . FUNCTIONID`.

#### **accelerometer→get\_advertisedValue()**

Returns the current value of the accelerometer (no more than 6 characters).

#### **accelerometer→get\_currentRawValue()**

Returns the uncalibrated, unrounded raw value returned by the sensor, in g, as a floating point number.

#### **accelerometer→get\_currentValue()**

Returns the current value of the acceleration, in g, as a floating point number.

#### **accelerometer→get\_errorMessage()**

Returns the error message of the latest error with the accelerometer.

#### **accelerometer→get\_errorType()**

Returns the numerical error code of the latest error with the accelerometer.

#### **accelerometer→get\_friendlyName()**

Returns a global identifier of the accelerometer in the format `MODULE_NAME . FUNCTION_NAME`.

#### **accelerometer→get\_functionDescriptor()**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

#### **accelerometer→get\_functionId()**

Returns the hardware identifier of the accelerometer, without reference to the module.

#### **accelerometer→get\_hardwareId()**

Returns the unique hardware identifier of the accelerometer in the form `SERIAL . FUNCTIONID`.

**accelerometer→get\_highestValue()**

Returns the maximal value observed for the acceleration since the device was started.

**accelerometer→get\_logFrequency()**

Returns the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory.

**accelerometer→get\_logicalName()**

Returns the logical name of the accelerometer.

**accelerometer→get\_lowestValue()**

Returns the minimal value observed for the acceleration since the device was started.

**accelerometer→get\_module()**

Gets the YModule object for the device on which the function is located.

**accelerometer→get\_module\_async(callback, context)**

Gets the YModule object for the device on which the function is located (asynchronous version).

**accelerometer→get\_recordedData(startTime, endTime)**

Retrieves a DataSet object holding historical data for this sensor, for a specified time interval.

**accelerometer→get\_reportFrequency()**

Returns the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function.

**accelerometer→get\_resolution()**

Returns the resolution of the measured values.

**accelerometer→get\_unit()**

Returns the measuring unit for the acceleration.

**accelerometer→get\_userData()**

Returns the value of the userData attribute, as previously stored using method set\_userData.

**accelerometer→get\_xValue()**

Returns the X component of the acceleration, as a floating point number.

**accelerometer→get\_yValue()**

Returns the Y component of the acceleration, as a floating point number.

**accelerometer→get\_zValue()**

Returns the Z component of the acceleration, as a floating point number.

**accelerometer→isOnline()**

Checks if the accelerometer is currently reachable, without raising any error.

**accelerometer→isOnline\_async(callback, context)**

Checks if the accelerometer is currently reachable, without raising any error (asynchronous version).

**accelerometer→load(msValidity)**

Preloads the accelerometer cache with a specified validity duration.

**accelerometer→loadCalibrationPoints(rawValues, refValues)**

Retrieves error correction data points previously entered using the method calibrateFromPoints.

**accelerometer→load\_async(msValidity, callback, context)**

Preloads the accelerometer cache with a specified validity duration (asynchronous version).

**accelerometer→nextAccelerometer()**

Continues the enumeration of accelerometers started using yFirstAccelerometer().

**accelerometer→registerTimedReportCallback(callback)**

Registers the callback function that is invoked on every periodic timed notification.

**accelerometer→registerValueCallback(callback)**

Registers the callback function that is invoked on every change of advertised value.

**accelerometer→set\_highestValue(newval)**

Changes the recorded maximal value observed.

**accelerometer→set\_logFrequency(newval)**

Changes the datalogger recording frequency for this function.

**accelerometer→set\_logicalName(newval)**

Changes the logical name of the accelerometer.

**accelerometer→set\_lowestValue(newval)**

Changes the recorded minimal value observed.

**accelerometer→set\_reportFrequency(newval)**

Changes the timed value notification frequency for this function.

**accelerometer→set\_resolution(newval)**

Changes the resolution of the measured physical values.

**accelerometer→set\_userData(data)**

Stores a user context provided as argument in the userData attribute of the function.

**accelerometer→wait\_async(callback, context)**

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.

## YAccelerometer.FindAccelerometer() yFindAccelerometer(yFindAccelerometer())

YAccelerometer

Retrieves an accelerometer for a given identifier.

```
function yFindAccelerometer( ByVal func As String ) As YAccelerometer
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the accelerometer is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YAccelerometer.isOnline()` to test if the accelerometer is indeed online at a given time. In case of ambiguity when looking for an accelerometer by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

**Parameters :**

**func** a string that uniquely characterizes the accelerometer

**Returns :**

a `YAccelerometer` object allowing you to drive the accelerometer.

---

**YAccelerometer.FirstAccelerometer()  
yFirstAccelerometer()yFirstAccelerometer()**

---

**YAccelerometer**

Starts the enumeration of accelerometers currently accessible.

```
function yFirstAccelerometer( ) As YAccelerometer
```

Use the method `YAccelerometer.nextAccelerometer( )` to iterate on next accelerometers.

**Returns :**

a pointer to a `YAccelerometer` object, corresponding to the first accelerometer currently online, or a `null` pointer if there are none.

**accelerometer** → **calibrateFromPoints()**  
**accelerometer.calibrateFromPoints()****YAccelerometer**

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

**procedure** **calibrateFromPoints()**

It is possible to configure up to five correction points. Correction points must be provided in ascending order, and be in the range of the sensor. The device will automatically perform a linear interpolation of the error correction between specified points. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

For more information on advanced capabilities to refine the calibration of sensors, please contact [support@yoctopuce.com](mailto:support@yoctopuce.com).

**Parameters :**

**rawValues** array of floating point numbers, corresponding to the raw values returned by the sensor for the correction points.

**refValues** array of floating point numbers, corresponding to the corrected values for the correction points.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.



**accelerometer**→**describe()****accelerometer.describe()****YAccelerometer**

Returns a short text that describes unambiguously the instance of the accelerometer in the form `TYPE(NAME)=SERIAL.FUNCTIONID`.

function **describe**( ) As String

More precisely, `TYPE` is the type of the function, `NAME` is the name used for the first access to the function, `SERIAL` is the serial number of the module if the module is connected or "unresolved", and `FUNCTIONID` is the hardware identifier of the function if the module is connected. For example, this method returns `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1` if the module is already connected or `Relay(BadCustomName.relay1)=unresolved` if the module has not yet been connected. This method does not trigger any USB or TCP transaction and can therefore be used in a debugger.

**Returns :**

a string that describes the accelerometer (ex: `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1`)

**accelerometer**→**get\_advertisedValue()**

**YAccelerometer**

**accelerometer**→**advertisedValue()**

**accelerometer.get\_advertisedValue()**

---

Returns the current value of the accelerometer (no more than 6 characters).

function **get\_advertisedValue( )** As String

**Returns :**

a string corresponding to the current value of the accelerometer (no more than 6 characters).

On failure, throws an exception or returns Y\_ADVERTISEDVALUE\_INVALID.

---

**accelerometer**→**get\_currentRawValue()****YAccelerometer****accelerometer**→**currentRawValue()****accelerometer.get\_currentRawValue()**

---

Returns the uncalibrated, unrounded raw value returned by the sensor, in g, as a floating point number.

```
function get_currentRawValue( ) As Double
```

**Returns :**

a floating point number corresponding to the uncalibrated, unrounded raw value returned by the sensor, in g, as a floating point number

On failure, throws an exception or returns `Y_CURRENTRAWVALUE_INVALID`.

**accelerometer**→**get\_currentValue()**

**YAccelerometer**

**accelerometer**→**currentValue()**

**accelerometer.get\_currentValue()**

---

Returns the current value of the acceleration, in g, as a floating point number.

```
function get_currentValue( ) As Double
```

**Returns :**

a floating point number corresponding to the current value of the acceleration, in g, as a floating point number

On failure, throws an exception or returns Y\_CURRENTVALUE\_INVALID.

---

**accelerometer→get\_errorMessage()****YAccelerometer****accelerometer→errorMessage()****accelerometer.get\_errorMessage()**

---

Returns the error message of the latest error with the accelerometer.

```
function get_errorMessage( ) As String
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using the accelerometer object

**accelerometer**→**get\_errorType()**

**YAccelerometer**

**accelerometer**→**errorType()**

**accelerometer.get\_errorType()**

---

Returns the numerical error code of the latest error with the accelerometer.

```
function get_errorType( ) As YRETCODE
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using the accelerometer object

---

**accelerometer**→**get\_functionDescriptor()**  
**accelerometer**→**functionDescriptor()**  
**accelerometer.get\_functionDescriptor()**

---

**YAccelerometer**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

function **get\_functionDescriptor**( ) As `YFUN_DESCR`

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`.

If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

**accelerometer→get\_functionId()**  
**accelerometer→functionId()**  
**accelerometer.get\_functionId()**

---

**YAccelerometer**

Returns the hardware identifier of the accelerometer, without reference to the module.

```
function get_functionId( ) As String
```

For example `relay1`

**Returns :**

a string that identifies the accelerometer (ex: `relay1`)

On failure, throws an exception or returns `Y_FUNCTIONID_INVALID`.



---

**accelerometer**→**get\_hardwareId()****YAccelerometer****accelerometer**→**hardwareId()****accelerometer.get\_hardwareId()**

---

Returns the unique hardware identifier of the accelerometer in the form `SERIAL.FUNCTIONID`.

```
function get_hardwareId( ) As String
```

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the accelerometer (for example `RELAYLO1-123456.relay1`).

**Returns :**

a string that uniquely identifies the accelerometer (ex: `RELAYLO1-123456.relay1`)

On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

**accelerometer**→**get\_highestValue()**  
**accelerometer**→**highestValue()**  
**accelerometer.get\_highestValue()**

---

**YAccelerometer**

Returns the maximal value observed for the acceleration since the device was started.

```
function get_highestValue( ) As Double
```

**Returns :**

a floating point number corresponding to the maximal value observed for the acceleration since the device was started

On failure, throws an exception or returns Y\_HIGHESTVALUE\_INVALID.

---

**accelerometer→get\_logFrequency()****YAccelerometer****accelerometer→logFrequency()****accelerometer.get\_logFrequency()**

---

Returns the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory.

```
function get_logFrequency( ) As String
```

**Returns :**

a string corresponding to the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory

On failure, throws an exception or returns `Y_LOGFREQUENCY_INVALID`.

**accelerometer→get\_logicalName()**

**YAccelerometer**

**accelerometer→logicalName()**

**accelerometer.get\_logicalName()**

---

Returns the logical name of the accelerometer.

```
function get_logicalName( ) As String
```

**Returns :**

a string corresponding to the logical name of the accelerometer.

On failure, throws an exception or returns Y\_LOGICALNAME\_INVALID.

---

**accelerometer**→**get\_lowestValue()****YAccelerometer****accelerometer**→**lowestValue()****accelerometer.get\_lowestValue()**

---

Returns the minimal value observed for the acceleration since the device was started.

```
function get_lowestValue( ) As Double
```

**Returns :**

a floating point number corresponding to the minimal value observed for the acceleration since the device was started

On failure, throws an exception or returns `Y_LOWESTVALUE_INVALID`.

**accelerometer**→**get\_module()**

**YAccelerometer**

**accelerometer**→**module()****accelerometer.get\_module()**

---

Gets the YModule object for the device on which the function is located.

function **get\_module()** As YModule

If the function cannot be located on any module, the returned instance of YModule is not shown as on-line.

**Returns :**

an instance of YModule

---

**accelerometer**→**get\_recordedData()****YAccelerometer****accelerometer**→**recordedData()****accelerometer.get\_recordedData()**

---

Retrieves a DataSet object holding historical data for this sensor, for a specified time interval.

```
function get_recordedData( ) As YDataSet
```

The measures will be retrieved from the data logger, which must have been turned on at the desired time. See the documentation of the DataSet class for information on how to get an overview of the recorded data, and how to load progressively a large set of measures from the data logger.

This function only works if the device uses a recent firmware, as DataSet objects are not supported by firmwares older than version 13000.

**Parameters :**

**startTime** the start of the desired measure time interval, as a Unix timestamp, i.e. the number of seconds since January 1, 1970 UTC. The special value 0 can be used to include any meaasure, without initial limit.

**endTime** the end of the desired measure time interval, as a Unix timestamp, i.e. the number of seconds since January 1, 1970 UTC. The special value 0 can be used to include any meaasure, without ending limit.

**Returns :**

an instance of YDataSet, providing access to historical data. Past measures can be loaded progressively using methods from the YDataSet object.

**accelerometer→get\_reportFrequency()**

**YAccelerometer**

**accelerometer→reportFrequency()**

**accelerometer.get\_reportFrequency()**

---

Returns the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function.

```
function get_reportFrequency( ) As String
```

**Returns :**

a string corresponding to the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function

On failure, throws an exception or returns Y\_REPORTFREQUENCY\_INVALID.



---

**accelerometer**→**get\_resolution()****YAccelerometer****accelerometer**→**resolution()****accelerometer.get\_resolution()**

---

Returns the resolution of the measured values.

```
function get_resolution( ) As Double
```

The resolution corresponds to the numerical precision of the measures, which is not always the same as the actual precision of the sensor.

**Returns :**

a floating point number corresponding to the resolution of the measured values

On failure, throws an exception or returns `Y_RESOLUTION_INVALID`.

**accelerometer**→**get\_unit()**

**YAccelerometer**

**accelerometer**→**unit()****accelerometer.get\_unit()**

---

Returns the measuring unit for the acceleration.

function **get\_unit**( ) As String

**Returns :**

a string corresponding to the measuring unit for the acceleration

On failure, throws an exception or returns `Y_UNIT_INVALID`.

---

**accelerometer→get\_userData()****YAccelerometer****accelerometer→userData()****accelerometer.getUserData()**

---

Returns the value of the userData attribute, as previously stored using method `set_userdata`.

```
function getUserData( ) As Object
```

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

**accelerometer**→**get\_xValue()**

**YAccelerometer**

**accelerometer**→**xValue()****accelerometer.get\_xValue()**

---

Returns the X component of the acceleration, as a floating point number.

function **get\_xValue**( ) As Double

**Returns :**

a floating point number corresponding to the X component of the acceleration, as a floating point number

On failure, throws an exception or returns `Y_XVALUE_INVALID`.

---

**accelerometer**→**get\_yValue()****YAccelerometer****accelerometer**→**yValue()****accelerometer.get\_yValue()**

---

Returns the Y component of the acceleration, as a floating point number.

function **get\_yValue( )** As Double

**Returns :**

a floating point number corresponding to the Y component of the acceleration, as a floating point number

On failure, throws an exception or returns `Y_YVALUE_INVALID`.

**accelerometer**→**get\_zValue()**

**YAccelerometer**

**accelerometer**→**zValue()****accelerometer.get\_zValue()**

---

Returns the Z component of the acceleration, as a floating point number.

function **get\_zValue**( ) As Double

**Returns :**

a floating point number corresponding to the Z component of the acceleration, as a floating point number

On failure, throws an exception or returns `Y_ZVALUE_INVALID`.

**accelerometer**→**isOnline()****accelerometer.isOnline()****YAccelerometer**

Checks if the accelerometer is currently reachable, without raising any error.

function **isOnline**( ) As Boolean

If there is a cached value for the accelerometer in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the accelerometer.

**Returns :**

`true` if the accelerometer can be reached, and `false` otherwise

**accelerometer** → **load()** **accelerometer.load()****YAccelerometer**

Preloads the accelerometer cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.



---

**accelerometer**→**loadCalibrationPoints()**  
**accelerometer.loadCalibrationPoints()****YAccelerometer**

---

Retrieves error correction data points previously entered using the method `calibrateFromPoints`.

procedure **loadCalibrationPoints( )**

**Parameters :**

**rawValues** array of floating point numbers, that will be filled by the function with the raw sensor values for the correction points.

**refValues** array of floating point numbers, that will be filled by the function with the desired values for the correction points.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**accelerometer**→**nextAccelerometer()**  
**accelerometer.nextAccelerometer()**

**YAccelerometer**

---

Continues the enumeration of accelerometers started using `yFirstAccelerometer()`.

function **nextAccelerometer**( ) As YAccelerometer

**Returns :**

a pointer to a `YAccelerometer` object, corresponding to an accelerometer currently online, or a `null` pointer if there are no more accelerometers to enumerate.

---

**accelerometer**→**registerTimedReportCallback()**  
**accelerometer.registerTimedReportCallback()**

---

**YAccelerometer**

Registers the callback function that is invoked on every periodic timed notification.

```
function registerTimedReportCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and an `YMeasure` object describing the new advertised value.

**accelerometer**→**registerValueCallback()**  
**accelerometer.registerValueCallback()**

**YAccelerometer**

---

Registers the callback function that is invoked on every change of advertised value.

```
function registerValueCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

---

**accelerometer→set\_highestValue()****YAccelerometer****accelerometer→setHighestValue()****accelerometer.set\_highestValue()**

---

Changes the recorded maximal value observed.

```
function set_highestValue( ByVal newval As Double) As Integer
```

**Parameters :**

**newval** a floating point number corresponding to the recorded maximal value observed

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**accelerometer**→**set\_logFrequency()**  
**accelerometer**→**setLogFrequency()**  
**accelerometer.set\_logFrequency()**

---

**YAccelerometer**

Changes the datalogger recording frequency for this function.

```
function set_logFrequency( ByVal newval As String) As Integer
```

The frequency can be specified as samples per second, as sample per minute (for instance "15/m") or in samples per hour (eg. "4/h"). To disable recording for this function, use the value "OFF".

**Parameters :**

**newval** a string corresponding to the datalogger recording frequency for this function

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**accelerometer**→**set\_logicalName()****YAccelerometer****accelerometer**→**setLogicalName()****accelerometer.set\_logicalName()**

---

Changes the logical name of the accelerometer.

```
function set_logicalName( ByVal newval As String) As Integer
```

You can use `yCheckLogicalName( )` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash( )` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the accelerometer.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**accelerometer**→**set\_lowestValue()**  
**accelerometer**→**setLowestValue()**  
**accelerometer.set\_lowestValue()**

---

**YAccelerometer**

Changes the recorded minimal value observed.

```
function set_lowestValue( ByVal newval As Double) As Integer
```

**Parameters :**

**newval** a floating point number corresponding to the recorded minimal value observed

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.



---

**accelerometer**→**set\_reportFrequency()****YAccelerometer****accelerometer**→**setReportFrequency()****accelerometer.set\_reportFrequency()**

---

Changes the timed value notification frequency for this function.

```
function set_reportFrequency( ByVal newval As String) As Integer
```

The frequency can be specified as samples per second, as sample per minute (for instance "15/m") or in samples per hour (eg. "4/h"). To disable timed value notifications for this function, use the value "OFF".

**Parameters :**

**newval** a string corresponding to the timed value notification frequency for this function

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**accelerometer**→**set\_resolution()**  
**accelerometer**→**setResolution()**  
**accelerometer.set\_resolution()**

---

**YAccelerometer**

Changes the resolution of the measured physical values.

```
function set_resolution( ByVal newval As Double) As Integer
```

The resolution corresponds to the numerical precision when displaying value. It does not change the precision of the measure itself.

**Parameters :**

**newval** a floating point number corresponding to the resolution of the measured physical values

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**accelerometer→set\_userdata()****YAccelerometer****accelerometer→setUserData()****accelerometer.set\_userdata()**

---

Stores a user context provided as argument in the `userData` attribute of the function.

```
procedure set_userdata( ByVal data As Object)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

### 3.3. Altitude function interface

The Yoctopuce application programming interface allows you to read an instant measure of the sensor, as well as the minimal and maximal values observed.

In order to use the functions described here, you should include:

js	<script type='text/javascript' src='yocto_altitude.js'></script>
nodejs	var yoctolib = require('yoctolib'); var YAltitude = yoctolib.YAltitude;
php	require_once('yocto_altitude.php');
c++	#include "yocto_altitude.h"
m	#import "yocto_altitude.h"
pas	uses yocto_altitude;
vb	yocto_altitude.vb
cs	yocto_altitude.cs
java	import com.yoctopuce.YoctoAPI.YAltitude;
py	from yocto_altitude import *

#### Global functions

##### yFindAltitude(func)

Retrieves an altimeter for a given identifier.

##### yFirstAltitude()

Starts the enumeration of altimeters currently accessible.

#### YAltitude methods

##### altitude→calibrateFromPoints(rawValues, refValues)

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

##### altitude→describe()

Returns a short text that describes unambiguously the instance of the altimeter in the form `TYPE ( NAME ) = SERIAL . FUNCTIONID`.

##### altitude→get\_advertisedValue()

Returns the current value of the altimeter (no more than 6 characters).

##### altitude→get\_currentRawValue()

Returns the uncalibrated, unrounded raw value returned by the sensor, in meters, as a floating point number.

##### altitude→get\_currentValue()

Returns the current value of the altitude, in meters, as a floating point number.

##### altitude→get\_errorMessage()

Returns the error message of the latest error with the altimeter.

##### altitude→get\_errorType()

Returns the numerical error code of the latest error with the altimeter.

##### altitude→get\_friendlyName()

Returns a global identifier of the altimeter in the format `MODULE_NAME . FUNCTION_NAME`.

##### altitude→get\_functionDescriptor()

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

##### altitude→get\_functionId()

Returns the hardware identifier of the altimeter, without reference to the module.

##### altitude→get\_hardwareId()

Returns the unique hardware identifier of the altimeter in the form `SERIAL . FUNCTIONID`.

**altitude**→**get\_highestValue()**

Returns the maximal value observed for the altitude since the device was started.

**altitude**→**get\_logFrequency()**

Returns the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory.

**altitude**→**get\_logicalName()**

Returns the logical name of the altimeter.

**altitude**→**get\_lowestValue()**

Returns the minimal value observed for the altitude since the device was started.

**altitude**→**get\_module()**

Gets the `YModule` object for the device on which the function is located.

**altitude**→**get\_module\_async(callback, context)**

Gets the `YModule` object for the device on which the function is located (asynchronous version).

**altitude**→**get\_qnh()**

Returns the barometric pressure adjusted to sea level used to compute the altitude (QNH).

**altitude**→**get\_recordedData(startTime, endTime)**

Retrieves a `DataSet` object holding historical data for this sensor, for a specified time interval.

**altitude**→**get\_reportFrequency()**

Returns the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function.

**altitude**→**get\_resolution()**

Returns the resolution of the measured values.

**altitude**→**get\_unit()**

Returns the measuring unit for the altitude.

**altitude**→**get\_userData()**

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

**altitude**→**isOnline()**

Checks if the altimeter is currently reachable, without raising any error.

**altitude**→**isOnline\_async(callback, context)**

Checks if the altimeter is currently reachable, without raising any error (asynchronous version).

**altitude**→**load(msValidity)**

Preloads the altimeter cache with a specified validity duration.

**altitude**→**loadCalibrationPoints(rawValues, refValues)**

Retrieves error correction data points previously entered using the method `calibrateFromPoints`.

**altitude**→**load\_async(msValidity, callback, context)**

Preloads the altimeter cache with a specified validity duration (asynchronous version).

**altitude**→**nextAltitude()**

Continues the enumeration of altimeters started using `yFirstAltitude()`.

**altitude**→**registerTimedReportCallback(callback)**

Registers the callback function that is invoked on every periodic timed notification.

**altitude**→**registerValueCallback(callback)**

Registers the callback function that is invoked on every change of advertised value.

**altitude**→**set\_currentValue(newval)**

Changes the current estimated altitude.

**altitude**→**set\_highestValue(newval)**

Changes the recorded maximal value observed.

### 3. Reference

---

**altitude**→**set\_logFrequency**(**newval**)

Changes the datalogger recording frequency for this function.

**altitude**→**set\_logicalName**(**newval**)

Changes the logical name of the altimeter.

**altitude**→**set\_lowestValue**(**newval**)

Changes the recorded minimal value observed.

**altitude**→**set\_qnh**(**newval**)

Changes the barometric pressure adjusted to sea level used to compute the altitude (QNH).

**altitude**→**set\_reportFrequency**(**newval**)

Changes the timed value notification frequency for this function.

**altitude**→**set\_resolution**(**newval**)

Changes the resolution of the measured physical values.

**altitude**→**set\_userData**(**data**)

Stores a user context provided as argument in the userData attribute of the function.

**altitude**→**wait\_async**(**callback**, **context**)

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.

## **YAltitude.FindAltitude() yFindAltitude()**

**YAltitude**

Retrieves an altimeter for a given identifier.

```
function yFindAltitude( ByVal func As String) As YAltitude
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the altimeter is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YAltitude.IsOnline()` to test if the altimeter is indeed online at a given time. In case of ambiguity when looking for an altimeter by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

**Parameters :**

**func** a string that uniquely characterizes the altimeter

**Returns :**

a `YAltitude` object allowing you to drive the altimeter.

## **YAltitude.FirstAltitude() yFirstAltitude()yFirstAltitude()**

---

**YAltitude**

Starts the enumeration of altimeters currently accessible.

```
function yFirstAltitude( ) As YAltitude
```

Use the method `YAltitude.nextAltitude()` to iterate on next altimeters.

**Returns :**

a pointer to a `YAltitude` object, corresponding to the first altimeter currently online, or a `null` pointer if there are none.



---

**altitude**→**calibrateFromPoints()**  
**altitude.calibrateFromPoints()****YAltitude**

---

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

**procedure calibrateFromPoints( )**

It is possible to configure up to five correction points. Correction points must be provided in ascending order, and be in the range of the sensor. The device will automatically perform a linear interpolation of the error correction between specified points. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

For more information on advanced capabilities to refine the calibration of sensors, please contact [support@yoctopuce.com](mailto:support@yoctopuce.com).

**Parameters :**

**rawValues** array of floating point numbers, corresponding to the raw values returned by the sensor for the correction points.

**refValues** array of floating point numbers, corresponding to the corrected values for the correction points.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**altitude**→**describe()**(altitude.describe())**YAltitude**

Returns a short text that describes unambiguously the instance of the altimeter in the form `TYPE (NAME) =SERIAL . FUNCTIONID`.

function **describe**( ) As String

More precisely, `TYPE` is the type of the function, `NAME` is the name used for the first access to the function, `SERIAL` is the serial number of the module if the module is connected or "unresolved", and `FUNCTIONID` is the hardware identifier of the function if the module is connected. For example, this method returns `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1` if the module is already connected or `Relay(BadCustomeName.relay1)=unresolved` if the module has not yet been connected. This method does not trigger any USB or TCP transaction and can therefore be used in a debugger.

**Returns :**

a string that describes the altimeter (ex: `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1`)

---

**altitude**→**get\_advertisedValue()****YAltitude****altitude**→**advertisedValue()****altitude.get\_advertisedValue()**

---

Returns the current value of the altimeter (no more than 6 characters).

```
function get_advertisedValue( ) As String
```

**Returns :**

a string corresponding to the current value of the altimeter (no more than 6 characters).

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

**altitude**→**get\_currentRawValue()**

**YAltitude**

**altitude**→**currentRawValue()**

**altitude.get\_currentRawValue()**

---

Returns the uncalibrated, unrounded raw value returned by the sensor, in meters, as a floating point number.

```
function get_currentRawValue( ) As Double
```

**Returns :**

a floating point number corresponding to the uncalibrated, unrounded raw value returned by the sensor, in meters, as a floating point number

On failure, throws an exception or returns `Y_CURRENTRAWVALUE_INVALID`.

---

**altitude**→**get\_currentValue()****YAltitude****altitude**→**currentValue()****altitude.get\_currentValue()**

---

Returns the current value of the altitude, in meters, as a floating point number.

function **get\_currentValue()** As Double

**Returns :**

a floating point number corresponding to the current value of the altitude, in meters, as a floating point number

On failure, throws an exception or returns `Y_CURRENTVALUE_INVALID`.

**altitude**→**get\_errorMessage()**

**YAltitude**

**altitude**→**errorMessage()****altitude**.**get\_errorMessage()**

---

Returns the error message of the latest error with the altimeter.

```
function get_errorMessage( ) As String
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using the altimeter object

---

**altitude**→**get\_errorType()****YAltitude****altitude**→**errorType()****altitude.get\_errorType()**

---

Returns the numerical error code of the latest error with the altimeter.

```
function get_errorType( ) As YRETCODE
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using the altimeter object

**altitude**→**get\_functionDescriptor()**

**YAltitude**

**altitude**→**functionDescriptor()**

**altitude.get\_functionDescriptor()**

---

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

`function get_functionDescriptor( )` As `YFUN_DESCR`

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`.

If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.



---

**altitude**→**get\_functionId()****YAltitude****altitude**→**functionId()****altitude.get\_functionId()**

---

Returns the hardware identifier of the altimeter, without reference to the module.

function **get\_functionId()** As String

For example `relay1`

**Returns :**

a string that identifies the altimeter (ex: `relay1`)

On failure, throws an exception or returns `Y_FUNCTIONID_INVALID`.

**altitude**→**get\_hardwareId()**

**YAltitude**

**altitude**→**hardwareId()****altitude.get\_hardwareId()**

---

Returns the unique hardware identifier of the altimeter in the form `SERIAL.FUNCTIONID`.

function **get\_hardwareId()** As String

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the altimeter (for example `RELAYLO1-123456.relay1`).

**Returns :**

a string that uniquely identifies the altimeter (ex: `RELAYLO1-123456.relay1`)

On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

---

**altitude**→**get\_highestValue()****YAltitude****altitude**→**highestValue()****altitude.get\_highestValue()**

---

Returns the maximal value observed for the altitude since the device was started.

```
function get_highestValue( ) As Double
```

**Returns :**

a floating point number corresponding to the maximal value observed for the altitude since the device was started

On failure, throws an exception or returns `Y_HIGHESTVALUE_INVALID`.

**altitude**→**get\_logFrequency()**

**YAltitude**

**altitude**→**logFrequency()****altitude.get\_logFrequency()**

---

Returns the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory.

function **get\_logFrequency()** As String

**Returns :**

a string corresponding to the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory

On failure, throws an exception or returns Y\_LOGFREQUENCY\_INVALID.

---

**altitude**→**get\_logicalName()****YAltitude****altitude**→**logicalName()****altitude.get\_logicalName()**

---

Returns the logical name of the altimeter.

```
function get_logicalName( ) As String
```

**Returns :**

a string corresponding to the logical name of the altimeter.

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

**altitude**→**get\_lowestValue()**

**YAltitude**

**altitude**→**lowestValue()****altitude.get\_lowestValue()**

---

Returns the minimal value observed for the altitude since the device was started.

function **get\_lowestValue()** As Double

**Returns :**

a floating point number corresponding to the minimal value observed for the altitude since the device was started

On failure, throws an exception or returns **Y\_LOWESTVALUE\_INVALID**.

---

**altitude**→**get\_module()****YAltitude****altitude**→**module()****altitude.get\_module()**

---

Gets the `YModule` object for the device on which the function is located.

```
function get_module( ) As YModule
```

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

**Returns :**

an instance of `YModule`

**altitude**→**get\_qnh()**

**YAltitude**

**altitude**→**qnh()****altitude.get\_qnh()**

---

Returns the barometric pressure adjusted to sea level used to compute the altitude (QNH).

function **get\_qnh**( ) As Double

**Returns :**

a floating point number corresponding to the barometric pressure adjusted to sea level used to compute the altitude (QNH)

On failure, throws an exception or returns `Y_QNH_INVALID`.



---

**altitude**→**get\_recordedData()****YAltitude****altitude**→**recordedData()****altitude.get\_recordedData()**

---

Retrieves a DataSet object holding historical data for this sensor, for a specified time interval.

```
function get_recordedData( ) As YDataSet
```

The measures will be retrieved from the data logger, which must have been turned on at the desired time. See the documentation of the DataSet class for information on how to get an overview of the recorded data, and how to load progressively a large set of measures from the data logger.

This function only works if the device uses a recent firmware, as DataSet objects are not supported by firmwares older than version 13000.

**Parameters :**

- startTime** the start of the desired measure time interval, as a Unix timestamp, i.e. the number of seconds since January 1, 1970 UTC. The special value 0 can be used to include any measure, without initial limit.
- endTime** the end of the desired measure time interval, as a Unix timestamp, i.e. the number of seconds since January 1, 1970 UTC. The special value 0 can be used to include any measure, without ending limit.

**Returns :**

an instance of YDataSet, providing access to historical data. Past measures can be loaded progressively using methods from the YDataSet object.

**altitude**→**get\_reportFrequency()**

**YAltitude**

**altitude**→**reportFrequency()**

**altitude.get\_reportFrequency()**

---

Returns the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function.

```
function get_reportFrequency( ) As String
```

**Returns :**

a string corresponding to the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function

On failure, throws an exception or returns Y\_REPORTFREQUENCY\_INVALID.

---

**altitude**→**get\_resolution()****YAltitude****altitude**→**resolution()****altitude.get\_resolution()**

---

Returns the resolution of the measured values.

function **get\_resolution**( ) As Double

The resolution corresponds to the numerical precision of the measures, which is not always the same as the actual precision of the sensor.

**Returns :**

a floating point number corresponding to the resolution of the measured values

On failure, throws an exception or returns `Y_RESOLUTION_INVALID`.

**altitude**→**get\_unit()**

**YAltitude**

**altitude**→**unit()****altitude.get\_unit()**

---

Returns the measuring unit for the altitude.

function **get\_unit**( ) As String

**Returns :**

a string corresponding to the measuring unit for the altitude

On failure, throws an exception or returns `Y_UNIT_INVALID`.

---

**altitude**→**get\_userData()****YAltitude****altitude**→**userData()****altitude.get\_userData()**

---

Returns the value of the userData attribute, as previously stored using method `set_userData`.

```
function get_userData( ) As Object
```

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

**altitude**→**isOnline()****altitude.isOnline()**

**YAltimeter**

---

Checks if the altimeter is currently reachable, without raising any error.

function **isOnline**( ) As Boolean

If there is a cached value for the altimeter in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the altimeter.

**Returns :**

`true` if the altimeter can be reached, and `false` otherwise

**altitude**→**load()****altitude.load()****YAltitude**

Preloads the altimeter cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

**altitude→loadCalibrationPoints()  
altitude.loadCalibrationPoints()**

**YAltitude**

Retrieves error correction data points previously entered using the method `calibrateFromPoints`.

procedure **loadCalibrationPoints( )**

**Parameters :**

**rawValues** array of floating point numbers, that will be filled by the function with the raw sensor values for the correction points.

**refValues** array of floating point numbers, that will be filled by the function with the desired values for the correction points.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.



---

**altitude**→**nextAltitude()****altitude.nextAltitude()****YAltitude**

---

Continues the enumeration of altimeters started using `yFirstAltitude()`.

```
function nextAltitude( ) As YAltitude
```

**Returns :**

a pointer to a `YAltitude` object, corresponding to an altimeter currently online, or a `null` pointer if there are no more altimeters to enumerate.

**altitude**→**registerTimedReportCallback()**  
**altitude.registerTimedReportCallback()****YAltitude**

Registers the callback function that is invoked on every periodic timed notification.

```
function registerTimedReportCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and an `YMeasure` object describing the new advertised value.

---

**altitude**→**registerValueCallback()**  
**altitude.registerValueCallback()**

---

**YAltitude**

Registers the callback function that is invoked on every change of advertised value.

```
function registerValueCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

**altitude**→**set\_currentValue()**  
**altitude**→**setCurrentValue()**  
**altitude.set\_currentValue()**

---

**YAltitude**

Changes the current estimated altitude.

```
function set_currentValue( ByVal newval As Double) As Integer
```

This allows to compensate for ambient pressure variations and to work in relative mode.

**Parameters :**

**newval** a floating point number corresponding to the current estimated altitude

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**altitude**→**set\_highestValue()**  
**altitude**→**setHighestValue()**  
**altitude.set\_highestValue()**

---

**YAltitude**

Changes the recorded maximal value observed.

```
function set_highestValue( ByVal newval As Double) As Integer
```

**Parameters :**

**newval** a floating point number corresponding to the recorded maximal value observed

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**altitude**→**set\_logFrequency()**

**YAltitude**

**altitude**→**setLogFrequency()**

**altitude.set\_logFrequency()**

---

Changes the datalogger recording frequency for this function.

```
function set_logFrequency( ByVal newval As String) As Integer
```

The frequency can be specified as samples per second, as sample per minute (for instance "15/m") or in samples per hour (eg. "4/h"). To disable recording for this function, use the value "OFF".

**Parameters :**

**newval** a string corresponding to the datalogger recording frequency for this function

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**altitude**→**set\_logicalName()****YAltitude****altitude**→**setLogicalName()****altitude.set\_logicalName()**

---

Changes the logical name of the altimeter.

```
function set_logicalName( ByVal newval As String) As Integer
```

You can use `yCheckLogicalName( )` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash( )` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the altimeter.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**altitude**→**set\_lowestValue()**

**YAltitude**

**altitude**→**setLowestValue()****altitude.set\_lowestValue()**

---

Changes the recorded minimal value observed.

```
function set_lowestValue( ByVal newval As Double) As Integer
```

**Parameters :**

**newval** a floating point number corresponding to the recorded minimal value observed

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.



---

**altitude**→**set\_qnh()****YAltitude****altitude**→**setQnh()****altitude.set\_qnh()**

---

Changes the barometric pressure adjusted to sea level used to compute the altitude (QNH).

```
function set_qnh( ByVal newval As Double) As Integer
```

This enables you to compensate for atmospheric pressure changes due to weather conditions.

**Parameters :**

**newval** a floating point number corresponding to the barometric pressure adjusted to sea level used to compute the altitude (QNH)

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**altitude**→**set\_reportFrequency()**

**YAltitude**

**altitude**→**setReportFrequency()**

**altitude.set\_reportFrequency()**

---

Changes the timed value notification frequency for this function.

```
function set_reportFrequency( ByVal newval As String) As Integer
```

The frequency can be specified as samples per second, as sample per minute (for instance "15/m") or in samples per hour (eg. "4/h"). To disable timed value notifications for this function, use the value "OFF".

**Parameters :**

**newval** a string corresponding to the timed value notification frequency for this function

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**altitude**→**set\_resolution()****YAltitude****altitude**→**setResolution()****altitude.set\_resolution()**

---

Changes the resolution of the measured physical values.

```
function set_resolution( ByVal newval As Double) As Integer
```

The resolution corresponds to the numerical precision when displaying value. It does not change the precision of the measure itself.

**Parameters :**

**newval** a floating point number corresponding to the resolution of the measured physical values

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**altitude**→**set\_userData()**

**YAltitude**

**altitude**→**setUserData()****altitude.set\_userData()**

---

Stores a user context provided as argument in the `userData` attribute of the function.

```
procedure set_userData( ByVal data As Object)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

## 3.4. AnButton function interface

Yoctopuce application programming interface allows you to measure the state of a simple button as well as to read an analog potentiometer (variable resistance). This can be use for instance with a continuous rotating knob, a throttle grip or a joystick. The module is capable to calibrate itself on min and max values, in order to compute a calibrated value that varies proportionally with the potentiometer position, regardless of its total resistance.

In order to use the functions described here, you should include:

js	<script type='text/javascript' src='yocto_anbutton.js'></script>
nodejs	var yoctolib = require('yoctolib'); var YAnButton = yoctolib.YAnButton;
php	require_once('yocto_anbutton.php');
c++	#include "yocto_anbutton.h"
m	#import "yocto_anbutton.h"
pas	uses yocto_anbutton;
vb	yocto_anbutton.vb
cs	yocto_anbutton.cs
java	import com.yoctopuce.YoctoAPI.YAnButton;
py	from yocto_anbutton import *

### Global functions

#### **yFindAnButton(func)**

Retrieves an analog input for a given identifier.

#### **yFirstAnButton()**

Starts the enumeration of analog inputs currently accessible.

### YAnButton methods

#### **anbutton→describe()**

Returns a short text that describes unambiguously the instance of the analog input in the form `TYPE ( NAME ) =SERIAL . FUNCTIONID`.

#### **anbutton→get\_advertisedValue()**

Returns the current value of the analog input (no more than 6 characters).

#### **anbutton→get\_analogCalibration()**

Tells if a calibration process is currently ongoing.

#### **anbutton→get\_calibratedValue()**

Returns the current calibrated input value (between 0 and 1000, included).

#### **anbutton→get\_calibrationMax()**

Returns the maximal value measured during the calibration (between 0 and 4095, included).

#### **anbutton→get\_calibrationMin()**

Returns the minimal value measured during the calibration (between 0 and 4095, included).

#### **anbutton→get\_errorMessage()**

Returns the error message of the latest error with the analog input.

#### **anbutton→get\_errorType()**

Returns the numerical error code of the latest error with the analog input.

#### **anbutton→get\_friendlyName()**

Returns a global identifier of the analog input in the format `MODULE_NAME . FUNCTION_NAME`.

#### **anbutton→get\_functionDescriptor()**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

**anbutton**→**get\_functionId()**

Returns the hardware identifier of the analog input, without reference to the module.

**anbutton**→**get\_hardwareId()**

Returns the unique hardware identifier of the analog input in the form `SERIAL.FUNCTIONID`.

**anbutton**→**get\_isPressed()**

Returns true if the input (considered as binary) is active (closed contact), and false otherwise.

**anbutton**→**get\_lastTimePressed()**

Returns the number of elapsed milliseconds between the module power on and the last time the input button was pressed (the input contact transitioned from open to closed).

**anbutton**→**get\_lastTimeReleased()**

Returns the number of elapsed milliseconds between the module power on and the last time the input button was released (the input contact transitioned from closed to open).

**anbutton**→**get\_logicalName()**

Returns the logical name of the analog input.

**anbutton**→**get\_module()**

Gets the `YModule` object for the device on which the function is located.

**anbutton**→**get\_module\_async(callback, context)**

Gets the `YModule` object for the device on which the function is located (asynchronous version).

**anbutton**→**get\_pulseCounter()**

Returns the pulse counter value

**anbutton**→**get\_pulseTimer()**

Returns the timer of the pulses counter (ms)

**anbutton**→**get\_rawValue()**

Returns the current measured input value as-is (between 0 and 4095, included).

**anbutton**→**get\_sensitivity()**

Returns the sensibility for the input (between 1 and 1000) for triggering user callbacks.

**anbutton**→**get\_userData()**

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

**anbutton**→**isOnline()**

Checks if the analog input is currently reachable, without raising any error.

**anbutton**→**isOnline\_async(callback, context)**

Checks if the analog input is currently reachable, without raising any error (asynchronous version).

**anbutton**→**load(msValidity)**

Preloads the analog input cache with a specified validity duration.

**anbutton**→**load\_async(msValidity, callback, context)**

Preloads the analog input cache with a specified validity duration (asynchronous version).

**anbutton**→**nextAnButton()**

Continues the enumeration of analog inputs started using `yFirstAnButton()`.

**anbutton**→**registerValueCallback(callback)**

Registers the callback function that is invoked on every change of advertised value.

**anbutton**→**resetCounter()**

Returns the pulse counter value as well as his timer

**anbutton**→**set\_analogCalibration(newval)**

Starts or stops the calibration process.

**anbutton**→**set\_calibrationMax(newval)**

Changes the maximal calibration value for the input (between 0 and 4095, included), without actually starting the automated calibration.

**anbutton**→**set\_calibrationMin(newval)**

Changes the minimal calibration value for the input (between 0 and 4095, included), without actually starting the automated calibration.

**anbutton**→**set\_logicalName(newval)**

Changes the logical name of the analog input.

**anbutton**→**set\_sensitivity(newval)**

Changes the sensibility for the input (between 1 and 1000) for triggering user callbacks.

**anbutton**→**set\_userData(data)**

Stores a user context provided as argument in the userData attribute of the function.

**anbutton**→**wait\_async(callback, context)**

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.

## YAnButton.FindAnButton() yFindAnButton()yFindAnButton()

YAnButton

Retrieves an analog input for a given identifier.

```
function yFindAnButton( ByVal func As String) As YAnButton
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the analog input is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YAnButton.IsOnline()` to test if the analog input is indeed online at a given time. In case of ambiguity when looking for an analog input by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

### Parameters :

**func** a string that uniquely characterizes the analog input

### Returns :

a `YAnButton` object allowing you to drive the analog input.



---

**YAnButton.FirstAnButton()  
yFirstAnButton()yFirstAnButton()**

---

**YAnButton**

Starts the enumeration of analog inputs currently accessible.

```
function yFirstAnButton( ) As YAnButton
```

Use the method `YAnButton.NextAnButton()` to iterate on next analog inputs.

**Returns :**

a pointer to a `YAnButton` object, corresponding to the first analog input currently online, or a `null` pointer if there are none.

**anbutton**→**describe()****anbutton.describe()****YAnButton**

Returns a short text that describes unambiguously the instance of the analog input in the form `TYPE (NAME) =SERIAL . FUNCTIONID`.

function **describe**( ) As String

More precisely, `TYPE` is the type of the function, `NAME` it the name used for the first access to the function, `SERIAL` is the serial number of the module if the module is connected or "unresolved", and `FUNCTIONID` is the hardware identifier of the function if the module is connected. For example, this method returns `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1` if the module is already connected or `Relay(BadCustomeName.relay1)=unresolved` if the module has not yet been connected. This method does not trigger any USB or TCP transaction and can therefore be used in a debugger.

**Returns :**

a string that describes the analog input (ex: `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1`)

---

**anbutton**→**get\_advertisedValue()****YAnButton****anbutton**→**advertisedValue()****anbutton.get\_advertisedValue()**

---

Returns the current value of the analog input (no more than 6 characters).

```
function get_advertisedValue( ) As String
```

**Returns :**

a string corresponding to the current value of the analog input (no more than 6 characters).

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

**anbutton**→**get\_analogCalibration()**

**YAnButton**

**anbutton**→**analogCalibration()**

**anbutton.get\_analogCalibration()**

---

Tells if a calibration process is currently ongoing.

```
function get_analogCalibration( ) As Integer
```

**Returns :**

either Y\_ANALOGCALIBRATION\_OFF or Y\_ANALOGCALIBRATION\_ON

On failure, throws an exception or returns Y\_ANALOGCALIBRATION\_INVALID.

---

**anbutton**→**get\_calibratedValue()****YAnButton****anbutton**→**calibratedValue()****anbutton.get\_calibratedValue()**

---

Returns the current calibrated input value (between 0 and 1000, included).

```
function get_calibratedValue( ) As Integer
```

**Returns :**

an integer corresponding to the current calibrated input value (between 0 and 1000, included)

On failure, throws an exception or returns `Y_CALIBRATEDVALUE_INVALID`.

**anbutton**→**get\_calibrationMax()**  
**anbutton**→**calibrationMax()**  
**anbutton.get\_calibrationMax()**

---

**YAnButton**

Returns the maximal value measured during the calibration (between 0 and 4095, included).

```
function get_calibrationMax( ) As Integer
```

**Returns :**

an integer corresponding to the maximal value measured during the calibration (between 0 and 4095, included)

On failure, throws an exception or returns `Y_CALIBRATIONMAX_INVALID`.

---

**anbutton**→**get\_calibrationMin()****YAnButton****anbutton**→**calibrationMin()****anbutton.get\_calibrationMin()**

---

Returns the minimal value measured during the calibration (between 0 and 4095, included).

```
function get_calibrationMin( ) As Integer
```

**Returns :**

an integer corresponding to the minimal value measured during the calibration (between 0 and 4095, included)

On failure, throws an exception or returns Y\_CALIBRATIONMIN\_INVALID.

**anbutton**→**get\_errorMessage()**  
**anbutton**→**errorMessage()**  
**anbutton.get\_errorMessage()**

---

**YAnButton**

Returns the error message of the latest error with the analog input.

```
function get_errorMessage( ) As String
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using the analog input object



---

**anbutton**→**get\_errorType()****YAnButton****anbutton**→**errorType()****anbutton.get\_errorType()**

---

Returns the numerical error code of the latest error with the analog input.

```
function get_errorType( ) As YRETCODE
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using the analog input object

**anbutton**→**get\_functionDescriptor()**  
**anbutton**→**functionDescriptor()**  
**anbutton.get\_functionDescriptor()**

---

**YAnButton**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

```
function get_functionDescriptor( ) As YFUN_DESCR
```

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`.

If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

---

**anbutton**→**get\_functionId()****YAnButton****anbutton**→**functionId()****anbutton.get\_functionId()**

---

Returns the hardware identifier of the analog input, without reference to the module.

function **get\_functionId**( ) As String

For example `relay1`

**Returns :**

a string that identifies the analog input (ex: `relay1`)

On failure, throws an exception or returns `Y_FUNCTIONID_INVALID`.

**anbutton**→**get\_hardwareId()**

**YAnButton**

**anbutton**→**hardwareId()****anbutton.get\_hardwareId()**

---

Returns the unique hardware identifier of the analog input in the form `SERIAL.FUNCTIONID`.

function **get\_hardwareId()** As String

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the analog input (for example `RELAYLO1-123456.relay1`).

**Returns :**

a string that uniquely identifies the analog input (ex: `RELAYLO1-123456.relay1`)

On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

---

**anbutton**→**get\_isPressed()****YAnButton****anbutton**→**isPressed()****anbutton.get\_isPressed()**

---

Returns true if the input (considered as binary) is active (closed contact), and false otherwise.

function **get\_isPressed( )** As Integer

**Returns :**

either `Y_ISPRESSED_FALSE` or `Y_ISPRESSED_TRUE`, according to true if the input (considered as binary) is active (closed contact), and false otherwise

On failure, throws an exception or returns `Y_ISPRESSED_INVALID`.

**anbutton**→**get\_lastTimePressed()**

**YAnButton**

**anbutton**→**lastTimePressed()**

**anbutton.get\_lastTimePressed()**

---

Returns the number of elapsed milliseconds between the module power on and the last time the input button was pressed (the input contact transitioned from open to closed).

function **get\_lastTimePressed**( ) As Long

**Returns :**

an integer corresponding to the number of elapsed milliseconds between the module power on and the last time the input button was pressed (the input contact transitioned from open to closed)

On failure, throws an exception or returns `Y_LASTTIMEPRESSED_INVALID`.

---

**anbutton**→**get\_lastTimeReleased()****YAnButton****anbutton**→**lastTimeReleased()****anbutton.get\_lastTimeReleased()**

---

Returns the number of elapsed milliseconds between the module power on and the last time the input button was released (the input contact transitioned from closed to open).

```
function get_lastTimeReleased( ) As Long
```

**Returns :**

an integer corresponding to the number of elapsed milliseconds between the module power on and the last time the input button was released (the input contact transitioned from closed to open)

On failure, throws an exception or returns `Y_LASTTIMERELASED_INVALID`.

**anbutton**→**get\_logicalName()**

**YAnButton**

**anbutton**→**logicalName()****anbutton.get\_logicalName()**

---

Returns the logical name of the analog input.

function **get\_logicalName**( ) As String

**Returns :**

a string corresponding to the logical name of the analog input.

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.



---

**anbutton**→**get\_module()****YAnButton****anbutton**→**module()****anbutton.get\_module()**

---

Gets the `YModule` object for the device on which the function is located.

```
function get_module( ) As YModule
```

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

**Returns :**

an instance of `YModule`

**anbutton**→**get\_pulseCounter()**  
**anbutton**→**pulseCounter()**  
**anbutton.get\_pulseCounter()**

---

**YAnButton**

Returns the pulse counter value

function **get\_pulseCounter**( ) As Long

**Returns :**

an integer corresponding to the pulse counter value

On failure, throws an exception or returns `Y_PULSECOUNTER_INVALID`.

---

**anbutton**→**get\_pulseTimer()****YAnButton****anbutton**→**pulseTimer()****anbutton.get\_pulseTimer()**

---

Returns the timer of the pulses counter (ms)

function **get\_pulseTimer**( ) As Long

**Returns :**

an integer corresponding to the timer of the pulses counter (ms)

On failure, throws an exception or returns `Y_PULSE_TIMER_INVALID`.

**anbutton**→**get\_rawValue()**

**YAnButton**

**anbutton**→**rawValue()****anbutton.get\_rawValue()**

---

Returns the current measured input value as-is (between 0 and 4095, included).

function **get\_rawValue**( ) As Integer

**Returns :**

an integer corresponding to the current measured input value as-is (between 0 and 4095, included)

On failure, throws an exception or returns `Y_RAWVALUE_INVALID`.

---

**anbutton**→**get\_sensitivity()****YAnButton****anbutton**→**sensitivity()****anbutton.get\_sensitivity()**

---

Returns the sensibility for the input (between 1 and 1000) for triggering user callbacks.

function **get\_sensitivity()** As Integer

**Returns :**

an integer corresponding to the sensibility for the input (between 1 and 1000) for triggering user callbacks

On failure, throws an exception or returns `Y_SENSITIVITY_INVALID`.

**anbutton**→**get\_userData()**

**YAnButton**

**anbutton**→**userData()****anbutton.get\_userData()**

---

Returns the value of the userData attribute, as previously stored using method `set_userData`.

function **get\_userData**( ) As Object

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

---

**anbutton**→**isOnline()**(**anbutton.isOnline()**)**YAnButton**

---

Checks if the analog input is currently reachable, without raising any error.

```
function isOnline( ) As Boolean
```

If there is a cached value for the analog input in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the analog input.

**Returns :**

`true` if the analog input can be reached, and `false` otherwise

**anbutton**→**load()****anbutton.load()****YAnButton**

Preloads the analog input cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.



---

**anbutton**→**nextAnButton()****anbutton.nextAnButton()****YAnButton**

---

Continues the enumeration of analog inputs started using `yFirstAnButton()`.

```
function nextAnButton( ) As YAnButton
```

**Returns :**

a pointer to a `YAnButton` object, corresponding to an analog input currently online, or a `null` pointer if there are no more analog inputs to enumerate.

**anbutton**→**registerValueCallback()**  
**anbutton.registerValueCallback()****YAnButton**

Registers the callback function that is invoked on every change of advertised value.

```
function registerValueCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

---

**anbutton**→**resetCounter()****anbutton.resetCounter()****YAnButton**

---

Returns the pulse counter value as well as his timer

```
function resetCounter( ) As Integer
```

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**anbutton**→**set\_analogCalibration()**  
**anbutton**→**setAnalogCalibration()**  
**anbutton.set\_analogCalibration()**

---

**YAnButton**

Starts or stops the calibration process.

```
function set_analogCalibration( ByVal newval As Integer) As Integer
```

Remember to call the `saveToFlash()` method of the module at the end of the calibration if the modification must be kept.

**Parameters :**

**newval** either `Y_ANALOGCALIBRATION_OFF` or `Y_ANALOGCALIBRATION_ON`

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

**anbutton**→**set\_calibrationMax()**  
**anbutton**→**setCalibrationMax()**  
**anbutton.set\_calibrationMax()**

**YAnButton**

Changes the maximal calibration value for the input (between 0 and 4095, included), without actually starting the automated calibration.

```
function set_calibrationMax( ByVal newval As Integer) As Integer
```

Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** an integer corresponding to the maximal calibration value for the input (between 0 and 4095, included), without actually starting the automated calibration

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**anbutton**→**set\_calibrationMin()**  
**anbutton**→**setCalibrationMin()**  
**anbutton.set\_calibrationMin()**

**YAnButton**

---

Changes the minimal calibration value for the input (between 0 and 4095, included), without actually starting the automated calibration.

```
function set_calibrationMin( ByVal newval As Integer) As Integer
```

Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** an integer corresponding to the minimal calibration value for the input (between 0 and 4095, included), without actually starting the automated calibration

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**anbutton**→**set\_logicalName()**  
**anbutton**→**setLogicalName()**  
**anbutton.set\_logicalName()**

---

**YAnButton**

Changes the logical name of the analog input.

```
function set_logicalName( ByVal newval As String) As Integer
```

You can use `yCheckLogicalName( )` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash( )` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the analog input.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**anbutton**→**set\_sensitivity()****YAnButton****anbutton**→**setSensitivity()****anbutton.set\_sensitivity()**

Changes the sensibility for the input (between 1 and 1000) for triggering user callbacks.

```
function set_sensitivity( ByVal newval As Integer) As Integer
```

The sensibility is used to filter variations around a fixed value, but does not preclude the transmission of events when the input value evolves constantly in the same direction. Special case: when the value 1000 is used, the callback will only be thrown when the logical state of the input switches from pressed to released and back. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** an integer corresponding to the sensibility for the input (between 1 and 1000) for triggering user callbacks

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.



---

**anbutton**→**set\_userData()****YAnButton****anbutton**→**setUserData()****anbutton.set\_userData()**

---

Stores a user context provided as argument in the `userData` attribute of the function.

```
procedure set_userData( ByVal data As Object)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

## 3.5. CarbonDioxide function interface

The Yoctopuce application programming interface allows you to read an instant measure of the sensor, as well as the minimal and maximal values observed.

In order to use the functions described here, you should include:

js	<code>&lt;script type='text/javascript' src='yocto_carbondioxide.js'&gt;&lt;/script&gt;</code>
nodejs	<code>var yoctolib = require('yoctolib'); var YCarbonDioxide = yoctolib.YCarbonDioxide;</code>
php	<code>require_once('yocto_carbondioxide.php');</code>
c++	<code>#include "yocto_carbondioxide.h"</code>
m	<code>#import "yocto_carbondioxide.h"</code>
pas	<code>uses yocto_carbondioxide;</code>
vb	<code>yocto_carbondioxide.vb</code>
cs	<code>yocto_carbondioxide.cs</code>
java	<code>import com.yoctopuce.YoctoAPI.YCarbonDioxide;</code>
py	<code>from yocto_carbondioxide import *</code>

### Global functions

#### **yFindCarbonDioxide(func)**

Retrieves a CO2 sensor for a given identifier.

#### **yFirstCarbonDioxide()**

Starts the enumeration of CO2 sensors currently accessible.

### YCarbonDioxide methods

#### **carbondioxide→calibrateFromPoints(rawValues, refValues)**

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

#### **carbondioxide→describe()**

Returns a short text that describes unambiguously the instance of the CO2 sensor in the form `TYPE ( NAME ) = SERIAL . FUNCTIONID`.

#### **carbondioxide→get\_advertisedValue()**

Returns the current value of the CO2 sensor (no more than 6 characters).

#### **carbondioxide→get\_currentRawValue()**

Returns the uncalibrated, unrounded raw value returned by the sensor, in ppm (vol), as a floating point number.

#### **carbondioxide→get\_currentValue()**

Returns the current value of the CO2 concentration, in ppm (vol), as a floating point number.

#### **carbondioxide→get\_errorMessage()**

Returns the error message of the latest error with the CO2 sensor.

#### **carbondioxide→get\_errorType()**

Returns the numerical error code of the latest error with the CO2 sensor.

#### **carbondioxide→get\_friendlyName()**

Returns a global identifier of the CO2 sensor in the format `MODULE_NAME . FUNCTION_NAME`.

#### **carbondioxide→get\_functionDescriptor()**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

#### **carbondioxide→get\_functionId()**

Returns the hardware identifier of the CO2 sensor, without reference to the module.

#### **carbondioxide→get\_hardwareId()**

Returns the unique hardware identifier of the CO2 sensor in the form `SERIAL.FUNCTIONID`.

**carbondioxide→get\_highestValue()**

Returns the maximal value observed for the CO2 concentration since the device was started.

**carbondioxide→get\_logFrequency()**

Returns the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory.

**carbondioxide→get\_logicalName()**

Returns the logical name of the CO2 sensor.

**carbondioxide→get\_lowestValue()**

Returns the minimal value observed for the CO2 concentration since the device was started.

**carbondioxide→get\_module()**

Gets the `YModule` object for the device on which the function is located.

**carbondioxide→get\_module\_async(callback, context)**

Gets the `YModule` object for the device on which the function is located (asynchronous version).

**carbondioxide→get\_recordedData(startTime, endTime)**

Retrieves a `DataSet` object holding historical data for this sensor, for a specified time interval.

**carbondioxide→get\_reportFrequency()**

Returns the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function.

**carbondioxide→get\_resolution()**

Returns the resolution of the measured values.

**carbondioxide→get\_unit()**

Returns the measuring unit for the CO2 concentration.

**carbondioxide→get\_userData()**

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

**carbondioxide→isOnline()**

Checks if the CO2 sensor is currently reachable, without raising any error.

**carbondioxide→isOnline\_async(callback, context)**

Checks if the CO2 sensor is currently reachable, without raising any error (asynchronous version).

**carbondioxide→load(msValidity)**

Preloads the CO2 sensor cache with a specified validity duration.

**carbondioxide→loadCalibrationPoints(rawValues, refValues)**

Retrieves error correction data points previously entered using the method `calibrateFromPoints`.

**carbondioxide→load\_async(msValidity, callback, context)**

Preloads the CO2 sensor cache with a specified validity duration (asynchronous version).

**carbondioxide→nextCarbonDioxide()**

Continues the enumeration of CO2 sensors started using `yFirstCarbonDioxide()`.

**carbondioxide→registerTimedReportCallback(callback)**

Registers the callback function that is invoked on every periodic timed notification.

**carbondioxide→registerValueCallback(callback)**

Registers the callback function that is invoked on every change of advertised value.

**carbondioxide→set\_highestValue(newval)**

Changes the recorded maximal value observed.

**carbondioxide→set\_logFrequency(newval)**

Changes the datalogger recording frequency for this function.

**carbondioxide→set\_logicalName(newval)**

### 3. Reference

---

Changes the logical name of the CO2 sensor.

**carbondioxide**→**set\_lowestValue(newval)**

Changes the recorded minimal value observed.

**carbondioxide**→**set\_reportFrequency(newval)**

Changes the timed value notification frequency for this function.

**carbondioxide**→**set\_resolution(newval)**

Changes the resolution of the measured physical values.

**carbondioxide**→**set\_userData(data)**

Stores a user context provided as argument in the userData attribute of the function.

**carbondioxide**→**wait\_async(callback, context)**

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.

## YCarbonDioxide.FindCarbonDioxide() yFindCarbonDioxide()yFindCarbonDioxide()

## YCarbonDioxide

Retrieves a CO2 sensor for a given identifier.

```
function yFindCarbonDioxide( ByVal func As String) As YCarbonDioxide
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the CO2 sensor is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YCarbonDioxide.isOnline()` to test if the CO2 sensor is indeed online at a given time. In case of ambiguity when looking for a CO2 sensor by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

### Parameters :

**func** a string that uniquely characterizes the CO2 sensor

### Returns :

a `YCarbonDioxide` object allowing you to drive the CO2 sensor.

## **YCarbonDioxide.FirstCarbonDioxide() yFirstCarbonDioxide()yFirstCarbonDioxide()**

---

**YCarbonDioxide**

Starts the enumeration of CO2 sensors currently accessible.

```
function yFirstCarbonDioxide( ) As YCarbonDioxide
```

Use the method `YCarbonDioxide.nextCarbonDioxide()` to iterate on next CO2 sensors.

**Returns :**

a pointer to a `YCarbonDioxide` object, corresponding to the first CO2 sensor currently online, or a `null` pointer if there are none.

---

**carbondioxide→calibrateFromPoints()  
carbondioxide.calibrateFromPoints()**

---

**YCarbonDioxide**

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

procedure **calibrateFromPoints()**

It is possible to configure up to five correction points. Correction points must be provided in ascending order, and be in the range of the sensor. The device will automatically perform a linear interpolation of the error correction between specified points. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

For more information on advanced capabilities to refine the calibration of sensors, please contact [support@yoctopuce.com](mailto:support@yoctopuce.com).

**Parameters :**

**rawValues** array of floating point numbers, corresponding to the raw values returned by the sensor for the correction points.

**refValues** array of floating point numbers, corresponding to the corrected values for the correction points.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**carbondioxide→describe()carbondioxide.describe()****YCarbonDioxide**

Returns a short text that describes unambiguously the instance of the CO2 sensor in the form `TYPE (NAME) =SERIAL.FUNCTIONID`.

function **describe**( ) As String

More precisely, `TYPE` is the type of the function, `NAME` it the name used for the first access to the function, `SERIAL` is the serial number of the module if the module is connected or "unresolved", and `FUNCTIONID` is the hardware identifier of the function if the module is connected. For example, this method returns `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1` if the module is already connected or `Relay(BadCustomeName.relay1)=unresolved` if the module has not yet been connected. This method does not trigger any USB or TCP transaction and can therefore be used in a debugger.

**Returns :**

a string that describes the CO2 sensor (ex: `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1`)



---

**carbondioxide**→**get\_advertisedValue()****YCarbonDioxide****carbondioxide**→**advertisedValue()****carbondioxide.get\_advertisedValue()**

---

Returns the current value of the CO2 sensor (no more than 6 characters).

```
function get_advertisedValue( ) As String
```

**Returns :**

a string corresponding to the current value of the CO2 sensor (no more than 6 characters).

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

**carbondioxide→get\_currentRawValue()**  
**carbondioxide→currentRawValue()**  
**carbondioxide.get\_currentRawValue()**

**YCarbonDioxide**

---

Returns the uncalibrated, unrounded raw value returned by the sensor, in ppm (vol), as a floating point number.

```
function get_currentRawValue( ) As Double
```

**Returns :**

a floating point number corresponding to the uncalibrated, unrounded raw value returned by the sensor, in ppm (vol), as a floating point number

On failure, throws an exception or returns Y\_CURRENTRAWVALUE\_INVALID.

---

**carbondioxide**→**get\_currentValue()****YCarbonDioxide****carbondioxide**→**currentValue()****carbondioxide.get\_currentValue()**

---

Returns the current value of the CO2 concentration, in ppm (vol), as a floating point number.

```
function get_currentValue( ) As Double
```

**Returns :**

a floating point number corresponding to the current value of the CO2 concentration, in ppm (vol), as a floating point number

On failure, throws an exception or returns `Y_CURRENTVALUE_INVALID`.

**carbondioxide→get\_errorMessage()  
carbondioxide→errorMessage()  
carbondioxide.get\_errorMessage()**

---

**YCarbonDioxide**

Returns the error message of the latest error with the CO2 sensor.

```
function get_errorMessage( ) As String
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using the CO2 sensor object

---

**carbondioxide→get\_errorType()**  
**carbondioxide→errorType()**  
**carbondioxide.get\_errorType()**

---

**YCarbonDioxide**

Returns the numerical error code of the latest error with the CO2 sensor.

```
function get_errorType( ) As YRETCODE
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using the CO2 sensor object

**carbondioxide→get\_functionDescriptor()**  
**carbondioxide→functionDescriptor()**  
**carbondioxide.get\_functionDescriptor()**

---

**YCarbonDioxide**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

```
function get_functionDescriptor( ) As YFUN_DESCR
```

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`.

If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

---

**carbondioxide**→**get\_functionId()**  
**carbondioxide**→**functionId()**  
**carbondioxide.get\_functionId()**

---

**YCarbonDioxide**

Returns the hardware identifier of the CO2 sensor, without reference to the module.

```
function get_functionId( ) As String
```

For example `relay1`

**Returns :**

a string that identifies the CO2 sensor (ex: `relay1`)

On failure, throws an exception or returns `Y_FUNCTIONID_INVALID`.

`carbondioxide→get_hardwareId()`  
`carbondioxide→hardwareId()`  
`carbondioxide.get_hardwareId()`

**YCarbonDioxide**

---

Returns the unique hardware identifier of the CO2 sensor in the form `SERIAL.FUNCTIONID`.

```
function get_hardwareId( ) As String
```

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the CO2 sensor (for example `RELAYLO1-123456.relay1`).

**Returns :**

a string that uniquely identifies the CO2 sensor (ex: `RELAYLO1-123456.relay1`)

On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.



---

**carbondioxide**→**get\_highestValue()****YCarbonDioxide****carbondioxide**→**highestValue()****carbondioxide.get\_highestValue()**

---

Returns the maximal value observed for the CO2 concentration since the device was started.

```
function get_highestValue( ) As Double
```

**Returns :**

a floating point number corresponding to the maximal value observed for the CO2 concentration since the device was started

On failure, throws an exception or returns `Y_HIGHESTVALUE_INVALID`.

**carbondioxide→get\_logFrequency()**  
**carbondioxide→logFrequency()**  
**carbondioxide.get\_logFrequency()**

**YCarbonDioxide**

---

Returns the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory.

function **get\_logFrequency( )** As String

**Returns :**

a string corresponding to the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory

On failure, throws an exception or returns Y\_LOGFREQUENCY\_INVALID.

---

**carbondioxide**→**get\_logicalName()****YCarbonDioxide****carbondioxide**→**logicalName()****carbondioxide.get\_logicalName()**

---

Returns the logical name of the CO2 sensor.

```
function get_logicalName( ) As String
```

**Returns :**

a string corresponding to the logical name of the CO2 sensor.

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

**carbondioxide**→**get\_lowestValue()**  
**carbondioxide**→**lowestValue()**  
**carbondioxide.get\_lowestValue()**

**YCarbonDioxide**

---

Returns the minimal value observed for the CO2 concentration since the device was started.

```
function get_lowestValue( ) As Double
```

**Returns :**

a floating point number corresponding to the minimal value observed for the CO2 concentration since the device was started

On failure, throws an exception or returns Y\_LOWESTVALUE\_INVALID.

---

**carbondioxide→get\_module()**  
**carbondioxide→module()**  
**carbondioxide.get\_module()**

---

**YCarbonDioxide**

Gets the YModule object for the device on which the function is located.

```
function get_module( ) As YModule
```

If the function cannot be located on any module, the returned instance of YModule is not shown as on-line.

**Returns :**

an instance of YModule

**carbondioxide→get\_recordedData()**  
**carbondioxide→recordedData()**  
**carbondioxide.get\_recordedData()**

**YCarbonDioxide**

Retrieves a DataSet object holding historical data for this sensor, for a specified time interval.

```
function get_recordedData( ) As YDataSet
```

The measures will be retrieved from the data logger, which must have been turned on at the desired time. See the documentation of the DataSet class for information on how to get an overview of the recorded data, and how to load progressively a large set of measures from the data logger.

This function only works if the device uses a recent firmware, as DataSet objects are not supported by firmwares older than version 13000.

**Parameters :**

**startTime** the start of the desired measure time interval, as a Unix timestamp, i.e. the number of seconds since January 1, 1970 UTC. The special value 0 can be used to include any meaasure, without initial limit.

**endTime** the end of the desired measure time interval, as a Unix timestamp, i.e. the number of seconds since January 1, 1970 UTC. The special value 0 can be used to include any meaasure, without ending limit.

**Returns :**

an instance of YDataSet, providing access to historical data. Past measures can be loaded progressively using methods from the YDataSet object.

---

**carbondioxide**→**get\_reportFrequency()****YCarbonDioxide****carbondioxide**→**reportFrequency()****carbondioxide.get\_reportFrequency()**

---

Returns the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function.

```
function get_reportFrequency( ) As String
```

**Returns :**

a string corresponding to the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function

On failure, throws an exception or returns `Y_REPORTFREQUENCY_INVALID`.

**carbondioxide**→**get\_resolution()**  
**carbondioxide**→**resolution()**  
**carbondioxide.get\_resolution()**

---

**YCarbonDioxide**

Returns the resolution of the measured values.

```
function get_resolution( ) As Double
```

The resolution corresponds to the numerical precision of the measures, which is not always the same as the actual precision of the sensor.

**Returns :**

a floating point number corresponding to the resolution of the measured values

On failure, throws an exception or returns Y\_RESOLUTION\_INVALID.



---

**carbondioxide**→**get\_unit()****YCarbonDioxide****carbondioxide**→**unit()****carbondioxide.get\_unit()**

---

Returns the measuring unit for the CO2 concentration.

function **get\_unit()** As String

**Returns :**

a string corresponding to the measuring unit for the CO2 concentration

On failure, throws an exception or returns `Y_UNIT_INVALID`.

**carbondioxide→get\_userData()**  
**carbondioxide→userData()**  
**carbondioxide.get\_userData()**

---

**YCarbonDioxide**

Returns the value of the userData attribute, as previously stored using method `set_userData`.

```
function get_userData( ) As Object
```

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

---

**carbondioxide**→**isOnline()****carbondioxide.isOnline()****YCarbonDioxide**

---

Checks if the CO2 sensor is currently reachable, without raising any error.

```
function isOnline( ) As Boolean
```

If there is a cached value for the CO2 sensor in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the CO2 sensor.

**Returns :**

`true` if the CO2 sensor can be reached, and `false` otherwise

## carbondioxide→load()carbondioxide.load()

YCarbonDioxide

---

Preloads the CO2 sensor cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**carbondioxide→loadCalibrationPoints()  
carbondioxide.loadCalibrationPoints()**

---

**YCarbonDioxide**

Retrieves error correction data points previously entered using the method `calibrateFromPoints`.

procedure **loadCalibrationPoints( )**

**Parameters :**

**rawValues** array of floating point numbers, that will be filled by the function with the raw sensor values for the correction points.

**refValues** array of floating point numbers, that will be filled by the function with the desired values for the correction points.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**carbondioxide**→**nextCarbonDioxide()**  
**carbondioxide.nextCarbonDioxide()**

**YCarbonDioxide**

---

Continues the enumeration of CO2 sensors started using `yFirstCarbonDioxide()`.

```
function nextCarbonDioxide( ) As YCarbonDioxide
```

**Returns :**

a pointer to a `YCarbonDioxide` object, corresponding to a CO2 sensor currently online, or a `null` pointer if there are no more CO2 sensors to enumerate.

---

**carbondioxide**→**registerTimedReportCallback()**  
**carbondioxide.registerTimedReportCallback()**

---

**YCarbonDioxide**

Registers the callback function that is invoked on every periodic timed notification.

```
function registerTimedReportCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and an `YMeasure` object describing the new advertised value.

**carbondioxide→registerValueCallback()  
carbondioxide.registerValueCallback()**

---

**YCarbonDioxide**

Registers the callback function that is invoked on every change of advertised value.

```
function registerValueCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.



---

**carbondioxide→set\_highestValue()**  
**carbondioxide→setHighestValue()**  
**carbondioxide.set\_highestValue()**

---

**YCarbonDioxide**

Changes the recorded maximal value observed.

```
function set_highestValue( ByVal newval As Double) As Integer
```

**Parameters :**

**newval** a floating point number corresponding to the recorded maximal value observed

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**carbondioxide→set\_logFrequency()  
carbondioxide→setLogFrequency()  
carbondioxide.set\_logFrequency()**

---

**YCarbonDioxide**

Changes the datalogger recording frequency for this function.

```
function set_logFrequency( ByVal newval As String) As Integer
```

The frequency can be specified as samples per second, as sample per minute (for instance "15/m") or in samples per hour (eg. "4/h"). To disable recording for this function, use the value "OFF".

**Parameters :**

**newval** a string corresponding to the datalogger recording frequency for this function

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**carbondioxide**→**set\_logicalName()**  
**carbondioxide**→**setLogicalName()**  
**carbondioxide.set\_logicalName()**

**YCarbonDioxide**

---

Changes the logical name of the CO2 sensor.

```
function set_logicalName( ByVal newval As String) As Integer
```

You can use `yCheckLogicalName( )` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash( )` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the CO2 sensor.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**carbondioxide**→**set\_lowestValue()**  
**carbondioxide**→**setLowestValue()**  
**carbondioxide.set\_lowestValue()**

---

**YCarbonDioxide**

Changes the recorded minimal value observed.

```
function set_lowestValue( ByVal newval As Double) As Integer
```

**Parameters :**

**newval** a floating point number corresponding to the recorded minimal value observed

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**carbondioxide**→**set\_reportFrequency()**  
**carbondioxide**→**setReportFrequency()**  
**carbondioxide.set\_reportFrequency()**

**YCarbonDioxide**

Changes the timed value notification frequency for this function.

```
function set_reportFrequency( ByVal newval As String) As Integer
```

The frequency can be specified as samples per second, as sample per minute (for instance "15/m") or in samples per hour (eg. "4/h"). To disable timed value notifications for this function, use the value "OFF".

**Parameters :**

**newval** a string corresponding to the timed value notification frequency for this function

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**carbondioxide**→**set\_resolution()**  
**carbondioxide**→**setResolution()**  
**carbondioxide.set\_resolution()**

---

**YCarbonDioxide**

Changes the resolution of the measured physical values.

```
function set_resolution( ByVal newval As Double) As Integer
```

The resolution corresponds to the numerical precision when displaying value. It does not change the precision of the measure itself.

**Parameters :**

**newval** a floating point number corresponding to the resolution of the measured physical values

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**carbondioxide**→**set\_userData()**  
**carbondioxide**→**setUserData()**  
**carbondioxide.set\_userData()**

---

**YCarbonDioxide**

Stores a user context provided as argument in the `userData` attribute of the function.

```
procedure set_userData( ByVal data As Object)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

## 3.6. ColorLed function interface

Yoctopuce application programming interface allows you to drive a color led using RGB coordinates as well as HSL coordinates. The module performs all conversions from RGB to HSL automatically. It is then self-evident to turn on a led with a given hue and to progressively vary its saturation or lightness. If needed, you can find more information on the difference between RGB and HSL in the section following this one.

In order to use the functions described here, you should include:

js	<code>&lt;script type='text/javascript' src='yocto_colorled.js'&gt;&lt;/script&gt;</code>
nodejs	<code>var yoctolib = require('yoctolib'); var YColorLed = yoctolib.YColorLed;</code>
php	<code>require_once('yocto_colorled.php');</code>
cpp	<code>#include "yocto_colorled.h"</code>
m	<code>#import "yocto_colorled.h"</code>
pas	<code>uses yocto_colorled;</code>
vb	<code>yocto_colorled.vb</code>
cs	<code>yocto_colorled.cs</code>
java	<code>import com.yoctopuce.YoctoAPI.YColorLed;</code>
py	<code>from yocto_colorled import *</code>

### Global functions

#### **yFindColorLed(func)**

Retrieves an RGB led for a given identifier.

#### **yFirstColorLed()**

Starts the enumeration of RGB leds currently accessible.

### YColorLed methods

#### **colorled→describe()**

Returns a short text that describes unambiguously the instance of the RGB led in the form `TYPE (NAME) =SERIAL . FUNCTIONID`.

#### **colorled→get\_advertisedValue()**

Returns the current value of the RGB led (no more than 6 characters).

#### **colorled→get\_errorMessage()**

Returns the error message of the latest error with the RGB led.

#### **colorled→get\_errorType()**

Returns the numerical error code of the latest error with the RGB led.

#### **colorled→get\_friendlyName()**

Returns a global identifier of the RGB led in the format `MODULE_NAME . FUNCTION_NAME`.

#### **colorled→get\_functionDescriptor()**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

#### **colorled→get\_functionId()**

Returns the hardware identifier of the RGB led, without reference to the module.

#### **colorled→get\_hardwareId()**

Returns the unique hardware identifier of the RGB led in the form `SERIAL . FUNCTIONID`.

#### **colorled→get\_hslColor()**

Returns the current HSL color of the led.

#### **colorled→get\_logicalName()**

Returns the logical name of the RGB led.



**colorled**→**get\_module()**

Gets the `YModule` object for the device on which the function is located.

**colorled**→**get\_module\_async(callback, context)**

Gets the `YModule` object for the device on which the function is located (asynchronous version).

**colorled**→**get\_rgbColor()**

Returns the current RGB color of the led.

**colorled**→**get\_rgbColorAtPowerOn()**

Returns the configured color to be displayed when the module is turned on.

**colorled**→**get\_userData()**

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

**colorled**→**hslMove(hsl\_target, ms\_duration)**

Performs a smooth transition in the HSL color space between the current color and a target color.

**colorled**→**isOnline()**

Checks if the RGB led is currently reachable, without raising any error.

**colorled**→**isOnline\_async(callback, context)**

Checks if the RGB led is currently reachable, without raising any error (asynchronous version).

**colorled**→**load(msValidity)**

Preloads the RGB led cache with a specified validity duration.

**colorled**→**load\_async(msValidity, callback, context)**

Preloads the RGB led cache with a specified validity duration (asynchronous version).

**colorled**→**nextColorLed()**

Continues the enumeration of RGB leds started using `yFirstColorLed()`.

**colorled**→**registerValueCallback(callback)**

Registers the callback function that is invoked on every change of advertised value.

**colorled**→**rgbMove(rgb\_target, ms\_duration)**

Performs a smooth transition in the RGB color space between the current color and a target color.

**colorled**→**set\_hslColor(newval)**

Changes the current color of the led, using a color HSL.

**colorled**→**set\_logicalName(newval)**

Changes the logical name of the RGB led.

**colorled**→**set\_rgbColor(newval)**

Changes the current color of the led, using a RGB color.

**colorled**→**set\_rgbColorAtPowerOn(newval)**

Changes the color that the led will display by default when the module is turned on.

**colorled**→**set\_userData(data)**

Stores a user context provided as argument in the `userData` attribute of the function.

**colorled**→**wait\_async(callback, context)**

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.

## YColorLed.FindColorLed() yFindColorLed()yFindColorLed()

YColorLed

Retrieves an RGB led for a given identifier.

```
function yFindColorLed( ByVal func As String) As YColorLed
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the RGB led is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YColorLed.IsOnline()` to test if the RGB led is indeed online at a given time. In case of ambiguity when looking for an RGB led by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

**Parameters :**

**func** a string that uniquely characterizes the RGB led

**Returns :**

a `YColorLed` object allowing you to drive the RGB led.

---

**YColorLed.FirstColorLed()  
yFirstColorLed()yFirstColorLed()**

---

**YColorLed**

Starts the enumeration of RGB leds currently accessible.

```
function yFirstColorLed( ) As YColorLed
```

Use the method `YColorLed.nextColorLed()` to iterate on next RGB leds.

**Returns :**

a pointer to a `YColorLed` object, corresponding to the first RGB led currently online, or a `null` pointer if there are none.

**colorled**→**describe()****colorled.describe()****YColorLed**

Returns a short text that describes unambiguously the instance of the RGB led in the form `TYPE (NAME) =SERIAL.FUNCTIONID`.

function **describe**( ) As String

More precisely, `TYPE` is the type of the function, `NAME` it the name used for the first access to the function, `SERIAL` is the serial number of the module if the module is connected or "unresolved", and `FUNCTIONID` is the hardware identifier of the function if the module is connected. For example, this method returns `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1` if the module is already connected or `Relay(BadCustomeName.relay1)=unresolved` if the module has not yet been connected. This method does not trigger any USB or TCP transaction and can therefore be used in a debugger.

**Returns :**

a string that describes the RGB led (ex: `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1`)

---

**colorled**→**get\_advertisedValue()****YColorLed****colorled**→**advertisedValue()****colorled.get\_advertisedValue()**

---

Returns the current value of the RGB led (no more than 6 characters).

```
function get_advertisedValue( ) As String
```

**Returns :**

a string corresponding to the current value of the RGB led (no more than 6 characters).

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

**colorled**→**get\_errorMessage()**  
**colorled**→**errorMessage()**  
**colorled.get\_errorMessage()**

---

**YColorLed**

Returns the error message of the latest error with the RGB led.

```
function get_errorMessage( ) As String
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using the RGB led object

---

**colorled**→**get\_errorType()****YColorLed****colorled**→**errorType()****colorled.get\_errorType()**

---

Returns the numerical error code of the latest error with the RGB led.

```
function get_errorType( ) As YRETCODE
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using the RGB led object

**colorled**→**get\_functionDescriptor()**  
**colorled**→**functionDescriptor()**  
**colorled.get\_functionDescriptor()**

---

**YColorLed**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

```
function get_functionDescriptor( ) As YFUN_DESCR
```

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`.

If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.



---

**colorled**→**get\_functionId()****YColorLed****colorled**→**functionId()****colorled.get\_functionId()**

---

Returns the hardware identifier of the RGB led, without reference to the module.

function **get\_functionId**( ) As String

For example `relay1`

**Returns :**

a string that identifies the RGB led (ex: `relay1`)

On failure, throws an exception or returns `Y_FUNCTIONID_INVALID`.

`colorled`→`get_hardwareId()`

**YColorLed**

`colorled`→`hardwareId()``colorled.get_hardwareId()`

---

Returns the unique hardware identifier of the RGB led in the form `SERIAL.FUNCTIONID`.

function `get_hardwareId()` As String

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the RGB led (for example `RELAYLO1-123456.relay1`).

**Returns :**

a string that uniquely identifies the RGB led (ex: `RELAYLO1-123456.relay1`)

On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

---

**colorled**→**get\_hslColor()****YColorLed****colorled**→**hslColor()****colorled.get\_hslColor()**

---

Returns the current HSL color of the led.

```
function get_hslColor( ) As Integer
```

**Returns :**

an integer corresponding to the current HSL color of the led

On failure, throws an exception or returns `Y_HSLCOLOR_INVALID`.

**colorled**→**get\_logicalName()**

**YColorLed**

**colorled**→**logicalName()****colorled.get\_logicalName()**

---

Returns the logical name of the RGB led.

function **get\_logicalName**( ) As String

**Returns :**

a string corresponding to the logical name of the RGB led.

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

---

**colorled**→**get\_module()****YColorLed****colorled**→**module()****colorled.get\_module()**

---

Gets the `YModule` object for the device on which the function is located.

```
function get_module( ) As YModule
```

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

**Returns :**

an instance of `YModule`

**colorled**→**get\_rgbColor()**

**YColorLed**

**colorled**→**rgbColor()****colorled.get\_rgbColor()**

---

Returns the current RGB color of the led.

```
function get_rgbColor( ) As Integer
```

**Returns :**

an integer corresponding to the current RGB color of the led

On failure, throws an exception or returns `Y_RGBCOLOR_INVALID`.

---

**colorled**→**get\_rgbColorAtPowerOn()****YColorLed****colorled**→**rgbColorAtPowerOn()****colorled.get\_rgbColorAtPowerOn()**

---

Returns the configured color to be displayed when the module is turned on.

```
function get_rgbColorAtPowerOn( ) As Integer
```

**Returns :**

an integer corresponding to the configured color to be displayed when the module is turned on

On failure, throws an exception or returns `Y_RGBCOLORATPOWERON_INVALID`.

**colorled**→**get\_userData()**

**YColorLed**

**colorled**→**userData()****colorled.get\_userData()**

---

Returns the value of the userData attribute, as previously stored using method `set_userData`.

function **get\_userData**( ) As Object

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.



**colorled**→**hslMove()****colorled.hslMove()****YColorLed**

Performs a smooth transition in the HSL color space between the current color and a target color.

```
function hslMove( ByVal hsl_target As Integer,  
                  ByVal ms_duration As Integer) As Integer
```

**Parameters :**

**hsl\_target** desired HSL color at the end of the transition

**ms\_duration** duration of the transition, in millisecond

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**colorled**→**isOnline()****colorled.isOnline()**

**YColorLed**

---

Checks if the RGB led is currently reachable, without raising any error.

function **isOnline**( ) As Boolean

If there is a cached value for the RGB led in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the RGB led.

**Returns :**

`true` if the RGB led can be reached, and `false` otherwise

**colorled**→**load()****colorled.load()****YColorLed**

Preloads the RGB led cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

**colorled**→**nextColorLed()**colorled.nextColorLed()

**YColorLed**

---

Continues the enumeration of RGB leds started using `yFirstColorLed()`.

function **nextColorLed()** As YColorLed

**Returns :**

a pointer to a YColorLed object, corresponding to an RGB led currently online, or a null pointer if there are no more RGB leds to enumerate.

---

**colorled**→**registerValueCallback()**  
**colorled.registerValueCallback()**

---

**YColorLed**

Registers the callback function that is invoked on every change of advertised value.

```
function registerValueCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

**colorled**→**rgbMove()****colorled.rgbMove()****YColorLed**

Performs a smooth transition in the RGB color space between the current color and a target color.

```
function rgbMove( ByVal rgb_target As Integer,  
                  ByVal ms_duration As Integer) As Integer
```

**Parameters :**

**rgb\_target** desired RGB color at the end of the transition  
**ms\_duration** duration of the transition, in millisecond

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**colorled**→**set\_hslColor()****YColorLed****colorled**→**setHslColor()****colorled.set\_hslColor()**

---

Changes the current color of the led, using a color HSL.

```
function set_hslColor( ByVal newval As Integer) As Integer
```

Encoding is done as follows: 0xHHSSLL.

**Parameters :**

**newval** an integer corresponding to the current color of the led, using a color HSL

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**colorled**→**set\_logicalName()**  
**colorled**→**setLogicalName()**  
**colorled.set\_logicalName()**

---

**YColorLed**

Changes the logical name of the RGB led.

```
function set_logicalName( ByVal newval As String) As Integer
```

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the RGB led.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.



---

**colorled**→**set\_rgbColor()****YColorLed****colorled**→**setRgbColor()****colorled.set\_rgbColor()**

---

Changes the current color of the led, using a RGB color.

```
function set_rgbColor( ByVal newval As Integer) As Integer
```

Encoding is done as follows: 0xRRGGBB.

**Parameters :**

**newval** an integer corresponding to the current color of the led, using a RGB color

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**colored**→**set\_rgbColorAtPowerOn()**  
**colored**→**setRgbColorAtPowerOn()**  
**colored.set\_rgbColorAtPowerOn()**

---

**YColorLed**

Changes the color that the led will display by default when the module is turned on.

```
function set_rgbColorAtPowerOn( ByVal newval As Integer) As Integer
```

This color will be displayed as soon as the module is powered on. Remember to call the `saveToFlash()` method of the module if the change should be kept.

**Parameters :**

**newval** an integer corresponding to the color that the led will display by default when the module is turned on

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**colorled**→**set\_userData()****YColorLed****colorled**→**setUserData()****colorled.set\_userData()**

---

Stores a user context provided as argument in the `userData` attribute of the function.

```
procedure set_userData( ByVal data As Object)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

## 3.7. Compass function interface

The Yoctopuce application programming interface allows you to read an instant measure of the sensor, as well as the minimal and maximal values observed.

In order to use the functions described here, you should include:

js	<code>&lt;script type='text/javascript' src='yocto_compass.js'&gt;&lt;/script&gt;</code>
nodejs	<code>var yoctolib = require('yoctolib'); var YCompass = yoctolib.YCompass;</code>
php	<code>require_once('yocto_compass.php');</code>
c++	<code>#include "yocto_compass.h"</code>
m	<code>#import "yocto_compass.h"</code>
pas	<code>uses yocto_compass;</code>
vb	<code>yocto_compass.vb</code>
cs	<code>yocto_compass.cs</code>
java	<code>import com.yoctopuce.YoctoAPI.YCompass;</code>
py	<code>from yocto_compass import *</code>

### Global functions

#### yFindCompass(func)

Retrieves a compass for a given identifier.

#### yFirstCompass()

Starts the enumeration of compasses currently accessible.

### YCompass methods

#### compass→calibrateFromPoints(rawValues, refValues)

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

#### compass→describe()

Returns a short text that describes unambiguously the instance of the compass in the form `TYPE ( NAME ) = SERIAL . FUNCTIONID`.

#### compass→get\_advertisedValue()

Returns the current value of the compass (no more than 6 characters).

#### compass→get\_currentRawValue()

Returns the uncalibrated, unrounded raw value returned by the sensor, in degrees, as a floating point number.

#### compass→get\_currentValue()

Returns the current value of the relative bearing, in degrees, as a floating point number.

#### compass→get\_errorMessage()

Returns the error message of the latest error with the compass.

#### compass→get\_errorType()

Returns the numerical error code of the latest error with the compass.

#### compass→get\_friendlyName()

Returns a global identifier of the compass in the format `MODULE_NAME . FUNCTION_NAME`.

#### compass→get\_functionDescriptor()

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

#### compass→get\_functionId()

Returns the hardware identifier of the compass, without reference to the module.

#### compass→get\_hardwareId()

Returns the unique hardware identifier of the compass in the form `SERIAL . FUNCTIONID`.

**compass→get\_highestValue()**

Returns the maximal value observed for the relative bearing since the device was started.

**compass→get\_logFrequency()**

Returns the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory.

**compass→get\_logicalName()**

Returns the logical name of the compass.

**compass→get\_lowestValue()**

Returns the minimal value observed for the relative bearing since the device was started.

**compass→get\_magneticHeading()**

Returns the magnetic heading, regardless of the configured bearing.

**compass→get\_module()**

Gets the `YModule` object for the device on which the function is located.

**compass→get\_module\_async(callback, context)**

Gets the `YModule` object for the device on which the function is located (asynchronous version).

**compass→get\_recordedData(startTime, endTime)**

Retrieves a `DataSet` object holding historical data for this sensor, for a specified time interval.

**compass→get\_reportFrequency()**

Returns the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function.

**compass→get\_resolution()**

Returns the resolution of the measured values.

**compass→get\_unit()**

Returns the measuring unit for the relative bearing.

**compass→get\_userData()**

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

**compass→isOnline()**

Checks if the compass is currently reachable, without raising any error.

**compass→isOnline\_async(callback, context)**

Checks if the compass is currently reachable, without raising any error (asynchronous version).

**compass→load(msValidity)**

Preloads the compass cache with a specified validity duration.

**compass→loadCalibrationPoints(rawValues, refValues)**

Retrieves error correction data points previously entered using the method `calibrateFromPoints`.

**compass→load\_async(msValidity, callback, context)**

Preloads the compass cache with a specified validity duration (asynchronous version).

**compass→nextCompass()**

Continues the enumeration of compasses started using `yFirstCompass()`.

**compass→registerTimedReportCallback(callback)**

Registers the callback function that is invoked on every periodic timed notification.

**compass→registerValueCallback(callback)**

Registers the callback function that is invoked on every change of advertised value.

**compass→set\_highestValue(newval)**

Changes the recorded maximal value observed.

**compass→set\_logFrequency(newval)**

Changes the datalogger recording frequency for this function.

### 3. Reference

---

**compass**→**set\_logicalName(newval)**

Changes the logical name of the compass.

**compass**→**set\_lowestValue(newval)**

Changes the recorded minimal value observed.

**compass**→**set\_reportFrequency(newval)**

Changes the timed value notification frequency for this function.

**compass**→**set\_resolution(newval)**

Changes the resolution of the measured physical values.

**compass**→**set\_userData(data)**

Stores a user context provided as argument in the userData attribute of the function.

**compass**→**wait\_async(callback, context)**

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.

## YCompass.FindCompass() yFindCompass()yFindCompass()

## YCompass

Retrieves a compass for a given identifier.

```
function yFindCompass( ByVal func As String) As YCompass
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the compass is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YCompass.IsOnline()` to test if the compass is indeed online at a given time. In case of ambiguity when looking for a compass by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

### Parameters :

**func** a string that uniquely characterizes the compass

### Returns :

a `YCompass` object allowing you to drive the compass.

## **YCompass.FirstCompass() yFirstCompass()yFirstCompass()**

---

**YCompass**

Starts the enumeration of compasses currently accessible.

```
function yFirstCompass( ) As YCompass
```

Use the method `YCompass.nextCompass( )` to iterate on next compasses.

**Returns :**

a pointer to a `YCompass` object, corresponding to the first compass currently online, or a `null` pointer if there are none.



---

**compass**→**calibrateFromPoints()**  
**compass.calibrateFromPoints()**

---

**YCompass**

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

**procedure calibrateFromPoints( )**

It is possible to configure up to five correction points. Correction points must be provided in ascending order, and be in the range of the sensor. The device will automatically perform a linear interpolation of the error correction between specified points. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

For more information on advanced capabilities to refine the calibration of sensors, please contact [support@yoctopuce.com](mailto:support@yoctopuce.com).

**Parameters :**

**rawValues** array of floating point numbers, corresponding to the raw values returned by the sensor for the correction points.

**refValues** array of floating point numbers, corresponding to the corrected values for the correction points.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**compass**→**describe()****compass.describe()****YCompass**

Returns a short text that describes unambiguously the instance of the compass in the form `TYPE (NAME) =SERIAL.FUNCTIONID`.

function **describe**( ) As String

More precisely, `TYPE` is the type of the function, `NAME` is the name used for the first access to the function, `SERIAL` is the serial number of the module if the module is connected or "unresolved", and `FUNCTIONID` is the hardware identifier of the function if the module is connected. For example, this method returns `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1` if the module is already connected or `Relay(BadCustomeName.relay1)=unresolved` if the module has not yet been connected. This method does not trigger any USB or TCP transaction and can therefore be used in a debugger.

**Returns :**

a string that describes the compass (ex: `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1`)

---

**compass**→**get\_advertisedValue()****YCompass****compass**→**advertisedValue()****compass.get\_advertisedValue()**

---

Returns the current value of the compass (no more than 6 characters).

```
function get_advertisedValue( ) As String
```

**Returns :**

a string corresponding to the current value of the compass (no more than 6 characters).

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

**compass**→**get\_currentRawValue()**  
**compass**→**currentRawValue()**  
**compass.get\_currentRawValue()**

**YCompass**

---

Returns the uncalibrated, unrounded raw value returned by the sensor, in degrees, as a floating point number.

```
function get_currentRawValue( ) As Double
```

**Returns :**

a floating point number corresponding to the uncalibrated, unrounded raw value returned by the sensor, in degrees, as a floating point number

On failure, throws an exception or returns `Y_CURRENTRAWVALUE_INVALID`.

---

**compass**→**get\_currentValue()****YCompass****compass**→**currentValue()****compass.get\_currentValue()**

---

Returns the current value of the relative bearing, in degrees, as a floating point number.

```
function get_currentValue( ) As Double
```

**Returns :**

a floating point number corresponding to the current value of the relative bearing, in degrees, as a floating point number

On failure, throws an exception or returns `Y_CURRENTVALUE_INVALID`.

**compass**→**get\_errorMessage()**  
**compass**→**errorMessage()**  
**compass.get\_errorMessage()**

---

**YCompass**

Returns the error message of the latest error with the compass.

```
function get_errorMessage( ) As String
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using the compass object

---

**compass**→**get\_errorType()****YCompass****compass**→**errorType()****compass.get\_errorType()**

---

Returns the numerical error code of the latest error with the compass.

```
function get_errorType( ) As YRETCODE
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using the compass object

---

**compass**→**get\_functionDescriptor()**  
**compass**→**functionDescriptor()**  
**compass.get\_functionDescriptor()**

---

**YCompass**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

`function get_functionDescriptor( )` As `YFUN_DESCR`

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`.

If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.



---

**compass**→**get\_functionId()****YCompass****compass**→**functionId()****compass.get\_functionId()**

---

Returns the hardware identifier of the compass, without reference to the module.

function **get\_functionId**( ) As String

For example `relay1`

**Returns :**

a string that identifies the compass (ex: `relay1`)

On failure, throws an exception or returns `Y_FUNCTIONID_INVALID`.

**compass**→**get\_hardwareId()**

**YCompass**

**compass**→**hardwareId()****compass.get\_hardwareId()**

---

Returns the unique hardware identifier of the compass in the form `SERIAL.FUNCTIONID`.

function **get\_hardwareId()** As String

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the compass (for example `RELAYLO1-123456.relay1`).

**Returns :**

a string that uniquely identifies the compass (ex: `RELAYLO1-123456.relay1`)

On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

---

**compass**→**get\_highestValue()****YCompass****compass**→**highestValue()****compass.get\_highestValue()**

---

Returns the maximal value observed for the relative bearing since the device was started.

```
function get_highestValue( ) As Double
```

**Returns :**

a floating point number corresponding to the maximal value observed for the relative bearing since the device was started

On failure, throws an exception or returns `Y_HIGHESTVALUE_INVALID`.

**compass**→**get\_logFrequency()**

**YCompass**

**compass**→**logFrequency()**

**compass.get\_logFrequency()**

---

Returns the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory.

function **get\_logFrequency()** As String

**Returns :**

a string corresponding to the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory

On failure, throws an exception or returns `Y_LOGFREQUENCY_INVALID`.

---

**compass**→**get\_logicalName()****YCompass****compass**→**logicalName()****compass.get\_logicalName()**

---

Returns the logical name of the compass.

```
function get_logicalName( ) As String
```

**Returns :**

a string corresponding to the logical name of the compass.

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

**compass**→**get\_lowestValue()**

**YCompass**

**compass**→**lowestValue()****compass.get\_lowestValue()**

---

Returns the minimal value observed for the relative bearing since the device was started.

function **get\_lowestValue()** As Double

**Returns :**

a floating point number corresponding to the minimal value observed for the relative bearing since the device was started

On failure, throws an exception or returns `Y_LOWESTVALUE_INVALID`.

---

**compass**→**get\_magneticHeading()****YCompass****compass**→**magneticHeading()****compass.get\_magneticHeading()**

---

Returns the magnetic heading, regardless of the configured bearing.

function **get\_magneticHeading**( ) As Double

**Returns :**

a floating point number corresponding to the magnetic heading, regardless of the configured bearing

On failure, throws an exception or returns `Y_MAGNETICHEADING_INVALID`.

**compass**→**get\_module()**

**YCompass**

**compass**→**module()****compass.get\_module()**

---

Gets the YModule object for the device on which the function is located.

function **get\_module**( ) As YModule

If the function cannot be located on any module, the returned instance of YModule is not shown as on-line.

**Returns :**

an instance of YModule



---

**compass**→**get\_recordedData()****YCompass****compass**→**recordedData()****compass.get\_recordedData()**

---

Retrieves a DataSet object holding historical data for this sensor, for a specified time interval.

```
function get_recordedData( ) As YDataSet
```

The measures will be retrieved from the data logger, which must have been turned on at the desired time. See the documentation of the DataSet class for information on how to get an overview of the recorded data, and how to load progressively a large set of measures from the data logger.

This function only works if the device uses a recent firmware, as DataSet objects are not supported by firmwares older than version 13000.

**Parameters :**

**startTime** the start of the desired measure time interval, as a Unix timestamp, i.e. the number of seconds since January 1, 1970 UTC. The special value 0 can be used to include any meaasure, without initial limit.

**endTime** the end of the desired measure time interval, as a Unix timestamp, i.e. the number of seconds since January 1, 1970 UTC. The special value 0 can be used to include any meaasure, without ending limit.

**Returns :**

an instance of YDataSet, providing access to historical data. Past measures can be loaded progressively using methods from the YDataSet object.

**compass**→**get\_reportFrequency()**

**YCompass**

**compass**→**reportFrequency()**

**compass.get\_reportFrequency()**

---

Returns the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function.

```
function get_reportFrequency( ) As String
```

**Returns :**

a string corresponding to the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function

On failure, throws an exception or returns `Y_REPORTFREQUENCY_INVALID`.

---

**compass**→**get\_resolution()****YCompass****compass**→**resolution()****compass.get\_resolution()**

---

Returns the resolution of the measured values.

function **get\_resolution**( ) As Double

The resolution corresponds to the numerical precision of the measures, which is not always the same as the actual precision of the sensor.

**Returns :**

a floating point number corresponding to the resolution of the measured values

On failure, throws an exception or returns `Y_RESOLUTION_INVALID`.

**compass**→**get\_unit()**

**YCompass**

**compass**→**unit()****compass.get\_unit()**

---

Returns the measuring unit for the relative bearing.

function **get\_unit**( ) As String

**Returns :**

a string corresponding to the measuring unit for the relative bearing

On failure, throws an exception or returns `Y_UNIT_INVALID`.

---

**compass**→**get\_userData()****YCompass****compass**→**userData()****compass.get\_userData()**

---

Returns the value of the userData attribute, as previously stored using method `set_userData`.

```
function get_userData( ) As Object
```

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

**compass**→**isOnline()****compass.isOnline()**

**YCompass**

---

Checks if the compass is currently reachable, without raising any error.

function **isOnline**( ) As Boolean

If there is a cached value for the compass in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the compass.

**Returns :**

`true` if the compass can be reached, and `false` otherwise

**compass**→**load()****compass.load()****YCompass**

Preloads the compass cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

**compass→loadCalibrationPoints()  
compass.loadCalibrationPoints()**

**YCompass**

Retrieves error correction data points previously entered using the method `calibrateFromPoints`.

procedure **loadCalibrationPoints( )**

**Parameters :**

**rawValues** array of floating point numbers, that will be filled by the function with the raw sensor values for the correction points.

**refValues** array of floating point numbers, that will be filled by the function with the desired values for the correction points.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.



---

**compass**→**nextCompass()****compass.nextCompass()****YCompass**

---

Continues the enumeration of compasses started using `yFirstCompass()`.

```
function nextCompass( ) As YCompass
```

**Returns :**

a pointer to a `YCompass` object, corresponding to a compass currently online, or a `null` pointer if there are no more compasses to enumerate.

**compass**→**registerTimedReportCallback()**  
**compass.registerTimedReportCallback()****YCompass**

Registers the callback function that is invoked on every periodic timed notification.

```
function registerTimedReportCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and an `YMeasure` object describing the new advertised value.

---

**compass**→**registerValueCallback()**  
**compass.registerValueCallback()**

---

**YCompass**

Registers the callback function that is invoked on every change of advertised value.

```
function registerValueCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

**compass**→**set\_highestValue()**  
**compass**→**setHighestValue()**  
**compass.set\_highestValue()**

---

**YCompass**

Changes the recorded maximal value observed.

```
function set_highestValue( ByVal newval As Double) As Integer
```

**Parameters :**

**newval** a floating point number corresponding to the recorded maximal value observed

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**compass**→**set\_logFrequency()****YCompass****compass**→**setLogFrequency()****compass.set\_logFrequency()**

---

Changes the datalogger recording frequency for this function.

```
function set_logFrequency( ByVal newval As String) As Integer
```

The frequency can be specified as samples per second, as sample per minute (for instance "15/m") or in samples per hour (eg. "4/h"). To disable recording for this function, use the value "OFF".

**Parameters :**

**newval** a string corresponding to the datalogger recording frequency for this function

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**compass**→**set\_logicalName()****YCompass****compass**→**setLogicalName()****compass.set\_logicalName()**

---

Changes the logical name of the compass.

```
function set_logicalName( ByVal newval As String) As Integer
```

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the compass.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**compass**→**set\_lowestValue()**  
**compass**→**setLowestValue()**  
**compass.set\_lowestValue()**

---

**YCompass**

Changes the recorded minimal value observed.

```
function set_lowestValue( ByVal newval As Double) As Integer
```

**Parameters :**

**newval** a floating point number corresponding to the recorded minimal value observed

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**compass**→**set\_reportFrequency()**  
**compass**→**setReportFrequency()**  
**compass.set\_reportFrequency()**

---

**YCompass**

Changes the timed value notification frequency for this function.

```
function set_reportFrequency( ByVal newval As String) As Integer
```

The frequency can be specified as samples per second, as sample per minute (for instance "15/m") or in samples per hour (eg. "4/h"). To disable timed value notifications for this function, use the value "OFF".

**Parameters :**

**newval** a string corresponding to the timed value notification frequency for this function

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.



---

**compass**→**set\_resolution()****YCompass****compass**→**setResolution()****compass.set\_resolution()**

---

Changes the resolution of the measured physical values.

```
function set_resolution( ByVal newval As Double) As Integer
```

The resolution corresponds to the numerical precision when displaying value. It does not change the precision of the measure itself.

**Parameters :**

**newval** a floating point number corresponding to the resolution of the measured physical values

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**compass**→**set\_userData()**

**YCompass**

**compass**→**setUserData()****compass.set\_userData()**

---

Stores a user context provided as argument in the `userData` attribute of the function.

```
procedure set_userData( ByVal data As Object)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

## 3.8. Current function interface

The Yoctopuce application programming interface allows you to read an instant measure of the sensor, as well as the minimal and maximal values observed.

In order to use the functions described here, you should include:

js	<script type='text/javascript' src='yocto_current.js'></script>
nodejs	var yoctolib = require('yoctolib'); var YCurrent = yoctolib.YCurrent;
php	require_once('yocto_current.php');
c++	#include "yocto_current.h"
m	#import "yocto_current.h"
pas	uses yocto_current;
vb	yocto_current.vb
cs	yocto_current.cs
java	import com.yoctopuce.YoctoAPI.YCurrent;
py	from yocto_current import *

### Global functions

#### **yFindCurrent(func)**

Retrieves a current sensor for a given identifier.

#### **yFirstCurrent()**

Starts the enumeration of current sensors currently accessible.

### YCurrent methods

#### **current→calibrateFromPoints(rawValues, refValues)**

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

#### **current→describe()**

Returns a short text that describes unambiguously the instance of the current sensor in the form `TYPE ( NAME ) = SERIAL . FUNCTIONID`.

#### **current→get\_advertisedValue()**

Returns the current value of the current sensor (no more than 6 characters).

#### **current→get\_currentRawValue()**

Returns the uncalibrated, unrounded raw value returned by the sensor, in mA, as a floating point number.

#### **current→get\_currentValue()**

Returns the current value of the current, in mA, as a floating point number.

#### **current→get\_errorMessage()**

Returns the error message of the latest error with the current sensor.

#### **current→get\_errorType()**

Returns the numerical error code of the latest error with the current sensor.

#### **current→get\_friendlyName()**

Returns a global identifier of the current sensor in the format `MODULE_NAME . FUNCTION_NAME`.

#### **current→get\_functionDescriptor()**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

#### **current→get\_functionId()**

Returns the hardware identifier of the current sensor, without reference to the module.

#### **current→get\_hardwareId()**

Returns the unique hardware identifier of the current sensor in the form `SERIAL . FUNCTIONID`.

**current**→**get\_highestValue()**

Returns the maximal value observed for the current since the device was started.

**current**→**get\_logFrequency()**

Returns the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory.

**current**→**get\_logicalName()**

Returns the logical name of the current sensor.

**current**→**get\_lowestValue()**

Returns the minimal value observed for the current since the device was started.

**current**→**get\_module()**

Gets the `YModule` object for the device on which the function is located.

**current**→**get\_module\_async(callback, context)**

Gets the `YModule` object for the device on which the function is located (asynchronous version).

**current**→**get\_recordedData(startTime, endTime)**

Retrieves a `DataSet` object holding historical data for this sensor, for a specified time interval.

**current**→**get\_reportFrequency()**

Returns the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function.

**current**→**get\_resolution()**

Returns the resolution of the measured values.

**current**→**get\_unit()**

Returns the measuring unit for the current.

**current**→**get\_userData()**

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

**current**→**isOnline()**

Checks if the current sensor is currently reachable, without raising any error.

**current**→**isOnline\_async(callback, context)**

Checks if the current sensor is currently reachable, without raising any error (asynchronous version).

**current**→**load(msValidity)**

Preloads the current sensor cache with a specified validity duration.

**current**→**loadCalibrationPoints(rawValues, refValues)**

Retrieves error correction data points previously entered using the method `calibrateFromPoints`.

**current**→**load\_async(msValidity, callback, context)**

Preloads the current sensor cache with a specified validity duration (asynchronous version).

**current**→**nextCurrent()**

Continues the enumeration of current sensors started using `yFirstCurrent()`.

**current**→**registerTimedReportCallback(callback)**

Registers the callback function that is invoked on every periodic timed notification.

**current**→**registerValueCallback(callback)**

Registers the callback function that is invoked on every change of advertised value.

**current**→**set\_highestValue(newval)**

Changes the recorded maximal value observed.

**current**→**set\_logFrequency(newval)**

Changes the datalogger recording frequency for this function.

**current**→**set\_logicalName(newval)**

Changes the logical name of the current sensor.

**current**→**set\_lowestValue(newval)**

Changes the recorded minimal value observed.

**current**→**set\_reportFrequency(newval)**

Changes the timed value notification frequency for this function.

**current**→**set\_resolution(newval)**

Changes the resolution of the measured physical values.

**current**→**set\_userData(data)**

Stores a user context provided as argument in the userData attribute of the function.

**current**→**wait\_async(callback, context)**

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.

## YCurrent.FindCurrent() yFindCurrent()yFindCurrent()

YCurrent

Retrieves a current sensor for a given identifier.

```
function yFindCurrent( ByVal func As String) As YCurrent
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the current sensor is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YCurrent.IsOnline()` to test if the current sensor is indeed online at a given time. In case of ambiguity when looking for a current sensor by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

**Parameters :**

**func** a string that uniquely characterizes the current sensor

**Returns :**

a `YCurrent` object allowing you to drive the current sensor.

---

**YCurrent.FirstCurrent()  
yFirstCurrent(yFirstCurrent())**

---

**YCurrent**

Starts the enumeration of current sensors currently accessible.

```
function yFirstCurrent( ) As YCurrent
```

Use the method `YCurrent.NextCurrent ( )` to iterate on next current sensors.

**Returns :**

a pointer to a `YCurrent` object, corresponding to the first current sensor currently online, or a `null` pointer if there are none.

**current**→**calibrateFromPoints()**  
**current.calibrateFromPoints()****YCurrent**

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

procedure **calibrateFromPoints()** ( )

It is possible to configure up to five correction points. Correction points must be provided in ascending order, and be in the range of the sensor. The device will automatically perform a linear interpolation of the error correction between specified points. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

For more information on advanced capabilities to refine the calibration of sensors, please contact [support@yoctopuce.com](mailto:support@yoctopuce.com).

**Parameters :**

**rawValues** array of floating point numbers, corresponding to the raw values returned by the sensor for the correction points.

**refValues** array of floating point numbers, corresponding to the corrected values for the correction points.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.



**current**→**describe()****current.describe()****YCurrent**

Returns a short text that describes unambiguously the instance of the current sensor in the form `TYPE (NAME) =SERIAL . FUNCTIONID`.

function **describe**( ) As String

More precisely, `TYPE` is the type of the function, `NAME` it the name used for the first access to the function, `SERIAL` is the serial number of the module if the module is connected or "unresolved", and `FUNCTIONID` is the hardware identifier of the function if the module is connected. For example, this method returns `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1` if the module is already connected or `Relay(BadCustomName.relay1)=unresolved` if the module has not yet been connected. This method does not trigger any USB or TCP transaction and can therefore be used in a debugger.

**Returns :**

a string that describes the current sensor (ex: `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1`)

**current**→**get\_advertisedValue()**

**YCurrent**

**current**→**advertisedValue()**

**current.get\_advertisedValue()**

---

Returns the current value of the current sensor (no more than 6 characters).

function **get\_advertisedValue( )** As String

**Returns :**

a string corresponding to the current value of the current sensor (no more than 6 characters).

On failure, throws an exception or returns Y\_ADVERTISEDVALUE\_INVALID.

---

**current**→**get\_currentRawValue()****YCurrent****current**→**currentRawValue()****current.get\_currentRawValue()**

---

Returns the uncalibrated, unrounded raw value returned by the sensor, in mA, as a floating point number.

```
function get_currentRawValue( ) As Double
```

**Returns :**

a floating point number corresponding to the uncalibrated, unrounded raw value returned by the sensor, in mA, as a floating point number

On failure, throws an exception or returns `Y_CURRENTRAWVALUE_INVALID`.

**current**→**get\_currentValue()**

**YCurrent**

**current**→**currentValue()****current.get\_currentValue()**

---

Returns the current value of the current, in mA, as a floating point number.

```
function get_currentValue( ) As Double
```

**Returns :**

a floating point number corresponding to the current value of the current, in mA, as a floating point number

On failure, throws an exception or returns `Y_CURRENTVALUE_INVALID`.

---

**current**→**get\_errorMessage()****YCurrent****current**→**errorMessage()****current.get\_errorMessage()**

---

Returns the error message of the latest error with the current sensor.

```
function get_errorMessage( ) As String
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using the current sensor object

**current**→**get\_errorType()**

**YCurrent**

**current**→**errorType()****current.get\_errorType()**

---

Returns the numerical error code of the latest error with the current sensor.

function **get\_errorType**( ) As YRETCODE

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using the current sensor object

---

**current**→**get\_functionDescriptor()**  
**current**→**functionDescriptor()**  
**current.get\_functionDescriptor()**

---

**YCurrent**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

function **get\_functionDescriptor**( ) As `YFUN_DESCR`

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`.

If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

**current**→**get\_functionId()**

**YCurrent**

**current**→**functionId()****current.get\_functionId()**

---

Returns the hardware identifier of the current sensor, without reference to the module.

function **get\_functionId**( ) As String

For example `relay1`

**Returns :**

a string that identifies the current sensor (ex: `relay1`)

On failure, throws an exception or returns `Y_FUNCTIONID_INVALID`.



---

**current**→**get\_hardwareId()****YCurrent****current**→**hardwareId()****current.get\_hardwareId()**

---

Returns the unique hardware identifier of the current sensor in the form `SERIAL.FUNCTIONID`.

function **get\_hardwareId()** As String

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the current sensor (for example `RELAYLO1-123456.relay1`).

**Returns :**

a string that uniquely identifies the current sensor (ex: `RELAYLO1-123456.relay1`)

On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

**current**→**get\_highestValue()**

**YCurrent**

**current**→**highestValue()****current.get\_highestValue()**

---

Returns the maximal value observed for the current since the device was started.

function **get\_highestValue**( ) As Double

**Returns :**

a floating point number corresponding to the maximal value observed for the current since the device was started

On failure, throws an exception or returns `Y_HIGHESTVALUE_INVALID`.

---

**current**→**get\_logFrequency()****YCurrent****current**→**logFrequency()****current.get\_logFrequency()**

---

Returns the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory.

function **get\_logFrequency**( ) As String

**Returns :**

a string corresponding to the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory

On failure, throws an exception or returns `Y_LOGFREQUENCY_INVALID`.

**current**→**get\_logicalName()**

**YCurrent**

**current**→**logicalName()****current.get\_logicalName()**

---

Returns the logical name of the current sensor.

function **get\_logicalName**( ) As String

**Returns :**

a string corresponding to the logical name of the current sensor.

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

---

**current**→**get\_lowestValue()****YCurrent****current**→**lowestValue()****current.get\_lowestValue()**

---

Returns the minimal value observed for the current since the device was started.

function **get\_lowestValue()** As Double

**Returns :**

a floating point number corresponding to the minimal value observed for the current since the device was started

On failure, throws an exception or returns `Y_LOWESTVALUE_INVALID`.

**current**→**get\_module()**

**YCurrent**

**current**→**module()****current.get\_module()**

---

Gets the YModule object for the device on which the function is located.

function **get\_module()** As YModule

If the function cannot be located on any module, the returned instance of YModule is not shown as on-line.

**Returns :**

an instance of YModule

---

**current**→**get\_recordedData()****YCurrent****current**→**recordedData()****current.get\_recordedData()**

---

Retrieves a DataSet object holding historical data for this sensor, for a specified time interval.

```
function get_recordedData( ) As YDataSet
```

The measures will be retrieved from the data logger, which must have been turned on at the desired time. See the documentation of the DataSet class for information on how to get an overview of the recorded data, and how to load progressively a large set of measures from the data logger.

This function only works if the device uses a recent firmware, as DataSet objects are not supported by firmwares older than version 13000.

**Parameters :**

- startTime** the start of the desired measure time interval, as a Unix timestamp, i.e. the number of seconds since January 1, 1970 UTC. The special value 0 can be used to include any measure, without initial limit.
- endTime** the end of the desired measure time interval, as a Unix timestamp, i.e. the number of seconds since January 1, 1970 UTC. The special value 0 can be used to include any measure, without ending limit.

**Returns :**

an instance of YDataSet, providing access to historical data. Past measures can be loaded progressively using methods from the YDataSet object.

**current**→**get\_reportFrequency()**

**YCurrent**

**current**→**reportFrequency()**

**current.get\_reportFrequency()**

---

Returns the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function.

```
function get_reportFrequency( ) As String
```

**Returns :**

a string corresponding to the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function

On failure, throws an exception or returns `Y_REPORTFREQUENCY_INVALID`.



---

**current**→**get\_resolution()****YCurrent****current**→**resolution()****current.get\_resolution()**

---

Returns the resolution of the measured values.

function **get\_resolution**( ) As Double

The resolution corresponds to the numerical precision of the measures, which is not always the same as the actual precision of the sensor.

**Returns :**

a floating point number corresponding to the resolution of the measured values

On failure, throws an exception or returns `Y_RESOLUTION_INVALID`.

**current**→**get\_unit()**

**YCurrent**

**current**→**unit()****current.get\_unit()**

---

Returns the measuring unit for the current.

function **get\_unit**( ) As String

**Returns :**

a string corresponding to the measuring unit for the current

On failure, throws an exception or returns `Y_UNIT_INVALID`.

---

**current**→**get\_userData()****YCurrent****current**→**userData()****current.get\_userData()**

---

Returns the value of the userData attribute, as previously stored using method `set_userData`.

```
function get_userData( ) As Object
```

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

**current**→**isOnline()****current.isOnline()**

**YCurrent**

---

Checks if the current sensor is currently reachable, without raising any error.

function **isOnline**( ) As Boolean

If there is a cached value for the current sensor in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the current sensor.

**Returns :**

`true` if the current sensor can be reached, and `false` otherwise

**current**→**load()****current.load()****YCurrent**

Preloads the current sensor cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

**current→loadCalibrationPoints()  
current.loadCalibrationPoints()**

**YCurrent**

Retrieves error correction data points previously entered using the method `calibrateFromPoints`.

procedure `loadCalibrationPoints( )`

**Parameters :**

**rawValues** array of floating point numbers, that will be filled by the function with the raw sensor values for the correction points.

**refValues** array of floating point numbers, that will be filled by the function with the desired values for the correction points.

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**current**→**nextCurrent()****current.nextCurrent()****YCurrent**

---

Continues the enumeration of current sensors started using `yFirstCurrent()`.

```
function nextCurrent( ) As YCurrent
```

**Returns :**

a pointer to a `YCurrent` object, corresponding to a current sensor currently online, or a `null` pointer if there are no more current sensors to enumerate.

**current**→**registerTimedReportCallback()**  
**current.registerTimedReportCallback()****YCurrent**

Registers the callback function that is invoked on every periodic timed notification.

```
function registerTimedReportCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and an `YMeasure` object describing the new advertised value.



---

**current**→**registerValueCallback()**  
**current.registerValueCallback()**

---

**YCurrent**

Registers the callback function that is invoked on every change of advertised value.

function **registerValueCallback**( ) As Integer

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

**current**→**set\_highestValue()**  
**current**→**setHighestValue()**  
**current.set\_highestValue()**

---

**YCurrent**

Changes the recorded maximal value observed.

```
function set_highestValue( ByVal newval As Double) As Integer
```

**Parameters :**

**newval** a floating point number corresponding to the recorded maximal value observed

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**current**→**set\_logFrequency()**  
**current**→**setLogFrequency()**  
**current.set\_logFrequency()**

---

**YCurrent**

Changes the datalogger recording frequency for this function.

```
function set_logFrequency( ByVal newval As String) As Integer
```

The frequency can be specified as samples per second, as sample per minute (for instance "15/m") or in samples per hour (eg. "4/h"). To disable recording for this function, use the value "OFF".

**Parameters :**

**newval** a string corresponding to the datalogger recording frequency for this function

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**current**→**set\_logicalName()**

**YCurrent**

**current**→**setLogicalName()****current.set\_logicalName()**

---

Changes the logical name of the current sensor.

```
function set_logicalName( ByVal newval As String) As Integer
```

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the current sensor.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**current**→**set\_lowestValue()****YCurrent****current**→**setLowestValue()****current.set\_lowestValue()**

---

Changes the recorded minimal value observed.

```
function set_lowestValue( ByVal newval As Double) As Integer
```

**Parameters :**

**newval** a floating point number corresponding to the recorded minimal value observed

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**current**→**set\_reportFrequency()**  
**current**→**setReportFrequency()**  
**current.set\_reportFrequency()**

---

**YCurrent**

Changes the timed value notification frequency for this function.

```
function set_reportFrequency( ByVal newval As String) As Integer
```

The frequency can be specified as samples per second, as sample per minute (for instance "15/m") or in samples per hour (eg. "4/h"). To disable timed value notifications for this function, use the value "OFF".

**Parameters :**

**newval** a string corresponding to the timed value notification frequency for this function

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**current**→**set\_resolution()****YCurrent****current**→**setResolution()****current.set\_resolution()**

---

Changes the resolution of the measured physical values.

```
function set_resolution( ByVal newval As Double) As Integer
```

The resolution corresponds to the numerical precision when displaying value. It does not change the precision of the measure itself.

**Parameters :**

**newval** a floating point number corresponding to the resolution of the measured physical values

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**current**→**set\_userData()**

**YCurrent**

**current**→**setUserData()****current.set\_userData()**

---

Stores a user context provided as argument in the `userData` attribute of the function.

```
procedure set_userData( ByVal data As Object)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored



## 3.9. DataLogger function interface

Yoctopuce sensors include a non-volatile memory capable of storing ongoing measured data automatically, without requiring a permanent connection to a computer. The DataLogger function controls the global parameters of the internal data logger.

In order to use the functions described here, you should include:

js	<script type='text/javascript' src='yocto_datalogger.js'></script>
nodejs	var yoctolib = require('yoctolib'); var YDataLogger = yoctolib.YDataLogger;
php	require_once('yocto_datalogger.php');
c++	#include "yocto_datalogger.h"
m	#import "yocto_datalogger.h"
pas	uses yocto_datalogger;
vb	yocto_datalogger.vb
cs	yocto_datalogger.cs
java	import com.yoctopuce.YoctoAPI.YDataLogger;
py	from yocto_datalogger import *

Global functions	
<b>yFindDataLogger(func)</b>	Retrieves a data logger for a given identifier.
<b>yFirstDataLogger()</b>	Starts the enumeration of data loggers currently accessible.
YDataLogger methods	
<b>datalogger→describe()</b>	Returns a short text that describes unambiguously the instance of the data logger in the form TYPE ( NAME ) = SERIAL . FUNCTIONID.
<b>datalogger→forgetAllDataStreams()</b>	Clears the data logger memory and discards all recorded data streams.
<b>datalogger→get_advertisedValue()</b>	Returns the current value of the data logger (no more than 6 characters).
<b>datalogger→get_autoStart()</b>	Returns the default activation state of the data logger on power up.
<b>datalogger→get_beaconDriven()</b>	Return true if the data logger is synchronised with the localization beacon.
<b>datalogger→get_currentRunIndex()</b>	Returns the current run number, corresponding to the number of times the module was powered on with the dataLogger enabled at some point.
<b>datalogger→get_dataSets()</b>	Returns a list of YDataSet objects that can be used to retrieve all measures stored by the data logger.
<b>datalogger→get_dataStreams(v)</b>	Builds a list of all data streams hold by the data logger (legacy method).
<b>datalogger→get_errorMessage()</b>	Returns the error message of the latest error with the data logger.
<b>datalogger→get_errorType()</b>	Returns the numerical error code of the latest error with the data logger.
<b>datalogger→get_friendlyName()</b>	

Returns a global identifier of the data logger in the format `MODULE_NAME . FUNCTION_NAME`.

**`datalogger→get_functionDescriptor()`**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

**`datalogger→get_functionId()`**

Returns the hardware identifier of the data logger, without reference to the module.

**`datalogger→get_hardwareId()`**

Returns the unique hardware identifier of the data logger in the form `SERIAL . FUNCTIONID`.

**`datalogger→get_logicalName()`**

Returns the logical name of the data logger.

**`datalogger→get_module()`**

Gets the `YModule` object for the device on which the function is located.

**`datalogger→get_module_async(callback, context)`**

Gets the `YModule` object for the device on which the function is located (asynchronous version).

**`datalogger→get_recording()`**

Returns the current activation state of the data logger.

**`datalogger→get_timeUTC()`**

Returns the Unix timestamp for current UTC time, if known.

**`datalogger→get_userData()`**

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

**`datalogger→isOnline()`**

Checks if the data logger is currently reachable, without raising any error.

**`datalogger→isOnline_async(callback, context)`**

Checks if the data logger is currently reachable, without raising any error (asynchronous version).

**`datalogger→load(msValidity)`**

Preloads the data logger cache with a specified validity duration.

**`datalogger→load_async(msValidity, callback, context)`**

Preloads the data logger cache with a specified validity duration (asynchronous version).

**`datalogger→nextDataLogger()`**

Continues the enumeration of data loggers started using `yFirstDataLogger()`.

**`datalogger→registerValueCallback(callback)`**

Registers the callback function that is invoked on every change of advertised value.

**`datalogger→set_autoStart(newval)`**

Changes the default activation state of the data logger on power up.

**`datalogger→set_beaconDriven(newval)`**

Changes the type of synchronisation of the data logger.

**`datalogger→set_logicalName(newval)`**

Changes the logical name of the data logger.

**`datalogger→set_recording(newval)`**

Changes the activation state of the data logger to start/stop recording data.

**`datalogger→set_timeUTC(newval)`**

Changes the current UTC time reference used for recorded data.

**`datalogger→set_userData(data)`**

Stores a user context provided as argument in the `userData` attribute of the function.

**`datalogger→wait_async(callback, context)`**

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.

## YDataLogger.FindDataLogger() yFindDataLogger()yFindDataLogger()

YDataLogger

Retrieves a data logger for a given identifier.

```
function yFindDataLogger( ByVal func As String) As YDataLogger
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the data logger is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YDataLogger.IsOnline()` to test if the data logger is indeed online at a given time. In case of ambiguity when looking for a data logger by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

### Parameters :

**func** a string that uniquely characterizes the data logger

### Returns :

a `YDataLogger` object allowing you to drive the data logger.

---

**YDataLogger.FirstDataLogger()  
yFirstDataLogger(yFirstDataLogger())**

---

**YDataLogger**

Starts the enumeration of data loggers currently accessible.

```
function yFirstDataLogger( ) As YDataLogger
```

Use the method `YDataLogger.nextDataLogger( )` to iterate on next data loggers.

**Returns :**

a pointer to a `YDataLogger` object, corresponding to the first data logger currently online, or a `null` pointer if there are none.

**datalogger**→**describe()****datalogger.describe()****YDataLogger**

Returns a short text that describes unambiguously the instance of the data logger in the form `TYPE (NAME) =SERIAL . FUNCTIONID`.

function **describe**( ) As String

More precisely, `TYPE` is the type of the function, `NAME` it the name used for the first access to the function, `SERIAL` is the serial number of the module if the module is connected or "unresolved", and `FUNCTIONID` is the hardware identifier of the function if the module is connected. For example, this method returns `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1` if the module is already connected or `Relay(BadCustomeName.relay1)=unresolved` if the module has not yet been connected. This method does not trigger any USB or TCP transaction and can therefore be used in a debugger.

**Returns :**

a string that describes the data logger (ex: `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1`)

---

**datalogger→forgetAllDataStreams()**  
**datalogger.forgetAllDataStreams()**

---

**YDataLogger**

Clears the data logger memory and discards all recorded data streams.

function **forgetAllDataStreams**( ) As Integer

This method also resets the current run index to zero.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**datalogger**→**get\_advertisedValue()**

**YDataLogger**

**datalogger**→**advertisedValue()**

**datalogger.get\_advertisedValue()**

---

Returns the current value of the data logger (no more than 6 characters).

```
function get_advertisedValue( ) As String
```

**Returns :**

a string corresponding to the current value of the data logger (no more than 6 characters).

On failure, throws an exception or returns Y\_ADVERTISEDVALUE\_INVALID.



---

**datalogger**→**get\_autoStart()****YDataLogger****datalogger**→**autoStart()****datalogger.get\_autoStart()**

---

Returns the default activation state of the data logger on power up.

function **get\_autoStart()** As Integer

**Returns :**

either Y\_AUTOSTART\_OFF or Y\_AUTOSTART\_ON, according to the default activation state of the data logger on power up

On failure, throws an exception or returns Y\_AUTOSTART\_INVALID.

**datalogger**→**get\_beaconDriven()**

**YDataLogger**

**datalogger**→**beaconDriven()**

**datalogger.get\_beaconDriven()**

---

Return true if the data logger is synchronised with the localization beacon.

```
function get_beaconDriven( ) As Integer
```

**Returns :**

either Y\_BEACONDRIVEN\_OFF or Y\_BEACONDRIVEN\_ON

On failure, throws an exception or returns Y\_BEACONDRIVEN\_INVALID.

---

**datalogger**→**get\_currentRunIndex()****YDataLogger****datalogger**→**currentRunIndex()****datalogger.get\_currentRunIndex()**

---

Returns the current run number, corresponding to the number of times the module was powered on with the dataLogger enabled at some point.

```
function get_currentRunIndex( ) As Integer
```

**Returns :**

an integer corresponding to the current run number, corresponding to the number of times the module was powered on with the dataLogger enabled at some point

On failure, throws an exception or returns `Y_CURRENTRUNINDEX_INVALID`.

**datalogger**→**get\_dataSets()**

**YDataLogger**

**datalogger**→**dataSets()****datalogger.get\_dataSets()**

---

Returns a list of YDataSet objects that can be used to retrieve all measures stored by the data logger.

```
function get_dataSets( ) As List
```

This function only works if the device uses a recent firmware, as YDataSet objects are not supported by firmwares older than version 13000.

**Returns :**

a list of YDataSet object.

On failure, throws an exception or returns an empty list.

---

**datalogger**→**get\_dataStreams()**  
**datalogger**→**dataStreams()**  
**datalogger.get\_dataStreams()**

---

**YDataLogger**

Builds a list of all data streams hold by the data logger (legacy method).

```
procedure get_dataStreams( ByVal v As List)
```

The caller must pass by reference an empty array to hold YDataStream objects, and the function fills it with objects describing available data sequences.

This is the old way to retrieve data from the DataLogger. For new applications, you should rather use `get_dataSets ( )` method, or call directly `get_recordedData ( )` on the sensor object.

**Parameters :**

**v** an array of YDataStream objects to be filled in

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**datalogger**→**get\_errorMessage()**

**YDataLogger**

**datalogger**→**errorMessage()**

**datalogger.get\_errorMessage()**

---

Returns the error message of the latest error with the data logger.

```
function get_errorMessage( ) As String
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using the data logger object

---

**datalogger**→**get\_errorType()****YDataLogger****datalogger**→**errorType()****datalogger.get\_errorType()**

---

Returns the numerical error code of the latest error with the data logger.

```
function get_errorType( ) As YRETCODE
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using the data logger object

**datalogger**→**get\_functionDescriptor()**

**YDataLogger**

**datalogger**→**functionDescriptor()**

**datalogger.get\_functionDescriptor()**

---

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

`function get_functionDescriptor( )` As `YFUN_DESCR`

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`.

If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.



---

**datalogger**→**get\_functionId()****YDataLogger****datalogger**→**functionId()****datalogger.get\_functionId()**

---

Returns the hardware identifier of the data logger, without reference to the module.

function **get\_functionId**( ) As String

For example `relay1`

**Returns :**

a string that identifies the data logger (ex: `relay1`)

On failure, throws an exception or returns `Y_FUNCTIONID_INVALID`.

**datalogger**→**get\_hardwareId()**

**YDataLogger**

**datalogger**→**hardwareId()**

**datalogger.get\_hardwareId()**

---

Returns the unique hardware identifier of the data logger in the form `SERIAL.FUNCTIONID`.

```
function get_hardwareId( ) As String
```

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the data logger (for example `RELAYLO1-123456.relay1`).

**Returns :**

a string that uniquely identifies the data logger (ex: `RELAYLO1-123456.relay1`)

On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

---

**datalogger**→**get\_logicalName()****YDataLogger****datalogger**→**logicalName()****datalogger.get\_logicalName()**

---

Returns the logical name of the data logger.

```
function get_logicalName( ) As String
```

**Returns :**

a string corresponding to the logical name of the data logger.

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

**datalogger**→**get\_module()**

**YDataLogger**

**datalogger**→**module()****datalogger.get\_module()**

---

Gets the YModule object for the device on which the function is located.

```
function get_module( ) As YModule
```

If the function cannot be located on any module, the returned instance of YModule is not shown as on-line.

**Returns :**

an instance of YModule

---

**datalogger**→**get\_recording()****YDataLogger****datalogger**→**recording()****datalogger.get\_recording()**

---

Returns the current activation state of the data logger.

function **get\_recording**( ) As Integer

**Returns :**

either `Y_RECORDING_OFF` or `Y_RECORDING_ON`, according to the current activation state of the data logger

On failure, throws an exception or returns `Y_RECORDING_INVALID`.

**datalogger**→**get\_timeUTC()**

**YDataLogger**

**datalogger**→**timeUTC()****datalogger.get\_timeUTC()**

---

Returns the Unix timestamp for current UTC time, if known.

function **get\_timeUTC()** As Long

**Returns :**

an integer corresponding to the Unix timestamp for current UTC time, if known

On failure, throws an exception or returns `Y_TIMEUTC_INVALID`.

---

**datalogger**→**get\_userData()****YDataLogger****datalogger**→**userData()****datalogger.get\_userData()**

---

Returns the value of the userData attribute, as previously stored using method `set_userData`.

```
function get_userData( ) As Object
```

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

## **datalogger**→**isOnline()****datalogger.isOnline()**

**YDataLogger**

---

Checks if the data logger is currently reachable, without raising any error.

```
function isOnline( ) As Boolean
```

If there is a cached value for the data logger in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the data logger.

**Returns :**

`true` if the data logger can be reached, and `false` otherwise



**datalogger**→**load()****datalogger.load()****YDataLogger**

Preloads the data logger cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

**datalogger**→**nextDataLogger()**  
**datalogger.nextDataLogger()**

**YDataLogger**

---

Continues the enumeration of data loggers started using `yFirstDataLogger()`.

function **nextDataLogger()** As YDataLogger

**Returns :**

a pointer to a YDataLogger object, corresponding to a data logger currently online, or a null pointer if there are no more data loggers to enumerate.

---

**datalogger→registerValueCallback()  
datalogger.registerValueCallback()**

---

**YDataLogger**

Registers the callback function that is invoked on every change of advertised value.

```
function registerValueCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

**datalogger**→**set\_autoStart()**

**YDataLogger**

**datalogger**→**setAutoStart()****datalogger.set\_autoStart()**

---

Changes the default activation state of the data logger on power up.

```
function set_autoStart( ByVal newval As Integer) As Integer
```

Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** either `Y_AUTOSTART_OFF` or `Y_AUTOSTART_ON`, according to the default activation state of the data logger on power up

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

**datalogger**→**set\_beaconDriven()**  
**datalogger**→**setBeaconDriven()**  
**datalogger.set\_beaconDriven()**

**YDataLogger**

Changes the type of synchronisation of the data logger.

```
function set_beaconDriven( ByVal newval As Integer) As Integer
```

Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** either `Y_BEACONDRIVEN_OFF` or `Y_BEACONDRIVEN_ON`, according to the type of synchronisation of the data logger

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**datalogger**→**set\_logicalName()****YDataLogger****datalogger**→**setLogicalName()****datalogger.set\_logicalName()**

---

Changes the logical name of the data logger.

```
function set_logicalName( ByVal newval As String) As Integer
```

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the data logger.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**datalogger**→**set\_recording()****YDataLogger****datalogger**→**setRecording()****datalogger.set\_recording()**

Changes the activation state of the data logger to start/stop recording data.

```
function set_recording( ByVal newval As Integer) As Integer
```

**Parameters :**

**newval** either Y\_RECORDING\_OFF or Y\_RECORDING\_ON, according to the activation state of the data logger to start/stop recording data

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**datalogger**→**set\_timeUTC()**

**YDataLogger**

**datalogger**→**setTimeUTC()****datalogger.set\_timeUTC()**

---

Changes the current UTC time reference used for recorded data.

```
function set_timeUTC( ByVal newval As Long) As Integer
```

**Parameters :**

**newval** an integer corresponding to the current UTC time reference used for recorded data

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.



---

**datalogger**→**set\_userData()****YDataLogger****datalogger**→**setUserData()****datalogger.set\_userData()**

---

Stores a user context provided as argument in the `userData` attribute of the function.

```
procedure set_userData( ByVal data As Object)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

## 3.10. Formatted data sequence

A run is a continuous interval of time during which a module was powered on. A data run provides easy access to all data collected during a given run, providing on-the-fly resampling at the desired reporting rate.

In order to use the functions described here, you should include:

js	<script type='text/javascript' src='yocto_datalogger.js'></script>
nodejs	var yoctolib = require('yoctolib'); var YDataLogger = yoctolib.YDataLogger;
php	require_once('yocto_datalogger.php');
c++	#include "yocto_datalogger.h"
m	#import "yocto_datalogger.h"
pas	uses yocto_datalogger;
vb	yocto_datalogger.vb
cs	yocto_datalogger.cs
java	import com.yoctopuce.YoctoAPI.YDataLogger;
py	from yocto_datalogger import *

### YDataRun methods

#### **datarun**→**get\_averageValue**(measureName, pos)

Returns the average value of the measure observed at the specified time period.

#### **datarun**→**get\_duration**()

Returns the duration (in seconds) of the data run.

#### **datarun**→**get\_maxValue**(measureName, pos)

Returns the maximal value of the measure observed at the specified time period.

#### **datarun**→**get\_measureNames**()

Returns the names of the measures recorded by the data logger.

#### **datarun**→**get\_minValue**(measureName, pos)

Returns the minimal value of the measure observed at the specified time period.

#### **datarun**→**get\_startTimeUTC**()

Returns the start time of the data run, relative to the Jan 1, 1970.

#### **datarun**→**get\_valueCount**()

Returns the number of values accessible in this run, given the selected data samples interval.

#### **datarun**→**get\_valueInterval**()

Returns the number of seconds covered by each value in this run.

#### **datarun**→**set\_valueInterval**(valueInterval)

Changes the number of seconds covered by each value in this run.

---

**datarun→get\_startTimeUTC()**  
**datarun→startTimeUTC()**

---

**YDataRun**

Returns the start time of the data run, relative to the Jan 1, 1970.

If the UTC time was not set in the datalogger at any time during the recording of this data run, and if this is not the current run, this method returns 0.

**Returns :**

an unsigned number corresponding to the number of seconds between the Jan 1, 1970 and the beginning of this data run (i.e. Unix time representation of the absolute time).

## 3.11. Recorded data sequence

YDataSet objects make it possible to retrieve a set of recorded measures for a given sensor and a specified time interval. They can be used to load data points with a progress report. When the YDataSet object is instantiated by the `get_recordedData()` function, no data is yet loaded from the module. It is only when the `loadMore()` method is called over and over than data will be effectively loaded from the dataLogger.

A preview of available measures is available using the function `get_preview()` as soon as `loadMore()` has been called once. Measures themselves are available using function `get_measures()` when loaded by subsequent calls to `loadMore()`.

This class can only be used on devices that use a recent firmware, as YDataSet objects are not supported by firmwares older than version 13000.

In order to use the functions described here, you should include:

js	<code>&lt;script type='text/javascript' src='yocto_api.js'&gt;&lt;/script&gt;</code>
nodejs	<code>var yoctolib = require('yoctolib');</code> <code>var YAPI = yoctolib.YAPI;</code> <code>var YModule = yoctolib.YModule;</code>
php	<code>require_once('yocto_api.php');</code>
cpp	<code>#include "yocto_api.h"</code>
m	<code>#import "yocto_api.h"</code>
pas	<code>uses yocto_api;</code>
vb	<code>yocto_api.vb</code>
cs	<code>yocto_api.cs</code>
java	<code>import com.yoctopuce.YoctoAPI.YModule;</code>
py	<code>from yocto_api import *</code>

### YDataSet methods

#### **dataset**→`get_endTimeUTC()`

Returns the end time of the dataset, relative to the Jan 1, 1970.

#### **dataset**→`get_functionId()`

Returns the hardware identifier of the function that performed the measure, without reference to the module.

#### **dataset**→`get_hardwareId()`

Returns the unique hardware identifier of the function who performed the measures, in the form `SERIAL.FUNCTIONID`.

#### **dataset**→`get_measures()`

Returns all measured values currently available for this DataSet, as a list of YMeasure objects.

#### **dataset**→`get_preview()`

Returns a condensed version of the measures that can be retrieved in this YDataSet, as a list of YMeasure objects.

#### **dataset**→`get_progress()`

Returns the progress of the downloads of the measures from the data logger, on a scale from 0 to 100.

#### **dataset**→`get_startTimeUTC()`

Returns the start time of the dataset, relative to the Jan 1, 1970.

#### **dataset**→`get_summary()`

Returns an YMeasure object which summarizes the whole DataSet.

#### **dataset**→`get_unit()`

Returns the measuring unit for the measured value.

**dataset→loadMore()**

Loads the the next block of measures from the dataLogger, and updates the progress indicator.

**dataset→loadMore\_async(callback, context)**

Loads the the next block of measures from the dataLogger asynchronously.

**dataset**→**get\_endTimeUTC()**

**YDataSet**

**dataset**→**endTimeUTC()****dataset.get\_endTimeUTC()**

---

Returns the end time of the dataset, relative to the Jan 1, 1970.

function **get\_endTimeUTC()** As Long

When the YDataSet is created, the end time is the value passed in parameter to the `get_dataSet()` function. After the very first call to `loadMore()`, the end time is updated to reflect the timestamp of the last measure actually found in the `dataLogger` within the specified range.

**Returns :**

an unsigned number corresponding to the number of seconds between the Jan 1, 1970 and the end of this data set (i.e. Unix time representation of the absolute time).

---

**dataset**→**get\_functionId()****YDataSet****dataset**→**functionId()****dataset.get\_functionId()**

---

Returns the hardware identifier of the function that performed the measure, without reference to the module.

```
function get_functionId( ) As String
```

For example `temperature1`.

**Returns :**

a string that identifies the function (ex: `temperature1`)

**dataset**→**get\_hardwareId()**

**YDataSet**

**dataset**→**hardwareId()****dataset.get\_hardwareId()**

---

Returns the unique hardware identifier of the function who performed the measures, in the form `SERIAL.FUNCTIONID`.

function **get\_hardwareId()** As String

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the function (for example `THRMCPL1-123456.temperature1`)

**Returns :**

a string that uniquely identifies the function (ex: `THRMCPL1-123456.temperature1`)

On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.



---

**dataset**→**get\_measures()****YDataSet****dataset**→**measures()****dataset.get\_measures()**

---

Returns all measured values currently available for this DataSet, as a list of YMeasure objects.

```
function get_measures( ) As List
```

Each item includes: - the start of the measure time interval - the end of the measure time interval - the minimal value observed during the time interval - the average value observed during the time interval - the maximal value observed during the time interval

Before calling this method, you should call `loadMore()` to load data from the device. You may have to call `loadMore()` several time until all rows are loaded, but you can start looking at available data rows before the load is complete.

The oldest measures are always loaded first, and the most recent measures will be loaded last. As a result, timestamps are normally sorted in ascending order within the measure table, unless there was an unexpected adjustment of the datalogger UTC clock.

**Returns :**

a table of records, where each record depicts the measured value for a given time interval

On failure, throws an exception or returns an empty array.

**dataset**→**get\_preview()**

**YDataSet**

**dataset**→**preview()****dataset.get\_preview()**

---

Returns a condensed version of the measures that can be retrieved in this YDataSet, as a list of YMeasure objects.

function **get\_preview**( ) As List

Each item includes: - the start of a time interval - the end of a time interval - the minimal value observed during the time interval - the average value observed during the time interval - the maximal value observed during the time interval

This preview is available as soon as `loadMore()` has been called for the first time.

**Returns :**

a table of records, where each record depicts the measured values during a time interval

On failure, throws an exception or returns an empty array.

---

**dataset**→**get\_progress()****YDataSet****dataset**→**progress()****dataset.get\_progress()**

---

Returns the progress of the downloads of the measures from the data logger, on a scale from 0 to 100.

```
function get_progress( ) As Integer
```

When the object is instantiated by `get_dataSet`, the progress is zero. Each time `loadMore()` is invoked, the progress is updated, to reach the value 100 only once all measures have been loaded.

**Returns :**

an integer in the range 0 to 100 (percentage of completion).

**dataset**→**get\_startTimeUTC()**

**YDataSet**

**dataset**→**startTimeUTC(dataset.get\_startTimeUTC())**

---

Returns the start time of the dataset, relative to the Jan 1, 1970.

function **get\_startTimeUTC()** As Long

When the YDataSet is created, the start time is the value passed in parameter to the `get_dataSet()` function. After the very first call to `loadMore()`, the start time is updated to reflect the timestamp of the first measure actually found in the dataLogger within the specified range.

**Returns :**

an unsigned number corresponding to the number of seconds between the Jan 1, 1970 and the beginning of this data set (i.e. Unix time representation of the absolute time).

---

**dataset**→**get\_summary()****YDataSet****dataset**→**summary()****dataset.get\_summary()**

---

Returns an YMeasure object which summarizes the whole DataSet.

function **get\_summary**( ) As YMeasure

It includes the following information: - the start of a time interval - the end of a time interval - the minimal value observed during the time interval - the average value observed during the time interval - the maximal value observed during the time interval

This summary is available as soon as `loadMore()` has been called for the first time.

**Returns :**

an YMeasure object

**dataset**→**get\_unit()**

**YDataSet**

**dataset**→**unit()****dataset.get\_unit()**

---

Returns the measuring unit for the measured value.

function **get\_unit**( ) As String

**Returns :**

a string that represents a physical unit.

On failure, throws an exception or returns `Y_UNIT_INVALID`.

---

**dataset**→**loadMore()****dataset.loadMore()****YDataSet**

---

Loads the the next block of measures from the dataLogger, and updates the progress indicator.

```
function loadMore( ) As Integer
```

**Returns :**

an integer in the range 0 to 100 (percentage of completion), or a negative error code in case of failure.

On failure, throws an exception or returns a negative error code.

## 3.12. Unformatted data sequence

YDataStream objects represent bare recorded measure sequences, exactly as found within the data logger present on Yoctopuce sensors.

In most cases, it is not necessary to use YDataStream objects directly, as the YDataSet objects (returned by the `get_recordedData()` method from sensors and the `get_dataSets()` method from the data logger) provide a more convenient interface.

In order to use the functions described here, you should include:

js	<code>&lt;script type='text/javascript' src='yocto_api.js'&gt;&lt;/script&gt;</code>
nodejs	<code>var yoctolib = require('yoctolib'); var YAPI = yoctolib.YAPI; var YModule = yoctolib.YModule;</code>
php	<code>require_once('yocto_api.php');</code>
cpp	<code>#include "yocto_api.h"</code>
m	<code>#import "yocto_api.h"</code>
pas	<code>uses yocto_api;</code>
vb	<code>yocto_api.vb</code>
cs	<code>yocto_api.cs</code>
java	<code>import com.yoctopuce.YoctoAPI.YModule;</code>
py	<code>from yocto_api import *</code>

### YDataStream methods

#### **datastream**→`get_averageValue()`

Returns the average of all measures observed within this stream.

#### **datastream**→`get_columnCount()`

Returns the number of data columns present in this stream.

#### **datastream**→`get_columnNames()`

Returns the title (or meaning) of each data column present in this stream.

#### **datastream**→`get_data(row, col)`

Returns a single measure from the data stream, specified by its row and column index.

#### **datastream**→`get_dataRows()`

Returns the whole data set contained in the stream, as a bidimensional table of numbers.

#### **datastream**→`get_dataSamplesIntervalMs()`

Returns the number of milliseconds between two consecutive rows of this data stream.

#### **datastream**→`get_duration()`

Returns the approximate duration of this stream, in seconds.

#### **datastream**→`get_maxValue()`

Returns the largest measure observed within this stream.

#### **datastream**→`get_minValue()`

Returns the smallest measure observed within this stream.

#### **datastream**→`get_rowCount()`

Returns the number of data rows present in this stream.

#### **datastream**→`get_runIndex()`

Returns the run index of the data stream.

#### **datastream**→`get_startTime()`

Returns the relative start time of the data stream, measured in seconds.

#### **datastream**→`get_startTimeUTC()`



Returns the start time of the data stream, relative to the Jan 1, 1970.

**datastream→get\_averageValue()**

**YDataStream**

**datastream→averageValue()**

**datastream.get\_averageValue()**

---

Returns the average of all measures observed within this stream.

```
function get_averageValue( ) As Double
```

If the device uses a firmware older than version 13000, this method will always return Y\_DATA\_INVALID.

**Returns :**

a floating-point number corresponding to the average value, or Y\_DATA\_INVALID if the stream is not yet complete (still recording).

On failure, throws an exception or returns Y\_DATA\_INVALID.

---

**datastream**→**get\_columnCount()****YDataStream****datastream**→**columnCount()****datastream.get\_columnCount()**

---

Returns the number of data columns present in this stream.

```
function get_columnCount( ) As Integer
```

The meaning of the values present in each column can be obtained using the method `get_columnNames()`.

If the device uses a firmware older than version 13000, this method fetches the whole data stream from the device if not yet done, which can cause a little delay.

**Returns :**

an unsigned number corresponding to the number of columns.

On failure, throws an exception or returns zero.

**datastream**→**get\_columnNames()**

**YDataStream**

**datastream**→**columnNames()**

**datastream.get\_columnNames()**

---

Returns the title (or meaning) of each data column present in this stream.

```
function get_columnNames( ) As List
```

In most case, the title of the data column is the hardware identifier of the sensor that produced the data. For streams recorded at a lower recording rate, the dataLogger stores the min, average and max value during each measure interval into three columns with suffixes `_min`, `_avg` and `_max` respectively.

If the device uses a firmware older than version 13000, this method fetches the whole data stream from the device if not yet done, which can cause a little delay.

**Returns :**

a list containing as many strings as there are columns in the data stream.

On failure, throws an exception or returns an empty array.

---

**datastream**→**get\_data()****YDataStream****datastream**→**data()****datastream.get\_data()**

---

Returns a single measure from the data stream, specified by its row and column index.

```
function get_data( ) As Double
```

The meaning of the values present in each column can be obtained using the method `get_columnNames()`.

This method fetches the whole data stream from the device, if not yet done.

**Parameters :**

**row** row index

**col** column index

**Returns :**

a floating-point number

On failure, throws an exception or returns `Y_DATA_INVALID`.

**datastream**→**get\_dataRows()**

**YDataStream**

**datastream**→**dataRows()****datastream.get\_dataRows()**

---

Returns the whole data set contained in the stream, as a bidimensional table of numbers.

function **get\_dataRows()** As List

The meaning of the values present in each column can be obtained using the method `get_columnNames()`.

This method fetches the whole data stream from the device, if not yet done.

**Returns :**

a list containing as many elements as there are rows in the data stream. Each row itself is a list of floating-point numbers.

On failure, throws an exception or returns an empty array.

---

**datastream**→**get\_dataSamplesIntervalMs()****YDataStream****datastream**→**dataSamplesIntervalMs()****datastream.get\_dataSamplesIntervalMs()**

---

Returns the number of milliseconds between two consecutive rows of this data stream.

```
function get_dataSamplesIntervalMs( ) As Integer
```

By default, the data logger records one row per second, but the recording frequency can be changed for each device function

**Returns :**

an unsigned number corresponding to a number of milliseconds.

**datastream**→**get\_duration()**

**YDataStream**

**datastream**→**duration()****datastream.get\_duration()**

---

Returns the approximate duration of this stream, in seconds.

function **get\_duration**( ) As Integer

**Returns :**

the number of seconds covered by this stream.

On failure, throws an exception or returns Y\_DURATION\_INVALID.



---

**datastream**→**get\_maxValue()****YDataStream****datastream**→**maxValue()****datastream.get\_maxValue()**

---

Returns the largest measure observed within this stream.

function **get\_maxValue()** As Double

If the device uses a firmware older than version 13000, this method will always return Y\_DATA\_INVALID.

**Returns :**

a floating-point number corresponding to the largest value, or Y\_DATA\_INVALID if the stream is not yet complete (still recording).

On failure, throws an exception or returns Y\_DATA\_INVALID.

**datastream**→**get\_minValue()**

**YDataStream**

**datastream**→**minValue()****datastream.get\_minValue()**

---

Returns the smallest measure observed within this stream.

```
function get_minValue( ) As Double
```

If the device uses a firmware older than version 13000, this method will always return Y\_DATA\_INVALID.

**Returns :**

a floating-point number corresponding to the smallest value, or Y\_DATA\_INVALID if the stream is not yet complete (still recording).

On failure, throws an exception or returns Y\_DATA\_INVALID.

---

**datastream**→**get\_rowCount()****YDataStream****datastream**→**rowCount()****datastream.get\_rowCount()**

---

Returns the number of data rows present in this stream.

function **get\_rowCount()** As Integer

If the device uses a firmware older than version 13000, this method fetches the whole data stream from the device if not yet done, which can cause a little delay.

**Returns :**

an unsigned number corresponding to the number of rows.

On failure, throws an exception or returns zero.

**datastream**→**get\_runIndex()**

**YDataStream**

**datastream**→**runIndex()****datastream.get\_runIndex()**

---

Returns the run index of the data stream.

```
function get_runIndex( ) As Integer
```

A run can be made of multiple datastreams, for different time intervals.

**Returns :**

an unsigned number corresponding to the run index.

---

**datastream**→**get\_startTime()****YDataStream****datastream**→**startTime()****datastream**.**get\_startTime()**

---

Returns the relative start time of the data stream, measured in seconds.

```
function get_startTime( ) As Integer
```

For recent firmwares, the value is relative to the present time, which means the value is always negative. If the device uses a firmware older than version 13000, value is relative to the start of the time the device was powered on, and is always positive. If you need an absolute UTC timestamp, use `get_startTimeUTC()`.

**Returns :**

an unsigned number corresponding to the number of seconds between the start of the run and the beginning of this data stream.

**datastream**→**get\_startTimeUTC()**

**YDataStream**

**datastream**→**startTimeUTC()**

**datastream.get\_startTimeUTC()**

---

Returns the start time of the data stream, relative to the Jan 1, 1970.

```
function get_startTimeUTC( ) As Long
```

If the UTC time was not set in the datalogger at the time of the recording of this data stream, this method returns 0.

**Returns :**

an unsigned number corresponding to the number of seconds between the Jan 1, 1970 and the beginning of this data stream (i.e. Unix time representation of the absolute time).

## 3.13. Digital IO function interface

The Yoctopuce application programming interface allows you to switch the state of each bit of the I/O port. You can switch all bits at once, or one by one. The library can also automatically generate short pulses of a determined duration. Electrical behavior of each I/O can be modified (open drain and reverse polarity).

In order to use the functions described here, you should include:

js	<code>&lt;script type='text/javascript' src='yocto_digitalio.js'&gt;&lt;/script&gt;</code>
nodejs	<code>var yoctolib = require('yoctolib'); var YDigitalIO = yoctolib.YDigitalIO;</code>
php	<code>require_once('yocto_digitalio.php');</code>
cpp	<code>#include "yocto_digitalio.h"</code>
m	<code>#import "yocto_digitalio.h"</code>
pas	<code>uses yocto_digitalio;</code>
vb	<code>yocto_digitalio.vb</code>
cs	<code>yocto_digitalio.cs</code>
java	<code>import com.yoctopuce.YoctoAPI.YDigitalIO;</code>
py	<code>from yocto_digitalio import *</code>

### Global functions

#### **yFindDigitalIO(func)**

Retrieves a digital IO port for a given identifier.

#### **yFirstDigitalIO()**

Starts the enumeration of digital IO ports currently accessible.

### YDigitalIO methods

#### **digitalio→delayedPulse(bitno, ms\_delay, ms\_duration)**

Schedules a pulse on a single bit for a specified duration.

#### **digitalio→describe()**

Returns a short text that describes unambiguously the instance of the digital IO port in the form `TYPE (NAME) = SERIAL . FUNCTIONID`.

#### **digitalio→get\_advertisedValue()**

Returns the current value of the digital IO port (no more than 6 characters).

#### **digitalio→get\_bitDirection(bitno)**

Returns the direction of a single bit from the I/O port (0 means the bit is an input, 1 an output).

#### **digitalio→get\_bitOpenDrain(bitno)**

Returns the type of electrical interface of a single bit from the I/O port.

#### **digitalio→get\_bitPolarity(bitno)**

Returns the polarity of a single bit from the I/O port (0 means the I/O works in regular mode, 1 means the I/O works in reverse mode).

#### **digitalio→get\_bitState(bitno)**

Returns the state of a single bit of the I/O port.

#### **digitalio→get\_errorMessage()**

Returns the error message of the latest error with the digital IO port.

#### **digitalio→get\_errorType()**

Returns the numerical error code of the latest error with the digital IO port.

#### **digitalio→get\_friendlyName()**

Returns a global identifier of the digital IO port in the format `MODULE_NAME . FUNCTION_NAME`.

**digitalio**→**get\_functionDescriptor()**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

**digitalio**→**get\_functionId()**

Returns the hardware identifier of the digital IO port, without reference to the module.

**digitalio**→**get\_hardwareId()**

Returns the unique hardware identifier of the digital IO port in the form `SERIAL.FUNCTIONID`.

**digitalio**→**get\_logicalName()**

Returns the logical name of the digital IO port.

**digitalio**→**get\_module()**

Gets the `YModule` object for the device on which the function is located.

**digitalio**→**get\_module\_async(callback, context)**

Gets the `YModule` object for the device on which the function is located (asynchronous version).

**digitalio**→**get\_outputVoltage()**

Returns the voltage source used to drive output bits.

**digitalio**→**get\_portDirection()**

Returns the IO direction of all bits of the port: 0 makes a bit an input, 1 makes it an output.

**digitalio**→**get\_portOpenDrain()**

Returns the electrical interface for each bit of the port.

**digitalio**→**get\_portPolarity()**

Returns the polarity of all the bits of the port.

**digitalio**→**get\_portSize()**

Returns the number of bits implemented in the I/O port.

**digitalio**→**get\_portState()**

Returns the digital IO port state: bit 0 represents input 0, and so on.

**digitalio**→**get\_userData()**

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

**digitalio**→**isOnline()**

Checks if the digital IO port is currently reachable, without raising any error.

**digitalio**→**isOnline\_async(callback, context)**

Checks if the digital IO port is currently reachable, without raising any error (asynchronous version).

**digitalio**→**load(msValidity)**

Preloads the digital IO port cache with a specified validity duration.

**digitalio**→**load\_async(msValidity, callback, context)**

Preloads the digital IO port cache with a specified validity duration (asynchronous version).

**digitalio**→**nextDigitalIO()**

Continues the enumeration of digital IO ports started using `yFirstDigitalIO()`.

**digitalio**→**pulse(bitno, ms\_duration)**

Triggers a pulse on a single bit for a specified duration.

**digitalio**→**registerValueCallback(callback)**

Registers the callback function that is invoked on every change of advertised value.

**digitalio**→**set\_bitDirection(bitno, bitdirection)**

Changes the direction of a single bit from the I/O port.

**digitalio**→**set\_bitOpenDrain(bitno, opendrain)**

Changes the electrical interface of a single bit from the I/O port.

**digitalio**→**set\_bitPolarity(bitno, bitpolarity)**



Changes the polarity of a single bit from the I/O port.

**digitalio**→**set\_bitState**(**bitno**, **bitstate**)

Sets a single bit of the I/O port.

**digitalio**→**set\_logicalName**(**newval**)

Changes the logical name of the digital IO port.

**digitalio**→**set\_outputVoltage**(**newval**)

Changes the voltage source used to drive output bits.

**digitalio**→**set\_portDirection**(**newval**)

Changes the IO direction of all bits of the port: 0 makes a bit an input, 1 makes it an output.

**digitalio**→**set\_portOpenDrain**(**newval**)

Changes the electrical interface for each bit of the port.

**digitalio**→**set\_portPolarity**(**newval**)

Changes the polarity of all the bits of the port: 0 makes a bit an input, 1 makes it an output.

**digitalio**→**set\_portState**(**newval**)

Changes the digital IO port state: bit 0 represents input 0, and so on.

**digitalio**→**set\_userData**(**data**)

Stores a user context provided as argument in the userData attribute of the function.

**digitalio**→**toggle\_bitState**(**bitno**)

Reverts a single bit of the I/O port.

**digitalio**→**wait\_async**(**callback**, **context**)

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.

## YDigitalIO.FindDigitalIO() yFindDigitalIO()yFindDigitalIO()

YDigitalIO

Retrieves a digital IO port for a given identifier.

```
function yFindDigitalIO( ByVal func As String) As YDigitalIO
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the digital IO port is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YDigitalIO.IsOnline()` to test if the digital IO port is indeed online at a given time. In case of ambiguity when looking for a digital IO port by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

**Parameters :**

**func** a string that uniquely characterizes the digital IO port

**Returns :**

a `YDigitalIO` object allowing you to drive the digital IO port.

---

**YDigitalIO.FirstDigitalIO()  
yFirstDigitalIO(yFirstDigitalIO())**

---

**YDigitalIO**

Starts the enumeration of digital IO ports currently accessible.

```
function yFirstDigitalIO( ) As YDigitalIO
```

Use the method `YDigitalIO.NextDigitalIO()` to iterate on next digital IO ports.

**Returns :**

a pointer to a `YDigitalIO` object, corresponding to the first digital IO port currently online, or a `null` pointer if there are none.

**digitalio**→**delayedPulse()****digitalio.delayedPulse()****YDigitalIO**

Schedules a pulse on a single bit for a specified duration.

```
function delayedPulse( ) As Integer
```

The specified bit will be turned to 1, and then back to 0 after the given duration.

**Parameters :**

- bitno** the bit number; lowest bit has index 0
- ms\_delay** waiting time before the pulse, in milliseconds
- ms\_duration** desired pulse duration in milliseconds. Be aware that the device time resolution is not guaranteed up to the millisecond.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**digitalio→describe()digitalio.describe()****YDigitalIO**

Returns a short text that describes unambiguously the instance of the digital IO port in the form `TYPE(NAME)=SERIAL.FUNCTIONID`.

function **describe**( ) As String

More precisely, `TYPE` is the type of the function, `NAME` is the name used for the first access to the function, `SERIAL` is the serial number of the module if the module is connected or "unresolved", and `FUNCTIONID` is the hardware identifier of the function if the module is connected. For example, this method returns `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1` if the module is already connected or `Relay(BadCustomName.relay1)=unresolved` if the module has not yet been connected. This method does not trigger any USB or TCP transaction and can therefore be used in a debugger.

**Returns :**

a string that describes the digital IO port (ex: `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1`)

**digitalio**→**get\_advertisedValue()**

**YDigitalIO**

**digitalio**→**advertisedValue()**

**digitalio.get\_advertisedValue()**

---

Returns the current value of the digital IO port (no more than 6 characters).

```
function get_advertisedValue( ) As String
```

**Returns :**

a string corresponding to the current value of the digital IO port (no more than 6 characters).

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

---

**digitalio**→**get\_bitDirection()****YDigitalIO****digitalio**→**bitDirection()****digitalio.get\_bitDirection()**

---

Returns the direction of a single bit from the I/O port (0 means the bit is an input, 1 an output).

function **get\_bitDirection()** As Integer

**Parameters :**

**bitno** the bit number; lowest bit has index 0

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**digitalio**→**get\_bitOpenDrain()**

**YDigitalIO**

**digitalio**→**bitOpenDrain()****digitalio.get\_bitOpenDrain()**

---

Returns the type of electrical interface of a single bit from the I/O port.

function **get\_bitOpenDrain( )** As Integer

(0 means the bit is an input, 1 an output).

**Parameters :**

**bitno** the bit number; lowest bit has index 0

**Returns :**

0 means the a bit is a regular input/output, 1 means the bit is an open-drain (open-collector) input/output.

On failure, throws an exception or returns a negative error code.



---

**digitalio**→**get\_bitPolarity()**

YDigitalIO

**digitalio**→**bitPolarity()****digitalio.get\_bitPolarity()**

---

Returns the polarity of a single bit from the I/O port (0 means the I/O works in regular mode, 1 means the I/O works in reverse mode).

```
function get_bitPolarity( ) As Integer
```

**Parameters :**

**bitno** the bit number; lowest bit has index 0

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**digitalio**→**get\_bitState()**

**YDigitalIO**

**digitalio**→**bitState()****digitalio.get\_bitState()**

---

Returns the state of a single bit of the I/O port.

```
function get_bitState( ) As Integer
```

**Parameters :**

**bitno** the bit number; lowest bit has index 0

**Returns :**

the bit state (0 or 1)

On failure, throws an exception or returns a negative error code.

---

**digitalio**→**get\_errorMessage()****YDigitalIO****digitalio**→**errorMessage()****digitalio.get\_errorMessage()**

---

Returns the error message of the latest error with the digital IO port.

```
function get_errorMessage( ) As String
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using the digital IO port object

**digitalio**→**get\_errorType()**

**YDigitalIO**

**digitalio**→**errorType()****digitalio.get\_errorType()**

---

Returns the numerical error code of the latest error with the digital IO port.

```
function get_errorType( ) As YRETCODE
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using the digital IO port object

---

**digitalio**→**get\_functionDescriptor()****YDigitalIO****digitalio**→**functionDescriptor()****digitalio.get\_functionDescriptor()**

---

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

```
function get_functionDescriptor( ) As YFUN_DESCR
```

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`.

If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

**digitalio**→**get\_functionId()**

**YDigitalIO**

**digitalio**→**functionId()****digitalio.get\_functionId()**

---

Returns the hardware identifier of the digital IO port, without reference to the module.

function **get\_functionId**( ) As String

For example `relay1`

**Returns :**

a string that identifies the digital IO port (ex: `relay1`)

On failure, throws an exception or returns `Y_FUNCTIONID_INVALID`.

---

**digitalio**→**get\_hardwareId()****YDigitalIO****digitalio**→**hardwareId()****digitalio.get\_hardwareId()**

---

Returns the unique hardware identifier of the digital IO port in the form `SERIAL.FUNCTIONID`.

function **get\_hardwareId()** As String

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the digital IO port (for example `RELAYLO1-123456.relay1`).

**Returns :**

a string that uniquely identifies the digital IO port (ex: `RELAYLO1-123456.relay1`)

On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

**digitalio**→**get\_logicalName()**

**YDigitalIO**

**digitalio**→**logicalName()****digitalio.get\_logicalName()**

---

Returns the logical name of the digital IO port.

function **get\_logicalName**( ) As String

**Returns :**

a string corresponding to the logical name of the digital IO port.

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.



---

**digitalio**→**get\_module()****YDigitalIO****digitalio**→**module()****digitalio.get\_module()**

---

Gets the `YModule` object for the device on which the function is located.

```
function get_module( ) As YModule
```

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

**Returns :**

an instance of `YModule`

**digitalio**→**get\_outputVoltage()**

**YDigitalIO**

**digitalio**→**outputVoltage()**

**digitalio.get\_outputVoltage()**

---

Returns the voltage source used to drive output bits.

```
function get_outputVoltage( ) As Integer
```

**Returns :**

a value among `Y_OUTPUTVOLTAGE_USB_5V`, `Y_OUTPUTVOLTAGE_USB_3V` and `Y_OUTPUTVOLTAGE_EXT_V` corresponding to the voltage source used to drive output bits

On failure, throws an exception or returns `Y_OUTPUTVOLTAGE_INVALID`.

---

**digitalio**→**get\_portDirection()****YDigitalIO****digitalio**→**portDirection()****digitalio.get\_portDirection()**

---

Returns the IO direction of all bits of the port: 0 makes a bit an input, 1 makes it an output.

function **get\_portDirection**( ) As Integer

**Returns :**

an integer corresponding to the IO direction of all bits of the port: 0 makes a bit an input, 1 makes it an output

On failure, throws an exception or returns **Y\_PORTDIRECTION\_INVALID**.

**digitalio**→**get\_portOpenDrain()**

**YDigitalIO**

**digitalio**→**portOpenDrain()**

**digitalio.get\_portOpenDrain()**

---

Returns the electrical interface for each bit of the port.

```
function get_portOpenDrain( ) As Integer
```

For each bit set to 0 the matching I/O works in the regular, intuitive way, for each bit set to 1, the I/O works in reverse mode.

**Returns :**

an integer corresponding to the electrical interface for each bit of the port

On failure, throws an exception or returns Y\_PORTOPENDRAIN\_INVALID.

---

**digitalio**→**get\_portPolarity()****YDigitalIO****digitalio**→**portPolarity()****digitalio.get\_portPolarity()**

---

Returns the polarity of all the bits of the port.

```
function get_portPolarity( ) As Integer
```

For each bit set to 0, the matching I/O works the regular, intuitive way; for each bit set to 1, the I/O works in reverse mode.

**Returns :**

an integer corresponding to the polarity of all the bits of the port

On failure, throws an exception or returns `Y_PORTPOLARITY_INVALID`.

**digitalio**→**get\_portSize()**

**YDigitalIO**

**digitalio**→**portSize()****digitalio.get\_portSize()**

---

Returns the number of bits implemented in the I/O port.

function **get\_portSize**( ) As Integer

**Returns :**

an integer corresponding to the number of bits implemented in the I/O port

On failure, throws an exception or returns `Y_PORTSIZE_INVALID`.

---

**digitalio**→**get\_portState()****YDigitalIO****digitalio**→**portState()****digitalio.get\_portState()**

---

Returns the digital IO port state: bit 0 represents input 0, and so on.

function **get\_portState**( ) As Integer

**Returns :**

an integer corresponding to the digital IO port state: bit 0 represents input 0, and so on

On failure, throws an exception or returns `Y_PORTSTATE_INVALID`.

**digitalio**→**get\_userData()**

**YDigitalIO**

**digitalio**→**userData()****digitalio.get\_userData()**

---

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

function **get\_userData**( ) As Object

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.



---

**digitalio**→**isOnline()****digitalio.isOnline()****YDigitalIO**

---

Checks if the digital IO port is currently reachable, without raising any error.

```
function isOnline( ) As Boolean
```

If there is a cached value for the digital IO port in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the digital IO port.

**Returns :**

`true` if the digital IO port can be reached, and `false` otherwise

**digitalio**→**load()****digitalio.load()****YDigitalIO**

Preloads the digital IO port cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**digitalio**→**nextDigitalIO()****digitalio.nextDigitalIO()****YDigitalIO**

---

Continues the enumeration of digital IO ports started using `yFirstDigitalIO()`.

```
function nextDigitalIO( ) As YDigitalIO
```

**Returns :**

a pointer to a `YDigitalIO` object, corresponding to a digital IO port currently online, or a null pointer if there are no more digital IO ports to enumerate.

**digitalio**→**pulse()****digitalio.pulse()**

YDigitalIO

Triggers a pulse on a single bit for a specified duration.

function **pulse**( ) As Integer

The specified bit will be turned to 1, and then back to 0 after the given duration.

**Parameters :**

**bitno** the bit number; lowest bit has index 0

**ms\_duration** desired pulse duration in milliseconds. Be aware that the device time resolution is not guaranteed up to the millisecond.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**digitalio**→**registerValueCallback()**  
**digitalio.registerValueCallback()**

---

YDigitalIO

Registers the callback function that is invoked on every change of advertised value.

```
function registerValueCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

**digitalio**→**set\_bitDirection()**

YDigitalIO

**digitalio**→**setBitDirection()****digitalio.set\_bitDirection()**

Changes the direction of a single bit from the I/O port.

```
function set_bitDirection( ) As Integer
```

**Parameters :**

**bitno** the bit number; lowest bit has index 0

**bitdirection** direction to set, 0 makes the bit an input, 1 makes it an output. Remember to call the `saveToFlash( )` method to make sure the setting is kept after a reboot.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**digitalio**→**set\_bitOpenDrain()**  
**digitalio**→**setBitOpenDrain()**  
**digitalio.set\_bitOpenDrain()**

**YDigitalIO**

Changes the electrical interface of a single bit from the I/O port.

```
function set_bitOpenDrain( ) As Integer
```

**Parameters :**

**bitno** the bit number; lowest bit has index 0  
**opendrain** 0 makes a bit a regular input/output, 1 makes it an open-drain (open-collector) input/output. Remember to call the `saveToFlash( )` method to make sure the setting is kept after a reboot.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**digitalio**→**set\_bitPolarity()****YDigitalIO****digitalio**→**setBitPolarity()****digitalio.set\_bitPolarity()**

Changes the polarity of a single bit from the I/O port.

```
function set_bitPolarity( ) As Integer
```

**Parameters :**

**bitno** the bit number; lowest bit has index 0.

**bitpolarity** polarity to set, 0 makes the I/O work in regular mode, 1 makes the I/O works in reverse mode. Remember to call the `saveToFlash( )` method to make sure the setting is kept after a reboot.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.



---

**digitalio**→**set\_bitState()**

YDigitalIO

**digitalio**→**setBitState()****digitalio.set\_bitState()**

---

Sets a single bit of the I/O port.

```
function set_bitState( ) As Integer
```

**Parameters :**

**bitno** the bit number; lowest bit has index 0

**bitstate** the state of the bit (1 or 0)

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**digitalio**→**set\_logicalName()****YDigitalIO****digitalio**→**setLogicalName()****digitalio.set\_logicalName()**

Changes the logical name of the digital IO port.

```
function set_logicalName( ByVal newval As String) As Integer
```

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the digital IO port.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**digitalio**→**set\_outputVoltage()**  
**digitalio**→**setOutputVoltage()**  
**digitalio.set\_outputVoltage()**

---

**YDigitalIO**

Changes the voltage source used to drive output bits.

```
function set_outputVoltage( ByVal newval As Integer) As Integer
```

Remember to call the `saveToFlash()` method to make sure the setting is kept after a reboot.

**Parameters :**

**newval** a value among `Y_OUTPUTVOLTAGE_USB_5V`, `Y_OUTPUTVOLTAGE_USB_3V` and `Y_OUTPUTVOLTAGE_EXT_V` corresponding to the voltage source used to drive output bits

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

**digitalio**→**set\_portDirection()**  
**digitalio**→**setPortDirection()**  
**digitalio.set\_portDirection()**

**YDigitalIO**

Changes the IO direction of all bits of the port: 0 makes a bit an input, 1 makes it an output.

```
function set_portDirection( ByVal newval As Integer) As Integer
```

Remember to call the `saveToFlash()` method to make sure the setting is kept after a reboot.

**Parameters :**

**newval** an integer corresponding to the IO direction of all bits of the port: 0 makes a bit an input, 1 makes it an output

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**digitalio**→**set\_portOpenDrain()**  
**digitalio**→**setPortOpenDrain()**  
**digitalio.set\_portOpenDrain()**

**YDigitalIO**

Changes the electrical interface for each bit of the port.

```
function set_portOpenDrain( ByVal newval As Integer) As Integer
```

0 makes a bit a regular input/output, 1 makes it an open-drain (open-collector) input/output. Remember to call the `saveToFlash()` method to make sure the setting is kept after a reboot.

**Parameters :**

**newval** an integer corresponding to the electrical interface for each bit of the port

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**digitalio**→**set\_portPolarity()**

**YDigitalIO**

**digitalio**→**setPortPolarity()****digitalio.set\_portPolarity()**

---

Changes the polarity of all the bits of the port: 0 makes a bit an input, 1 makes it an output.

```
function set_portPolarity( ByVal newval As Integer) As Integer
```

Remember to call the `saveToFlash()` method to make sure the setting will be kept after a reboot.

**Parameters :**

**newval** an integer corresponding to the polarity of all the bits of the port: 0 makes a bit an input, 1 makes it an output

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**digitalio**→**set\_portState()**

YDigitalIO

**digitalio**→**setPortState()****digitalio.set\_portState()**

---

Changes the digital IO port state: bit 0 represents input 0, and so on.

```
function set_portState( ByVal newval As Integer) As Integer
```

This function has no effect on bits configured as input in `portDirection`.

**Parameters :**

**newval** an integer corresponding to the digital IO port state: bit 0 represents input 0, and so on

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**digitalio**→**set\_userData()**

**YDigitalIO**

**digitalio**→**setUserData()****digitalio.set\_userData()**

---

Stores a user context provided as argument in the `userData` attribute of the function.

```
procedure set_userData( ByVal data As Object)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored



---

**digitalio**→**toggle\_bitState()****digitalio.toggle\_bitState()****YDigitalIO**

---

Reverts a single bit of the I/O port.

```
function toggle_bitState( ) As Integer
```

**Parameters :**

**bitno** the bit number; lowest bit has index 0

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

## 3.14. Display function interface

Yoctopuce display interface has been designed to easily show information and images. The device provides built-in multi-layer rendering. Layers can be drawn offline, individually, and freely moved on the display. It can also replay recorded sequences (animations).

In order to use the functions described here, you should include:

js	<script type='text/javascript' src='yocto_display.js'></script>
nodejs	var yoctolib = require('yoctolib'); var YDisplay = yoctolib.YDisplay;
php	require_once('yocto_display.php');
c++	#include "yocto_display.h"
m	#import "yocto_display.h"
pas	uses yocto_display;
vb	yocto_display.vb
cs	yocto_display.cs
java	import com.yoctopuce.YoctoAPI.YDisplay;
py	from yocto_display import *

### Global functions

#### yFindDisplay(func)

Retrieves a display for a given identifier.

#### yFirstDisplay()

Starts the enumeration of displays currently accessible.

### YDisplay methods

#### display→copyLayerContent(srcLayerId, dstLayerId)

Copies the whole content of a layer to another layer.

#### display→describe()

Returns a short text that describes unambiguously the instance of the display in the form TYPE (NAME) =SERIAL . FUNCTIONID.

#### display→fade(brightness, duration)

Smoothly changes the brightness of the screen to produce a fade-in or fade-out effect.

#### display→get\_advertisedValue()

Returns the current value of the display (no more than 6 characters).

#### display→get\_brightness()

Returns the luminosity of the module informative leds (from 0 to 100).

#### display→get\_displayHeight()

Returns the display height, in pixels.

#### display→get\_displayLayer(layerId)

Returns a YDisplayLayer object that can be used to draw on the specified layer.

#### display→get\_displayType()

Returns the display type: monochrome, gray levels or full color.

#### display→get\_displayWidth()

Returns the display width, in pixels.

#### display→get\_enabled()

Returns true if the screen is powered, false otherwise.

#### display→get\_errorMessage()

Returns the error message of the latest error with the display.

**display**→**getErrorType()**

Returns the numerical error code of the latest error with the display.

**display**→**getFriendlyName()**

Returns a global identifier of the display in the format `MODULE_NAME . FUNCTION_NAME`.

**display**→**getFunctionDescriptor()**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

**display**→**getFunctionId()**

Returns the hardware identifier of the display, without reference to the module.

**display**→**getHardwareId()**

Returns the unique hardware identifier of the display in the form `SERIAL . FUNCTIONID`.

**display**→**getLayerCount()**

Returns the number of available layers to draw on.

**display**→**getLayerHeight()**

Returns the height of the layers to draw on, in pixels.

**display**→**getLayerWidth()**

Returns the width of the layers to draw on, in pixels.

**display**→**getLogicalName()**

Returns the logical name of the display.

**display**→**getModule()**

Gets the `YModule` object for the device on which the function is located.

**display**→**getModule\_async(callback, context)**

Gets the `YModule` object for the device on which the function is located (asynchronous version).

**display**→**getOrientation()**

Returns the currently selected display orientation.

**display**→**getStartupSeq()**

Returns the name of the sequence to play when the displayed is powered on.

**display**→**getUserData()**

Returns the value of the `userData` attribute, as previously stored using method `set_userdata`.

**display**→**isOnline()**

Checks if the display is currently reachable, without raising any error.

**display**→**isOnline\_async(callback, context)**

Checks if the display is currently reachable, without raising any error (asynchronous version).

**display**→**load(msValidity)**

Preloads the display cache with a specified validity duration.

**display**→**load\_async(msValidity, callback, context)**

Preloads the display cache with a specified validity duration (asynchronous version).

**display**→**newSequence()**

Starts to record all display commands into a sequence, for later replay.

**display**→**nextDisplay()**

Continues the enumeration of displays started using `yFirstDisplay()`.

**display**→**pauseSequence(delay\_ms)**

Waits for a specified delay (in milliseconds) before playing next commands in current sequence.

**display**→**playSequence(sequenceName)**

Replays a display sequence previously recorded using `newSequence()` and `saveSequence()`.

**display**→**registerValueCallback(callback)**

### 3. Reference

Registers the callback function that is invoked on every change of advertised value.

#### **display→resetAll()**

Clears the display screen and resets all display layers to their default state.

#### **display→saveSequence(sequenceName)**

Stops recording display commands and saves the sequence into the specified file on the display internal memory.

#### **display→set\_brightness(newval)**

Changes the brightness of the display.

#### **display→set\_enabled(newval)**

Changes the power state of the display.

#### **display→set\_logicalName(newval)**

Changes the logical name of the display.

#### **display→set\_orientation(newval)**

Changes the display orientation.

#### **display→set\_startupSeq(newval)**

Changes the name of the sequence to play when the displayed is powered on.

#### **display→set\_userData(data)**

Stores a user context provided as argument in the userData attribute of the function.

#### **display→stopSequence()**

Stops immediately any ongoing sequence replay.

#### **display→swapLayerContent(layerIdA, layerIdB)**

Swaps the whole content of two layers.

#### **display→upload(pathname, content)**

Uploads an arbitrary file (for instance a GIF file) to the display, to the specified full path name.

#### **display→wait\_async(callback, context)**

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.

## YDisplay.FindDisplay() yFindDisplay()yFindDisplay()

YDisplay

Retrieves a display for a given identifier.

```
function yFindDisplay( ByVal func As String) As YDisplay
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the display is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YDisplay.IsOnline()` to test if the display is indeed online at a given time. In case of ambiguity when looking for a display by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

### Parameters :

**func** a string that uniquely characterizes the display

### Returns :

a `YDisplay` object allowing you to drive the display.

## **YDisplay.FirstDisplay() yFirstDisplay()yFirstDisplay()**

---

**YDisplay**

Starts the enumeration of displays currently accessible.

```
function yFirstDisplay( ) As YDisplay
```

Use the method `YDisplay.nextDisplay()` to iterate on next displays.

**Returns :**

a pointer to a `YDisplay` object, corresponding to the first display currently online, or a `null` pointer if there are none.

---

**display**→**copyLayerContent()**  
**display.copyLayerContent()**

---

YDisplay

Copies the whole content of a layer to another layer.

```
function copyLayerContent( ) As Integer
```

The color and transparency of all the pixels from the destination layer are set to match the source pixels. This method only affects the displayed content, but does not change any property of the layer object. Note that layer 0 has no transparency support (it is always completely opaque).

**Parameters :**

**srcLayerId** the identifier of the source layer (a number in range 0..layerCount-1)

**dstLayerId** the identifier of the destination layer (a number in range 0..layerCount-1)

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**display**→**describe()**(**display.describe()**)**YDisplay**

Returns a short text that describes unambiguously the instance of the display in the form `TYPE (NAME) =SERIAL.FUNCTIONID`.

function **describe**( ) As String

More precisely, `TYPE` is the type of the function, `NAME` is the name used for the first access to the function, `SERIAL` is the serial number of the module if the module is connected or "unresolved", and `FUNCTIONID` is the hardware identifier of the function if the module is connected. For example, this method returns `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1` if the module is already connected or `Relay(BadCustomeName.relay1)=unresolved` if the module has not yet been connected. This method does not trigger any USB or TCP transaction and can therefore be used in a debugger.

**Returns :**

a string that describes the display (ex: `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1`)



---

**display**→**fade()****display.fade()****YDisplay**

---

Smoothly changes the brightness of the screen to produce a fade-in or fade-out effect.

```
function fade( ) As Integer
```

**Parameters :**

**brightness** the new screen brightness

**duration** duration of the brightness transition, in milliseconds.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**display**→**get\_advertisedValue()**

**YDisplay**

**display**→**advertisedValue()**

**display.get\_advertisedValue()**

---

Returns the current value of the display (no more than 6 characters).

```
function get_advertisedValue( ) As String
```

**Returns :**

a string corresponding to the current value of the display (no more than 6 characters).

On failure, throws an exception or returns Y\_ADVERTISEDVALUE\_INVALID.

---

**display**→**get\_brightness()****YDisplay****display**→**brightness()****display.get\_brightness()**

---

Returns the luminosity of the module informative leds (from 0 to 100).

function **get\_brightness**( ) As Integer

**Returns :**

an integer corresponding to the luminosity of the module informative leds (from 0 to 100)

On failure, throws an exception or returns `Y_BRIGHTNESS_INVALID`.

**display**→**get\_displayHeight()**

**YDisplay**

**display**→**displayHeight()****display.get\_displayHeight()**

---

Returns the display height, in pixels.

function **get\_displayHeight**( ) As Integer

**Returns :**

an integer corresponding to the display height, in pixels

On failure, throws an exception or returns `Y_DISPLAYHEIGHT_INVALID`.

---

**display**→**get\_displayLayer()****YDisplay****display**→**displayLayer()****display.get\_displayLayer()**

---

Returns a YDisplayLayer object that can be used to draw on the specified layer.

```
function get_displayLayer( ) As YDisplayLayer
```

The content is displayed only when the layer is active on the screen (and not masked by other overlapping layers).

**Parameters :**

**layerId** the identifier of the layer (a number in range 0..layerCount-1)

**Returns :**

an YDisplayLayer object

On failure, throws an exception or returns `null`.

**display**→**get\_displayType()**

**YDisplay**

**display**→**displayType()****display.get\_displayType()**

---

Returns the display type: monochrome, gray levels or full color.

function **get\_displayType( )** As Integer

**Returns :**

a value among `Y_DISPLAYTYPE_MONO`, `Y_DISPLAYTYPE_GRAY` and `Y_DISPLAYTYPE_RGB` corresponding to the display type: monochrome, gray levels or full color

On failure, throws an exception or returns `Y_DISPLAYTYPE_INVALID`.

---

**display**→**get\_displayWidth()****YDisplay****display**→**displayWidth()****display.get\_displayWidth()**

---

Returns the display width, in pixels.

```
function get_displayWidth( ) As Integer
```

**Returns :**

an integer corresponding to the display width, in pixels

On failure, throws an exception or returns `Y_DISPLAYWIDTH_INVALID`.

**display**→**get\_enabled()**

**YDisplay**

**display**→**enabled()****display.get\_enabled()**

---

Returns true if the screen is powered, false otherwise.

function **get\_enabled**( ) As Integer

**Returns :**

either `Y_ENABLED_FALSE` or `Y_ENABLED_TRUE`, according to true if the screen is powered, false otherwise

On failure, throws an exception or returns `Y_ENABLED_INVALID`.



---

**display**→**get\_errorMessage()****YDisplay****display**→**errorMessage()****display.errorMessage()**

---

Returns the error message of the latest error with the display.

```
function get_errorMessage( ) As String
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using the display object

**display**→**get\_errorType()**

**YDisplay**

**display**→**errorType()****display.get\_errorType()**

---

Returns the numerical error code of the latest error with the display.

```
function get_errorType( ) As YRETCODE
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using the display object

---

**display**→**get\_functionDescriptor()**  
**display**→**functionDescriptor()**  
**display.get\_functionDescriptor()**

---

**YDisplay**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

function **get\_functionDescriptor**( ) As `YFUN_DESCR`

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`.

If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

**display**→**get\_functionId()**

**YDisplay**

**display**→**functionId()****display.get\_functionId()**

---

Returns the hardware identifier of the display, without reference to the module.

function **get\_functionId**( ) As String

For example `relay1`

**Returns :**

a string that identifies the display (ex: `relay1`)

On failure, throws an exception or returns `Y_FUNCTIONID_INVALID`.

---

**display**→**get\_hardwareId()****YDisplay****display**→**hardwareId()****display.get\_hardwareId()**

---

Returns the unique hardware identifier of the display in the form `SERIAL.FUNCTIONID`.

function **get\_hardwareId()** As String

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the display (for example `RELAYLO1-123456.relay1`).

**Returns :**

a string that uniquely identifies the display (ex: `RELAYLO1-123456.relay1`)

On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

**display**→**get\_layerCount()**

**YDisplay**

**display**→**layerCount()****display.get\_layerCount()**

---

Returns the number of available layers to draw on.

function **get\_layerCount**( ) As Integer

**Returns :**

an integer corresponding to the number of available layers to draw on

On failure, throws an exception or returns `Y_LAYERCOUNT_INVALID`.

---

**display**→**get\_layerHeight()****YDisplay****display**→**layerHeight()****display.get\_layerHeight()**

---

Returns the height of the layers to draw on, in pixels.

function **get\_layerHeight**( ) As Integer

**Returns :**

an integer corresponding to the height of the layers to draw on, in pixels

On failure, throws an exception or returns `Y_LAYERHEIGHT_INVALID`.

**display**→**get\_layerWidth()**

**YDisplay**

**display**→**layerWidth()****display.get\_layerWidth()**

---

Returns the width of the layers to draw on, in pixels.

function **get\_layerWidth**( ) As Integer

**Returns :**

an integer corresponding to the width of the layers to draw on, in pixels

On failure, throws an exception or returns `Y_LAYERWIDTH_INVALID`.



---

**display**→**get\_logicalName()****YDisplay****display**→**logicalName()****display.get\_logicalName()**

---

Returns the logical name of the display.

function **get\_logicalName**( ) As String

**Returns :**

a string corresponding to the logical name of the display.

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

**display**→**get\_module()**

**YDisplay**

**display**→**module()****display.get\_module()**

---

Gets the YModule object for the device on which the function is located.

function **get\_module()** As YModule

If the function cannot be located on any module, the returned instance of YModule is not shown as on-line.

**Returns :**

an instance of YModule

---

**display**→**get\_orientation()****YDisplay****display**→**orientation()****display.get\_orientation()**

---

Returns the currently selected display orientation.

function **get\_orientation**( ) As Integer

**Returns :**

a value among `Y_ORIENTATION_LEFT`, `Y_ORIENTATION_UP`, `Y_ORIENTATION_RIGHT` and `Y_ORIENTATION_DOWN` corresponding to the currently selected display orientation

On failure, throws an exception or returns `Y_ORIENTATION_INVALID`.

**display**→**get\_startupSeq()**

**YDisplay**

**display**→**startupSeq()****display.get\_startupSeq()**

---

Returns the name of the sequence to play when the displayed is powered on.

```
function get_startupSeq( ) As String
```

**Returns :**

a string corresponding to the name of the sequence to play when the displayed is powered on

On failure, throws an exception or returns `Y_STARTUPSEQ_INVALID`.

---

**display**→**get\_userData()****YDisplay****display**→**userData()****display.get\_userData()**

---

Returns the value of the userData attribute, as previously stored using method `set_userData`.

```
function get_userData( ) As Object
```

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

## display→isOnline()display.isOnline()

YDisplay

---

Checks if the display is currently reachable, without raising any error.

```
function isOnline( ) As Boolean
```

If there is a cached value for the display in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the display.

**Returns :**

true if the display can be reached, and false otherwise

**display**→**load()****display.load()****YDisplay**

Preloads the display cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

## display→newSequence()display.newSequence()

YDisplay

---

Starts to record all display commands into a sequence, for later replay.

```
function newSequence( ) As Integer
```

The name used to store the sequence is specified when calling `saveSequence()`, once the recording is complete.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.



---

**display**→**nextDisplay()****display.nextDisplay()****YDisplay**

---

Continues the enumeration of displays started using `yFirstDisplay()`.

```
function nextDisplay( ) As YDisplay
```

**Returns :**

a pointer to a `YDisplay` object, corresponding to a display currently online, or a `null` pointer if there are no more displays to enumerate.

## **display→pauseSequence()display.pauseSequence()**

**YDisplay**

Waits for a specified delay (in milliseconds) before playing next commands in current sequence.

```
function pauseSequence( ) As Integer
```

This method can be used while recording a display sequence, to insert a timed wait in the sequence (without any immediate effect). It can also be used dynamically while playing a pre-recorded sequence, to suspend or resume the execution of the sequence. To cancel a delay, call the same method with a zero delay.

**Parameters :**

**delay\_ms** the duration to wait, in milliseconds

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**display**→**playSequence()****display.playSequence()****YDisplay**

---

Replays a display sequence previously recorded using `newSequence()` and `saveSequence()`.

```
function playSequence( ) As Integer
```

**Parameters :**

**sequenceName** the name of the newly created sequence

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**display**→**registerValueCallback()**  
**display.registerValueCallback()**

YDisplay

Registers the callback function that is invoked on every change of advertised value.

```
function registerValueCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

---

**display→resetAll()display.resetAll()**

---

**YDisplay**

Clears the display screen and resets all display layers to their default state.

```
function resetAll( ) As Integer
```

Using this function in a sequence will kill the sequence play-back. Don't use that function to reset the display at sequence start-up.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

## **display**→**saveSequence()****display.saveSequence()**

**YDisplay**

Stops recording display commands and saves the sequence into the specified file on the display internal memory.

```
function saveSequence( ) As Integer
```

The sequence can be later replayed using `playSequence( )`.

**Parameters :**

**sequenceName** the name of the newly created sequence

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**display**→**set\_brightness()****YDisplay****display**→**setBrightness()****display.set\_brightness()**

---

Changes the brightness of the display.

```
function set_brightness( ByVal newval As Integer) As Integer
```

The parameter is a value between 0 and 100. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** an integer corresponding to the brightness of the display

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**display**→**set\_enabled()**

**YDisplay**

**display**→**setEnabled()****display.set\_enabled()**

---

Changes the power state of the display.

```
function set_enabled( ByVal newval As Integer) As Integer
```

**Parameters :**

**newval** either Y\_ENABLED\_FALSE or Y\_ENABLED\_TRUE, according to the power state of the display

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.



---

**display**→**set\_logicalName()****YDisplay****display**→**setLogicalName()****display.set\_logicalName()**

---

Changes the logical name of the display.

```
function set_logicalName( ByVal newval As String) As Integer
```

You can use `yCheckLogicalName( )` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash( )` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the display.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**display**→**set\_orientation()**

**YDisplay**

**display**→**setOrientation()****display.set\_orientation()**

---

Changes the display orientation.

```
function set_orientation( ByVal newval As Integer) As Integer
```

Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a value among `Y_ORIENTATION_LEFT`, `Y_ORIENTATION_UP`, `Y_ORIENTATION_RIGHT` and `Y_ORIENTATION_DOWN` corresponding to the display orientation

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**display**→**set\_startupSeq()****YDisplay****display**→**setStartupSeq()****display.set\_startupSeq()**

---

Changes the name of the sequence to play when the displayed is powered on.

```
function set_startupSeq( ByVal newval As String) As Integer
```

Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the name of the sequence to play when the displayed is powered on

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**display**→**set\_userData()**

**YDisplay**

**display**→**setUserData()****display.set\_userData()**

---

Stores a user context provided as argument in the `userData` attribute of the function.

```
procedure set_userData( ByVal data As Object)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

---

**display**→**stopSequence()****display.stopSequence()****YDisplay**

---

Stops immediately any ongoing sequence replay.

```
function stopSequence( ) As Integer
```

The display is left as is.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**display**→**swapLayerContent()**  
**display.swapLayerContent()**

YDisplay

Swaps the whole content of two layers.

```
function swapLayerContent( ) As Integer
```

The color and transparency of all the pixels from the two layers are swapped. This method only affects the displayed content, but does not change any property of the layer objects. In particular, the visibility of each layer stays unchanged. When used between one hidden layer and a visible layer, this method makes it possible to easily implement double-buffering. Note that layer 0 has no transparency support (it is always completely opaque).

**Parameters :**

**layerIdA** the first layer (a number in range 0..layerCount-1)

**layerIdB** the second layer (a number in range 0..layerCount-1)

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**display**→**upload()****display.upload()****YDisplay**

---

Uploads an arbitrary file (for instance a GIF file) to the display, to the specified full path name.

procedure **upload()**

If a file already exists with the same path name, its content is overwritten.

**Parameters :**

**pathname** path and name of the new file to create

**content** binary buffer with the content to set

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

## 3.15. DisplayLayer object interface

A DisplayLayer is an image layer containing objects to display (bitmaps, text, etc.). The content is displayed only when the layer is active on the screen (and not masked by other overlapping layers).

In order to use the functions described here, you should include:

js	<script type='text/javascript' src='yocto_display.js'></script>
nodejs	var yoctolib = require('yoctolib'); var YDisplay = yoctolib.YDisplay;
php	require_once('yocto_display.php');
c++	#include "yocto_display.h"
m	#import "yocto_display.h"
pas	uses yocto_display;
vb	yocto_display.vb
cs	yocto_display.cs
java	import com.yoctopuce.YoctoAPI.YDisplay;
py	from yocto_display import *

### YDisplayLayer methods

#### displaylayer→clear()

Erases the whole content of the layer (makes it fully transparent).

#### displaylayer→clearConsole()

Blanks the console area within console margins, and resets the console pointer to the upper left corner of the console.

#### displaylayer→consoleOut(text)

Outputs a message in the console area, and advances the console pointer accordingly.

#### displaylayer→drawBar(x1, y1, x2, y2)

Draws a filled rectangular bar at a specified position.

#### displaylayer→drawBitmap(x, y, w, bitmap, bgcolor)

Draws a bitmap at the specified position.

#### displaylayer→drawCircle(x, y, r)

Draws an empty circle at a specified position.

#### displaylayer→drawDisc(x, y, r)

Draws a filled disc at a given position.

#### displaylayer→drawImage(x, y, imagename)

Draws a GIF image at the specified position.

#### displaylayer→drawPixel(x, y)

Draws a single pixel at the specified position.

#### displaylayer→drawRect(x1, y1, x2, y2)

Draws an empty rectangle at a specified position.

#### displaylayer→drawText(x, y, anchor, text)

Draws a text string at the specified position.

#### displaylayer→get\_display()

Gets parent YDisplay.

#### displaylayer→get\_displayHeight()

Returns the display height, in pixels.

#### displaylayer→get\_displayWidth()

Returns the display width, in pixels.



**displaylayer→get\_layerHeight()**

Returns the height of the layers to draw on, in pixels.

**displaylayer→get\_layerWidth()**

Returns the width of the layers to draw on, in pixels.

**displaylayer→hide()**

Hides the layer.

**displaylayer→lineTo(x, y)**

Draws a line from current drawing pointer position to the specified position.

**displaylayer→moveTo(x, y)**

Moves the drawing pointer of this layer to the specified position.

**displaylayer→reset()**

Reverts the layer to its initial state (fully transparent, default settings).

**displaylayer→selectColorPen(color)**

Selects the pen color for all subsequent drawing functions, including text drawing.

**displaylayer→selectEraser()**

Selects an eraser instead of a pen for all subsequent drawing functions, except for bitmap copy functions.

**displaylayer→selectFont(fontname)**

Selects a font to use for the next text drawing functions, by providing the name of the font file.

**displaylayer→selectGrayPen(graylevel)**

Selects the pen gray level for all subsequent drawing functions, including text drawing.

**displaylayer→setAntialiasingMode(mode)**

Enables or disables anti-aliasing for drawing oblique lines and circles.

**displaylayer→setConsoleBackground(bgcol)**

Sets up the background color used by the `clearConsole` function and by the console scrolling feature.

**displaylayer→setConsoleMargins(x1, y1, x2, y2)**

Sets up display margins for the `consoleOut` function.

**displaylayer→setConsoleWordWrap(wordwrap)**

Sets up the wrapping behaviour used by the `consoleOut` function.

**displaylayer→setLayerPosition(x, y, scrollTime)**

Sets the position of the layer relative to the display upper left corner.

**displaylayer→unhide()**

Shows the layer.

## displaylayer→clear()displaylayer.clear()

YDisplayLayer

---

Erases the whole content of the layer (makes it fully transparent).

```
function clear( ) As Integer
```

This method does not change any other attribute of the layer. To reinitialize the layer attributes to defaults settings, use the method `reset( )` instead.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**displaylayer→clearConsole()**  
**displaylayer.clearConsole()**

---

**YDisplayLayer**

Blanks the console area within console margins, and resets the console pointer to the upper left corner of the console.

```
function clearConsole( ) As Integer
```

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**displaylayer→consoleOut()displaylayer.consoleOut()**

**YDisplayLayer**

---

Outputs a message in the console area, and advances the console pointer accordingly.

function **consoleOut**( ) As Integer

The console pointer position is automatically moved to the beginning of the next line when a newline character is met, or when the right margin is hit. When the new text to display extends below the lower margin, the console area is automatically scrolled up.

**Parameters :**

**text** the message to display

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**displaylayer→drawBar()displaylayer.drawBar()****YDisplayLayer**

Draws a filled rectangular bar at a specified position.

```
function drawBar( ) As Integer
```

**Parameters :**

- x1** the distance from left of layer to the left border of the rectangle, in pixels
- y1** the distance from top of layer to the top border of the rectangle, in pixels
- x2** the distance from left of layer to the right border of the rectangle, in pixels
- y2** the distance from top of layer to the bottom border of the rectangle, in pixels

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**displaylayer→drawBitmap()  
displaylayer.drawBitmap()****YDisplayLayer**

Draws a bitmap at the specified position.

**procedure drawBitmap( )**

The bitmap is provided as a binary object, where each pixel maps to a bit, from left to right and from top to bottom. The most significant bit of each byte maps to the leftmost pixel, and the least significant bit maps to the rightmost pixel. Bits set to 1 are drawn using the layer selected pen color. Bits set to 0 are drawn using the specified background gray level, unless -1 is specified, in which case they are not drawn at all (as if transparent).

**Parameters :**

- x** the distance from left of layer to the left of the bitmap, in pixels
- y** the distance from top of layer to the top of the bitmap, in pixels
- w** the width of the bitmap, in pixels
- bitmap** a binary object
- bgcol** the background gray level to use for zero bits (0 = black, 255 = white), or -1 to leave the pixels unchanged

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**displaylayer**→**drawCircle()****displaylayer.drawCircle()****YDisplayLayer**

---

Draws an empty circle at a specified position.

```
function drawCircle( ) As Integer
```

**Parameters :**

- x** the distance from left of layer to the center of the circle, in pixels
- y** the distance from top of layer to the center of the circle, in pixels
- r** the radius of the circle, in pixels

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**displaylayer→drawDisc()displaylayer.drawDisc()**

**YDisplayLayer**

Draws a filled disc at a given position.

```
function drawDisc( ) As Integer
```

**Parameters :**

- x** the distance from left of layer to the center of the disc, in pixels
- y** the distance from top of layer to the center of the disc, in pixels
- r** the radius of the disc, in pixels

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.



**displaylayer→drawImage()displaylayer.drawImage()****YDisplayLayer**

Draws a GIF image at the specified position.

```
function drawImage( ) As Integer
```

The GIF image must have been previously uploaded to the device built-in memory. If you experience problems using an image file, check the device logs for any error message such as missing image file or bad image file format.

**Parameters :**

- x** the distance from left of layer to the left of the image, in pixels
- y** the distance from top of layer to the top of the image, in pixels
- imagename** the GIF file name

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**displaylayer**→**drawPixel()****displaylayer.drawPixel()**

---

**YDisplayLayer**

Draws a single pixel at the specified position.

function **drawPixel**( ) As Integer

**Parameters :**

- x** the distance from left of layer, in pixels
- y** the distance from top of layer, in pixels

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**displaylayer→drawRect()displaylayer.drawRect()**

---

**YDisplayLayer**

Draws an empty rectangle at a specified position.

```
function drawRect( ) As Integer
```

**Parameters :**

- x1** the distance from left of layer to the left border of the rectangle, in pixels
- y1** the distance from top of layer to the top border of the rectangle, in pixels
- x2** the distance from left of layer to the right border of the rectangle, in pixels
- y2** the distance from top of layer to the bottom border of the rectangle, in pixels

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**displaylayer**→**drawText()****displaylayer.drawText()****YDisplayLayer**

Draws a text string at the specified position.

```
function drawText( ) As Integer
```

The point of the text that is aligned to the specified pixel position is called the anchor point, and can be chosen among several options. Text is rendered from left to right, without implicit wrapping.

**Parameters :**

- x** the distance from left of layer to the text anchor point, in pixels
- y** the distance from top of layer to the text anchor point, in pixels
- anchor** the text anchor point, chosen among the Y\_ALIGN enumeration: Y\_ALIGN\_TOP\_LEFT, Y\_ALIGN\_CENTER\_LEFT, Y\_ALIGN\_BASELINE\_LEFT, Y\_ALIGN\_BOTTOM\_LEFT, Y\_ALIGN\_TOP\_CENTER, Y\_ALIGN\_CENTER, Y\_ALIGN\_BASELINE\_CENTER, Y\_ALIGN\_BOTTOM\_CENTER, Y\_ALIGN\_TOP\_DECIMAL, Y\_ALIGN\_CENTER\_DECIMAL, Y\_ALIGN\_BASELINE\_DECIMAL, Y\_ALIGN\_BOTTOM\_DECIMAL, Y\_ALIGN\_TOP\_RIGHT, Y\_ALIGN\_CENTER\_RIGHT, Y\_ALIGN\_BASELINE\_RIGHT, Y\_ALIGN\_BOTTOM\_RIGHT.
- text** the text string to draw

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**displaylayer**→**get\_display()****YDisplayLayer****displaylayer**→**display()****displaylayer.get\_display()**

---

Gets parent YDisplay.

```
function get_display( ) As YDisplay
```

Returns the parent YDisplay object of the current YDisplayLayer.

**Returns :**

an YDisplay object

**displaylayer→get\_displayHeight()**

**YDisplayLayer**

**displaylayer→displayHeight()**

**displaylayer.get\_displayHeight()**

---

Returns the display height, in pixels.

```
function get_displayHeight( ) As Integer
```

**Returns :**

an integer corresponding to the display height, in pixels On failure, throws an exception or returns Y\_DISPLAYHEIGHT\_INVALID.

---

**displaylayer**→**get\_displayWidth()****YDisplayLayer****displaylayer**→**displayWidth()****displaylayer.get\_displayWidth()**

---

Returns the display width, in pixels.

```
function get_displayWidth( ) As Integer
```

**Returns :**

an integer corresponding to the display width, in pixels On failure, throws an exception or returns Y\_DISPLAYWIDTH\_INVALID.

**displaylayer→get\_layerHeight()**

**YDisplayLayer**

**displaylayer→layerHeight()**

**displaylayer.get\_layerHeight()**

---

Returns the height of the layers to draw on, in pixels.

```
function get_layerHeight( ) As Integer
```

**Returns :**

an integer corresponding to the height of the layers to draw on, in pixels

On failure, throws an exception or returns Y\_LAYERHEIGHT\_INVALID.



---

**displaylayer**→**get\_layerWidth()****YDisplayLayer****displaylayer**→**layerWidth()****displaylayer.get\_layerWidth()**

---

Returns the width of the layers to draw on, in pixels.

```
function get_layerWidth( ) As Integer
```

**Returns :**

an integer corresponding to the width of the layers to draw on, in pixels

On failure, throws an exception or returns Y\_LAYERWIDTH\_INVALID.

## displaylayer→hide()displaylayer.hide()

YDisplayLayer

---

Hides the layer.

```
function hide( ) As Integer
```

The state of the layer is perserved but the layer is not displayed on the screen until the next call to `unhide()`. Hiding the layer can positively affect the drawing speed, since it postpones the rendering until all operations are completed (double-buffering).

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**displaylayer**→**lineTo()**(displaylayer.lineTo())**YDisplayLayer**

---

Draws a line from current drawing pointer position to the specified position.

```
function lineTo( ) As Integer
```

The specified destination pixel is included in the line. The pointer position is then moved to the end point of the line.

**Parameters :**

- x** the distance from left of layer to the end point of the line, in pixels
- y** the distance from top of layer to the end point of the line, in pixels

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**displaylayer→moveTo()displaylayer.moveTo()**

**YDisplayLayer**

---

Moves the drawing pointer of this layer to the specified position.

```
function moveTo( ) As Integer
```

**Parameters :**

**x** the distance from left of layer, in pixels

**y** the distance from top of layer, in pixels

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**displaylayer**→**reset()****displaylayer.reset()****YDisplayLayer**

Reverts the layer to its initial state (fully transparent, default settings).

```
function reset( ) As Integer
```

Reinitializes the drawing pointer to the upper left position, and selects the most visible pen color. If you only want to erase the layer content, use the method `clear()` instead.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**displaylayer→selectColorPen()  
displaylayer.selectColorPen()****YDisplayLayer**

Selects the pen color for all subsequent drawing functions, including text drawing.

function **selectColorPen**( ) As Integer

The pen color is provided as an RGB value. For grayscale or monochrome displays, the value is automatically converted to the proper range.

**Parameters :**

**color** the desired pen color, as a 24-bit RGB value

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**displaylayer**→**selectEraser()**  
**displaylayer.selectEraser()****YDisplayLayer**

---

Selects an eraser instead of a pen for all subsequent drawing functions, except for bitmap copy functions.

```
function selectEraser( ) As Integer
```

Any point drawn using the eraser becomes transparent (as when the layer is empty), showing the other layers beneath it.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**displaylayer**→**selectFont()****displaylayer.selectFont()****YDisplayLayer**

Selects a font to use for the next text drawing functions, by providing the name of the font file.

```
function selectFont( ) As Integer
```

You can use a built-in font as well as a font file that you have previously uploaded to the device built-in memory. If you experience problems selecting a font file, check the device logs for any error message such as missing font file or bad font file format.

**Parameters :**

**fontname** the font file name

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.



---

**displaylayer**→**selectGrayPen()**  
**displaylayer.selectGrayPen()**

---

**YDisplayLayer**

Selects the pen gray level for all subsequent drawing functions, including text drawing.

function **selectGrayPen**( ) As Integer

The gray level is provided as a number between 0 (black) and 255 (white, or whichever the highest color is). For monochrome displays (without gray levels), any value lower than 128 is rendered as black, and any value equal or above to 128 is non-black.

**Parameters :**

**graylevel** the desired gray level, from 0 to 255

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**displaylayer→setAntialiasingMode()  
displaylayer.setAntialiasingMode()**

YDisplayLayer

Enables or disables anti-aliasing for drawing oblique lines and circles.

```
function setAntialiasingMode( ) As Integer
```

Anti-aliasing provides a smoother aspect when looked from far enough, but it can add fuzzyness when the display is looked from very close. At the end of the day, it is your personal choice. Anti-aliasing is enabled by default on grayscale and color displays, but you can disable it if you prefer. This setting has no effect on monochrome displays.

**Parameters :**

**mode** true to enable antialiasing, false to disable it.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**displaylayer**→**setConsoleBackground()**  
**displaylayer.setConsoleBackground()**

---

**YDisplayLayer**

Sets up the background color used by the `clearConsole` function and by the console scrolling feature.

```
function setConsoleBackground( ) As Integer
```

**Parameters :**

**bgcol** the background gray level to use when scrolling (0 = black, 255 = white), or -1 for transparent

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**displaylayer→setConsoleMargins()  
displaylayer.setConsoleMargins()**

YDisplayLayer

Sets up display margins for the `consoleOut` function.

```
function setConsoleMargins( ) As Integer
```

**Parameters :**

- x1** the distance from left of layer to the left margin, in pixels
- y1** the distance from top of layer to the top margin, in pixels
- x2** the distance from left of layer to the right margin, in pixels
- y2** the distance from top of layer to the bottom margin, in pixels

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**displaylayer**→**setConsoleWordWrap()**  
**displaylayer.setConsoleWordWrap()**

---

**YDisplayLayer**

Sets up the wrapping behaviour used by the `consoleOut` function.

```
function setConsoleWordWrap( ) As Integer
```

**Parameters :**

**wordwrap** `true` to wrap only between words, `false` to wrap on the last column anyway.

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

**displaylayer→setLayerPosition()  
displaylayer.setLayerPosition()**

YDisplayLayer

Sets the position of the layer relative to the display upper left corner.

```
function setLayerPosition( ) As Integer
```

When smooth scrolling is used, the display offset of the layer is automatically updated during the next milliseconds to animate the move of the layer.

**Parameters :**

- x** the distance from left of display to the upper left corner of the layer
- y** the distance from top of display to the upper left corner of the layer
- scrollTime** number of milliseconds to use for smooth scrolling, or 0 if the scrolling should be immediate.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**displaylayer**→**unhide()**displaylayer.unhide()**YDisplayLayer**

---

Shows the layer.

```
function unhide( ) As Integer
```

Shows the layer again after a hide command.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

## 3.16. External power supply control interface

Yoctopuce application programming interface allows you to control the power source to use for module functions that require high current. The module can also automatically disconnect the external power when a voltage drop is observed on the external power source (external battery running out of power).

In order to use the functions described here, you should include:

js	<script type='text/javascript' src='yocto_dualpower.js'></script>
nodejs	var yoctolib = require('yoctolib'); var YDualPower = yoctolib.YDualPower;
php	require_once('yocto_dualpower.php');
c++	#include "yocto_dualpower.h"
m	#import "yocto_dualpower.h"
pas	uses yocto_dualpower;
vb	yocto_dualpower.vb
cs	yocto_dualpower.cs
java	import com.yoctopuce.YoctoAPI.YDualPower;
py	from yocto_dualpower import *

### Global functions

#### yFindDualPower(func)

Retrieves a dual power control for a given identifier.

#### yFirstDualPower()

Starts the enumeration of dual power controls currently accessible.

### YDualPower methods

#### dualpower→describe()

Returns a short text that describes unambiguously the instance of the power control in the form `TYPE ( NAME ) = SERIAL . FUNCTIONID`.

#### dualpower→get\_advertisedValue()

Returns the current value of the power control (no more than 6 characters).

#### dualpower→get\_errorMessage()

Returns the error message of the latest error with the power control.

#### dualpower→get\_errorType()

Returns the numerical error code of the latest error with the power control.

#### dualpower→get\_extVoltage()

Returns the measured voltage on the external power source, in millivolts.

#### dualpower→get\_friendlyName()

Returns a global identifier of the power control in the format `MODULE_NAME . FUNCTION_NAME`.

#### dualpower→get\_functionDescriptor()

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

#### dualpower→get\_functionId()

Returns the hardware identifier of the power control, without reference to the module.

#### dualpower→get\_hardwareId()

Returns the unique hardware identifier of the power control in the form `SERIAL . FUNCTIONID`.

#### dualpower→get\_logicalName()

Returns the logical name of the power control.

#### dualpower→get\_module()



Gets the `YModule` object for the device on which the function is located.

**`dualpower→get_module_async(callback, context)`**

Gets the `YModule` object for the device on which the function is located (asynchronous version).

**`dualpower→get_powerControl()`**

Returns the selected power source for module functions that require lots of current.

**`dualpower→get_powerState()`**

Returns the current power source for module functions that require lots of current.

**`dualpower→get_userData()`**

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

**`dualpower→isOnline()`**

Checks if the power control is currently reachable, without raising any error.

**`dualpower→isOnline_async(callback, context)`**

Checks if the power control is currently reachable, without raising any error (asynchronous version).

**`dualpower→load(msValidity)`**

Preloads the power control cache with a specified validity duration.

**`dualpower→load_async(msValidity, callback, context)`**

Preloads the power control cache with a specified validity duration (asynchronous version).

**`dualpower→nextDualPower()`**

Continues the enumeration of dual power controls started using `yFirstDualPower()`.

**`dualpower→registerValueCallback(callback)`**

Registers the callback function that is invoked on every change of advertised value.

**`dualpower→set_logicalName(newval)`**

Changes the logical name of the power control.

**`dualpower→set_powerControl(newval)`**

Changes the selected power source for module functions that require lots of current.

**`dualpower→set_userData(data)`**

Stores a user context provided as argument in the `userData` attribute of the function.

**`dualpower→wait_async(callback, context)`**

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.

## YDualPower.FindDualPower() yFindDualPower()yFindDualPower()

YDualPower

Retrieves a dual power control for a given identifier.

```
function yFindDualPower( ByVal func As String) As YDualPower
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the power control is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YDualPower.IsOnline()` to test if the power control is indeed online at a given time. In case of ambiguity when looking for a dual power control by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

### Parameters :

**func** a string that uniquely characterizes the power control

### Returns :

a `YDualPower` object allowing you to drive the power control.

---

**YDualPower.FirstDualPower()  
yFirstDualPower()yFirstDualPower()**

---

**YDualPower**

Starts the enumeration of dual power controls currently accessible.

```
function yFirstDualPower( ) As YDualPower
```

Use the method `YDualPower.nextDualPower()` to iterate on next dual power controls.

**Returns :**

a pointer to a `YDualPower` object, corresponding to the first dual power control currently online, or a `null` pointer if there are none.

**dualpower**→**describe()****dualpower.describe()****YDualPower**

Returns a short text that describes unambiguously the instance of the power control in the form `TYPE (NAME) =SERIAL . FUNCTIONID`.

function **describe**( ) As String

More precisely, `TYPE` is the type of the function, `NAME` it the name used for the first access to the function, `SERIAL` is the serial number of the module if the module is connected or "unresolved", and `FUNCTIONID` is the hardware identifier of the function if the module is connected. For example, this method returns `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1` if the module is already connected or `Relay(BadCustomeName.relay1)=unresolved` if the module has not yet been connected. This method does not trigger any USB or TCP transaction and can therefore be used in a debugger.

**Returns :**

a string that describes the power control (ex: `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1`)

---

**dualpower**→**get\_advertisedValue()****YDualPower****dualpower**→**advertisedValue()****dualpower.get\_advertisedValue()**

---

Returns the current value of the power control (no more than 6 characters).

```
function get_advertisedValue( ) As String
```

**Returns :**

a string corresponding to the current value of the power control (no more than 6 characters).

On failure, throws an exception or returns Y\_ADVERTISEDVALUE\_INVALID.

**dualpower**→**get\_errorMessage()**

**YDualPower**

**dualpower**→**errorMessage()**

**dualpower.get\_errorMessage()**

---

Returns the error message of the latest error with the power control.

```
function get_errorMessage( ) As String
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using the power control object

---

**dualpower**→**get\_errorType()****YDualPower****dualpower**→**errorType()****dualpower.get\_errorType()**

---

Returns the numerical error code of the latest error with the power control.

```
function get_errorType( ) As YRETCODE
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using the power control object

**dualpower**→**get\_extVoltage()**

**YDualPower**

**dualpower**→**extVoltage()****dualpower.get\_extVoltage()**

---

Returns the measured voltage on the external power source, in millivolts.

function **get\_extVoltage**( ) As Integer

**Returns :**

an integer corresponding to the measured voltage on the external power source, in millivolts

On failure, throws an exception or returns `Y_EXTVOLTAGE_INVALID`.



---

**dualpower**→**get\_functionDescriptor()****YDualPower****dualpower**→**functionDescriptor()****dualpower.get\_functionDescriptor()**

---

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

function **get\_functionDescriptor**( ) As `YFUN_DESCR`

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`.

If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

**dualpower**→**get\_functionId()**

**YDualPower**

**dualpower**→**functionId()****dualpower.get\_functionId()**

---

Returns the hardware identifier of the power control, without reference to the module.

function **get\_functionId**( ) As String

For example `relay1`

**Returns :**

a string that identifies the power control (ex: `relay1`)

On failure, throws an exception or returns `Y_FUNCTIONID_INVALID`.

---

**dualpower**→**get\_hardwareId()****YDualPower****dualpower**→**hardwareId()****dualpower.get\_hardwareId()**

---

Returns the unique hardware identifier of the power control in the form `SERIAL.FUNCTIONID`.

function **get\_hardwareId()** As String

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the power control (for example `RELAYLO1-123456.relay1`).

**Returns :**

a string that uniquely identifies the power control (ex: `RELAYLO1-123456.relay1`)

On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

**dualpower**→**get\_logicalName()**

**YDualPower**

**dualpower**→**logicalName()**

**dualpower.get\_logicalName()**

---

Returns the logical name of the power control.

```
function get_logicalName( ) As String
```

**Returns :**

a string corresponding to the logical name of the power control.

On failure, throws an exception or returns Y\_LOGICALNAME\_INVALID.

---

**dualpower**→**get\_module()****YDualPower****dualpower**→**module()****dualpower.get\_module()**

---

Gets the `YModule` object for the device on which the function is located.

```
function get_module( ) As YModule
```

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

**Returns :**

an instance of `YModule`

**dualpower**→**get\_powerControl()**

**YDualPower**

**dualpower**→**powerControl()**

**dualpower.get\_powerControl()**

---

Returns the selected power source for module functions that require lots of current.

function **get\_powerControl**( ) As Integer

**Returns :**

a value among Y\_POWERCONTROL\_AUTO, Y\_POWERCONTROL\_FROM\_USB, Y\_POWERCONTROL\_FROM\_EXT and Y\_POWERCONTROL\_OFF corresponding to the selected power source for module functions that require lots of current

On failure, throws an exception or returns Y\_POWERCONTROL\_INVALID.

---

**dualpower**→**get\_powerState()****YDualPower****dualpower**→**powerState()****dualpower.get\_powerState()**

---

Returns the current power source for module functions that require lots of current.

```
function get_powerState( ) As Integer
```

**Returns :**

a value among `Y_POWERSTATE_OFF`, `Y_POWERSTATE_FROM_USB` and `Y_POWERSTATE_FROM_EXT` corresponding to the current power source for module functions that require lots of current

On failure, throws an exception or returns `Y_POWERSTATE_INVALID`.

**dualpower**→**get\_userData()**

**YDualPower**

**dualpower**→**userData()****dualpower.get\_userData()**

---

Returns the value of the userData attribute, as previously stored using method `set_userData`.

function **get\_userData**( ) As Object

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.



---

**dualpower**→**isOnline()****dualpower.isOnline()****YDualPower**

---

Checks if the power control is currently reachable, without raising any error.

```
function isOnline( ) As Boolean
```

If there is a cached value for the power control in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the power control.

**Returns :**

`true` if the power control can be reached, and `false` otherwise

**dualpower**→**load()****dualpower.load()****YDualPower**

Preloads the power control cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**dualpower**→**nextDualPower()**  
**dualpower.nextDualPower()**

---

**YDualPower**

Continues the enumeration of dual power controls started using `yFirstDualPower()`.

```
function nextDualPower( ) As YDualPower
```

**Returns :**

a pointer to a `YDualPower` object, corresponding to a dual power control currently online, or a null pointer if there are no more dual power controls to enumerate.

**dualpower**→**registerValueCallback()**  
**dualpower.registerValueCallback()**

YDualPower

Registers the callback function that is invoked on every change of advertised value.

```
function registerValueCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

---

**dualpower**→**set\_logicalName()****YDualPower****dualpower**→**setLogicalName()****dualpower.set\_logicalName()**

---

Changes the logical name of the power control.

```
function set_logicalName( ByVal newval As String) As Integer
```

You can use `yCheckLogicalName( )` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash( )` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the power control.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**dualpower**→**set\_powerControl()**  
**dualpower**→**setPowerControl()**  
**dualpower.set\_powerControl()**

**YDualPower**

Changes the selected power source for module functions that require lots of current.

```
function set_powerControl( ByVal newval As Integer) As Integer
```

**Parameters :**

**newval** a value among Y\_POWERCONTROL\_AUTO, Y\_POWERCONTROL\_FROM\_USB, Y\_POWERCONTROL\_FROM\_EXT and Y\_POWERCONTROL\_OFF corresponding to the selected power source for module functions that require lots of current

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**dualpower**→**set\_userData()****YDualPower****dualpower**→**setUserData()****dualpower.set\_userData()**

---

Stores a user context provided as argument in the `userData` attribute of the function.

```
procedure set_userData( ByVal data As Object)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

## 3.17. Files function interface

The filesystem interface makes it possible to store files on some devices, for instance to design a custom web UI (for networked devices) or to add fonts (on display devices).

In order to use the functions described here, you should include:

js	<script type='text/javascript' src='yocto_files.js'></script>
nodejs	var yoctolib = require('yoctolib'); var YFiles = yoctolib.YFiles;
php	require_once('yocto_files.php');
c++	#include "yocto_files.h"
m	#import "yocto_files.h"
pas	uses yocto_files;
vb	yocto_files.vb
cs	yocto_files.cs
java	import com.yoctopuce.YoctoAPI.YFiles;
py	from yocto_files import *

### Global functions

#### yFindFiles(func)

Retrieves a filesystem for a given identifier.

#### yFirstFiles()

Starts the enumeration of filesystems currently accessible.

### YFiles methods

#### files→describe()

Returns a short text that describes unambiguously the instance of the filesystem in the form TYPE ( NAME ) =SERIAL . FUNCTIONID.

#### files→download(pathname)

Downloads the requested file and returns a binary buffer with its content.

#### files→download\_async(pathname, callback, context)

Downloads the requested file and returns a binary buffer with its content.

#### files→format\_fs()

Reinitialize the filesystem to its clean, unfragmented, empty state.

#### files→get\_advertisedValue()

Returns the current value of the filesystem (no more than 6 characters).

#### files→get\_errorMessage()

Returns the error message of the latest error with the filesystem.

#### files→get\_errorType()

Returns the numerical error code of the latest error with the filesystem.

#### files→get\_filesCount()

Returns the number of files currently loaded in the filesystem.

#### files→get\_freeSpace()

Returns the free space for uploading new files to the filesystem, in bytes.

#### files→get\_friendlyName()

Returns a global identifier of the filesystem in the format MODULE\_NAME . FUNCTION\_NAME.

#### files→get\_functionDescriptor()

Returns a unique identifier of type YFUN\_DESCR corresponding to the function.

#### files→get\_functionId()



Returns the hardware identifier of the filesystem, without reference to the module.

**files**→**get\_hardwareId()**

Returns the unique hardware identifier of the filesystem in the form `SERIAL.FUNCTIONID`.

**files**→**get\_list(pattern)**

Returns a list of `YFileRecord` objects that describe files currently loaded in the filesystem.

**files**→**get\_logicalName()**

Returns the logical name of the filesystem.

**files**→**get\_module()**

Gets the `YModule` object for the device on which the function is located.

**files**→**get\_module\_async(callback, context)**

Gets the `YModule` object for the device on which the function is located (asynchronous version).

**files**→**get\_userData()**

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

**files**→**isOnline()**

Checks if the filesystem is currently reachable, without raising any error.

**files**→**isOnline\_async(callback, context)**

Checks if the filesystem is currently reachable, without raising any error (asynchronous version).

**files**→**load(msValidity)**

Preloads the filesystem cache with a specified validity duration.

**files**→**load\_async(msValidity, callback, context)**

Preloads the filesystem cache with a specified validity duration (asynchronous version).

**files**→**nextFiles()**

Continues the enumeration of filesystems started using `yFirstFiles()`.

**files**→**registerValueCallback(callback)**

Registers the callback function that is invoked on every change of advertised value.

**files**→**remove(pathname)**

Deletes a file, given by its full path name, from the filesystem.

**files**→**set\_logicalName(newval)**

Changes the logical name of the filesystem.

**files**→**set\_userData(data)**

Stores a user context provided as argument in the `userData` attribute of the function.

**files**→**upload(pathname, content)**

Uploads a file to the filesystem, to the specified full path name.

**files**→**wait\_async(callback, context)**

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.

## YFiles.FindFiles() yFindFiles()yFindFiles()

YFiles

Retrieves a filesystem for a given identifier.

```
function yFindFiles( ByVal func As String) As YFiles
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the filesystem is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YFiles.IsOnline()` to test if the filesystem is indeed online at a given time. In case of ambiguity when looking for a filesystem by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

**Parameters :**

**func** a string that uniquely characterizes the filesystem

**Returns :**

a `YFiles` object allowing you to drive the filesystem.

---

**YFiles.FirstFiles()**  
**yFirstFiles()yFirstFiles()**

---

**YFiles**

Starts the enumeration of filesystems currently accessible.

```
function yFirstFiles( ) As YFiles
```

Use the method `YFiles.nextFiles()` to iterate on next filesystems.

**Returns :**

a pointer to a `YFiles` object, corresponding to the first filesystem currently online, or a `null` pointer if there are none.

**files**→**describe()****files.describe()****YFiles**

Returns a short text that describes unambiguously the instance of the filesystem in the form `TYPE (NAME) =SERIAL . FUNCTIONID`.

function **describe**( ) As String

More precisely, `TYPE` is the type of the function, `NAME` is the name used for the first access to the function, `SERIAL` is the serial number of the module if the module is connected or "unresolved", and `FUNCTIONID` is the hardware identifier of the function if the module is connected. For example, this method returns `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1` if the module is already connected or `Relay(BadCustomeName.relay1)=unresolved` if the module has not yet been connected. This method does not trigger any USB or TCP transaction and can therefore be used in a debugger.

**Returns :**

a string that describes the filesystem (ex: `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1`)

---

**files**→**download()****files.download()****YFiles**

---

Downloads the requested file and returns a binary buffer with its content.

```
function download( ) As Byte
```

**Parameters :**

**pathname** path and name of the file to download

**Returns :**

a binary buffer with the file content

On failure, throws an exception or returns an empty content.

## files→format\_fs()files.format\_fs()

YFiles

---

Reinitialize the filesystem to its clean, unfragmented, empty state.

function **format\_fs**( ) As Integer

All files previously uploaded are permanently lost.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**files**→**get\_advertisedValue()****YFiles****files**→**advertisedValue()****files.get\_advertisedValue()**

---

Returns the current value of the filesystem (no more than 6 characters).

function **get\_advertisedValue**( ) As String

**Returns :**

a string corresponding to the current value of the filesystem (no more than 6 characters).

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

**files**→**get\_errorMessage()**

**YFiles**

**files**→**errorMessage()****files.get\_errorMessage()**

---

Returns the error message of the latest error with the filesystem.

function **get\_errorMessage**( ) As String

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using the filesystem object



---

**files**→**get\_errorType()****YFiles****files**→**errorType()****files.get\_errorType()**

---

Returns the numerical error code of the latest error with the filesystem.

```
function get_errorType( ) As YRETCODE
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using the filesystem object

**files**→**get\_filesCount()**

**YFiles**

**files**→**filesCount()****files.get\_filesCount()**

---

Returns the number of files currently loaded in the filesystem.

function **get\_filesCount**( ) As Integer

**Returns :**

an integer corresponding to the number of files currently loaded in the filesystem

On failure, throws an exception or returns `Y_FILESCOUNT_INVALID`.

---

**files**→**get\_freeSpace()****YFiles****files**→**freeSpace()****files.get\_freeSpace()**

---

Returns the free space for uploading new files to the filesystem, in bytes.

function **get\_freeSpace**( ) As Integer

**Returns :**

an integer corresponding to the free space for uploading new files to the filesystem, in bytes

On failure, throws an exception or returns `Y_FREESPACE_INVALID`.

---

**files**→**get\_functionDescriptor()**  
**files**→**functionDescriptor()**  
**files.get\_functionDescriptor()**

---

**YFiles**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

`function get_functionDescriptor( )` As `YFUN_DESCR`

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`.

If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

---

**files**→**get\_functionId()****YFiles****files**→**functionId()****files.get\_functionId()**

---

Returns the hardware identifier of the filesystem, without reference to the module.

function **get\_functionId**( ) As String

For example `relay1`

**Returns :**

a string that identifies the filesystem (ex: `relay1`)

On failure, throws an exception or returns `Y_FUNCTIONID_INVALID`.

**files**→**get\_hardwareId()**

**YFiles**

**files**→**hardwareId()****files.get\_hardwareId()**

---

Returns the unique hardware identifier of the filesystem in the form `SERIAL.FUNCTIONID`.

function **get\_hardwareId()** As String

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the filesystem (for example `RELAYLO1-123456.relay1`).

**Returns :**

a string that uniquely identifies the filesystem (ex: `RELAYLO1-123456.relay1`)

On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

---

**files**→**get\_list()****YFiles****files**→**list()****files.get\_list()**

---

Returns a list of `YFileRecord` objects that describe files currently loaded in the filesystem.

function `get_list( )` As List

**Parameters :**

**pattern** an optional filter pattern, using star and question marks as wildcards. When an empty pattern is provided, all file records are returned.

**Returns :**

a list of `YFileRecord` objects, containing the file path and name, byte size and 32-bit CRC of the file content.

On failure, throws an exception or returns an empty list.

**files**→**get\_logicalName()**

**YFiles**

**files**→**logicalName()****files.get\_logicalName()**

---

Returns the logical name of the filesystem.

function **get\_logicalName**( ) As String

**Returns :**

a string corresponding to the logical name of the filesystem.

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.



---

**files**→**get\_module()****YFiles****files**→**module()****files.get\_module()**

---

Gets the `YModule` object for the device on which the function is located.

function **get\_module**( ) As `YModule`

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

**Returns :**

an instance of `YModule`

**files**→**get\_userData()**

**YFiles**

**files**→**userData()****files.get\_userData()**

---

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

function `get_userData( )` As Object

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

---

**files**→**isOnline()****files.isOnline()****YFiles**

---

Checks if the filesystem is currently reachable, without raising any error.

```
function isOnline( ) As Boolean
```

If there is a cached value for the filesystem in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the filesystem.

**Returns :**

`true` if the filesystem can be reached, and `false` otherwise

**files→load()files.load()**

Preloads the filesystem cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**files**→**nextFiles()****files.nextFiles()****YFiles**

---

Continues the enumeration of filesystems started using `yFirstFiles()`.

```
function nextFiles( ) As YFiles
```

**Returns :**

a pointer to a `YFiles` object, corresponding to a filesystem currently online, or a `null` pointer if there are no more filesystems to enumerate.

---

**files**→**registerValueCallback()**  
**files.registerValueCallback()**

---

YFiles

Registers the callback function that is invoked on every change of advertised value.

```
function registerValueCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

---

**files→remove()files.remove()**

---

**YFiles**

Deletes a file, given by its full path name, from the filesystem.

```
function remove( ) As Integer
```

Because of filesystem fragmentation, deleting a file may not always free up the whole space used by the file. However, rewriting a file with the same path name will always reuse any space not freed previously. If you need to ensure that no space is taken by previously deleted files, you can use `format_fs` to fully reinitialize the filesystem.

**Parameters :**

**pathname** path and name of the file to remove.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**files**→**set\_logicalName()****files**→**setLogicalName()****files.set\_logicalName()**

Changes the logical name of the filesystem.

```
function set_logicalName( ByVal newval As String) As Integer
```

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the filesystem.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.



---

**files**→**set\_userData()****YFiles****files**→**setUserData()****files.set\_userData()**

---

Stores a user context provided as argument in the userData attribute of the function.

```
procedure set_userData( ByVal data As Object)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

**files**→**upload()****files.upload()**

Uploads a file to the filesystem, to the specified full path name.

procedure **upload**( )

If a file already exists with the same path name, its content is overwritten.

**Parameters :**

**pathname** path and name of the new file to create

**content** binary buffer with the content to set

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

## 3.18. GenericSensor function interface

The Yoctopuce application programming interface allows you to read an instant measure of the sensor, as well as the minimal and maximal values observed.

In order to use the functions described here, you should include:

js	<script type='text/javascript' src='yocto_genericsensor.js'></script>
nodejs	var yoctolib = require('yoctolib'); var YGenericSensor = yoctolib.YGenericSensor;
php	require_once('yocto_genericsensor.php');
c++	#include "yocto_genericsensor.h"
m	#import "yocto_genericsensor.h"
pas	uses yocto_genericsensor;
vb	yocto_genericsensor.vb
cs	yocto_genericsensor.cs
java	import com.yoctopuce.YoctoAPI.YGenericSensor;
py	from yocto_genericsensor import *

### Global functions

#### **yFindGenericSensor(func)**

Retrieves a generic sensor for a given identifier.

#### **yFirstGenericSensor()**

Starts the enumeration of generic sensors currently accessible.

### YGenericSensor methods

#### **genericsensor→calibrateFromPoints(rawValues, refValues)**

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

#### **genericsensor→describe()**

Returns a short text that describes unambiguously the instance of the generic sensor in the form `TYPE ( NAME ) = SERIAL . FUNCTIONID`.

#### **genericsensor→get\_advertisedValue()**

Returns the current value of the generic sensor (no more than 6 characters).

#### **genericsensor→get\_currentRawValue()**

Returns the uncalibrated, unrounded raw value returned by the sensor.

#### **genericsensor→get\_currentValue()**

Returns the current measured value.

#### **genericsensor→get\_errorMessage()**

Returns the error message of the latest error with the generic sensor.

#### **genericsensor→get\_errorType()**

Returns the numerical error code of the latest error with the generic sensor.

#### **genericsensor→get\_friendlyName()**

Returns a global identifier of the generic sensor in the format `MODULE_NAME . FUNCTION_NAME`.

#### **genericsensor→get\_functionDescriptor()**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

#### **genericsensor→get\_functionId()**

Returns the hardware identifier of the generic sensor, without reference to the module.

#### **genericsensor→get\_hardwareId()**

Returns the unique hardware identifier of the generic sensor in the form `SERIAL . FUNCTIONID`.

**genericsensor**→**get\_highestValue()**

Returns the maximal value observed for the measure since the device was started.

**genericsensor**→**get\_logFrequency()**

Returns the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory.

**genericsensor**→**get\_logicalName()**

Returns the logical name of the generic sensor.

**genericsensor**→**get\_lowestValue()**

Returns the minimal value observed for the measure since the device was started.

**genericsensor**→**get\_module()**

Gets the YModule object for the device on which the function is located.

**genericsensor**→**get\_module\_async(callback, context)**

Gets the YModule object for the device on which the function is located (asynchronous version).

**genericsensor**→**get\_recordedData(startTime, endTime)**

Retrieves a DataSet object holding historical data for this sensor, for a specified time interval.

**genericsensor**→**get\_reportFrequency()**

Returns the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function.

**genericsensor**→**get\_resolution()**

Returns the resolution of the measured values.

**genericsensor**→**get\_signalBias()**

Returns the electric signal bias for zero shift adjustment.

**genericsensor**→**get\_signalRange()**

Returns the electric signal range used by the sensor.

**genericsensor**→**get\_signalUnit()**

Returns the measuring unit of the electrical signal used by the sensor.

**genericsensor**→**get\_signalValue()**

Returns the measured value of the electrical signal used by the sensor.

**genericsensor**→**get\_unit()**

Returns the measuring unit for the measure.

**genericsensor**→**get\_userData()**

Returns the value of the userData attribute, as previously stored using method `set_userData`.

**genericsensor**→**get\_valueRange()**

Returns the physical value range measured by the sensor.

**genericsensor**→**isOnline()**

Checks if the generic sensor is currently reachable, without raising any error.

**genericsensor**→**isOnline\_async(callback, context)**

Checks if the generic sensor is currently reachable, without raising any error (asynchronous version).

**genericsensor**→**load(msValidity)**

Preloads the generic sensor cache with a specified validity duration.

**genericsensor**→**loadCalibrationPoints(rawValues, refValues)**

Retrieves error correction data points previously entered using the method `calibrateFromPoints`.

**genericsensor**→**load\_async(msValidity, callback, context)**

Preloads the generic sensor cache with a specified validity duration (asynchronous version).

**genericsensor**→**nextGenericSensor()**

Continues the enumeration of generic sensors started using `yFirstGenericSensor()`.

**genericsensor**→**registerTimedReportCallback(callback)**

Registers the callback function that is invoked on every periodic timed notification.

**genericsensor**→**registerValueCallback(callback)**

Registers the callback function that is invoked on every change of advertised value.

**genericsensor**→**set\_highestValue(newval)**

Changes the recorded maximal value observed.

**genericsensor**→**set\_logFrequency(newval)**

Changes the datalogger recording frequency for this function.

**genericsensor**→**set\_logicalName(newval)**

Changes the logical name of the generic sensor.

**genericsensor**→**set\_lowestValue(newval)**

Changes the recorded minimal value observed.

**genericsensor**→**set\_reportFrequency(newval)**

Changes the timed value notification frequency for this function.

**genericsensor**→**set\_resolution(newval)**

Changes the resolution of the measured physical values.

**genericsensor**→**set\_signalBias(newval)**

Changes the electric signal bias for zero shift adjustment.

**genericsensor**→**set\_signalRange(newval)**

Changes the electric signal range used by the sensor.

**genericsensor**→**set\_unit(newval)**

Changes the measuring unit for the measured value.

**genericsensor**→**set\_userData(data)**

Stores a user context provided as argument in the userData attribute of the function.

**genericsensor**→**set\_valueRange(newval)**

Changes the physical value range measured by the sensor.

**genericsensor**→**wait\_async(callback, context)**

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.

**genericsensor**→**zeroAdjust()**

Adjusts the signal bias so that the current signal value is need precisely as zero.

## YGenericSensor.FindGenericSensor() yFindGenericSensor()yFindGenericSensor()

YGenericSensor

Retrieves a generic sensor for a given identifier.

```
function yFindGenericSensor( ByVal func As String) As YGenericSensor
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the generic sensor is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YGenericSensor.IsOnline()` to test if the generic sensor is indeed online at a given time. In case of ambiguity when looking for a generic sensor by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

**Parameters :**

**func** a string that uniquely characterizes the generic sensor

**Returns :**

a `YGenericSensor` object allowing you to drive the generic sensor.

---

**YGenericSensor.FirstGenericSensor()  
yFirstGenericSensor()yFirstGenericSensor()**

---

**YGenericSensor**

Starts the enumeration of generic sensors currently accessible.

```
function yFirstGenericSensor( ) As YGenericSensor
```

Use the method `YGenericSensor.nextGenericSensor( )` to iterate on next generic sensors.

**Returns :**

a pointer to a `YGenericSensor` object, corresponding to the first generic sensor currently online, or a `null` pointer if there are none.

**genericsensor**→**calibrateFromPoints()**  
**genericsensor.calibrateFromPoints()****YGenericSensor**

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

procedure **calibrateFromPoints()**

It is possible to configure up to five correction points. Correction points must be provided in ascending order, and be in the range of the sensor. The device will automatically perform a linear interpolation of the error correction between specified points. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

For more information on advanced capabilities to refine the calibration of sensors, please contact [support@yoctopuce.com](mailto:support@yoctopuce.com).

**Parameters :**

**rawValues** array of floating point numbers, corresponding to the raw values returned by the sensor for the correction points.

**refValues** array of floating point numbers, corresponding to the corrected values for the correction points.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.



**genericsensor→describe()genericsensor.describe()****YGenericSensor**

Returns a short text that describes unambiguously the instance of the generic sensor in the form `TYPE(NAME)=SERIAL.FUNCTIONID`.

function **describe**( ) As String

More precisely, `TYPE` is the type of the function, `NAME` is the name used for the first access to the function, `SERIAL` is the serial number of the module if the module is connected or "unresolved", and `FUNCTIONID` is the hardware identifier of the function if the module is connected. For example, this method returns `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1` if the module is already connected or `Relay(BadCustomName.relay1)=unresolved` if the module has not yet been connected. This method does not trigger any USB or TCP transaction and can therefore be used in a debugger.

**Returns :**

a string that describes the generic sensor (ex: `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1`)

**genericsensor**→**get\_advertisedValue()**

**YGenericSensor**

**genericsensor**→**advertisedValue()**

**genericsensor.get\_advertisedValue()**

---

Returns the current value of the generic sensor (no more than 6 characters).

function **get\_advertisedValue( )** As String

**Returns :**

a string corresponding to the current value of the generic sensor (no more than 6 characters).

On failure, throws an exception or returns Y\_ADVERTISEDVALUE\_INVALID.

---

**genericsensor**→**get\_currentRawValue()****YGenericSensor****genericsensor**→**currentRawValue()****genericsensor.get\_currentRawValue()**

---

Returns the uncalibrated, unrounded raw value returned by the sensor.

```
function get_currentRawValue( ) As Double
```

**Returns :**

a floating point number corresponding to the uncalibrated, unrounded raw value returned by the sensor

On failure, throws an exception or returns `Y_CURRENTRAWVALUE_INVALID`.

**genericsensor→get\_currentValue()**  
**genericsensor→currentValue()**  
**genericsensor.get\_currentValue()**

---

**YGenericSensor**

Returns the current measured value.

```
function get_currentValue( ) As Double
```

**Returns :**

a floating point number corresponding to the current measured value

On failure, throws an exception or returns Y\_CURRENTVALUE\_INVALID.

---

**genericsensor→get\_errorMessage()****YGenericSensor****genericsensor→errorMessage()****genericsensor.get\_errorMessage()**

---

Returns the error message of the latest error with the generic sensor.

```
function get_errorMessage( ) As String
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using the generic sensor object

**genericsensor→get\_errorType()**  
**genericsensor→errorType()**  
**genericsensor.get\_errorType()**

---

**YGenericSensor**

Returns the numerical error code of the latest error with the generic sensor.

```
function get_errorType( ) As YRETCODE
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using the generic sensor object

---

**genericsensor**→**get\_functionDescriptor()**  
**genericsensor**→**functionDescriptor()**  
**genericsensor.get\_functionDescriptor()**

---

**YGenericSensor**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

function **get\_functionDescriptor**( ) As `YFUN_DESCR`

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`.

If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

**genericsensor**→**get\_functionId()**  
**genericsensor**→**functionId()**  
**genericsensor.get\_functionId()**

---

**YGenericSensor**

Returns the hardware identifier of the generic sensor, without reference to the module.

```
function get_functionId( ) As String
```

For example `relay1`

**Returns :**

a string that identifies the generic sensor (ex: `relay1`)

On failure, throws an exception or returns `Y_FUNCTIONID_INVALID`.



---

**genericsensor**→**get\_hardwareId()****YGenericSensor****genericsensor**→**hardwareId()****genericsensor.get\_hardwareId()**

---

Returns the unique hardware identifier of the generic sensor in the form `SERIAL.FUNCTIONID`.

```
function get_hardwareId( ) As String
```

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the generic sensor (for example `RELAYLO1-123456.relay1`).

**Returns :**

a string that uniquely identifies the generic sensor (ex: `RELAYLO1-123456.relay1`)

On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

**genericsensor**→**get\_highestValue()**  
**genericsensor**→**highestValue()**  
**genericsensor.get\_highestValue()**

---

**YGenericSensor**

Returns the maximal value observed for the measure since the device was started.

```
function get_highestValue( ) As Double
```

**Returns :**

a floating point number corresponding to the maximal value observed for the measure since the device was started

On failure, throws an exception or returns `Y_HIGHESTVALUE_INVALID`.

---

**genericsensor**→**get\_logFrequency()****YGenericSensor****genericsensor**→**logFrequency()****genericsensor.get\_logFrequency()**

---

Returns the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory.

```
function get_logFrequency( ) As String
```

**Returns :**

a string corresponding to the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory

On failure, throws an exception or returns `Y_LOGFREQUENCY_INVALID`.

**genericsensor**→**get\_logicalName()**  
**genericsensor**→**logicalName()**  
**genericsensor.get\_logicalName()**

---

**YGenericSensor**

Returns the logical name of the generic sensor.

```
function get_logicalName( ) As String
```

**Returns :**

a string corresponding to the logical name of the generic sensor.

On failure, throws an exception or returns Y\_LOGICALNAME\_INVALID.

---

**genericsensor**→**get\_lowestValue()****YGenericSensor****genericsensor**→**lowestValue()****genericsensor.get\_lowestValue()**

---

Returns the minimal value observed for the measure since the device was started.

```
function get_lowestValue( ) As Double
```

**Returns :**

a floating point number corresponding to the minimal value observed for the measure since the device was started

On failure, throws an exception or returns `Y_LOWESTVALUE_INVALID`.

**genericsensor→get\_module()**  
**genericsensor→module()**  
**genericsensor.get\_module()**

---

**YGenericSensor**

Gets the YModule object for the device on which the function is located.

function **get\_module()** As YModule

If the function cannot be located on any module, the returned instance of YModule is not shown as on-line.

**Returns :**

an instance of YModule

**genericsensor**→**get\_recordedData()****YGenericSensor****genericsensor**→**recordedData()****genericsensor.get\_recordedData()**

Retrieves a DataSet object holding historical data for this sensor, for a specified time interval.

```
function get_recordedData( ) As YDataSet
```

The measures will be retrieved from the data logger, which must have been turned on at the desired time. See the documentation of the DataSet class for information on how to get an overview of the recorded data, and how to load progressively a large set of measures from the data logger.

This function only works if the device uses a recent firmware, as DataSet objects are not supported by firmwares older than version 13000.

**Parameters :**

**startTime** the start of the desired measure time interval, as a Unix timestamp, i.e. the number of seconds since January 1, 1970 UTC. The special value 0 can be used to include any meaasure, without initial limit.

**endTime** the end of the desired measure time interval, as a Unix timestamp, i.e. the number of seconds since January 1, 1970 UTC. The special value 0 can be used to include any meaasure, without ending limit.

**Returns :**

an instance of YDataSet, providing access to historical data. Past measures can be loaded progressively using methods from the YDataSet object.

**genericsensor→get\_reportFrequency()**

**YGenericSensor**

**genericsensor→reportFrequency()**

**genericsensor.get\_reportFrequency()**

---

Returns the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function.

```
function get_reportFrequency( ) As String
```

**Returns :**

a string corresponding to the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function

On failure, throws an exception or returns Y\_REPORTFREQUENCY\_INVALID.



---

**genericsensor**→**get\_resolution()**  
**genericsensor**→**resolution()**  
**genericsensor.get\_resolution()**

---

**YGenericSensor**

Returns the resolution of the measured values.

```
function get_resolution( ) As Double
```

The resolution corresponds to the numerical precision of the measures, which is not always the same as the actual precision of the sensor.

**Returns :**

a floating point number corresponding to the resolution of the measured values

On failure, throws an exception or returns `Y_RESOLUTION_INVALID`.

**genericsensor→get\_signalBias()**

**YGenericSensor**

**genericsensor→signalBias()**

**genericsensor.get\_signalBias()**

---

Returns the electric signal bias for zero shift adjustment.

function **get\_signalBias**( ) As Double

A positive bias means that the signal is over-reporting the measure, while a negative bias means that the signal is underreporting the measure.

**Returns :**

a floating point number corresponding to the electric signal bias for zero shift adjustment

On failure, throws an exception or returns Y\_SIGNALBIAS\_INVALID.

---

**genericsensor→get\_signalRange()****YGenericSensor****genericsensor→signalRange()****genericsensor.get\_signalRange()**

---

Returns the electric signal range used by the sensor.

```
function get_signalRange( ) As String
```

**Returns :**

a string corresponding to the electric signal range used by the sensor

On failure, throws an exception or returns Y\_SIGNALRANGE\_INVALID.

**genericsensor**→**get\_signalUnit()**  
**genericsensor**→**signalUnit()**  
**genericsensor.get\_signalUnit()**

---

**YGenericSensor**

Returns the measuring unit of the electrical signal used by the sensor.

```
function get_signalUnit( ) As String
```

**Returns :**

a string corresponding to the measuring unit of the electrical signal used by the sensor

On failure, throws an exception or returns Y\_SIGNALUNIT\_INVALID.

---

**genericsensor**→**get\_signalValue()****YGenericSensor****genericsensor**→**signalValue()****genericsensor.get\_signalValue()**

---

Returns the measured value of the electrical signal used by the sensor.

```
function get_signalValue( ) As Double
```

**Returns :**

a floating point number corresponding to the measured value of the electrical signal used by the sensor

On failure, throws an exception or returns `Y_SIGNALVALUE_INVALID`.

**genericsensor**→**get\_unit()**

**YGenericSensor**

**genericsensor**→**unit()****genericsensor.get\_unit()**

---

Returns the measuring unit for the measure.

function **get\_unit**( ) As String

**Returns :**

a string corresponding to the measuring unit for the measure

On failure, throws an exception or returns `Y_UNIT_INVALID`.

---

**genericsensor→get\_userData()****YGenericSensor****genericsensor→userData()****genericsensor.get\_userData()**

---

Returns the value of the userData attribute, as previously stored using method `set_userData`.

```
function get_userData( ) As Object
```

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

**genericsensor→get\_valueRange()**  
**genericsensor→valueRange()**  
**genericsensor.get\_valueRange()**

---

**YGenericSensor**

Returns the physical value range measured by the sensor.

```
function get_valueRange( ) As String
```

**Returns :**

a string corresponding to the physical value range measured by the sensor

On failure, throws an exception or returns Y\_VALUERANGE\_INVALID.



---

**genericsensor**→**isOnline()****genericsensor.isOnline()****YGenericSensor**

---

Checks if the generic sensor is currently reachable, without raising any error.

```
function isOnline( ) As Boolean
```

If there is a cached value for the generic sensor in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the generic sensor.

**Returns :**

`true` if the generic sensor can be reached, and `false` otherwise

**genericsensor**→**load()****genericsensor.load()****YGenericSensor**

Preloads the generic sensor cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**genericsensor→loadCalibrationPoints()  
genericsensor.loadCalibrationPoints()**

---

**YGenericSensor**

Retrieves error correction data points previously entered using the method `calibrateFromPoints`.

procedure **loadCalibrationPoints( )**

**Parameters :**

**rawValues** array of floating point numbers, that will be filled by the function with the raw sensor values for the correction points.

**refValues** array of floating point numbers, that will be filled by the function with the desired values for the correction points.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**genericsensor**→**nextGenericSensor()**  
**genericsensor.nextGenericSensor()**

**YGenericSensor**

---

Continues the enumeration of generic sensors started using `yFirstGenericSensor()`.

function **nextGenericSensor()** As YGenericSensor

**Returns :**

a pointer to a YGenericSensor object, corresponding to a generic sensor currently online, or a null pointer if there are no more generic sensors to enumerate.

---

**genericsensor**→**registerTimedReportCallback()**  
**genericsensor.registerTimedReportCallback()**

---

**YGenericSensor**

Registers the callback function that is invoked on every periodic timed notification.

```
function registerTimedReportCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and an `YMeasure` object describing the new advertised value.

**genericsensor**→**registerValueCallback()**  
**genericsensor.registerValueCallback()****YGenericSensor**

Registers the callback function that is invoked on every change of advertised value.

```
function registerValueCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

---

**genericsensor**→**set\_highestValue()**  
**genericsensor**→**setHighestValue()**  
**genericsensor.set\_highestValue()**

---

**YGenericSensor**

Changes the recorded maximal value observed.

```
function set_highestValue( ByVal newval As Double) As Integer
```

**Parameters :**

**newval** a floating point number corresponding to the recorded maximal value observed

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**genericsensor→set\_logFrequency()**  
**genericsensor→setLogFrequency()**  
**genericsensor.set\_logFrequency()**

**YGenericSensor**

---

Changes the datalogger recording frequency for this function.

```
function set_logFrequency( ByVal newval As String) As Integer
```

The frequency can be specified as samples per second, as sample per minute (for instance "15/m") or in samples per hour (eg. "4/h"). To disable recording for this function, use the value "OFF".

**Parameters :**

**newval** a string corresponding to the datalogger recording frequency for this function

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.



**genericsensor**→**set\_logicalName()****YGenericSensor****genericsensor**→**setLogicalName()****genericsensor.set\_logicalName()**

Changes the logical name of the generic sensor.

```
function set_logicalName( ByVal newval As String) As Integer
```

You can use `yCheckLogicalName( )` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash( )` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the generic sensor.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**genericsensor**→**set\_lowestValue()**  
**genericsensor**→**setLowestValue()**  
**genericsensor.set\_lowestValue()**

---

**YGenericSensor**

Changes the recorded minimal value observed.

```
function set_lowestValue( ByVal newval As Double) As Integer
```

**Parameters :**

**newval** a floating point number corresponding to the recorded minimal value observed

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**genericsensor**→**set\_reportFrequency()**  
**genericsensor**→**setReportFrequency()**  
**genericsensor.set\_reportFrequency()**

---

**YGenericSensor**

Changes the timed value notification frequency for this function.

```
function set_reportFrequency( ByVal newval As String) As Integer
```

The frequency can be specified as samples per second, as sample per minute (for instance "15/m") or in samples per hour (eg. "4/h"). To disable timed value notifications for this function, use the value "OFF".

**Parameters :**

**newval** a string corresponding to the timed value notification frequency for this function

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**genericsensor**→**set\_resolution()**  
**genericsensor**→**setResolution()**  
**genericsensor.set\_resolution()**

---

**YGenericSensor**

Changes the resolution of the measured physical values.

```
function set_resolution( ByVal newval As Double) As Integer
```

The resolution corresponds to the numerical precision when displaying value. It does not change the precision of the measure itself.

**Parameters :**

**newval** a floating point number corresponding to the resolution of the measured physical values

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**genericsensor**→**set\_signalBias()****YGenericSensor****genericsensor**→**setSignalBias()****genericsensor.set\_signalBias()**

---

Changes the electric signal bias for zero shift adjustment.

```
function set_signalBias( ByVal newval As Double) As Integer
```

If your electric signal reads positif when it should be zero, setup a positive signalBias of the same value to fix the zero shift.

**Parameters :**

**newval** a floating point number corresponding to the electric signal bias for zero shift adjustment

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**genericsensor**→**set\_signalRange()**  
**genericsensor**→**setSignalRange()**  
**genericsensor.set\_signalRange()**

---

**YGenericSensor**

Changes the electric signal range used by the sensor.

```
function set_signalRange( ByVal newval As String) As Integer
```

**Parameters :**

**newval** a string corresponding to the electric signal range used by the sensor

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**genericsensor**→**set\_unit()****YGenericSensor****genericsensor**→**setUnit()****genericsensor.set\_unit()**

---

Changes the measuring unit for the measured value.

```
function set_unit( ByVal newval As String) As Integer
```

Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the measuring unit for the measured value

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**genericsensor**→**set\_userData()**  
**genericsensor**→**setUserData()**  
**genericsensor.set\_userData()**

---

**YGenericSensor**

Stores a user context provided as argument in the userData attribute of the function.

```
procedure set_userData( ByVal data As Object)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored



---

**genericsensor**→**set\_valueRange()****YGenericSensor****genericsensor**→**setValueRange()****genericsensor.set\_valueRange()**

---

Changes the physical value range measured by the sensor.

```
function set_valueRange( ByVal newval As String) As Integer
```

As a side effect, the range modification may automatically modify the display resolution.

**Parameters :**

**newval** a string corresponding to the physical value range measured by the sensor

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**genericsensor→zeroAdjust()**  
**genericsensor.zeroAdjust()**

**YGenericSensor**

---

Adjusts the signal bias so that the current signal value is need precisely as zero.

function **zeroAdjust**( ) As Integer

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

## 3.19. Gyroscope function interface

The Yoctopuce application programming interface allows you to read an instant measure of the sensor, as well as the minimal and maximal values observed.

In order to use the functions described here, you should include:

js	<code>&lt;script type='text/javascript' src='yocto_gyro.js'&gt;&lt;/script&gt;</code>
nodejs	<code>var yoctolib = require('yoctolib'); var YGyro = yoctolib.YGyro;</code>
php	<code>require_once('yocto_gyro.php');</code>
cpp	<code>#include "yocto_gyro.h"</code>
m	<code>#import "yocto_gyro.h"</code>
pas	<code>uses yocto_gyro;</code>
vb	<code>yocto_gyro.vb</code>
cs	<code>yocto_gyro.cs</code>
java	<code>import com.yoctopuce.YoctoAPI.YGyro;</code>
py	<code>from yocto_gyro import *</code>

### Global functions

#### **yFindGyro(func)**

Retrieves a gyroscope for a given identifier.

#### **yFirstGyro()**

Starts the enumeration of gyroscopes currently accessible.

### YGyro methods

#### **gyro→calibrateFromPoints(rawValues, refValues)**

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

#### **gyro→describe()**

Returns a short text that describes unambiguously the instance of the gyroscope in the form `TYPE ( NAME ) = SERIAL . FUNCTIONID`.

#### **gyro→get\_advertisedValue()**

Returns the current value of the gyroscope (no more than 6 characters).

#### **gyro→get\_currentRawValue()**

Returns the uncalibrated, unrounded raw value returned by the sensor, in degrees per second, as a floating point number.

#### **gyro→get\_currentValue()**

Returns the current value of the angular velocity, in degrees per second, as a floating point number.

#### **gyro→get\_errorMessage()**

Returns the error message of the latest error with the gyroscope.

#### **gyro→get\_errorType()**

Returns the numerical error code of the latest error with the gyroscope.

#### **gyro→get\_friendlyName()**

Returns a global identifier of the gyroscope in the format `MODULE_NAME . FUNCTION_NAME`.

#### **gyro→get\_functionDescriptor()**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

#### **gyro→get\_functionId()**

Returns the hardware identifier of the gyroscope, without reference to the module.

#### **gyro→get\_hardwareId()**

### 3. Reference

Returns the unique hardware identifier of the gyroscope in the form `SERIAL . FUNCTIONID`.

#### **gyro**→**get\_heading()**

Returns the estimated heading angle, based on the integration of gyroscopic measures combined with acceleration and magnetic field measurements.

#### **gyro**→**get\_highestValue()**

Returns the maximal value observed for the angular velocity since the device was started.

#### **gyro**→**get\_logFrequency()**

Returns the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory.

#### **gyro**→**get\_logicalName()**

Returns the logical name of the gyroscope.

#### **gyro**→**get\_lowestValue()**

Returns the minimal value observed for the angular velocity since the device was started.

#### **gyro**→**get\_module()**

Gets the `YModule` object for the device on which the function is located.

#### **gyro**→**get\_module\_async(callback, context)**

Gets the `YModule` object for the device on which the function is located (asynchronous version).

#### **gyro**→**get\_pitch()**

Returns the estimated pitch angle, based on the integration of gyroscopic measures combined with acceleration and magnetic field measurements.

#### **gyro**→**get\_quaternionW()**

Returns the *w* component (real part) of the quaternion describing the device estimated orientation, based on the integration of gyroscopic measures combined with acceleration and magnetic field measurements.

#### **gyro**→**get\_quaternionX()**

Returns the *x* component of the quaternion describing the device estimated orientation, based on the integration of gyroscopic measures combined with acceleration and magnetic field measurements.

#### **gyro**→**get\_quaternionY()**

Returns the *y* component of the quaternion describing the device estimated orientation, based on the integration of gyroscopic measures combined with acceleration and magnetic field measurements.

#### **gyro**→**get\_quaternionZ()**

Returns the *z* component of the quaternion describing the device estimated orientation, based on the integration of gyroscopic measures combined with acceleration and magnetic field measurements.

#### **gyro**→**get\_recordedData(startTime, endTime)**

Retrieves a `DataSet` object holding historical data for this sensor, for a specified time interval.

#### **gyro**→**get\_reportFrequency()**

Returns the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function.

#### **gyro**→**get\_resolution()**

Returns the resolution of the measured values.

#### **gyro**→**get\_roll()**

Returns the estimated roll angle, based on the integration of gyroscopic measures combined with acceleration and magnetic field measurements.

#### **gyro**→**get\_unit()**

Returns the measuring unit for the angular velocity.

#### **gyro**→**get\_userData()**

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

#### **gyro**→**get\_xValue()**

Returns the angular velocity around the X axis of the device, as a floating point number.

**gyro→get\_yValue()**

Returns the angular velocity around the Y axis of the device, as a floating point number.

**gyro→get\_zValue()**

Returns the angular velocity around the Z axis of the device, as a floating point number.

**gyro→isOnline()**

Checks if the gyroscope is currently reachable, without raising any error.

**gyro→isOnline\_async(callback, context)**

Checks if the gyroscope is currently reachable, without raising any error (asynchronous version).

**gyro→load(msValidity)**

Preloads the gyroscope cache with a specified validity duration.

**gyro→loadCalibrationPoints(rawValues, refValues)**

Retrieves error correction data points previously entered using the method `calibrateFromPoints`.

**gyro→load\_async(msValidity, callback, context)**

Preloads the gyroscope cache with a specified validity duration (asynchronous version).

**gyro→nextGyro()**

Continues the enumeration of gyroscopes started using `yFirstGyro()`.

**gyro→registerAnglesCallback(callback)**

Registers a callback function that will be invoked each time that the estimated device orientation has changed.

**gyro→registerQuaternionCallback(callback)**

Registers a callback function that will be invoked each time that the estimated device orientation has changed.

**gyro→registerTimedReportCallback(callback)**

Registers the callback function that is invoked on every periodic timed notification.

**gyro→registerValueCallback(callback)**

Registers the callback function that is invoked on every change of advertised value.

**gyro→set\_highestValue(newval)**

Changes the recorded maximal value observed.

**gyro→set\_logFrequency(newval)**

Changes the datalogger recording frequency for this function.

**gyro→set\_logicalName(newval)**

Changes the logical name of the gyroscope.

**gyro→set\_lowestValue(newval)**

Changes the recorded minimal value observed.

**gyro→set\_reportFrequency(newval)**

Changes the timed value notification frequency for this function.

**gyro→set\_resolution(newval)**

Changes the resolution of the measured physical values.

**gyro→set\_userData(data)**

Stores a user context provided as argument in the `userData` attribute of the function.

**gyro→wait\_async(callback, context)**

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.

## YGyro.FindGyro() yFindGyro()yFindGyro()

YGyro

Retrieves a gyroscope for a given identifier.

```
function yFindGyro( ByVal func As String) As YGyro
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the gyroscope is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YGyro.IsOnline()` to test if the gyroscope is indeed online at a given time. In case of ambiguity when looking for a gyroscope by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

**Parameters :**

**func** a string that uniquely characterizes the gyroscope

**Returns :**

a `YGyro` object allowing you to drive the gyroscope.

---

**YGyro.FirstGyro()  
yFirstGyro()yFirstGyro()**

---

**YGyro**

Starts the enumeration of gyroscopes currently accessible.

```
function yFirstGyro( ) As YGyro
```

Use the method `YGyro.nextGyro( )` to iterate on next gyroscopes.

**Returns :**

a pointer to a `YGyro` object, corresponding to the first gyro currently online, or a `null` pointer if there are none.

**gyro**→**calibrateFromPoints()**  
**gyro.calibrateFromPoints()****YGyro**

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

procedure **calibrateFromPoints()** ( )

It is possible to configure up to five correction points. Correction points must be provided in ascending order, and be in the range of the sensor. The device will automatically perform a linear interpolation of the error correction between specified points. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

For more information on advanced capabilities to refine the calibration of sensors, please contact [support@yoctopuce.com](mailto:support@yoctopuce.com).

**Parameters :**

**rawValues** array of floating point numbers, corresponding to the raw values returned by the sensor for the correction points.

**refValues** array of floating point numbers, corresponding to the corrected values for the correction points.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.



**gyro→describe()****gyro.describe()****YGyro**

Returns a short text that describes unambiguously the instance of the gyroscope in the form `TYPE(NAME)=SERIAL.FUNCTIONID`.

function **describe**( ) As String

More precisely, `TYPE` is the type of the function, `NAME` is the name used for the first access to the function, `SERIAL` is the serial number of the module if the module is connected or "unresolved", and `FUNCTIONID` is the hardware identifier of the function if the module is connected. For example, this method returns `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1` if the module is already connected or `Relay(BadCustomName.relay1)=unresolved` if the module has not yet been connected. This method does not trigger any USB or TCP transaction and can therefore be used in a debugger.

**Returns :**

a string that describes the gyroscope (ex: `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1`)

**gyro**→**get\_advertisedValue()**

**YGyro**

**gyro**→**advertisedValue()****gyro.get\_advertisedValue()**

---

Returns the current value of the gyroscope (no more than 6 characters).

function **get\_advertisedValue()** As String

**Returns :**

a string corresponding to the current value of the gyroscope (no more than 6 characters).

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

---

**gyro**→**get\_currentRawValue()****YGyro****gyro**→**currentRawValue()****gyro.get\_currentRawValue()**

---

Returns the uncalibrated, unrounded raw value returned by the sensor, in degrees per second, as a floating point number.

```
function get_currentRawValue( ) As Double
```

**Returns :**

a floating point number corresponding to the uncalibrated, unrounded raw value returned by the sensor, in degrees per second, as a floating point number

On failure, throws an exception or returns `Y_CURRENTRAWVALUE_INVALID`.

**gyro**→**get\_currentValue()**

**YGyro**

**gyro**→**currentValue()****gyro.get\_currentValue()**

---

Returns the current value of the angular velocity, in degrees per second, as a floating point number.

function **get\_currentValue( )** As Double

**Returns :**

a floating point number corresponding to the current value of the angular velocity, in degrees per second, as a floating point number

On failure, throws an exception or returns `Y_CURRENTVALUE_INVALID`.

---

**gyro**→**get\_errorMessage()****YGyro****gyro**→**errorMessage()****gyro.get\_errorMessage()**

---

Returns the error message of the latest error with the gyroscope.

```
function get_errorMessage( ) As String
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using the gyroscope object

**gyro**→**get\_errorType()**

**YGyro**

**gyro**→**errorType()****gyro.get\_errorType()**

---

Returns the numerical error code of the latest error with the gyroscope.

```
function get_errorType( ) As YRETCODE
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using the gyroscope object

---

**gyro**→**get\_functionDescriptor()**  
**gyro**→**functionDescriptor()**  
**gyro.get\_functionDescriptor()**

---

**YGyro**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

```
function get_functionDescriptor( ) As YFUN_DESCR
```

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`.

If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

**gyro**→**get\_functionId()**

**YGyro**

**gyro**→**functionId()****gyro.get\_functionId()**

---

Returns the hardware identifier of the gyroscope, without reference to the module.

function **get\_functionId**( ) As String

For example `relay1`

**Returns :**

a string that identifies the gyroscope (ex: `relay1`)

On failure, throws an exception or returns `Y_FUNCTIONID_INVALID`.



---

**gyro**→**get\_hardwareId()****YGyro****gyro**→**hardwareId()****gyro.get\_hardwareId()**

---

Returns the unique hardware identifier of the gyroscope in the form `SERIAL.FUNCTIONID`.

function **get\_hardwareId()** As String

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the gyroscope (for example `RELAYLO1-123456.relay1`).

**Returns :**

a string that uniquely identifies the gyroscope (ex: `RELAYLO1-123456.relay1`)

On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

**gyro**→**get\_heading()**

**YGyro**

**gyro**→**heading()****gyro.get\_heading()**

---

Returns the estimated heading angle, based on the integration of gyroscopic measures combined with acceleration and magnetic field measurements.

```
function get_heading( ) As Double
```

The axis corresponding to the heading can be mapped to any of the device X, Y or Z physical directions using methods of the class `YRefFrame`.

**Returns :**

a floating-point number corresponding to heading in degrees, between 0 and 360.

---

**gyro**→**get\_highestValue()****YGyro****gyro**→**highestValue()****gyro.get\_highestValue()**

---

Returns the maximal value observed for the angular velocity since the device was started.

function **get\_highestValue()** As Double

**Returns :**

a floating point number corresponding to the maximal value observed for the angular velocity since the device was started

On failure, throws an exception or returns `Y_HIGHESTVALUE_INVALID`.

**gyro**→**get\_logFrequency()**

**YGyro**

**gyro**→**logFrequency()****gyro.get\_logFrequency()**

---

Returns the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory.

function **get\_logFrequency( )** As String

**Returns :**

a string corresponding to the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory

On failure, throws an exception or returns Y\_LOGFREQUENCY\_INVALID.

---

**gyro**→**get\_logicalName()****YGyro****gyro**→**logicalName()****gyro.get\_logicalName()**

---

Returns the logical name of the gyroscope.

```
function get_logicalName( ) As String
```

**Returns :**

a string corresponding to the logical name of the gyroscope.

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

**gyro**→**get\_lowestValue()**

**YGyro**

**gyro**→**lowestValue()****gyro.get\_lowestValue()**

---

Returns the minimal value observed for the angular velocity since the device was started.

function **get\_lowestValue()** As Double

**Returns :**

a floating point number corresponding to the minimal value observed for the angular velocity since the device was started

On failure, throws an exception or returns `Y_LOWESTVALUE_INVALID`.

---

**gyro**→**get\_module()**  
**gyro**→**module()****gyro.get\_module()**

---

**YGyro**

Gets the `YModule` object for the device on which the function is located.

```
function get_module( ) As YModule
```

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

**Returns :**

an instance of `YModule`

**gyro**→**get\_pitch()**

**YGyro**

**gyro**→**pitch()****gyro.get\_pitch()**

---

Returns the estimated pitch angle, based on the integration of gyroscopic measures combined with acceleration and magnetic field measurements.

```
function get_pitch( ) As Double
```

The axis corresponding to the pitch angle can be mapped to any of the device X, Y or Z physical directions using methods of the class `YRefFrame`.

**Returns :**

a floating-point number corresponding to pitch angle in degrees, between -90 and +90.



---

**gyro**→**get\_quaternionW()****YGyro****gyro**→**quaternionW()****gyro.get\_quaternionW()**

---

Returns the *w* component (real part) of the quaternion describing the device estimated orientation, based on the integration of gyroscopic measures combined with acceleration and magnetic field measurements.

```
function get_quaternionW( ) As Double
```

**Returns :**

a floating-point number corresponding to the *w* component of the quaternion.

**gyro**→**get\_quaternionX()**

**YGyro**

**gyro**→**quaternionX()****gyro.get\_quaternionX()**

---

Returns the  $x$  component of the quaternion describing the device estimated orientation, based on the integration of gyroscopic measures combined with acceleration and magnetic field measurements.

```
function get_quaternionX( ) As Double
```

The  $x$  component is mostly correlated with rotations on the roll axis.

**Returns :**

a floating-point number corresponding to the  $x$  component of the quaternion.

---

**gyro**→**get\_quaternionY()****YGyro****gyro**→**quaternionY()****gyro.get\_quaternionY()**

---

Returns the  $y$  component of the quaternion describing the device estimated orientation, based on the integration of gyroscopic measures combined with acceleration and magnetic field measurements.

```
function get_quaternionY( ) As Double
```

The  $y$  component is mostly correlated with rotations on the pitch axis.

**Returns :**

a floating-point number corresponding to the  $y$  component of the quaternion.

**gyro**→**get\_quaternionZ()**

**YGyro**

**gyro**→**quaternionZ()****gyro.get\_quaternionZ()**

---

Returns the  $x$  component of the quaternion describing the device estimated orientation, based on the integration of gyroscopic measures combined with acceleration and magnetic field measurements.

```
function get_quaternionZ( ) As Double
```

The  $x$  component is mostly correlated with changes of heading.

**Returns :**

a floating-point number corresponding to the  $z$  component of the quaternion.

---

**gyro**→**get\_recordedData()****YGyro****gyro**→**recordedData()****gyro.get\_recordedData()**

---

Retrieves a DataSet object holding historical data for this sensor, for a specified time interval.

```
function get_recordedData( ) As YDataSet
```

The measures will be retrieved from the data logger, which must have been turned on at the desired time. See the documentation of the DataSet class for information on how to get an overview of the recorded data, and how to load progressively a large set of measures from the data logger.

This function only works if the device uses a recent firmware, as DataSet objects are not supported by firmwares older than version 13000.

**Parameters :**

- startTime** the start of the desired measure time interval, as a Unix timestamp, i.e. the number of seconds since January 1, 1970 UTC. The special value 0 can be used to include any measure, without initial limit.
- endTime** the end of the desired measure time interval, as a Unix timestamp, i.e. the number of seconds since January 1, 1970 UTC. The special value 0 can be used to include any measure, without ending limit.

**Returns :**

an instance of YDataSet, providing access to historical data. Past measures can be loaded progressively using methods from the YDataSet object.

**gyro**→**get\_reportFrequency()**

**YGyro**

**gyro**→**reportFrequency()****gyro.get\_reportFrequency()**

---

Returns the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function.

function **get\_reportFrequency()** As String

**Returns :**

a string corresponding to the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function

On failure, throws an exception or returns Y\_REPORTFREQUENCY\_INVALID.

---

**gyro**→**get\_resolution()****YGyro****gyro**→**resolution()****gyro.get\_resolution()**

---

Returns the resolution of the measured values.

```
function get_resolution( ) As Double
```

The resolution corresponds to the numerical precision of the measures, which is not always the same as the actual precision of the sensor.

**Returns :**

a floating point number corresponding to the resolution of the measured values

On failure, throws an exception or returns `Y_RESOLUTION_INVALID`.

**gyro**→**get\_roll()**

**YGyro**

**gyro**→**roll()****gyro.get\_roll()**

---

Returns the estimated roll angle, based on the integration of gyroscopic measures combined with acceleration and magnetic field measurements.

function **get\_roll()** As Double

The axis corresponding to the roll angle can be mapped to any of the device X, Y or Z physical directions using methods of the class `YRefFrame`.

**Returns :**

a floating-point number corresponding to roll angle in degrees, between -180 and +180.



---

**gyro**→**get\_unit()****YGyro****gyro**→**unit()****gyro.get\_unit()**

---

Returns the measuring unit for the angular velocity.

function **get\_unit**( ) As String

**Returns :**

a string corresponding to the measuring unit for the angular velocity

On failure, throws an exception or returns Y\_UNIT\_INVALID.

**gyro**→**get\_userData()**

**YGyro**

**gyro**→**userData()****gyro.get\_userData()**

---

Returns the value of the userData attribute, as previously stored using method `set_userData`.

function `get_userData( )` As Object

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

---

**gyro**→**get\_xValue()****YGyro****gyro**→**xValue()****gyro.get\_xValue()**

---

Returns the angular velocity around the X axis of the device, as a floating point number.

```
function get_xValue( ) As Double
```

**Returns :**

a floating point number corresponding to the angular velocity around the X axis of the device, as a floating point number

On failure, throws an exception or returns `Y_XVALUE_INVALID`.

**gyro**→**get\_yValue()**

**YGyro**

**gyro**→**yValue()****gyro.get\_yValue()**

---

Returns the angular velocity around the Y axis of the device, as a floating point number.

function **get\_yValue( )** As Double

**Returns :**

a floating point number corresponding to the angular velocity around the Y axis of the device, as a floating point number

On failure, throws an exception or returns `Y_YVALUE_INVALID`.

---

**gyro**→**get\_zValue()****YGyro****gyro**→**zValue()****gyro.get\_zValue()**

---

Returns the angular velocity around the Z axis of the device, as a floating point number.

function **get\_zValue**( ) As Double

**Returns :**

a floating point number corresponding to the angular velocity around the Z axis of the device, as a floating point number

On failure, throws an exception or returns `Y_ZVALUE_INVALID`.

## gyro→isOnline()gyro.isOnline()

YGyro

Checks if the gyroscope is currently reachable, without raising any error.

function **isOnline**( ) As Boolean

If there is a cached value for the gyroscope in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the gyroscope.

**Returns :**

`true` if the gyroscope can be reached, and `false` otherwise

**gyro→load()****gyro.load()****YGyro**

Preloads the gyroscope cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

**gyro→loadCalibrationPoints()**  
**gyro.loadCalibrationPoints()****YGyro**

Retrieves error correction data points previously entered using the method `calibrateFromPoints`.

procedure **loadCalibrationPoints( )**

**Parameters :**

**rawValues** array of floating point numbers, that will be filled by the function with the raw sensor values for the correction points.

**refValues** array of floating point numbers, that will be filled by the function with the desired values for the correction points.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.



---

**gyro→nextGyro()gyro.nextGyro()****YGyro**

---

Continues the enumeration of gyroscopes started using `yFirstGyro()`.

```
function nextGyro() As YGyro
```

**Returns :**

a pointer to a `YGyro` object, corresponding to a gyroscope currently online, or a `null` pointer if there are no more gyroscopes to enumerate.

**gyro→registerAnglesCallback()**  
**gyro.registerAnglesCallback()****YGyro**

Registers a callback function that will be invoked each time that the estimated device orientation has changed.

```
function registerAnglesCallback( ) As Integer
```

The call frequency is typically around 95Hz during a move. The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to invoke, or a null pointer. The callback function should take four arguments: the YGyro object of the turning device, and the floating point values of the three angles roll, pitch and heading in degrees (as floating-point numbers).

---

**gyro→registerQuaternionCallback()**  
**gyro.registerQuaternionCallback()**

---

**YGyro**

Registers a callback function that will be invoked each time that the estimated device orientation has changed.

```
function registerQuaternionCallback( ) As Integer
```

The call frequency is typically around 95Hz during a move. The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to invoke, or a null pointer. The callback function should take five arguments: the YGyro object of the turning device, and the floating point values of the four components w, x, y and z (as floating-point numbers).

**gyro→registerTimedReportCallback()**  
**gyro.registerTimedReportCallback()****YGyro**

Registers the callback function that is invoked on every periodic timed notification.

```
function registerTimedReportCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and an `YMeasure` object describing the new advertised value.

---

**gyro→registerValueCallback()**  
**gyro.registerValueCallback()**

---

**YGyro**

Registers the callback function that is invoked on every change of advertised value.

```
function registerValueCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

**gyro**→**set\_highestValue()**

**YGyro**

**gyro**→**setHighestValue()****gyro.set\_highestValue()**

---

Changes the recorded maximal value observed.

```
function set_highestValue( ByVal newval As Double) As Integer
```

**Parameters :**

**newval** a floating point number corresponding to the recorded maximal value observed

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**gyro→set\_logFrequency()****YGyro****gyro→setLogFrequency()gyro.set\_logFrequency()**

---

Changes the datalogger recording frequency for this function.

```
function set_logFrequency( ByVal newval As String) As Integer
```

The frequency can be specified as samples per second, as sample per minute (for instance "15/m") or in samples per hour (eg. "4/h"). To disable recording for this function, use the value "OFF".

**Parameters :**

**newval** a string corresponding to the datalogger recording frequency for this function

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**gyro**→**set\_logicalName()****YGyro****gyro**→**setLogicalName()****gyro.set\_logicalName()**

Changes the logical name of the gyroscope.

```
function set_logicalName( ByVal newval As String) As Integer
```

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the gyroscope.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.



---

**gyro**→**set\_lowestValue()****YGyro****gyro**→**setLowestValue()****gyro.set\_lowestValue()**

---

Changes the recorded minimal value observed.

```
function set_lowestValue( ByVal newval As Double) As Integer
```

**Parameters :**

**newval** a floating point number corresponding to the recorded minimal value observed

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**gyro→set\_reportFrequency()**

**YGyro**

**gyro→setReportFrequency()**

**gyro.set\_reportFrequency()**

---

Changes the timed value notification frequency for this function.

```
function set_reportFrequency( ByVal newval As String) As Integer
```

The frequency can be specified as samples per second, as sample per minute (for instance "15/m") or in samples per hour (eg. "4/h"). To disable timed value notifications for this function, use the value "OFF".

**Parameters :**

**newval** a string corresponding to the timed value notification frequency for this function

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**gyro→set\_resolution()****YGyro****gyro→setResolution()gyro.set\_resolution()**

---

Changes the resolution of the measured physical values.

```
function set_resolution( ByVal newval As Double) As Integer
```

The resolution corresponds to the numerical precision when displaying value. It does not change the precision of the measure itself.

**Parameters :**

**newval** a floating point number corresponding to the resolution of the measured physical values

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**gyro**→**set\_userData()**

**YGyro**

**gyro**→**setUserData()****gyro.set\_userData()**

---

Stores a user context provided as argument in the `userData` attribute of the function.

```
procedure set_userData( ByVal data As Object)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

## 3.20. Yocto-hub port interface

YHubPort objects provide control over the power supply for every YoctoHub port and provide information about the device connected to it. The logical name of a YHubPort is always automatically set to the unique serial number of the Yoctopuce device connected to it.

In order to use the functions described here, you should include:

js	<script type='text/javascript' src='yocto_hubport.js'></script>
nodejs	var yoctolib = require('yoctolib'); var YHubPort = yoctolib.YHubPort;
php	require_once('yocto_hubport.php');
cpp	#include "yocto_hubport.h"
m	#import "yocto_hubport.h"
pas	uses yocto_hubport;
vb	yocto_hubport.vb
cs	yocto_hubport.cs
java	import com.yoctopuce.YoctoAPI.YHubPort;
py	from yocto_hubport import *

### Global functions

#### yFindHubPort(func)

Retrieves a Yocto-hub port for a given identifier.

#### yFirstHubPort()

Starts the enumeration of Yocto-hub ports currently accessible.

### YHubPort methods

#### hubport→describe()

Returns a short text that describes unambiguously the instance of the Yocto-hub port in the form `TYPE ( NAME ) = SERIAL . FUNCTIONID`.

#### hubport→get\_advertisedValue()

Returns the current value of the Yocto-hub port (no more than 6 characters).

#### hubport→get\_baudRate()

Returns the current baud rate used by this Yocto-hub port, in kbps.

#### hubport→get\_enabled()

Returns true if the Yocto-hub port is powered, false otherwise.

#### hubport→get\_errorMessage()

Returns the error message of the latest error with the Yocto-hub port.

#### hubport→get\_errorType()

Returns the numerical error code of the latest error with the Yocto-hub port.

#### hubport→get\_friendlyName()

Returns a global identifier of the Yocto-hub port in the format `MODULE_NAME . FUNCTION_NAME`.

#### hubport→get\_functionDescriptor()

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

#### hubport→get\_functionId()

Returns the hardware identifier of the Yocto-hub port, without reference to the module.

#### hubport→get\_hardwareId()

Returns the unique hardware identifier of the Yocto-hub port in the form `SERIAL . FUNCTIONID`.

#### hubport→get\_logicalName()

Returns the logical name of the Yocto-hub port.

**hubport→get\_module()**

Gets the YModule object for the device on which the function is located.

**hubport→get\_module\_async(callback, context)**

Gets the YModule object for the device on which the function is located (asynchronous version).

**hubport→get\_portState()**

Returns the current state of the Yocto-hub port.

**hubport→get\_userData()**

Returns the value of the userData attribute, as previously stored using method set\_userData.

**hubport→isOnline()**

Checks if the Yocto-hub port is currently reachable, without raising any error.

**hubport→isOnline\_async(callback, context)**

Checks if the Yocto-hub port is currently reachable, without raising any error (asynchronous version).

**hubport→load(msValidity)**

Preloads the Yocto-hub port cache with a specified validity duration.

**hubport→load\_async(msValidity, callback, context)**

Preloads the Yocto-hub port cache with a specified validity duration (asynchronous version).

**hubport→nextHubPort()**

Continues the enumeration of Yocto-hub ports started using yFirstHubPort().

**hubport→registerValueCallback(callback)**

Registers the callback function that is invoked on every change of advertised value.

**hubport→set\_enabled(newval)**

Changes the activation of the Yocto-hub port.

**hubport→set\_logicalName(newval)**

Changes the logical name of the Yocto-hub port.

**hubport→set\_userData(data)**

Stores a user context provided as argument in the userData attribute of the function.

**hubport→wait\_async(callback, context)**

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.

## **YHubPort.FindHubPort()** **yFindHubPort()****yFindHubPort()**

**YHubPort**

Retrieves a Yocto-hub port for a given identifier.

```
function yFindHubPort( ByVal func As String) As YHubPort
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the Yocto-hub port is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YHubPort.IsOnline()` to test if the Yocto-hub port is indeed online at a given time. In case of ambiguity when looking for a Yocto-hub port by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

**Parameters :**

**func** a string that uniquely characterizes the Yocto-hub port

**Returns :**

a `YHubPort` object allowing you to drive the Yocto-hub port.

## **YHubPort.FirstHubPort() yFirstHubPort()**

**YHubPort**

---

Starts the enumeration of Yocto-hub ports currently accessible.

```
function yFirstHubPort( ) As YHubPort
```

Use the method `YHubPort.nextHubPort()` to iterate on next Yocto-hub ports.

**Returns :**

a pointer to a `YHubPort` object, corresponding to the first Yocto-hub port currently online, or a `null` pointer if there are none.



**hubport**→**describe()****hubport.describe()****YHubPort**

Returns a short text that describes unambiguously the instance of the Yocto-hub port in the form `TYPE (NAME) =SERIAL . FUNCTIONID`.

function **describe**( ) As String

More precisely, `TYPE` is the type of the function, `NAME` it the name used for the first access to the function, `SERIAL` is the serial number of the module if the module is connected or "unresolved", and `FUNCTIONID` is the hardware identifier of the function if the module is connected. For example, this method returns `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1` if the module is already connected or `Relay(BadCustomName.relay1)=unresolved` if the module has not yet been connected. This method does not trigger any USB or TCP transaction and can therefore be used in a debugger.

**Returns :**

a string that describes the Yocto-hub port (ex: `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1`)

**hubport**→**get\_advertisedValue()**

**YHubPort**

**hubport**→**advertisedValue()**

**hubport.get\_advertisedValue()**

---

Returns the current value of the Yocto-hub port (no more than 6 characters).

```
function get_advertisedValue( ) As String
```

**Returns :**

a string corresponding to the current value of the Yocto-hub port (no more than 6 characters).

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

---

**hubport**→**get\_baudRate()****YHubPort****hubport**→**baudRate()****hubport.get\_baudRate()**

---

Returns the current baud rate used by this Yocto-hub port, in kbps.

```
function get_baudRate( ) As Integer
```

The default value is 1000 kbps, but a slower rate may be used if communication problems are encountered.

**Returns :**

an integer corresponding to the current baud rate used by this Yocto-hub port, in kbps

On failure, throws an exception or returns `Y_BAUDRATE_INVALID`.

**hubport**→**get\_enabled()**

**YHubPort**

**hubport**→**enabled()****hubport.get\_enabled()**

---

Returns true if the Yocto-hub port is powered, false otherwise.

function **get\_enabled**( ) As Integer

**Returns :**

either `Y_ENABLED_FALSE` or `Y_ENABLED_TRUE`, according to true if the Yocto-hub port is powered, false otherwise

On failure, throws an exception or returns `Y_ENABLED_INVALID`.

---

**hubport**→**get\_errorMessage()****YHubPort****hubport**→**errorMessage()****hubport.get\_errorMessage()**

---

Returns the error message of the latest error with the Yocto-hub port.

```
function get_errorMessage( ) As String
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using the Yocto-hub port object

**hubport**→**get\_errorType()**

**YHubPort**

**hubport**→**errorType()****hubport.get\_errorType()**

---

Returns the numerical error code of the latest error with the Yocto-hub port.

function **get\_errorType**( ) As YRETCODE

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using the Yocto-hub port object

---

**hubport**→**get\_functionDescriptor()****YHubPort****hubport**→**functionDescriptor()****hubport.get\_functionDescriptor()**

---

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

```
function get_functionDescriptor( ) As YFUN_DESCR
```

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`.

If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

**hubport**→**get\_functionId()**

**YHubPort**

**hubport**→**functionId()****hubport.get\_functionId()**

---

Returns the hardware identifier of the Yocto-hub port, without reference to the module.

function **get\_functionId**( ) As String

For example `relay1`

**Returns :**

a string that identifies the Yocto-hub port (ex: `relay1`)

On failure, throws an exception or returns `Y_FUNCTIONID_INVALID`.



---

**hubport**→**get\_hardwareId()****YHubPort****hubport**→**hardwareId()****hubport.get\_hardwareId()**

---

Returns the unique hardware identifier of the Yocto-hub port in the form `SERIAL.FUNCTIONID`.

function **get\_hardwareId()** As String

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the Yocto-hub port (for example `RELAYLO1-123456.relay1`).

**Returns :**

a string that uniquely identifies the Yocto-hub port (ex: `RELAYLO1-123456.relay1`)

On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

**hubport**→**get\_logicalName()**

**YHubPort**

**hubport**→**logicalName()****hubport.get\_logicalName()**

---

Returns the logical name of the Yocto-hub port.

function **get\_logicalName**( ) As String

**Returns :**

a string corresponding to the logical name of the Yocto-hub port.

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

---

**hubport**→**get\_module()****YHubPort****hubport**→**module()****hubport.get\_module()**

---

Gets the `YModule` object for the device on which the function is located.

```
function get_module( ) As YModule
```

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

**Returns :**

an instance of `YModule`

**hubport**→**get\_portState()**

**YHubPort**

**hubport**→**portState()****hubport.get\_portState()**

---

Returns the current state of the Yocto-hub port.

function **get\_portState**( ) As Integer

**Returns :**

a value among Y\_PORTSTATE\_OFF, Y\_PORTSTATE\_OVRLD, Y\_PORTSTATE\_ON, Y\_PORTSTATE\_RUN and Y\_PORTSTATE\_PROG corresponding to the current state of the Yocto-hub port

On failure, throws an exception or returns Y\_PORTSTATE\_INVALID.

---

**hubport**→**get\_userData()****YHubPort****hubport**→**userData()****hubport.get\_userData()**

---

Returns the value of the userData attribute, as previously stored using method `set_userData`.

```
function get_userData( ) As Object
```

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

## hubport→isOnline()hubport.isOnline()

YHubPort

---

Checks if the Yocto-hub port is currently reachable, without raising any error.

```
function isOnline( ) As Boolean
```

If there is a cached value for the Yocto-hub port in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the Yocto-hub port.

**Returns :**

`true` if the Yocto-hub port can be reached, and `false` otherwise

---

**hubport**→**load()****hubport.load()****YHubPort**

---

Preloads the Yocto-hub port cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

**hubport**→**nextHubPort()**hubport.nextHubPort()

**YHubPort**

---

Continues the enumeration of Yocto-hub ports started using `yFirstHubPort()`.

```
function nextHubPort( ) As YHubPort
```

**Returns :**

a pointer to a `YHubPort` object, corresponding to a Yocto-hub port currently online, or a `null` pointer if there are no more Yocto-hub ports to enumerate.



---

**hubport**→**registerValueCallback()**  
**hubport.registerValueCallback()**

---

**YHubPort**

Registers the callback function that is invoked on every change of advertised value.

```
function registerValueCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

**hubport**→**set\_enabled()**

**YHubPort**

**hubport**→**setEnabled()****hubport.set\_enabled()**

---

Changes the activation of the Yocto-hub port.

```
function set_enabled( ByVal newval As Integer) As Integer
```

If the port is enabled, the connected module is powered. Otherwise, port power is shut down.

**Parameters :**

**newval** either Y\_ENABLED\_FALSE or Y\_ENABLED\_TRUE, according to the activation of the Yocto-hub port

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**hubport**→**set\_logicalName()****YHubPort****hubport**→**setLogicalName()****hubport.set\_logicalName()**

---

Changes the logical name of the Yocto-hub port.

```
function set_logicalName( ByVal newval As String) As Integer
```

You can use `yCheckLogicalName( )` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash( )` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the Yocto-hub port.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**hubport**→**set\_userData()**

**YHubPort**

**hubport**→**setUserData()****hubport.set\_userData()**

---

Stores a user context provided as argument in the `userData` attribute of the function.

```
procedure set_userData( ByVal data As Object)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

## 3.21. Humidity function interface

The Yoctopuce application programming interface allows you to read an instant measure of the sensor, as well as the minimal and maximal values observed.

In order to use the functions described here, you should include:

js	<script type='text/javascript' src='yocto_humidity.js'></script>
nodejs	var yoctolib = require('yoctolib'); var YHumidity = yoctolib.YHumidity;
php	require_once('yocto_humidity.php');
c++	#include "yocto_humidity.h"
m	#import "yocto_humidity.h"
pas	uses yocto_humidity;
vb	yocto_humidity.vb
cs	yocto_humidity.cs
java	import com.yoctopuce.YoctoAPI.YHumidity;
py	from yocto_humidity import *

### Global functions

#### **yFindHumidity(func)**

Retrieves a humidity sensor for a given identifier.

#### **yFirstHumidity()**

Starts the enumeration of humidity sensors currently accessible.

### YHumidity methods

#### **humidity→calibrateFromPoints(rawValues, refValues)**

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

#### **humidity→describe()**

Returns a short text that describes unambiguously the instance of the humidity sensor in the form `TYPE ( NAME ) = SERIAL . FUNCTIONID`.

#### **humidity→get\_advertisedValue()**

Returns the current value of the humidity sensor (no more than 6 characters).

#### **humidity→get\_currentRawValue()**

Returns the uncalibrated, unrounded raw value returned by the sensor, in %RH, as a floating point number.

#### **humidity→get\_currentValue()**

Returns the current value of the humidity, in %RH, as a floating point number.

#### **humidity→get\_errorMessage()**

Returns the error message of the latest error with the humidity sensor.

#### **humidity→get\_errorType()**

Returns the numerical error code of the latest error with the humidity sensor.

#### **humidity→get\_friendlyName()**

Returns a global identifier of the humidity sensor in the format `MODULE_NAME . FUNCTION_NAME`.

#### **humidity→get\_functionDescriptor()**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

#### **humidity→get\_functionId()**

Returns the hardware identifier of the humidity sensor, without reference to the module.

#### **humidity→get\_hardwareId()**

Returns the unique hardware identifier of the humidity sensor in the form `SERIAL . FUNCTIONID`.

### 3. Reference

#### **humidity**→**get\_highestValue()**

Returns the maximal value observed for the humidity since the device was started.

#### **humidity**→**get\_logFrequency()**

Returns the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory.

#### **humidity**→**get\_logicalName()**

Returns the logical name of the humidity sensor.

#### **humidity**→**get\_lowestValue()**

Returns the minimal value observed for the humidity since the device was started.

#### **humidity**→**get\_module()**

Gets the `YModule` object for the device on which the function is located.

#### **humidity**→**get\_module\_async(callback, context)**

Gets the `YModule` object for the device on which the function is located (asynchronous version).

#### **humidity**→**get\_recordedData(startTime, endTime)**

Retrieves a `DataSet` object holding historical data for this sensor, for a specified time interval.

#### **humidity**→**get\_reportFrequency()**

Returns the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function.

#### **humidity**→**get\_resolution()**

Returns the resolution of the measured values.

#### **humidity**→**get\_unit()**

Returns the measuring unit for the humidity.

#### **humidity**→**get\_userData()**

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

#### **humidity**→**isOnline()**

Checks if the humidity sensor is currently reachable, without raising any error.

#### **humidity**→**isOnline\_async(callback, context)**

Checks if the humidity sensor is currently reachable, without raising any error (asynchronous version).

#### **humidity**→**load(msValidity)**

Preloads the humidity sensor cache with a specified validity duration.

#### **humidity**→**loadCalibrationPoints(rawValues, refValues)**

Retrieves error correction data points previously entered using the method `calibrateFromPoints`.

#### **humidity**→**load\_async(msValidity, callback, context)**

Preloads the humidity sensor cache with a specified validity duration (asynchronous version).

#### **humidity**→**nextHumidity()**

Continues the enumeration of humidity sensors started using `yFirstHumidity()`.

#### **humidity**→**registerTimedReportCallback(callback)**

Registers the callback function that is invoked on every periodic timed notification.

#### **humidity**→**registerValueCallback(callback)**

Registers the callback function that is invoked on every change of advertised value.

#### **humidity**→**set\_highestValue(newval)**

Changes the recorded maximal value observed.

#### **humidity**→**set\_logFrequency(newval)**

Changes the datalogger recording frequency for this function.

#### **humidity**→**set\_logicalName(newval)**

Changes the logical name of the humidity sensor.

**humidity→set\_lowestValue(newval)**

Changes the recorded minimal value observed.

**humidity→set\_reportFrequency(newval)**

Changes the timed value notification frequency for this function.

**humidity→set\_resolution(newval)**

Changes the resolution of the measured physical values.

**humidity→set\_userData(data)**

Stores a user context provided as argument in the userData attribute of the function.

**humidity→wait\_async(callback, context)**

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.

## YHumidity.FindHumidity() yFindHumidity()yFindHumidity()

YHumidity

Retrieves a humidity sensor for a given identifier.

```
function yFindHumidity( ByVal func As String) As YHumidity
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the humidity sensor is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YHumidity.isOnline()` to test if the humidity sensor is indeed online at a given time. In case of ambiguity when looking for a humidity sensor by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

**Parameters :**

**func** a string that uniquely characterizes the humidity sensor

**Returns :**

a `YHumidity` object allowing you to drive the humidity sensor.



---

**YHumidity.FirstHumidity()  
yFirstHumidity()yFirstHumidity()**

---

**YHumidity**

Starts the enumeration of humidity sensors currently accessible.

```
function yFirstHumidity( ) As YHumidity
```

Use the method `YHumidity.nextHumidity()` to iterate on next humidity sensors.

**Returns :**

a pointer to a `YHumidity` object, corresponding to the first humidity sensor currently online, or a `null` pointer if there are none.

## humidity→calibrateFromPoints() humidity.calibrateFromPoints()

YHumidity

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

procedure `calibrateFromPoints( )`

It is possible to configure up to five correction points. Correction points must be provided in ascending order, and be in the range of the sensor. The device will automatically perform a linear interpolation of the error correction between specified points. Remember to call the `saveToFlash( )` method of the module if the modification must be kept.

For more information on advanced capabilities to refine the calibration of sensors, please contact [support@yoctopuce.com](mailto:support@yoctopuce.com).

### Parameters :

**rawValues** array of floating point numbers, corresponding to the raw values returned by the sensor for the correction points.

**refValues** array of floating point numbers, corresponding to the corrected values for the correction points.

### Returns :

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**humidity**→**describe()****humidity.describe()****YHumidity**

---

Returns a short text that describes unambiguously the instance of the humidity sensor in the form `TYPE (NAME) =SERIAL . FUNCTIONID`.

function **describe**( ) As String

More precisely, `TYPE` is the type of the function, `NAME` it the name used for the first access to the function, `SERIAL` is the serial number of the module if the module is connected or "unresolved", and `FUNCTIONID` is the hardware identifier of the function if the module is connected. For example, this method returns `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1` if the module is already connected or `Relay(BadCustomName.relay1)=unresolved` if the module has not yet been connected. This method does not trigger any USB or TCP transaction and can therefore be used in a debugger.

**Returns :**

a string that describes the humidity sensor (ex: `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1`)

**humidity**→**get\_advertisedValue()**

**YHumidity**

**humidity**→**advertisedValue()**

**humidity**.**get\_advertisedValue()**

---

Returns the current value of the humidity sensor (no more than 6 characters).

```
function get_advertisedValue( ) As String
```

**Returns :**

a string corresponding to the current value of the humidity sensor (no more than 6 characters).

On failure, throws an exception or returns Y\_ADVERTISEDVALUE\_INVALID.

---

**humidity**→**get\_currentRawValue()****YHumidity****humidity**→**currentRawValue()****humidity.get\_currentRawValue()**

---

Returns the uncalibrated, unrounded raw value returned by the sensor, in %RH, as a floating point number.

```
function get_currentRawValue( ) As Double
```

**Returns :**

a floating point number corresponding to the uncalibrated, unrounded raw value returned by the sensor, in %RH, as a floating point number

On failure, throws an exception or returns `Y_CURRENTRAWVALUE_INVALID`.

**humidity**→**get\_currentValue()**

**YHumidity**

**humidity**→**currentValue()****humidity.get\_currentValue()**

---

Returns the current value of the humidity, in %RH, as a floating point number.

```
function get_currentValue( ) As Double
```

**Returns :**

a floating point number corresponding to the current value of the humidity, in %RH, as a floating point number

On failure, throws an exception or returns `Y_CURRENTVALUE_INVALID`.

---

**humidity**→**get\_errorMessage()****YHumidity****humidity**→**errorMessage()****humidity.get\_errorMessage()**

---

Returns the error message of the latest error with the humidity sensor.

```
function get_errorMessage( ) As String
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using the humidity sensor object

**humidity**→**get\_errorType()**

**YHumidity**

**humidity**→**errorType()****humidity.get\_errorType()**

---

Returns the numerical error code of the latest error with the humidity sensor.

```
function get_errorType( ) As YRETCODE
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using the humidity sensor object



---

**humidity→get\_functionDescriptor()****YHumidity****humidity→functionDescriptor()****humidity.get\_functionDescriptor()**

---

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

```
function get_functionDescriptor( ) As YFUN_DESCR
```

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`.

If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

**humidity**→**get\_functionId()**

**YHumidity**

**humidity**→**functionId()****humidity.get\_functionId()**

---

Returns the hardware identifier of the humidity sensor, without reference to the module.

function **get\_functionId**( ) As String

For example `relay1`

**Returns :**

a string that identifies the humidity sensor (ex: `relay1`)

On failure, throws an exception or returns `Y_FUNCTIONID_INVALID`.

---

**humidity**→**get\_hardwareId()****YHumidity****humidity**→**hardwareId()****humidity.get\_hardwareId()**

---

Returns the unique hardware identifier of the humidity sensor in the form `SERIAL.FUNCTIONID`.

function **get\_hardwareId()** As String

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the humidity sensor (for example `RELAYLO1-123456.relay1`).

**Returns :**

a string that uniquely identifies the humidity sensor (ex: `RELAYLO1-123456.relay1`)

On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

humidity→get\_highestValue()

YHumidity

humidity→highestValue()

humidity.get\_highestValue()

---

Returns the maximal value observed for the humidity since the device was started.

```
function get_highestValue( ) As Double
```

**Returns :**

a floating point number corresponding to the maximal value observed for the humidity since the device was started

On failure, throws an exception or returns Y\_HIGHESTVALUE\_INVALID.

---

**humidity→get\_logFrequency()****YHumidity****humidity→logFrequency()****humidity.get\_logFrequency()**

---

Returns the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory.

```
function get_logFrequency( ) As String
```

**Returns :**

a string corresponding to the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory

On failure, throws an exception or returns Y\_LOGFREQUENCY\_INVALID.

**humidity**→**get\_logicalName()**

**YHumidity**

**humidity**→**logicalName()****humidity.get\_logicalName()**

---

Returns the logical name of the humidity sensor.

function **get\_logicalName**( ) As String

**Returns :**

a string corresponding to the logical name of the humidity sensor.

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

---

**humidity**→**get\_lowestValue()****YHumidity****humidity**→**lowestValue()****humidity.get\_lowestValue()**

---

Returns the minimal value observed for the humidity since the device was started.

```
function get_lowestValue( ) As Double
```

**Returns :**

a floating point number corresponding to the minimal value observed for the humidity since the device was started

On failure, throws an exception or returns `Y_LOWESTVALUE_INVALID`.

**humidity**→**get\_module()**

**YHumidity**

**humidity**→**module()****humidity.get\_module()**

---

Gets the YModule object for the device on which the function is located.

function **get\_module()** As YModule

If the function cannot be located on any module, the returned instance of YModule is not shown as on-line.

**Returns :**

an instance of YModule



---

**humidity**→**get\_recordedData()****YHumidity****humidity**→**recordedData()****humidity.get\_recordedData()**

---

Retrieves a DataSet object holding historical data for this sensor, for a specified time interval.

```
function get_recordedData( ) As YDataSet
```

The measures will be retrieved from the data logger, which must have been turned on at the desired time. See the documentation of the DataSet class for information on how to get an overview of the recorded data, and how to load progressively a large set of measures from the data logger.

This function only works if the device uses a recent firmware, as DataSet objects are not supported by firmwares older than version 13000.

**Parameters :**

**startTime** the start of the desired measure time interval, as a Unix timestamp, i.e. the number of seconds since January 1, 1970 UTC. The special value 0 can be used to include any meaasure, without initial limit.

**endTime** the end of the desired measure time interval, as a Unix timestamp, i.e. the number of seconds since January 1, 1970 UTC. The special value 0 can be used to include any meaasure, without ending limit.

**Returns :**

an instance of YDataSet, providing access to historical data. Past measures can be loaded progressively using methods from the YDataSet object.

humidity→get\_reportFrequency()

YHumidity

humidity→reportFrequency()

humidity.get\_reportFrequency()

---

Returns the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function.

```
function get_reportFrequency( ) As String
```

**Returns :**

a string corresponding to the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function

On failure, throws an exception or returns Y\_REPORTFREQUENCY\_INVALID.

---

**humidity**→**get\_resolution()****YHumidity****humidity**→**resolution()****humidity.get\_resolution()**

---

Returns the resolution of the measured values.

```
function get_resolution( ) As Double
```

The resolution corresponds to the numerical precision of the measures, which is not always the same as the actual precision of the sensor.

**Returns :**

a floating point number corresponding to the resolution of the measured values

On failure, throws an exception or returns `Y_RESOLUTION_INVALID`.

**humidity**→**get\_unit()**

**YHumidity**

**humidity**→**unit()****humidity.get\_unit()**

---

Returns the measuring unit for the humidity.

```
function get_unit( ) As String
```

**Returns :**

a string corresponding to the measuring unit for the humidity

On failure, throws an exception or returns `Y_UNIT_INVALID`.

---

**humidity**→**get\_userdata()****YHumidity****humidity**→**userData()****humidity.get\_userdata()**

---

Returns the value of the userData attribute, as previously stored using method `set_userdata`.

```
function get_userdata( ) As Object
```

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

## humidity→isOnline()humidity.isOnline()

YHumidity

---

Checks if the humidity sensor is currently reachable, without raising any error.

```
function isOnline( ) As Boolean
```

If there is a cached value for the humidity sensor in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the humidity sensor.

**Returns :**

`true` if the humidity sensor can be reached, and `false` otherwise

---

**humidity→load()humidity.load()**

---

**YHumidity**

Preloads the humidity sensor cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

**humidity→loadCalibrationPoints()  
humidity.loadCalibrationPoints()**

**YHumidity**

Retrieves error correction data points previously entered using the method `calibrateFromPoints`.

procedure `loadCalibrationPoints( )`

**Parameters :**

**rawValues** array of floating point numbers, that will be filled by the function with the raw sensor values for the correction points.

**refValues** array of floating point numbers, that will be filled by the function with the desired values for the correction points.

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.



---

**humidity**→**nextHumidity()****humidity.nextHumidity()****YHumidity**

---

Continues the enumeration of humidity sensors started using `yFirstHumidity()`.

```
function nextHumidity( ) As YHumidity
```

**Returns :**

a pointer to a `YHumidity` object, corresponding to a humidity sensor currently online, or a `null` pointer if there are no more humidity sensors to enumerate.

---

**humidity**→**registerTimedReportCallback()**  
**humidity.registerTimedReportCallback()**

---

**YHumidity**

Registers the callback function that is invoked on every periodic timed notification.

```
function registerTimedReportCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and an `YMeasure` object describing the new advertised value.

---

**humidity→registerValueCallback()**  
**humidity.registerValueCallback()**

---

**YHumidity**

Registers the callback function that is invoked on every change of advertised value.

```
function registerValueCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

humidity→set\_highestValue()

YHumidity

humidity→setHighestValue()

humidity.set\_highestValue()

---

Changes the recorded maximal value observed.

```
function set_highestValue( ByVal newval As Double) As Integer
```

**Parameters :**

**newval** a floating point number corresponding to the recorded maximal value observed

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**humidity**→**set\_logFrequency()****YHumidity****humidity**→**setLogFrequency()****humidity.set\_logFrequency()**

---

Changes the datalogger recording frequency for this function.

```
function set_logFrequency( ByVal newval As String) As Integer
```

The frequency can be specified as samples per second, as sample per minute (for instance "15/m") or in samples per hour (eg. "4/h"). To disable recording for this function, use the value "OFF".

**Parameters :**

**newval** a string corresponding to the datalogger recording frequency for this function

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**humidity→set\_logicalName()  
humidity→setLogicalName()  
humidity.set\_logicalName()**

---

**YHumidity**

Changes the logical name of the humidity sensor.

```
function set_logicalName( ByVal newval As String) As Integer
```

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the humidity sensor.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**humidity**→**set\_lowestValue()****YHumidity****humidity**→**setLowestValue()****humidity.set\_lowestValue()**

---

Changes the recorded minimal value observed.

```
function set_lowestValue( ByVal newval As Double) As Integer
```

**Parameters :**

**newval** a floating point number corresponding to the recorded minimal value observed

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**humidity→set\_reportFrequency()**

**YHumidity**

**humidity→setReportFrequency()**

**humidity.set\_reportFrequency()**

---

Changes the timed value notification frequency for this function.

```
function set_reportFrequency( ByVal newval As String) As Integer
```

The frequency can be specified as samples per second, as sample per minute (for instance "15/m") or in samples per hour (eg. "4/h"). To disable timed value notifications for this function, use the value "OFF".

**Parameters :**

**newval** a string corresponding to the timed value notification frequency for this function

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.



---

**humidity**→**set\_resolution()****YHumidity****humidity**→**setResolution()****humidity.set\_resolution()**

---

Changes the resolution of the measured physical values.

```
function set_resolution( ByVal newval As Double) As Integer
```

The resolution corresponds to the numerical precision when displaying value. It does not change the precision of the measure itself.

**Parameters :**

**newval** a floating point number corresponding to the resolution of the measured physical values

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**humidity**→**set\_userData()**

**YHumidity**

**humidity**→**setUserData()****humidity.set\_userData()**

---

Stores a user context provided as argument in the userData attribute of the function.

```
procedure set_userData( ByVal data As Object)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

## 3.22. Led function interface

Yoctopuce application programming interface allows you not only to drive the intensity of the led, but also to have it blink at various preset frequencies.

In order to use the functions described here, you should include:

js	<script type='text/javascript' src='yocto_led.js'></script>
nodejs	var yoctolib = require('yoctolib'); var YLed = yoctolib.YLed;
php	require_once('yocto_led.php');
cpp	#include "yocto_led.h"
m	#import "yocto_led.h"
pas	uses yocto_led;
vb	yocto_led.vb
cs	yocto_led.cs
java	import com.yoctopuce.YoctoAPI.YLed;
py	from yocto_led import *

### Global functions

#### yFindLed(func)

Retrieves a led for a given identifier.

#### yFirstLed()

Starts the enumeration of leds currently accessible.

### YLed methods

#### led→describe()

Returns a short text that describes unambiguously the instance of the led in the form `TYPE (NAME) = SERIAL . FUNCTIONID`.

#### led→get\_advertisedValue()

Returns the current value of the led (no more than 6 characters).

#### led→get\_blinking()

Returns the current led signaling mode.

#### led→get\_errorMessage()

Returns the error message of the latest error with the led.

#### led→get\_errorType()

Returns the numerical error code of the latest error with the led.

#### led→get\_friendlyName()

Returns a global identifier of the led in the format `MODULE_NAME . FUNCTION_NAME`.

#### led→get\_functionDescriptor()

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

#### led→get\_functionId()

Returns the hardware identifier of the led, without reference to the module.

#### led→get\_hardwareId()

Returns the unique hardware identifier of the led in the form `SERIAL . FUNCTIONID`.

#### led→get\_logicalName()

Returns the logical name of the led.

#### led→get\_luminosity()

Returns the current led intensity (in per cent).

#### led→get\_module()

Gets the `YModule` object for the device on which the function is located.

**led→get\_module\_async(callback, context)**

Gets the `YModule` object for the device on which the function is located (asynchronous version).

**led→get\_power()**

Returns the current led state.

**led→get\_userData()**

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

**led→isOnline()**

Checks if the led is currently reachable, without raising any error.

**led→isOnline\_async(callback, context)**

Checks if the led is currently reachable, without raising any error (asynchronous version).

**led→load(msValidity)**

Preloads the led cache with a specified validity duration.

**led→load\_async(msValidity, callback, context)**

Preloads the led cache with a specified validity duration (asynchronous version).

**led→nextLed()**

Continues the enumeration of leds started using `yFirstLed()`.

**led→registerValueCallback(callback)**

Registers the callback function that is invoked on every change of advertised value.

**led→set\_blinking(newval)**

Changes the current led signaling mode.

**led→set\_logicalName(newval)**

Changes the logical name of the led.

**led→set\_luminosity(newval)**

Changes the current led intensity (in per cent).

**led→set\_power(newval)**

Changes the state of the led.

**led→set\_userData(data)**

Stores a user context provided as argument in the `userData` attribute of the function.

**led→wait\_async(callback, context)**

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.

## YLed.FindLed() yFindLed(yFindLed())

YLed

Retrieves a led for a given identifier.

```
function yFindLed( ByVal func As String) As YLed
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the led is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YLed.isOnline()` to test if the led is indeed online at a given time. In case of ambiguity when looking for a led by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

### Parameters :

**func** a string that uniquely characterizes the led

### Returns :

a YLed object allowing you to drive the led.

## YLed.FirstLed() yFirstLed()yFirstLed()

---

YLed

Starts the enumeration of leds currently accessible.

```
function yFirstLed( ) As YLed
```

Use the method `YLed.nextLed()` to iterate on next leds.

**Returns :**

a pointer to a `YLed` object, corresponding to the first led currently online, or a `null` pointer if there are none.

**led**→**describe()****led.describe()****YLed**

Returns a short text that describes unambiguously the instance of the led in the form `TYPE(NAME)=SERIAL.FUNCTIONID`.

function **describe**( ) As String

More precisely, `TYPE` is the type of the function, `NAME` is the name used for the first access to the function, `SERIAL` is the serial number of the module if the module is connected or "unresolved", and `FUNCTIONID` is the hardware identifier of the function if the module is connected. For example, this method returns `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1` if the module is already connected or `Relay(BadCustomName.relay1)=unresolved` if the module has not yet been connected. This method does not trigger any USB or TCP transaction and can therefore be used in a debugger.

**Returns :**

a string that describes the led (ex: `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1`)

**led**→**get\_advertisedValue()**

**YLed**

**led**→**advertisedValue()****led.get\_advertisedValue()**

---

Returns the current value of the led (no more than 6 characters).

```
function get_advertisedValue( ) As String
```

**Returns :**

a string corresponding to the current value of the led (no more than 6 characters).

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.



---

**led**→**get\_blinking()****YLed****led**→**blinking()****led.get\_blinking()**

---

Returns the current led signaling mode.

function **get\_blinking**( ) As Integer

**Returns :**

a value among `Y_BLINKING_STILL`, `Y_BLINKING_RELAX`, `Y_BLINKING_AWARE`, `Y_BLINKING_RUN`, `Y_BLINKING_CALL` and `Y_BLINKING_PANIC` corresponding to the current led signaling mode

On failure, throws an exception or returns `Y_BLINKING_INVALID`.

**led**→**get\_errorMessage()**

**YLed**

**led**→**errorMessage()****led.get\_errorMessage()**

---

Returns the error message of the latest error with the led.

```
function get_errorMessage( ) As String
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using the led object

---

**led**→`get_errorType()`**YLed****led**→`errorType()`**led**.`get_errorType()`

---

Returns the numerical error code of the latest error with the led.

```
function get_errorType() As YRETCODE
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using the led object

**led**→**get\_functionDescriptor()**

**YLed**

**led**→**functionDescriptor()**

**led.get\_functionDescriptor()**

---

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

```
function get_functionDescriptor( ) As YFUN_DESCR
```

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`.

If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

---

**led**→`get_functionId()`**YLed****led**→`functionId()`**led.get\_functionId()**

---

Returns the hardware identifier of the led, without reference to the module.

function `get_functionId( )` As String

For example `relay1`

**Returns :**

a string that identifies the led (ex: `relay1`)

On failure, throws an exception or returns `Y_FUNCTIONID_INVALID`.

**led**→**get\_hardwareId()**

**YLed**

**led**→**hardwareId()****led.get\_hardwareId()**

---

Returns the unique hardware identifier of the led in the form `SERIAL.FUNCTIONID`.

```
function get_hardwareId( ) As String
```

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the led (for example `RELAYLO1-123456.relay1`).

**Returns :**

a string that uniquely identifies the led (ex: `RELAYLO1-123456.relay1`)

On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

---

**led**→**get\_logicalName()****YLed****led**→**logicalName()****led.get\_logicalName()**

---

Returns the logical name of the led.

```
function get_logicalName( ) As String
```

**Returns :**

a string corresponding to the logical name of the led.

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

**led**→**get\_luminosity()**

**YLed**

**led**→**luminosity()****led.get\_luminosity()**

---

Returns the current led intensity (in per cent).

function **get\_luminosity**( ) As Integer

**Returns :**

an integer corresponding to the current led intensity (in per cent)

On failure, throws an exception or returns `Y_LUMINOSITY_INVALID`.



---

**led**→**get\_module()****YLed****led**→**module()****led.get\_module()**

---

Gets the `YModule` object for the device on which the function is located.

```
function get_module( ) As YModule
```

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

**Returns :**

an instance of `YModule`

**led**→**get\_power()**

**YLed**

**led**→**power()****led.get\_power()**

---

Returns the current led state.

function **get\_power**( ) As Integer

**Returns :**

either Y\_POWER\_OFF or Y\_POWER\_ON, according to the current led state

On failure, throws an exception or returns Y\_POWER\_INVALID.

---

**led**→**get\_userData()****YLed****led**→**userData()****led.get\_userData()**

---

Returns the value of the userData attribute, as previously stored using method `set_userData`.

```
function get_userData( ) As Object
```

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

## led→isOnline()led.isOnline()

YLed

---

Checks if the led is currently reachable, without raising any error.

```
function isOnline( ) As Boolean
```

If there is a cached value for the led in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the led.

**Returns :**

`true` if the led can be reached, and `false` otherwise

**led**→**load()****led.load()****YLed**

Preloads the led cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

## led→nextLed()led.nextLed()

YLed

---

Continues the enumeration of leds started using `yFirstLed()`.

```
function nextLed( ) As YLed
```

**Returns :**

a pointer to a `YLed` object, corresponding to a led currently online, or a `null` pointer if there are no more leds to enumerate.

---

**led→registerValueCallback()  
led.registerValueCallback()**

---

YLed

Registers the callback function that is invoked on every change of advertised value.

```
function registerValueCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

**led**→**set\_blinking()**

**YLed**

**led**→**setBlinking()****led.set\_blinking()**

---

Changes the current led signaling mode.

```
function set_blinking( ByVal newval As Integer) As Integer
```

**Parameters :**

**newval** a value among Y\_BLINKING\_STILL, Y\_BLINKING\_RELAX, Y\_BLINKING\_AWARE, Y\_BLINKING\_RUN, Y\_BLINKING\_CALL and Y\_BLINKING\_PANIC corresponding to the current led signaling mode

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.



---

**led**→**set\_logicalName()****YLed****led**→**setLogicalName()****led.set\_logicalName()**

---

Changes the logical name of the led.

```
function set_logicalName( ByVal newval As String) As Integer
```

You can use `yCheckLogicalName( )` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash( )` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the led.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**led**→**set\_luminosity()**

**YLed**

**led**→**setLuminosity()****led.set\_luminosity()**

---

Changes the current led intensity (in per cent).

```
function set_luminosity( ByVal newval As Integer) As Integer
```

**Parameters :**

**newval** an integer corresponding to the current led intensity (in per cent)

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**led**→**set\_power()****YLed****led**→**setPower()****led.set\_power()**

---

Changes the state of the led.

```
function set_power( ByVal newval As Integer) As Integer
```

**Parameters :**

**newval** either Y\_POWER\_OFF or Y\_POWER\_ON, according to the state of the led

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**led**→**set\_userData()**

**YLed**

**led**→**setUserData()****led.set\_userData()**

---

Stores a user context provided as argument in the `userData` attribute of the function.

```
procedure set_userData( ByVal data As Object)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

## 3.23. LightSensor function interface

The Yoctopuce application programming interface allows you to read an instant measure of the sensor, as well as the minimal and maximal values observed.

In order to use the functions described here, you should include:

js	<script type='text/javascript' src='yocto_lightsensor.js'></script>
nodejs	var yoctolib = require('yoctolib'); var YLightSensor = yoctolib.YLightSensor;
php	require_once('yocto_lightsensor.php');
cpp	#include "yocto_lightsensor.h"
m	#import "yocto_lightsensor.h"
pas	uses yocto_lightsensor;
vb	yocto_lightsensor.vb
cs	yocto_lightsensor.cs
java	import com.yoctopuce.YoctoAPI.YLightSensor;
py	from yocto_lightsensor import *

### Global functions

#### yFindLightSensor(func)

Retrieves a light sensor for a given identifier.

#### yFirstLightSensor()

Starts the enumeration of light sensors currently accessible.

### YLightSensor methods

#### lightsensor→calibrate(calibratedVal)

Changes the sensor-specific calibration parameter so that the current value matches a desired target (linear scaling).

#### lightsensor→calibrateFromPoints(rawValues, refValues)

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

#### lightsensor→describe()

Returns a short text that describes unambiguously the instance of the light sensor in the form TYPE (NAME) =SERIAL.FUNCTIONID.

#### lightsensor→get\_advertisedValue()

Returns the current value of the light sensor (no more than 6 characters).

#### lightsensor→get\_currentRawValue()

Returns the uncalibrated, unrounded raw value returned by the sensor, in lux, as a floating point number.

#### lightsensor→get\_currentValue()

Returns the current value of the ambient light, in lux, as a floating point number.

#### lightsensor→get\_errorMessage()

Returns the error message of the latest error with the light sensor.

#### lightsensor→get\_errorType()

Returns the numerical error code of the latest error with the light sensor.

#### lightsensor→get\_friendlyName()

Returns a global identifier of the light sensor in the format MODULE\_NAME.FUNCTION\_NAME.

#### lightsensor→get\_functionDescriptor()

Returns a unique identifier of type YFUN\_DESCR corresponding to the function.

#### lightsensor→get\_functionId()

	Returns the hardware identifier of the light sensor, without reference to the module.
<b>lightsensor</b> → <b>get_hardwareId()</b>	Returns the unique hardware identifier of the light sensor in the form <code>SERIAL.FUNCTIONID</code> .
<b>lightsensor</b> → <b>get_highestValue()</b>	Returns the maximal value observed for the ambient light since the device was started.
<b>lightsensor</b> → <b>get_logFrequency()</b>	Returns the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory.
<b>lightsensor</b> → <b>get_logicalName()</b>	Returns the logical name of the light sensor.
<b>lightsensor</b> → <b>get_lowestValue()</b>	Returns the minimal value observed for the ambient light since the device was started.
<b>lightsensor</b> → <b>get_measureType()</b>	Returns the type of light measure.
<b>lightsensor</b> → <b>get_module()</b>	Gets the <code>YModule</code> object for the device on which the function is located.
<b>lightsensor</b> → <b>get_module_async(callback, context)</b>	Gets the <code>YModule</code> object for the device on which the function is located (asynchronous version).
<b>lightsensor</b> → <b>get_recordedData(startTime, endTime)</b>	Retrieves a <code>DataSet</code> object holding historical data for this sensor, for a specified time interval.
<b>lightsensor</b> → <b>get_reportFrequency()</b>	Returns the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function.
<b>lightsensor</b> → <b>get_resolution()</b>	Returns the resolution of the measured values.
<b>lightsensor</b> → <b>get_unit()</b>	Returns the measuring unit for the ambient light.
<b>lightsensor</b> → <b>get_userData()</b>	Returns the value of the <code>userData</code> attribute, as previously stored using method <code>set_userData</code> .
<b>lightsensor</b> → <b>isOnline()</b>	Checks if the light sensor is currently reachable, without raising any error.
<b>lightsensor</b> → <b>isOnline_async(callback, context)</b>	Checks if the light sensor is currently reachable, without raising any error (asynchronous version).
<b>lightsensor</b> → <b>load(msValidity)</b>	Preloads the light sensor cache with a specified validity duration.
<b>lightsensor</b> → <b>loadCalibrationPoints(rawValues, refValues)</b>	Retrieves error correction data points previously entered using the method <code>calibrateFromPoints</code> .
<b>lightsensor</b> → <b>load_async(msValidity, callback, context)</b>	Preloads the light sensor cache with a specified validity duration (asynchronous version).
<b>lightsensor</b> → <b>nextLightSensor()</b>	Continues the enumeration of light sensors started using <code>yFirstLightSensor()</code> .
<b>lightsensor</b> → <b>registerTimedReportCallback(callback)</b>	Registers the callback function that is invoked on every periodic timed notification.
<b>lightsensor</b> → <b>registerValueCallback(callback)</b>	Registers the callback function that is invoked on every change of advertised value.
<b>lightsensor</b> → <b>set_highestValue(newval)</b>	

Changes the recorded maximal value observed.

**lightsensor**→**set\_logFrequency(newval)**

Changes the datalogger recording frequency for this function.

**lightsensor**→**set\_logicalName(newval)**

Changes the logical name of the light sensor.

**lightsensor**→**set\_lowestValue(newval)**

Changes the recorded minimal value observed.

**lightsensor**→**set\_measureType(newval)**

Modify the light sensor type used in the device.

**lightsensor**→**set\_reportFrequency(newval)**

Changes the timed value notification frequency for this function.

**lightsensor**→**set\_resolution(newval)**

Changes the resolution of the measured physical values.

**lightsensor**→**set\_userData(data)**

Stores a user context provided as argument in the userData attribute of the function.

**lightsensor**→**wait\_async(callback, context)**

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.

## YLightSensor.FindLightSensor() yFindLightSensor()yFindLightSensor()

YLightSensor

Retrieves a light sensor for a given identifier.

```
function yFindLightSensor( ByVal func As String) As YLightSensor
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the light sensor is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YLightSensor.IsOnline()` to test if the light sensor is indeed online at a given time. In case of ambiguity when looking for a light sensor by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

**Parameters :**

**func** a string that uniquely characterizes the light sensor

**Returns :**

a `YLightSensor` object allowing you to drive the light sensor.



---

**YLightSensor.FirstLightSensor()  
yFirstLightSensor()yFirstLightSensor()**

---

**YLightSensor**

Starts the enumeration of light sensors currently accessible.

```
function yFirstLightSensor( ) As YLightSensor
```

Use the method `YLightSensor.NextLightSensor( )` to iterate on next light sensors.

**Returns :**

a pointer to a `YLightSensor` object, corresponding to the first light sensor currently online, or a `null` pointer if there are none.

## lightsensor→calibrate()lightsensor.calibrate()

YLightSensor

Changes the sensor-specific calibration parameter so that the current value matches a desired target (linear scaling).

```
function calibrate( ByVal calibratedVal As Double) As Integer
```

### Parameters :

**calibratedVal** the desired target value.

### Returns :

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**lightsensor**→**calibrateFromPoints()**  
**lightsensor.calibrateFromPoints()****YLightSensor**

---

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

**procedure** **calibrateFromPoints()**

It is possible to configure up to five correction points. Correction points must be provided in ascending order, and be in the range of the sensor. The device will automatically perform a linear interpolation of the error correction between specified points. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

For more information on advanced capabilities to refine the calibration of sensors, please contact [support@yoctopuce.com](mailto:support@yoctopuce.com).

**Parameters :**

**rawValues** array of floating point numbers, corresponding to the raw values returned by the sensor for the correction points.

**refValues** array of floating point numbers, corresponding to the corrected values for the correction points.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**lightsensor**→**describe()**lightsensor.describe()**YLightSensor**

Returns a short text that describes unambiguously the instance of the light sensor in the form `TYPE (NAME) =SERIAL.FUNCTIONID`.

function **describe**( ) As String

More precisely, `TYPE` is the type of the function, `NAME` it the name used for the first access to the function, `SERIAL` is the serial number of the module if the module is connected or "unresolved", and `FUNCTIONID` is the hardware identifier of the function if the module is connected. For example, this method returns `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1` if the module is already connected or `Relay(BadCustomeName.relay1)=unresolved` if the module has not yet been connected. This method does not trigger any USB or TCP transaction and can therefore be used in a debugger.

**Returns :**

a string that describes the light sensor (ex: `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1`)

---

**lightsensor**→**get\_advertisedValue()****YLightSensor****lightsensor**→**advertisedValue()****lightsensor.get\_advertisedValue()**

---

Returns the current value of the light sensor (no more than 6 characters).

```
function get_advertisedValue( ) As String
```

**Returns :**

a string corresponding to the current value of the light sensor (no more than 6 characters).

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

**lightsensor**→**get\_currentRawValue()**

**YLightSensor**

**lightsensor**→**currentRawValue()**

**lightsensor.get\_currentRawValue()**

---

Returns the uncalibrated, unrounded raw value returned by the sensor, in lux, as a floating point number.

```
function get_currentRawValue( ) As Double
```

**Returns :**

a floating point number corresponding to the uncalibrated, unrounded raw value returned by the sensor, in lux, as a floating point number

On failure, throws an exception or returns `Y_CURRENTRAWVALUE_INVALID`.

---

**lightsensor→get\_currentValue()****YLightSensor****lightsensor→currentValue()****lightsensor.get\_currentValue()**

---

Returns the current value of the ambient light, in lux, as a floating point number.

```
function get_currentValue( ) As Double
```

**Returns :**

a floating point number corresponding to the current value of the ambient light, in lux, as a floating point number

On failure, throws an exception or returns `Y_CURRENTVALUE_INVALID`.

**lightsensor→get\_errorMessage()**

**YLightSensor**

**lightsensor→errorMessage()**

**lightsensor.get\_errorMessage()**

---

Returns the error message of the latest error with the light sensor.

```
function get_errorMessage( ) As String
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using the light sensor object



---

**lightsensor**→**get\_errorType()****YLightSensor****lightsensor**→**errorType()****lightsensor.get\_errorType()**

---

Returns the numerical error code of the latest error with the light sensor.

```
function get_errorType( ) As YRETCODE
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using the light sensor object

**lightsensor**→**get\_functionDescriptor()**  
**lightsensor**→**functionDescriptor()**  
**lightsensor.get\_functionDescriptor()**

---

**YLightSensor**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

```
function get_functionDescriptor( ) As YFUN_DESCR
```

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`.

If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

---

**lightsensor**→**get\_functionId()****YLightSensor****lightsensor**→**functionId()****lightsensor.get\_functionId()**

---

Returns the hardware identifier of the light sensor, without reference to the module.

function **get\_functionId**( ) As String

For example `relay1`

**Returns :**

a string that identifies the light sensor (ex: `relay1`)

On failure, throws an exception or returns `Y_FUNCTIONID_INVALID`.

**lightsensor→get\_hardwareId()**

**YLightSensor**

**lightsensor→hardwareId()**

**lightsensor.get\_hardwareId()**

---

Returns the unique hardware identifier of the light sensor in the form `SERIAL.FUNCTIONID`.

```
function get_hardwareId( ) As String
```

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the light sensor (for example `RELAYLO1-123456.relay1`).

**Returns :**

a string that uniquely identifies the light sensor (ex: `RELAYLO1-123456.relay1`)

On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

---

**lightsensor→get\_highestValue()****YLightSensor****lightsensor→highestValue()****lightsensor.get\_highestValue()**

---

Returns the maximal value observed for the ambient light since the device was started.

```
function get_highestValue( ) As Double
```

**Returns :**

a floating point number corresponding to the maximal value observed for the ambient light since the device was started

On failure, throws an exception or returns Y\_HIGHESTVALUE\_INVALID.

lightsensor→get\_logFrequency()

YLightSensor

lightsensor→logFrequency()

lightsensor.get\_logFrequency()

---

Returns the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory.

```
function get_logFrequency( ) As String
```

**Returns :**

a string corresponding to the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory

On failure, throws an exception or returns Y\_LOGFREQUENCY\_INVALID.

---

**lightsensor**→**get\_logicalName()****YLightSensor****lightsensor**→**logicalName()****lightsensor.get\_logicalName()**

---

Returns the logical name of the light sensor.

```
function get_logicalName( ) As String
```

**Returns :**

a string corresponding to the logical name of the light sensor.

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

lightsensor→get\_lowestValue()

YLightSensor

lightsensor→lowestValue()

lightsensor.get\_lowestValue()

---

Returns the minimal value observed for the ambient light since the device was started.

```
function get_lowestValue( ) As Double
```

**Returns :**

a floating point number corresponding to the minimal value observed for the ambient light since the device was started

On failure, throws an exception or returns Y\_LOWESTVALUE\_INVALID.



---

**lightsensor**→**get\_measureType()**  
**lightsensor**→**measureType()**  
**lightsensor.get\_measureType()**

---

**YLightSensor**

Returns the type of light measure.

```
function get_measureType( ) As Integer
```

**Returns :**

a value among `Y_MEASURETYPE_HUMAN_EYE`, `Y_MEASURETYPE_WIDE_SPECTRUM`, `Y_MEASURETYPE_INFRARED`, `Y_MEASURETYPE_HIGH_RATE` and `Y_MEASURETYPE_HIGH_ENERGY` corresponding to the type of light measure

On failure, throws an exception or returns `Y_MEASURETYPE_INVALID`.

**lightsensor→get\_module()**

**YLightSensor**

**lightsensor→module()lightsensor.get\_module()**

---

Gets the YModule object for the device on which the function is located.

function **get\_module()** As YModule

If the function cannot be located on any module, the returned instance of YModule is not shown as on-line.

**Returns :**

an instance of YModule

---

**lightsensor→get\_recordedData()****YLightSensor****lightsensor→recordedData()****lightsensor.get\_recordedData()**

---

Retrieves a DataSet object holding historical data for this sensor, for a specified time interval.

```
function get_recordedData( ) As YDataSet
```

The measures will be retrieved from the data logger, which must have been turned on at the desired time. See the documentation of the DataSet class for information on how to get an overview of the recorded data, and how to load progressively a large set of measures from the data logger.

This function only works if the device uses a recent firmware, as DataSet objects are not supported by firmwares older than version 13000.

**Parameters :**

**startTime** the start of the desired measure time interval, as a Unix timestamp, i.e. the number of seconds since January 1, 1970 UTC. The special value 0 can be used to include any meaasure, without initial limit.

**endTime** the end of the desired measure time interval, as a Unix timestamp, i.e. the number of seconds since January 1, 1970 UTC. The special value 0 can be used to include any meaasure, without ending limit.

**Returns :**

an instance of YDataSet, providing access to historical data. Past measures can be loaded progressively using methods from the YDataSet object.

lightsensor→get\_reportFrequency()

YLightSensor

lightsensor→reportFrequency()

lightsensor.get\_reportFrequency()

---

Returns the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function.

```
function get_reportFrequency( ) As String
```

**Returns :**

a string corresponding to the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function

On failure, throws an exception or returns Y\_REPORTFREQUENCY\_INVALID.

---

**lightsensor**→**get\_resolution()****YLightSensor****lightsensor**→**resolution()****lightsensor.get\_resolution()**

---

Returns the resolution of the measured values.

```
function get_resolution( ) As Double
```

The resolution corresponds to the numerical precision of the measures, which is not always the same as the actual precision of the sensor.

**Returns :**

a floating point number corresponding to the resolution of the measured values

On failure, throws an exception or returns `Y_RESOLUTION_INVALID`.

lightsensor→get\_unit()

YLightSensor

lightsensor→unit()lightsensor.get\_unit()

---

Returns the measuring unit for the ambient light.

function `get_unit( )` As String

**Returns :**

a string corresponding to the measuring unit for the ambient light

On failure, throws an exception or returns `Y_UNIT_INVALID`.

---

**lightsensor**→**get\_userData()****YLightSensor****lightsensor**→**userData()****lightsensor.get\_userData()**

---

Returns the value of the userData attribute, as previously stored using method `set_userData`.

function **get\_userData**( ) As Object

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

## lightsensor→isOnline()lightsensor.isOnline()

YLightSensor

---

Checks if the light sensor is currently reachable, without raising any error.

```
function isOnline( ) As Boolean
```

If there is a cached value for the light sensor in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the light sensor.

**Returns :**

`true` if the light sensor can be reached, and `false` otherwise



**lightsensor**→**load()****lightsensor.load()****YLightSensor**

Preloads the light sensor cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

**lightsensor→loadCalibrationPoints()  
lightsensor.loadCalibrationPoints()**

**YLightSensor**

Retrieves error correction data points previously entered using the method `calibrateFromPoints`.

procedure **loadCalibrationPoints( )**

**Parameters :**

**rawValues** array of floating point numbers, that will be filled by the function with the raw sensor values for the correction points.

**refValues** array of floating point numbers, that will be filled by the function with the desired values for the correction points.

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**lightsensor**→**nextLightSensor()**  
**lightsensor.nextLightSensor()**

---

**YLightSensor**

Continues the enumeration of light sensors started using `yFirstLightSensor()`.

```
function nextLightSensor( ) As YLightSensor
```

**Returns :**

a pointer to a `YLightSensor` object, corresponding to a light sensor currently online, or a `null` pointer if there are no more light sensors to enumerate.

**lightsensor**→**registerTimedReportCallback()**  
**lightsensor.registerTimedReportCallback()**

**YLightSensor**

---

Registers the callback function that is invoked on every periodic timed notification.

```
function registerTimedReportCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and an `YMeasure` object describing the new advertised value.

---

**lightsensor**→**registerValueCallback()**  
**lightsensor.registerValueCallback()**

---

**YLightSensor**

Registers the callback function that is invoked on every change of advertised value.

```
function registerValueCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

**lightsensor**→**set\_highestValue()**  
**lightsensor**→**setHighestValue()**  
**lightsensor.set\_highestValue()**

---

**YLightSensor**

Changes the recorded maximal value observed.

```
function set_highestValue( ByVal newval As Double) As Integer
```

**Parameters :**

**newval** a floating point number corresponding to the recorded maximal value observed

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**lightsensor**→**set\_logFrequency()****YLightSensor****lightsensor**→**setLogFrequency()****lightsensor.set\_logFrequency()**

---

Changes the datalogger recording frequency for this function.

```
function set_logFrequency( ByVal newval As String) As Integer
```

The frequency can be specified as samples per second, as sample per minute (for instance "15/m") or in samples per hour (eg. "4/h"). To disable recording for this function, use the value "OFF".

**Parameters :**

**newval** a string corresponding to the datalogger recording frequency for this function

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**lightsensor**→**set\_logicalName()**

**YLightSensor**

**lightsensor**→**setLogicalName()**

**lightsensor.set\_logicalName()**

---

Changes the logical name of the light sensor.

```
function set_logicalName( ByVal newval As String) As Integer
```

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the light sensor.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.



---

**lightsensor**→**set\_lowestValue()****YLightSensor****lightsensor**→**setLowestValue()****lightsensor.set\_lowestValue()**

---

Changes the recorded minimal value observed.

```
function set_lowestValue( ByVal newval As Double) As Integer
```

**Parameters :**

**newval** a floating point number corresponding to the recorded minimal value observed

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**lightsensor**→**set\_measureType()****YLightSensor****lightsensor**→**setMeasureType()****lightsensor.set\_measureType()**

Modify the light sensor type used in the device.

```
function set_measureType( ByVal newval As Integer) As Integer
```

The measure can either approximate the response of the human eye, focus on a specific light spectrum, depending on the capabilities of the light-sensitive cell. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a value among `Y_MEASURETYPE_HUMAN_EYE`, `Y_MEASURETYPE_WIDE_SPECTRUM`, `Y_MEASURETYPE_INFRARED`, `Y_MEASURETYPE_HIGH_RATE` and `Y_MEASURETYPE_HIGH_ENERGY`

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**lightsensor**→**set\_reportFrequency()****YLightSensor****lightsensor**→**setReportFrequency()****lightsensor.set\_reportFrequency()**

---

Changes the timed value notification frequency for this function.

```
function set_reportFrequency( ByVal newval As String) As Integer
```

The frequency can be specified as samples per second, as sample per minute (for instance "15/m") or in samples per hour (eg. "4/h"). To disable timed value notifications for this function, use the value "OFF".

**Parameters :**

**newval** a string corresponding to the timed value notification frequency for this function

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**lightsensor→set\_resolution()**  
**lightsensor→setResolution()**  
**lightsensor.set\_resolution()**

**YLightSensor**

---

Changes the resolution of the measured physical values.

```
function set_resolution( ByVal newval As Double) As Integer
```

The resolution corresponds to the numerical precision when displaying value. It does not change the precision of the measure itself.

**Parameters :**

**newval** a floating point number corresponding to the resolution of the measured physical values

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**lightsensor→set\_userdata()****YLightSensor****lightsensor→setUserData()****lightsensor.set\_userdata()**

---

Stores a user context provided as argument in the `userData` attribute of the function.

```
procedure set_userdata( ByVal data As Object)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

## 3.24. Magnetometer function interface

The Yoctopuce application programming interface allows you to read an instant measure of the sensor, as well as the minimal and maximal values observed.

In order to use the functions described here, you should include:

js	<script type='text/javascript' src='yocto_magnetometer.js'></script>
nodejs	var yoctolib = require('yoctolib'); var YMagnetometer = yoctolib.YMagnetometer;
php	require_once('yocto_magnetometer.php');
c++	#include "yocto_magnetometer.h"
m	#import "yocto_magnetometer.h"
pas	uses yocto_magnetometer;
vb	yocto_magnetometer.vb
cs	yocto_magnetometer.cs
java	import com.yoctopuce.YoctoAPI.YMagnetometer;
py	from yocto_magnetometer import *

### Global functions

#### yFindMagnetometer(func)

Retrieves a magnetometer for a given identifier.

#### yFirstMagnetometer()

Starts the enumeration of magnetometers currently accessible.

### YMagnetometer methods

#### magnetometer→calibrateFromPoints(rawValues, refValues)

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

#### magnetometer→describe()

Returns a short text that describes unambiguously the instance of the magnetometer in the form `TYPE ( NAME ) = SERIAL . FUNCTIONID`.

#### magnetometer→get\_advertisedValue()

Returns the current value of the magnetometer (no more than 6 characters).

#### magnetometer→get\_currentRawValue()

Returns the uncalibrated, unrounded raw value returned by the sensor, in mT, as a floating point number.

#### magnetometer→get\_currentValue()

Returns the current value of the magnetic field, in mT, as a floating point number.

#### magnetometer→get\_errorMessage()

Returns the error message of the latest error with the magnetometer.

#### magnetometer→get\_errorType()

Returns the numerical error code of the latest error with the magnetometer.

#### magnetometer→get\_friendlyName()

Returns a global identifier of the magnetometer in the format `MODULE_NAME . FUNCTION_NAME`.

#### magnetometer→get\_functionDescriptor()

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

#### magnetometer→get\_functionId()

Returns the hardware identifier of the magnetometer, without reference to the module.

#### magnetometer→get\_hardwareId()

Returns the unique hardware identifier of the magnetometer in the form `SERIAL . FUNCTIONID`.

**magnetometer→get\_highestValue()**

Returns the maximal value observed for the magnetic field since the device was started.

**magnetometer→get\_logFrequency()**

Returns the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory.

**magnetometer→get\_logicalName()**

Returns the logical name of the magnetometer.

**magnetometer→get\_lowestValue()**

Returns the minimal value observed for the magnetic field since the device was started.

**magnetometer→get\_module()**

Gets the YModule object for the device on which the function is located.

**magnetometer→get\_module\_async(callback, context)**

Gets the YModule object for the device on which the function is located (asynchronous version).

**magnetometer→get\_recordedData(startTime, endTime)**

Retrieves a DataSet object holding historical data for this sensor, for a specified time interval.

**magnetometer→get\_reportFrequency()**

Returns the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function.

**magnetometer→get\_resolution()**

Returns the resolution of the measured values.

**magnetometer→get\_unit()**

Returns the measuring unit for the magnetic field.

**magnetometer→get\_userData()**

Returns the value of the userData attribute, as previously stored using method set\_userData.

**magnetometer→get\_xValue()**

Returns the X component of the magnetic field, as a floating point number.

**magnetometer→get\_yValue()**

Returns the Y component of the magnetic field, as a floating point number.

**magnetometer→get\_zValue()**

Returns the Z component of the magnetic field, as a floating point number.

**magnetometer→isOnline()**

Checks if the magnetometer is currently reachable, without raising any error.

**magnetometer→isOnline\_async(callback, context)**

Checks if the magnetometer is currently reachable, without raising any error (asynchronous version).

**magnetometer→load(msValidity)**

Preloads the magnetometer cache with a specified validity duration.

**magnetometer→loadCalibrationPoints(rawValues, refValues)**

Retrieves error correction data points previously entered using the method calibrateFromPoints.

**magnetometer→load\_async(msValidity, callback, context)**

Preloads the magnetometer cache with a specified validity duration (asynchronous version).

**magnetometer→nextMagnetometer()**

Continues the enumeration of magnetometers started using yFirstMagnetometer().

**magnetometer→registerTimedReportCallback(callback)**

Registers the callback function that is invoked on every periodic timed notification.

**magnetometer→registerValueCallback(callback)**

Registers the callback function that is invoked on every change of advertised value.

### 3. Reference

---

**magnetometer**→**set\_highestValue(newval)**

Changes the recorded maximal value observed.

**magnetometer**→**set\_logFrequency(newval)**

Changes the datalogger recording frequency for this function.

**magnetometer**→**set\_logicalName(newval)**

Changes the logical name of the magnetometer.

**magnetometer**→**set\_lowestValue(newval)**

Changes the recorded minimal value observed.

**magnetometer**→**set\_reportFrequency(newval)**

Changes the timed value notification frequency for this function.

**magnetometer**→**set\_resolution(newval)**

Changes the resolution of the measured physical values.

**magnetometer**→**set\_userData(data)**

Stores a user context provided as argument in the userData attribute of the function.

**magnetometer**→**wait\_async(callback, context)**

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.



## YMagnetometer.FindMagnetometer() yFindMagnetometer()yFindMagnetometer()

## YMagnetometer

Retrieves a magnetometer for a given identifier.

```
function yFindMagnetometer( ByVal func As String) As YMagnetometer
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the magnetometer is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YMagnetometer.isOnline()` to test if the magnetometer is indeed online at a given time. In case of ambiguity when looking for a magnetometer by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

### Parameters :

**func** a string that uniquely characterizes the magnetometer

### Returns :

a `YMagnetometer` object allowing you to drive the magnetometer.

## **YMagnetometer.FirstMagnetometer() yFirstMagnetometer()yFirstMagnetometer()**

---

**YMagnetometer**

Starts the enumeration of magnetometers currently accessible.

```
function yFirstMagnetometer( ) As YMagnetometer
```

Use the method `YMagnetometer.nextMagnetometer()` to iterate on next magnetometers.

**Returns :**

a pointer to a `YMagnetometer` object, corresponding to the first magnetometer currently online, or a `null` pointer if there are none.

---

**magnetometer**→**calibrateFromPoints()**  
**magnetometer.calibrateFromPoints()****YMagnetometer**

---

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

**procedure** **calibrateFromPoints()**

It is possible to configure up to five correction points. Correction points must be provided in ascending order, and be in the range of the sensor. The device will automatically perform a linear interpolation of the error correction between specified points. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

For more information on advanced capabilities to refine the calibration of sensors, please contact [support@yoctopuce.com](mailto:support@yoctopuce.com).

**Parameters :**

**rawValues** array of floating point numbers, corresponding to the raw values returned by the sensor for the correction points.

**refValues** array of floating point numbers, corresponding to the corrected values for the correction points.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**magnetometer**→**describe()**(magnetometer.describe())**YMagnetometer**

Returns a short text that describes unambiguously the instance of the magnetometer in the form `TYPE (NAME) =SERIAL . FUNCTIONID`.

function **describe**( ) As String

More precisely, `TYPE` is the type of the function, `NAME` it the name used for the first access to the function, `SERIAL` is the serial number of the module if the module is connected or "unresolved", and `FUNCTIONID` is the hardware identifier of the function if the module is connected. For example, this method returns `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1` if the module is already connected or `Relay(BadCustomeName.relay1)=unresolved` if the module has not yet been connected. This method does not trigger any USB or TCP transaction and can therefore be used in a debugger.

**Returns :**

a string that describes the magnetometer (ex: `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1`)

---

**magnetometer**→**get\_advertisedValue()**

**YMagnetometer**

**magnetometer**→**advertisedValue()**

**magnetometer.get\_advertisedValue()**

---

Returns the current value of the magnetometer (no more than 6 characters).

```
function get_advertisedValue( ) As String
```

**Returns :**

a string corresponding to the current value of the magnetometer (no more than 6 characters).

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

**magnetometer→get\_currentRawValue()**

**YMagnetometer**

**magnetometer→currentRawValue()**

**magnetometer.get\_currentRawValue()**

---

Returns the uncalibrated, unrounded raw value returned by the sensor, in mT, as a floating point number.

```
function get_currentRawValue( ) As Double
```

**Returns :**

a floating point number corresponding to the uncalibrated, unrounded raw value returned by the sensor, in mT, as a floating point number

On failure, throws an exception or returns `Y_CURRENTRAWVALUE_INVALID`.

---

**magnetometer**→**get\_currentValue()****YMagnetometer****magnetometer**→**currentValue()****magnetometer.get\_currentValue()**

---

Returns the current value of the magnetic field, in mT, as a floating point number.

```
function get_currentValue( ) As Double
```

**Returns :**

a floating point number corresponding to the current value of the magnetic field, in mT, as a floating point number

On failure, throws an exception or returns `Y_CURRENTVALUE_INVALID`.

**magnetometer→get\_errorMessage()**

**YMagnetometer**

**magnetometer→errorMessage()**

**magnetometer.get\_errorMessage()**

---

Returns the error message of the latest error with the magnetometer.

```
function get_errorMessage( ) As String
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using the magnetometer object



---

**magnetometer**→**get\_errorType()****YMagnetometer****magnetometer**→**errorType()****magnetometer.get\_errorType()**

---

Returns the numerical error code of the latest error with the magnetometer.

```
function get_errorType( ) As YRETCODE
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using the magnetometer object

**magnetometer**→**get\_functionDescriptor()**

**YMagnetometer**

**magnetometer**→**functionDescriptor()**

**magnetometer.get\_functionDescriptor()**

---

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

`function get_functionDescriptor( )` As `YFUN_DESCR`

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`.

If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

---

**magnetometer**→**get\_functionId()**  
**magnetometer**→**functionId()**  
**magnetometer.get\_functionId()**

---

**YMagnetometer**

Returns the hardware identifier of the magnetometer, without reference to the module.

```
function get_functionId( ) As String
```

For example `relay1`

**Returns :**

a string that identifies the magnetometer (ex: `relay1`)

On failure, throws an exception or returns `Y_FUNCTIONID_INVALID`.

magnetometer→get\_hardwareId()

YMagnetometer

magnetometer→hardwareId()

magnetometer.get\_hardwareId()

---

Returns the unique hardware identifier of the magnetometer in the form SERIAL.FUNCTIONID.

```
function get_hardwareId( ) As String
```

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the magnetometer (for example RELAYLO1-123456.relay1).

**Returns :**

a string that uniquely identifies the magnetometer (ex: RELAYLO1-123456.relay1)

On failure, throws an exception or returns Y\_HARDWAREID\_INVALID.

---

**magnetometer**→**get\_highestValue()****YMagnetometer****magnetometer**→**highestValue()****magnetometer.get\_highestValue()**

---

Returns the maximal value observed for the magnetic field since the device was started.

```
function get_highestValue( ) As Double
```

**Returns :**

a floating point number corresponding to the maximal value observed for the magnetic field since the device was started

On failure, throws an exception or returns `Y_HIGHESTVALUE_INVALID`.

magnetometer→get\_logFrequency()

YMagnetometer

magnetometer→logFrequency()

magnetometer.get\_logFrequency()

---

Returns the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory.

function **get\_logFrequency**( ) As String

**Returns :**

a string corresponding to the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory

On failure, throws an exception or returns Y\_LOGFREQUENCY\_INVALID.

---

**magnetometer**→**get\_logicalName()****YMagnetometer****magnetometer**→**logicalName()****magnetometer.get\_logicalName()**

---

Returns the logical name of the magnetometer.

```
function get_logicalName( ) As String
```

**Returns :**

a string corresponding to the logical name of the magnetometer.

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

magnetometer→get\_lowestValue()

YMagnetometer

magnetometer→lowestValue()

magnetometer.get\_lowestValue()

---

Returns the minimal value observed for the magnetic field since the device was started.

```
function get_lowestValue( ) As Double
```

**Returns :**

a floating point number corresponding to the minimal value observed for the magnetic field since the device was started

On failure, throws an exception or returns Y\_LOWESTVALUE\_INVALID.



---

**magnetometer**→**get\_module()**  
**magnetometer**→**module()**  
**magnetometer.get\_module()**

---

**YMagnetometer**

Gets the `YModule` object for the device on which the function is located.

```
function get_module( ) As YModule
```

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

**Returns :**

an instance of `YModule`

**magnetometer**→**get\_recordedData()**

**YMagnetometer**

**magnetometer**→**recordedData()**

**magnetometer.get\_recordedData()**

---

Retrieves a DataSet object holding historical data for this sensor, for a specified time interval.

```
function get_recordedData( ) As YDataSet
```

The measures will be retrieved from the data logger, which must have been turned on at the desired time. See the documentation of the DataSet class for information on how to get an overview of the recorded data, and how to load progressively a large set of measures from the data logger.

This function only works if the device uses a recent firmware, as DataSet objects are not supported by firmwares older than version 13000.

**Parameters :**

**startTime** the start of the desired measure time interval, as a Unix timestamp, i.e. the number of seconds since January 1, 1970 UTC. The special value 0 can be used to include any measure, without initial limit.

**endTime** the end of the desired measure time interval, as a Unix timestamp, i.e. the number of seconds since January 1, 1970 UTC. The special value 0 can be used to include any measure, without ending limit.

**Returns :**

an instance of YDataSet, providing access to historical data. Past measures can be loaded progressively using methods from the YDataSet object.

---

**magnetometer**→**get\_reportFrequency()****YMagnetometer****magnetometer**→**reportFrequency()****magnetometer.get\_reportFrequency()**

---

Returns the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function.

```
function get_reportFrequency( ) As String
```

**Returns :**

a string corresponding to the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function

On failure, throws an exception or returns `Y_REPORTFREQUENCY_INVALID`.

magnetometer→get\_resolution()

YMagnetometer

magnetometer→resolution()

magnetometer.get\_resolution()

---

Returns the resolution of the measured values.

```
function get_resolution( ) As Double
```

The resolution corresponds to the numerical precision of the measures, which is not always the same as the actual precision of the sensor.

**Returns :**

a floating point number corresponding to the resolution of the measured values

On failure, throws an exception or returns Y\_RESOLUTION\_INVALID.

---

**magnetometer**→**get\_unit()****YMagnetometer****magnetometer**→**unit()****magnetometer.get\_unit()**

---

Returns the measuring unit for the magnetic field.

function **get\_unit()** As String

**Returns :**

a string corresponding to the measuring unit for the magnetic field

On failure, throws an exception or returns `Y_UNIT_INVALID`.

**magnetometer**→**get\_userData()**

**YMagnetometer**

**magnetometer**→**userData()**

**magnetometer.userData()**

---

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

```
function get_userData( ) As Object
```

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

---

**magnetometer**→**get\_xValue()****YMagnetometer****magnetometer**→**xValue()****magnetometer.get\_xValue()**

---

Returns the X component of the magnetic field, as a floating point number.

function **get\_xValue()** As Double

**Returns :**

a floating point number corresponding to the X component of the magnetic field, as a floating point number

On failure, throws an exception or returns `Y_XVALUE_INVALID`.

magnetometer→get\_yValue()

YMagnetometer

magnetometer→yValue()magnetometer.get\_yValue()

---

Returns the Y component of the magnetic field, as a floating point number.

function get\_yValue( ) As Double

**Returns :**

a floating point number corresponding to the Y component of the magnetic field, as a floating point number

On failure, throws an exception or returns Y\_YVALUE\_INVALID.



---

**magnetometer**→**get\_zValue()****YMagnetometer****magnetometer**→**zValue()****magnetometer.get\_zValue()**

---

Returns the Z component of the magnetic field, as a floating point number.

function **get\_zValue( )** As Double

**Returns :**

a floating point number corresponding to the Z component of the magnetic field, as a floating point number

On failure, throws an exception or returns `Y_ZVALUE_INVALID`.

**magnetometer**→**isOnline()****magnetometer.isOnline()**

**YMagnetometer**

---

Checks if the magnetometer is currently reachable, without raising any error.

function **isOnline**( ) As Boolean

If there is a cached value for the magnetometer in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the magnetometer.

**Returns :**

`true` if the magnetometer can be reached, and `false` otherwise

**magnetometer**→**load()****magnetometer.load()****YMagnetometer**

Preloads the magnetometer cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

**magnetometer→loadCalibrationPoints()  
magnetometer.loadCalibrationPoints()**

**YMagnetometer**

Retrieves error correction data points previously entered using the method `calibrateFromPoints`.

procedure **loadCalibrationPoints( )**

**Parameters :**

**rawValues** array of floating point numbers, that will be filled by the function with the raw sensor values for the correction points.

**refValues** array of floating point numbers, that will be filled by the function with the desired values for the correction points.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**magnetometer**→**nextMagnetometer()**  
**magnetometer.nextMagnetometer()**

---

**YMagnetometer**

Continues the enumeration of magnetometers started using `yFirstMagnetometer()`.

```
function nextMagnetometer( ) As YMagnetometer
```

**Returns :**

a pointer to a `YMagnetometer` object, corresponding to a magnetometer currently online, or a `null` pointer if there are no more magnetometers to enumerate.

**magnetometer**→**registerTimedReportCallback()**  
**magnetometer.registerTimedReportCallback()**

**YMagnetometer**

---

Registers the callback function that is invoked on every periodic timed notification.

```
function registerTimedReportCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and an `YMeasure` object describing the new advertised value.

---

**magnetometer**→**registerValueCallback()**  
**magnetometer.registerValueCallback()**

---

**YMagnetometer**

Registers the callback function that is invoked on every change of advertised value.

```
function registerValueCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

magnetometer→set\_highestValue()

YMagnetometer

magnetometer→setHighestValue()

magnetometer.set\_highestValue()

---

Changes the recorded maximal value observed.

```
function set_highestValue( ByVal newval As Double) As Integer
```

**Parameters :**

**newval** a floating point number corresponding to the recorded maximal value observed

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.



**magnetometer**→**set\_logFrequency()**  
**magnetometer**→**setLogFrequency()**  
**magnetometer.set\_logFrequency()**

**YMagnetometer**

Changes the datalogger recording frequency for this function.

```
function set_logFrequency( ByVal newval As String) As Integer
```

The frequency can be specified as samples per second, as sample per minute (for instance "15/m") or in samples per hour (eg. "4/h"). To disable recording for this function, use the value "OFF".

**Parameters :**

**newval** a string corresponding to the datalogger recording frequency for this function

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**magnetometer**→**set\_logicalName()**

**YMagnetometer**

**magnetometer**→**setLogicalName()**

**magnetometer.set\_logicalName()**

---

Changes the logical name of the magnetometer.

```
function set_logicalName( ByVal newval As String) As Integer
```

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the magnetometer.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**magnetometer**→**set\_lowestValue()****YMagnetometer****magnetometer**→**setLowestValue()****magnetometer.set\_lowestValue()**

---

Changes the recorded minimal value observed.

```
function set_lowestValue( ByVal newval As Double) As Integer
```

**Parameters :**

**newval** a floating point number corresponding to the recorded minimal value observed

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**magnetometer→set\_reportFrequency()**

**YMagnetometer**

**magnetometer→setReportFrequency()**

**magnetometer.set\_reportFrequency()**

---

Changes the timed value notification frequency for this function.

```
function set_reportFrequency( ByVal newval As String) As Integer
```

The frequency can be specified as samples per second, as sample per minute (for instance "15/m") or in samples per hour (eg. "4/h"). To disable timed value notifications for this function, use the value "OFF".

**Parameters :**

**newval** a string corresponding to the timed value notification frequency for this function

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**magnetometer**→**set\_resolution()**  
**magnetometer**→**setResolution()**  
**magnetometer.set\_resolution()**

---

**YMagnetometer**

Changes the resolution of the measured physical values.

```
function set_resolution( ByVal newval As Double) As Integer
```

The resolution corresponds to the numerical precision when displaying value. It does not change the precision of the measure itself.

**Parameters :**

**newval** a floating point number corresponding to the resolution of the measured physical values

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**magnetometer→set\_userdata()**

**YMagnetometer**

**magnetometer→setUserData()**

**magnetometer.set\_userdata()**

---

Stores a user context provided as argument in the userData attribute of the function.

```
procedure set_userdata( ByVal data As Object)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

## 3.25. Measured value

YMeasure objects are used within the API to represent a value measured at a specified time. These objects are used in particular in conjunction with the YDataSet class.

In order to use the functions described here, you should include:

js	<script type='text/javascript' src='yocto_api.js'></script>
nodejs	var yoctolib = require('yoctolib'); var YAPI = yoctolib.YAPI; var YModule = yoctolib.YModule;
php	require_once('yocto_api.php');
cpp	#include "yocto_api.h"
m	#import "yocto_api.h"
pas	uses yocto_api;
vb	yocto_api.vb
cs	yocto_api.cs
java	import com.yoctopuce.YoctoAPI.YModule;
py	from yocto_api import *

### YMeasure methods

#### **measure**→**get\_averageValue()**

Returns the average value observed during the time interval covered by this measure.

#### **measure**→**get\_endTimeUTC()**

Returns the end time of the measure, relative to the Jan 1, 1970 UTC (Unix timestamp).

#### **measure**→**get\_maxValue()**

Returns the largest value observed during the time interval covered by this measure.

#### **measure**→**get\_minValue()**

Returns the smallest value observed during the time interval covered by this measure.

#### **measure**→**get\_startTimeUTC()**

Returns the start time of the measure, relative to the Jan 1, 1970 UTC (Unix timestamp).

**measure**→**get\_averageValue()**

**YMeasure**

**measure**→**averageValue()**

**measure.get\_averageValue()**

---

Returns the average value observed during the time interval covered by this measure.

function **get\_averageValue( )** As Double

**Returns :**

a floating-point number corresponding to the average value observed.



---

**measure**→**get\_endTimeUTC()****YMeasure****measure**→**endTimeUTC()****measure.get\_endTimeUTC()**

---

Returns the end time of the measure, relative to the Jan 1, 1970 UTC (Unix timestamp).

```
function get_endTimeUTC( ) As Double
```

When the recording rate is higher than 1 sample per second, the timestamp may have a fractional part.

**Returns :**

an floating point number corresponding to the number of seconds between the Jan 1, 1970 UTC and the end of this measure.

**measure**→**get\_maxValue()**

**YMeasure**

**measure**→**maxValue()****measure.get\_maxValue()**

---

Returns the largest value observed during the time interval covered by this measure.

function **get\_maxValue**( ) As Double

**Returns :**

a floating-point number corresponding to the largest value observed.

---

**measure**→**get\_minValue()****YMeasure****measure**→**minValue()****measure.get\_minValue()**

---

Returns the smallest value observed during the time interval covered by this measure.

function **get\_minValue**( ) As Double

**Returns :**

a floating-point number corresponding to the smallest value observed.

**measure**→**get\_startTimeUTC()**

**YMeasure**

**measure**→**startTimeUTC()**

**measure.get\_startTimeUTC()**

---

Returns the start time of the measure, relative to the Jan 1, 1970 UTC (Unix timestamp).

```
function get_startTimeUTC( ) As Double
```

When the recording rate is higher than 1 sample per second, the timestamp may have a fractional part.

**Returns :**

an floating point number corresponding to the number of seconds between the Jan 1, 1970 UTC and the beginning of this measure.

## 3.26. Module control interface

This interface is identical for all Yoctopuce USB modules. It can be used to control the module global parameters, and to enumerate the functions provided by each module.

In order to use the functions described here, you should include:

js	<script type='text/javascript' src='yocto_api.js'></script>
nodejs	var yoctolib = require('yoctolib'); var YAPI = yoctolib.YAPI; var YModule = yoctolib.YModule;
php	require_once('yocto_api.php');
cpp	#include "yocto_api.h"
m	#import "yocto_api.h"
pas	uses yocto_api;
vb	yocto_api.vb
cs	yocto_api.cs
java	import com.yoctopuce.YoctoAPI.YModule;
py	from yocto_api import *

### Global functions

#### **yFindModule(func)**

Allows you to find a module from its serial number or from its logical name.

#### **yFirstModule()**

Starts the enumeration of modules currently accessible.

### YModule methods

#### **module→checkFirmware(path, onlynew)**

Test if the byn file is valid for this module.

#### **module→describe()**

Returns a descriptive text that identifies the module.

#### **module→download(pathname)**

Downloads the specified built-in file and returns a binary buffer with its content.

#### **module→functionCount()**

Returns the number of functions (beside the "module" interface) available on the module.

#### **module→functionId(functionIndex)**

Retrieves the hardware identifier of the *n*th function on the module.

#### **module→functionName(functionIndex)**

Retrieves the logical name of the *n*th function on the module.

#### **module→functionValue(functionIndex)**

Retrieves the advertised value of the *n*th function on the module.

#### **module→get\_allSettings()**

Returns all the setting of the module.

#### **module→get\_beacon()**

Returns the state of the localization beacon.

#### **module→get\_errorMessage()**

Returns the error message of the latest error with this module object.

#### **module→get\_errorType()**

Returns the numerical error code of the latest error with this module object.

#### **module→get\_firmwareRelease()**

<code>module→get_firmwareVersion()</code>	Returns the version of the firmware embedded in the module.
<code>module→get_hardwareId()</code>	Returns the unique hardware identifier of the module.
<code>module→get_icon2d()</code>	Returns the icon of the module.
<code>module→get_lastLogs()</code>	Returns a string with last logs of the module.
<code>module→get_logicalName()</code>	Returns the logical name of the module.
<code>module→get_luminosity()</code>	Returns the luminosity of the module informative leds (from 0 to 100).
<code>module→get_persistentSettings()</code>	Returns the current state of persistent module settings.
<code>module→get_productId()</code>	Returns the USB device identifier of the module.
<code>module→get_productName()</code>	Returns the commercial name of the module, as set by the factory.
<code>module→get_productRelease()</code>	Returns the hardware release version of the module.
<code>module→get_rebootCountdown()</code>	Returns the remaining number of seconds before the module restarts, or zero when no reboot has been scheduled.
<code>module→get_serialNumber()</code>	Returns the serial number of the module, as set by the factory.
<code>module→get_upTime()</code>	Returns the number of milliseconds spent since the module was powered on.
<code>module→get_usbCurrent()</code>	Returns the current consumed by the module on the USB bus, in milli-amps.
<code>module→get_userData()</code>	Returns the value of the userData attribute, as previously stored using method <code>set_userData</code> .
<code>module→get_userVar()</code>	Returns the value previously stored in this attribute.
<code>module→isOnline()</code>	Checks if the module is currently reachable, without raising any error.
<code>module→isOnline_async(callback, context)</code>	Checks if the module is currently reachable, without raising any error.
<code>module→load(msValidity)</code>	Preloads the module cache with a specified validity duration.
<code>module→load_async(msValidity, callback, context)</code>	Preloads the module cache with a specified validity duration (asynchronous version).
<code>module→nextModule()</code>	Continues the module enumeration started using <code>yFirstModule()</code> .
<code>module→reboot(secBeforeReboot)</code>	Schedules a simple module reboot after the given number of seconds.
<code>module→registerLogCallback(callback)</code>	Registers a device log callback function.

**module**→**revertFromFlash()**

Reloads the settings stored in the nonvolatile memory, as when the module is powered on.

**module**→**saveToFlash()**

Saves current settings in the nonvolatile memory of the module.

**module**→**set\_allSettings(settings)**

Restore all the setting of the module.

**module**→**set\_beacon(newval)**

Turns on or off the module localization beacon.

**module**→**set\_logicalName(newval)**

Changes the logical name of the module.

**module**→**set\_luminosity(newval)**

Changes the luminosity of the module informative leds.

**module**→**set\_userData(data)**

Stores a user context provided as argument in the userData attribute of the function.

**module**→**set\_userVar(newval)**

Returns the value previously stored in this attribute.

**module**→**triggerFirmwareUpdate(secBeforeReboot)**

Schedules a module reboot into special firmware update mode.

**module**→**updateFirmware(path)**

Prepare a firmware upgrade of the module.

**module**→**wait\_async(callback, context)**

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.

**YModule.FindModule()  
yFindModule()yFindModule()****YModule**

Allows you to find a module from its serial number or from its logical name.

```
function yFindModule( ByVal func As String) As YModule
```

This function does not require that the module is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YModule.IsOnline()` to test if the module is indeed online at a given time. In case of ambiguity when looking for a module by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

**Parameters :**

**func** a string containing either the serial number or the logical name of the desired module

**Returns :**

a `YModule` object allowing you to drive the module or get additional information on the module.



---

**YModule.FirstModule()  
yFirstModule()yFirstModule()**

---

**YModule**

Starts the enumeration of modules currently accessible.

```
function yFirstModule( ) As YModule
```

Use the method `YModule.nextModule( )` to iterate on the next modules.

**Returns :**

a pointer to a `YModule` object, corresponding to the first module currently online, or a `null` pointer if there are none.

**module**→**checkFirmware()****module.checkFirmware()****YModule**

Test if the byn file is valid for this module.

```
function checkFirmware( ) As String
```

This method is useful to test if the module need to be updated. It's possible to pass an directory instead of a file. In this case this method return the path of the most recent appropriate byn file. If the parameter `onlynew` is true the function will discard firmware that are older or equal to the installed firmware.

**Parameters :**

- path** the path of a byn file or a directory that contain byn files
- onlynew** return only files that are strictly newer

**Returns :**

: the path of the byn file to use or a empty string if no byn files match the requirement

On failure, throws an exception or returns a string that start with "error:".

---

**module**→**describe()****module.describe()****YModule**

---

Returns a descriptive text that identifies the module.

```
function describe( ) As String
```

The text may include either the logical name or the serial number of the module.

**Returns :**

a string that describes the module

**module**→**download()****module.download()**

**YModule**

---

Downloads the specified built-in file and returns a binary buffer with its content.

function **download**( ) As Byte

**Parameters :**

**pathname** name of the new file to load

**Returns :**

a binary buffer with the file content

On failure, throws an exception or returns `YAPI_INVALID_STRING`.

---

**module**→**functionCount()****module.functionCount()****YModule**

---

Returns the number of functions (beside the "module" interface) available on the module.

```
function functionCount( ) As Integer
```

**Returns :**

the number of functions on the module

On failure, throws an exception or returns a negative error code.

---

**module**→**functionId()****module.functionId()****YModule**

---

Retrieves the hardware identifier of the *n*th function on the module.

```
function functionId( ByVal functionIndex As Integer) As String
```

**Parameters :**

**functionIndex** the index of the function for which the information is desired, starting at 0 for the first function.

**Returns :**

a string corresponding to the unambiguous hardware identifier of the requested module function

On failure, throws an exception or returns an empty string.

---

**module**→**functionName()****module.functionName()****YModule**

---

Retrieves the logical name of the *n*th function on the module.

```
function functionName( ByVal functionIndex As Integer) As String
```

**Parameters :**

**functionIndex** the index of the function for which the information is desired, starting at 0 for the first function.

**Returns :**

a string corresponding to the logical name of the requested module function

On failure, throws an exception or returns an empty string.

**module**→**functionValue()****module.functionValue()**

**YModule**

---

Retrieves the advertised value of the *n*th function on the module.

```
function functionValue( ByVal functionIndex As Integer) As String
```

**Parameters :**

**functionIndex** the index of the function for which the information is desired, starting at 0 for the first function.

**Returns :**

a short string (up to 6 characters) corresponding to the advertised value of the requested module function

On failure, throws an exception or returns an empty string.



---

**module**→**get\_allSettings()****YModule****module**→**allSettings()****module.get\_allSettings()**

---

Returns all the setting of the module.

function **get\_allSettings**( ) As Byte

Useful to backup all the logical name and calibrations parameters of a connected module.

**Returns :**

a binary buffer with all settings.

On failure, throws an exception or returns `YAPI_INVALID_STRING`.

**module**→**get\_beacon()**

**YModule**

**module**→**beacon()****module.get\_beacon()**

---

Returns the state of the localization beacon.

function **get\_beacon**( ) As Integer

**Returns :**

either `Y_BEACON_OFF` or `Y_BEACON_ON`, according to the state of the localization beacon

On failure, throws an exception or returns `Y_BEACON_INVALID`.

---

**module**→**get\_errorMessage()****YModule****module**→**errorMessage()****module.get\_errorMessage()**

---

Returns the error message of the latest error with this module object.

function **get\_errorMessage**( ) As String

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using this module object

**module**→**get\_errorType()**

**YModule**

**module**→**errorType()****module.get\_errorType()**

---

Returns the numerical error code of the latest error with this module object.

function **get\_errorType**( ) As YRETCODE

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using this module object

---

**module**→**get\_firmwareRelease()****YModule****module**→**firmwareRelease()****module.get\_firmwareRelease()**

---

Returns the version of the firmware embedded in the module.

```
function get_firmwareRelease( ) As String
```

**Returns :**

a string corresponding to the version of the firmware embedded in the module

On failure, throws an exception or returns `Y_FIRMWARERELEASE_INVALID`.

**module**→**get\_hardwareId()**

**YModule**

**module**→**hardwareId()****module.get\_hardwareId()**

---

Returns the unique hardware identifier of the module.

function **get\_hardwareId**( ) As String

The unique hardware identifier is made of the device serial number followed by string ".module".

**Returns :**

a string that uniquely identifies the module

---

**module**→**get\_icon2d()****YModule****module**→**icon2d()****module.get\_icon2d()**

---

Returns the icon of the module.

function **get\_icon2d**( ) As Byte

The icon is a PNG image and does not exceeds 1536 bytes.

**Returns :**

a binary buffer with module icon, in png format. On failure, throws an exception or returns `YAPI_INVALID_STRING`.

**module**→**get\_lastLogs()**

**YModule**

**module**→**lastLogs()****module.get\_lastLogs()**

---

Returns a string with last logs of the module.

function **get\_lastLogs()** As String

This method return only logs that are still in the module.

**Returns :**

a string with last logs of the module. On failure, throws an exception or returns YAPI\_INVALID\_STRING.



---

**module**→**get\_logicalName()****YModule****module**→**logicalName()****module.get\_logicalName()**

---

Returns the logical name of the module.

function **get\_logicalName( )** As String

**Returns :**

a string corresponding to the logical name of the module

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

**module**→**get\_luminosity()**

**YModule**

**module**→**luminosity()****module.get\_luminosity()**

---

Returns the luminosity of the module informative leds (from 0 to 100).

function **get\_luminosity**( ) As Integer

**Returns :**

an integer corresponding to the luminosity of the module informative leds (from 0 to 100)

On failure, throws an exception or returns `Y_LUMINOSITY_INVALID`.

---

**module**→**get\_persistentSettings()****YModule****module**→**persistentSettings()****module.get\_persistentSettings()**

---

Returns the current state of persistent module settings.

```
function get_persistentSettings( ) As Integer
```

**Returns :**

a value among `Y_PERSISTENTSETTINGS_LOADED`, `Y_PERSISTENTSETTINGS_SAVED` and `Y_PERSISTENTSETTINGS_MODIFIED` corresponding to the current state of persistent module settings

On failure, throws an exception or returns `Y_PERSISTENTSETTINGS_INVALID`.

**module**→**get\_productId()**

**YModule**

**module**→**productId()****module.get\_productId()**

---

Returns the USB device identifier of the module.

function **get\_productId()** As Integer

**Returns :**

an integer corresponding to the USB device identifier of the module

On failure, throws an exception or returns `Y_PRODUCTID_INVALID`.

---

**module**→**get\_productName()****YModule****module**→**productName()****module.get\_productName()**

---

Returns the commercial name of the module, as set by the factory.

```
function get_productName( ) As String
```

**Returns :**

a string corresponding to the commercial name of the module, as set by the factory

On failure, throws an exception or returns `Y_PRODUCTNAME_INVALID`.

**module**→**get\_productRelease()**

**YModule**

**module**→**productRelease()**

**module.get\_productRelease()**

---

Returns the hardware release version of the module.

function **get\_productRelease()** As Integer

**Returns :**

an integer corresponding to the hardware release version of the module

On failure, throws an exception or returns Y\_PRODUCTRELEASE\_INVALID.

---

**module**→**get\_rebootCountdown()****YModule****module**→**rebootCountdown()****module.get\_rebootCountdown()**

---

Returns the remaining number of seconds before the module restarts, or zero when no reboot has been scheduled.

```
function get_rebootCountdown( ) As Integer
```

**Returns :**

an integer corresponding to the remaining number of seconds before the module restarts, or zero when no reboot has been scheduled

On failure, throws an exception or returns `Y_REBOOTCOUNTDOWN_INVALID`.

**module**→**get\_serialNumber()**

**YModule**

**module**→**serialNumber()****module.get\_serialNumber()**

---

Returns the serial number of the module, as set by the factory.

function **get\_serialNumber**( ) As String

**Returns :**

a string corresponding to the serial number of the module, as set by the factory

On failure, throws an exception or returns `Y_SERIALNUMBER_INVALID`.



---

**module**→**get\_upTime()****YModule****module**→**upTime()****module.get\_upTime()**

---

Returns the number of milliseconds spent since the module was powered on.

function **get\_upTime()** As Long

**Returns :**

an integer corresponding to the number of milliseconds spent since the module was powered on

On failure, throws an exception or returns `Y_UPTIME_INVALID`.

**module**→**get\_usbCurrent()**

**YModule**

**module**→**usbCurrent()****module.get\_usbCurrent()**

---

Returns the current consumed by the module on the USB bus, in milli-amps.

function **get\_usbCurrent()** As Integer

**Returns :**

an integer corresponding to the current consumed by the module on the USB bus, in milli-amps

On failure, throws an exception or returns `Y_USBCURRENT_INVALID`.

---

**module**→**get\_userData()****YModule****module**→**userData()****module.get\_userData()**

---

Returns the value of the userData attribute, as previously stored using method `set_userData`.

function **get\_userData**( ) As Object

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

**module**→**get\_userVar()**

**YModule**

**module**→**userVar()****module.get\_userVar()**

---

Returns the value previously stored in this attribute.

function **get\_userVar( )** As Integer

On startup and after a device reboot, the value is always reset to zero.

**Returns :**

an integer corresponding to the value previously stored in this attribute

On failure, throws an exception or returns Y\_USERVAR\_INVALID.

---

**module**→**isOnline()****module.isOnline()****YModule**

---

Checks if the module is currently reachable, without raising any error.

```
function isOnline( ) As Boolean
```

If there are valid cached values for the module, that have not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the requested module.

**Returns :**

`true` if the module can be reached, and `false` otherwise

**module**→**load()****module.load()****YModule**

Preloads the module cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

By default, whenever accessing a device, all module attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded module parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**module**→**nextModule()****module.nextModule()****YModule**

---

Continues the module enumeration started using `yFirstModule()`.

```
function nextModule( ) As YModule
```

**Returns :**

a pointer to a `YModule` object, corresponding to the next module found, or a `null` pointer if there are no more modules to enumerate.

**module→reboot()****module.reboot()**

**YModule**

---

Schedules a simple module reboot after the given number of seconds.

function **reboot**( ) As Integer

**Parameters :**

**secBeforeReboot** number of seconds before rebooting

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.



---

**module**→**registerLogCallback()**  
**module.registerLogCallback()**

---

**YModule**

Registers a device log callback function.

```
function registerLogCallback( ByVal callback As YModuleLogCallback) As Integer
```

This callback will be called each time that a module sends a new log message. Mostly useful to debug a Yoctopuce module.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the module object that emitted the log message, and the character string containing the log.

**module→revertFromFlash()**  
**module.revertFromFlash()**

**YModule**

---

Reloads the settings stored in the nonvolatile memory, as when the module is powered on.

function **revertFromFlash**( ) As Integer

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**module**→**saveToFlash()****module.saveToFlash()****YModule**

---

Saves current settings in the nonvolatile memory of the module.

```
function saveToFlash( ) As Integer
```

Warning: the number of allowed save operations during a module life is limited (about 100000 cycles). Do not call this function within a loop.

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

**module**→**set\_allSettings()**

**YModule**

**module**→**setAllSettings()****module.set\_allSettings()**

---

Restore all the setting of the module.

procedure **set\_allSettings()**

Useful to restore all the logical name and calibrations parameters of a module from a backup.

**Parameters :**

**settings** a binary buffer with all settings.

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**module**→**set\_beacon()****YModule****module**→**setBeacon()****module.set\_beacon()**

---

Turns on or off the module localization beacon.

```
function set_beacon( ByVal newval As Integer) As Integer
```

**Parameters :**

**newval** either Y\_BEACON\_OFF or Y\_BEACON\_ON

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**module**→**set\_logicalName()**

**YModule**

**module**→**setLogicalName()****module.set\_logicalName()**

---

Changes the logical name of the module.

```
function set_logicalName( ByVal newval As String) As Integer
```

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the module

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**module**→**set\_luminosity()****YModule****module**→**setLuminosity()****module.set\_luminosity()**

---

Changes the luminosity of the module informative leds.

```
function set_luminosity( ByVal newval As Integer) As Integer
```

The parameter is a value between 0 and 100. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** an integer corresponding to the luminosity of the module informative leds

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**module**→**set\_userData()**

**YModule**

**module**→**setUserData()****module.set\_userData()**

---

Stores a user context provided as argument in the `userData` attribute of the function.

```
procedure set_userData( ByVal data As Object)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored



---

**module**→**set\_userVar()****YModule****module**→**setUserVar()****module.set\_userVar()**

---

Returns the value previously stored in this attribute.

```
function set_userVar( ByVal newval As Integer) As Integer
```

On startup and after a device reboot, the value is always reset to zero.

**Parameters :**

**newval** an integer

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**module**→**triggerFirmwareUpdate()**  
**module.triggerFirmwareUpdate()**

---

**YModule**

Schedules a module reboot into special firmware update mode.

function **triggerFirmwareUpdate( )** As Integer

**Parameters :**

**secBeforeReboot** number of seconds before rebooting

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**module**→**updateFirmware()****module.updateFirmware()****YModule**

---

Prepare a firmware upgrade of the module.

```
function updateFirmware( ) As YFirmwareUpdate
```

This method return a object `YFirmwareUpdate` which will handle the firmware upgrade process.

**Parameters :**

**path** the path of the byn file to use.

**Returns :**

: A object `YFirmwareUpdate`.

## 3.27. Motor function interface

Yoctopuce application programming interface allows you to drive the power sent to the motor to make it turn both ways, but also to drive accelerations and decelerations. The motor will then accelerate automatically: you will not have to monitor it. The API also allows to slow down the motor by shortening its terminals: the motor will then act as an electromagnetic brake.

In order to use the functions described here, you should include:

js	<code>&lt;script type='text/javascript' src='yocto_motor.js'&gt;&lt;/script&gt;</code>
nodejs	<code>var yoctolib = require('yoctolib'); var YMotor = yoctolib.YMotor;</code>
php	<code>require_once('yocto_motor.php');</code>
cpp	<code>#include "yocto_motor.h"</code>
m	<code>#import "yocto_motor.h"</code>
pas	<code>uses yocto_motor;</code>
vb	<code>yocto_motor.vb</code>
cs	<code>yocto_motor.cs</code>
java	<code>import com.yoctopuce.YoctoAPI.YMotor;</code>
py	<code>from yocto_motor import *</code>

### Global functions

#### **yFindMotor(func)**

Retrieves a motor for a given identifier.

#### **yFirstMotor()**

Starts the enumeration of motors currently accessible.

### YMotor methods

#### **motor→brakingForceMove(targetPower, delay)**

Changes progressively the braking force applied to the motor for a specific duration.

#### **motor→describe()**

Returns a short text that describes unambiguously the instance of the motor in the form `TYPE ( NAME ) =SERIAL . FUNCTIONID`.

#### **motor→drivingForceMove(targetPower, delay)**

Changes progressively the power sent to the moteur for a specific duration.

#### **motor→get\_advertisedValue()**

Returns the current value of the motor (no more than 6 characters).

#### **motor→get\_brakingForce()**

Returns the braking force applied to the motor, as a percentage.

#### **motor→get\_cutOffVoltage()**

Returns the threshold voltage under which the controller automatically switches to error state and prevents further current draw.

#### **motor→get\_drivingForce()**

Returns the power sent to the motor, as a percentage between -100% and +100%.

#### **motor→get\_errorMessage()**

Returns the error message of the latest error with the motor.

#### **motor→get\_errorType()**

Returns the numerical error code of the latest error with the motor.

#### **motor→get\_failSafeTimeout()**

Returns the delay in milliseconds allowed for the controller to run autonomously without receiving any instruction from the control process.

**motor**→**get\_frequency()**

Returns the PWM frequency used to control the motor.

**motor**→**get\_friendlyName()**

Returns a global identifier of the motor in the format `MODULE_NAME . FUNCTION_NAME`.

**motor**→**get\_functionDescriptor()**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

**motor**→**get\_functionId()**

Returns the hardware identifier of the motor, without reference to the module.

**motor**→**get\_hardwareId()**

Returns the unique hardware identifier of the motor in the form `SERIAL . FUNCTIONID`.

**motor**→**get\_logicalName()**

Returns the logical name of the motor.

**motor**→**get\_module()**

Gets the `YModule` object for the device on which the function is located.

**motor**→**get\_module\_async(callback, context)**

Gets the `YModule` object for the device on which the function is located (asynchronous version).

**motor**→**get\_motorStatus()**

Return the controller state.

**motor**→**get\_overCurrentLimit()**

Returns the current threshold (in mA) above which the controller automatically switches to error state.

**motor**→**get\_starterTime()**

Returns the duration (in ms) during which the motor is driven at low frequency to help it start up.

**motor**→**get\_userData()**

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

**motor**→**isOnline()**

Checks if the motor is currently reachable, without raising any error.

**motor**→**isOnline\_async(callback, context)**

Checks if the motor is currently reachable, without raising any error (asynchronous version).

**motor**→**keepALive()**

Rearms the controller failsafe timer.

**motor**→**load(msValidity)**

Preloads the motor cache with a specified validity duration.

**motor**→**load\_async(msValidity, callback, context)**

Preloads the motor cache with a specified validity duration (asynchronous version).

**motor**→**nextMotor()**

Continues the enumeration of motors started using `yFirstMotor()`.

**motor**→**registerValueCallback(callback)**

Registers the callback function that is invoked on every change of advertised value.

**motor**→**resetStatus()**

Reset the controller state to IDLE.

**motor**→**set\_brakingForce(newval)**

Changes immediately the braking force applied to the motor (in percents).

**motor**→**set\_cutOffVoltage(newval)**

Changes the threshold voltage under which the controller automatically switches to error state and prevents further current draw.

### 3. Reference

---

**motor**→**set\_drivingForce(newval)**

Changes immediately the power sent to the motor.

**motor**→**set\_failSafeTimeout(newval)**

Changes the delay in milliseconds allowed for the controller to run autonomously without receiving any instruction from the control process.

**motor**→**set\_frequency(newval)**

Changes the PWM frequency used to control the motor.

**motor**→**set\_logicalName(newval)**

Changes the logical name of the motor.

**motor**→**set\_overCurrentLimit(newval)**

Changes the current threshold (in mA) above which the controller automatically switches to error state.

**motor**→**set\_starterTime(newval)**

Changes the duration (in ms) during which the motor is driven at low frequency to help it start up.

**motor**→**set\_userData(data)**

Stores a user context provided as argument in the userData attribute of the function.

**motor**→**wait\_async(callback, context)**

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.

## YMotor.FindMotor() yFindMotor()yFindMotor()

YMotor

Retrieves a motor for a given identifier.

```
function yFindMotor( ByVal func As String) As YMotor
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the motor is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YMotor.isOnline()` to test if the motor is indeed online at a given time. In case of ambiguity when looking for a motor by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

**Parameters :**

**func** a string that uniquely characterizes the motor

**Returns :**

a `YMotor` object allowing you to drive the motor.

**YMotor.FirstMotor()**

**YMotor**

**yFirstMotor()yFirstMotor()**

---

Starts the enumeration of motors currently accessible.

```
function yFirstMotor( ) As YMotor
```

Use the method `YMotor.nextMotor()` to iterate on next motors.

**Returns :**

a pointer to a `YMotor` object, corresponding to the first motor currently online, or a `null` pointer if there are none.



---

**motor**→**brakingForceMove()**  
**motor.brakingForceMove()**

---

**YMotor**

Changes progressively the braking force applied to the motor for a specific duration.

function **brakingForceMove**( ) As Integer

**Parameters :**

**targetPower** desired braking force, in percents

**delay** duration (in ms) of the transition

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**motor**→**describe()****motor.describe()****YMotor**

Returns a short text that describes unambiguously the instance of the motor in the form `TYPE (NAME) =SERIAL.FUNCTIONID`.

function **describe**( ) As String

More precisely, `TYPE` is the type of the function, `NAME` is the name used for the first access to the function, `SERIAL` is the serial number of the module if the module is connected or "unresolved", and `FUNCTIONID` is the hardware identifier of the function if the module is connected. For example, this method returns `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1` if the module is already connected or `Relay(BadCustomeName.relay1)=unresolved` if the module has not yet been connected. This method does not trigger any USB or TCP transaction and can therefore be used in a debugger.

**Returns :**

a string that describes the motor (ex: `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1`)

---

**motor**→**drivingForceMove()**  
**motor.drivingForceMove()**

---

**YMotor**

Changes progressively the power sent to the moteur for a specific duration.

function **drivingForceMove**( ) As Integer

**Parameters :**

**targetPower** desired motor power, in percents (between -100% and +100%)

**delay** duration (in ms) of the transition

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**motor**→**get\_advertisedValue()**

**YMotor**

**motor**→**advertisedValue()**

**motor.get\_advertisedValue()**

---

Returns the current value of the motor (no more than 6 characters).

function **get\_advertisedValue( )** As String

**Returns :**

a string corresponding to the current value of the motor (no more than 6 characters).

On failure, throws an exception or returns Y\_ADVERTISEDVALUE\_INVALID.

---

**motor**→**get\_brakingForce()****YMotor****motor**→**brakingForce()****motor.get\_brakingForce()**

---

Returns the braking force applied to the motor, as a percentage.

function **get\_brakingForce**( ) As Double

The value 0 corresponds to no braking (free wheel).

**Returns :**

a floating point number corresponding to the braking force applied to the motor, as a percentage

On failure, throws an exception or returns Y\_BRAKINGFORCE\_INVALID.

**motor**→**get\_cutOffVoltage()**

**YMotor**

**motor**→**cutOffVoltage()****motor.get\_cutOffVoltage()**

---

Returns the threshold voltage under which the controller automatically switches to error state and prevents further current draw.

function **get\_cutOffVoltage**( ) As Double

This setting prevents damage to a battery that can occur when drawing current from an "empty" battery.

**Returns :**

a floating point number corresponding to the threshold voltage under which the controller automatically switches to error state and prevents further current draw

On failure, throws an exception or returns `Y_CUTOFFVOLTAGE_INVALID`.

---

**motor**→**get\_drivingForce()****YMotor****motor**→**drivingForce()****motor.get\_drivingForce()**

---

Returns the power sent to the motor, as a percentage between -100% and +100%.

function **get\_drivingForce**( ) As Double

**Returns :**

a floating point number corresponding to the power sent to the motor, as a percentage between -100% and +100%

On failure, throws an exception or returns Y\_DRIVINGFORCE\_INVALID.

**motor**→**get\_errorMessage()**

**YMotor**

**motor**→**errorMessage()****motor.get\_errorMessage()**

---

Returns the error message of the latest error with the motor.

function **get\_errorMessage**( ) As String

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using the motor object



---

**motor**→**get\_errorType()****YMotor****motor**→**errorType()****motor.get\_errorType()**

---

Returns the numerical error code of the latest error with the motor.

function **get\_errorType**( ) As YRETCODE

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using the motor object

**motor**→**get\_failSafeTimeout()**

**YMotor**

**motor**→**failSafeTimeout()****motor.get\_failSafeTimeout()**

---

Returns the delay in milliseconds allowed for the controller to run autonomously without receiving any instruction from the control process.

function **get\_failSafeTimeout( )** As Integer

When this delay has elapsed, the controller automatically stops the motor and switches to FAILSAFE error. Failsafe security is disabled when the value is zero.

**Returns :**

an integer corresponding to the delay in milliseconds allowed for the controller to run autonomously without receiving any instruction from the control process

On failure, throws an exception or returns `Y_FAILSAFETIMEOUT_INVALID`.

---

**motor**→**get\_frequency()****YMotor****motor**→**frequency()****motor.get\_frequency()**

---

Returns the PWM frequency used to control the motor.

function **get\_frequency**( ) As Double

**Returns :**

a floating point number corresponding to the PWM frequency used to control the motor

On failure, throws an exception or returns `Y_FREQUENCY_INVALID`.

**motor**→**get\_functionDescriptor()**

**YMotor**

**motor**→**functionDescriptor()**

**motor.get\_functionDescriptor()**

---

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

`function get_functionDescriptor( )` As `YFUN_DESCR`

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`.

If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

---

**motor**→**get\_functionId()****YMotor****motor**→**functionId()****motor.get\_functionId()**

---

Returns the hardware identifier of the motor, without reference to the module.

function **get\_functionId()** As String

For example `relay1`

**Returns :**

a string that identifies the motor (ex: `relay1`)

On failure, throws an exception or returns `Y_FUNCTIONID_INVALID`.

**motor**→**get\_hardwareId()**

**YMotor**

**motor**→**hardwareId()****motor.get\_hardwareId()**

---

Returns the unique hardware identifier of the motor in the form `SERIAL.FUNCTIONID`.

function **get\_hardwareId()** As String

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the motor (for example `RELAYLO1-123456.relay1`).

**Returns :**

a string that uniquely identifies the motor (ex: `RELAYLO1-123456.relay1`)

On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

---

**motor**→**get\_logicalName()****YMotor****motor**→**logicalName()****motor.get\_logicalName()**

---

Returns the logical name of the motor.

```
function get_logicalName( ) As String
```

**Returns :**

a string corresponding to the logical name of the motor.

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

**motor**→**get\_module()**

**YMotor**

**motor**→**module()****motor.get\_module()**

---

Gets the YModule object for the device on which the function is located.

function **get\_module()** As YModule

If the function cannot be located on any module, the returned instance of YModule is not shown as on-line.

**Returns :**

an instance of YModule



---

**motor**→**get\_motorStatus()****YMotor****motor**→**motorStatus()****motor.get\_motorStatus()**

---

Return the controller state.

```
function get_motorStatus( ) As Integer
```

Possible states are: IDLE when the motor is stopped/in free wheel, ready to start; FORWD when the controller is driving the motor forward; BACKWD when the controller is driving the motor backward; BRAKE when the controller is braking; LOVOLT when the controller has detected a low voltage condition; HICURR when the controller has detected an overcurrent condition; HIHEAT when the controller has detected an overheat condition; FAILSF when the controller switched on the failsafe security.

When an error condition occurred (LOVOLT, HICURR, HIHEAT, FAILSF), the controller status must be explicitly reset using the `resetStatus` function.

**Returns :**

a value among Y\_MOTORSTATUS\_IDLE, Y\_MOTORSTATUS\_BRAKE, Y\_MOTORSTATUS\_FORWD, Y\_MOTORSTATUS\_BACKWD, Y\_MOTORSTATUS\_LOVOLT, Y\_MOTORSTATUS\_HICURR, Y\_MOTORSTATUS\_HIHEAT and Y\_MOTORSTATUS\_FAILSF

On failure, throws an exception or returns Y\_MOTORSTATUS\_INVALID.

**motor**→**get\_ overCurrentLimit()**

**YMotor**

**motor**→**overCurrentLimit()**

**motor.get\_ overCurrentLimit()**

---

Returns the current threshold (in mA) above which the controller automatically switches to error state.

```
function get_ overCurrentLimit( ) As Integer
```

A zero value means that there is no limit.

**Returns :**

an integer corresponding to the current threshold (in mA) above which the controller automatically switches to error state

On failure, throws an exception or returns `Y_OVERCURRENTLIMIT_INVALID`.

---

**motor**→**get\_starterTime()****YMotor****motor**→**starterTime()****motor.get\_starterTime()**

---

Returns the duration (in ms) during which the motor is driven at low frequency to help it start up.

function **get\_starterTime**( ) As Integer

**Returns :**

an integer corresponding to the duration (in ms) during which the motor is driven at low frequency to help it start up

On failure, throws an exception or returns `Y_STARTERTIME_INVALID`.

**motor**→**get\_userData()**

**YMotor**

**motor**→**userData()****motor.get\_userData()**

---

Returns the value of the userData attribute, as previously stored using method `set_userData`.

function **get\_userData**( ) As Object

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

---

**motor**→**isOnline()****motor.isOnline()****YMotor**

---

Checks if the motor is currently reachable, without raising any error.

```
function isOnline( ) As Boolean
```

If there is a cached value for the motor in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the motor.

**Returns :**

`true` if the motor can be reached, and `false` otherwise

**motor**→**keepALive()****motor.keepALive()**

---

**YMotor**

Rearms the controller failsafe timer.

```
function keepALive( ) As Integer
```

When the motor is running and the failsafe feature is active, this function should be called periodically to prove that the control process is running properly. Otherwise, the motor is automatically stopped after the specified timeout. Calling a motor *set* function implicitly rearms the failsafe timer.

**motor**→**load()****motor.load()****YMotor**

Preloads the motor cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

**motor**→**nextMotor()**(**motor.nextMotor()**)

**YMotor**

---

Continues the enumeration of motors started using `yFirstMotor()`.

function **nextMotor()** As YMotor

**Returns :**

a pointer to a YMotor object, corresponding to a motor currently online, or a null pointer if there are no more motors to enumerate.



---

**motor**→**registerValueCallback()**  
**motor.registerValueCallback()**

---

**YMotor**

Registers the callback function that is invoked on every change of advertised value.

```
function registerValueCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

**motor**→**resetStatus()****motor.resetStatus()**

---

**YMotor**

Reset the controller state to IDLE.

```
function resetStatus( ) As Integer
```

This function must be invoked explicitly after any error condition is signaled.

---

**motor**→**set\_brakingForce()****YMotor****motor**→**setBrakingForce()****motor.set\_brakingForce()**

---

Changes immediately the braking force applied to the motor (in percents).

```
function set_brakingForce( ByVal newval As Double) As Integer
```

The value 0 corresponds to no braking (free wheel). When the braking force is changed, the driving power is set to zero. The value is a percentage.

**Parameters :**

**newval** a floating point number corresponding to immediately the braking force applied to the motor (in percents)

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**motor**→**set\_cutOffVoltage()**

**YMotor**

**motor**→**setCutOffVoltage()****motor.set\_cutOffVoltage()**

---

Changes the threshold voltage under which the controller automatically switches to error state and prevents further current draw.

```
function set_cutOffVoltage( ByVal newval As Double) As Integer
```

This setting prevent damage to a battery that can occur when drawing current from an "empty" battery. Note that whatever the cutoff threshold, the controller switches to undervoltage error state if the power supply goes under 3V, even for a very brief time.

**Parameters :**

**newval** a floating point number corresponding to the threshold voltage under which the controller automatically switches to error state and prevents further current draw

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**motor**→**set\_drivingForce()****YMotor****motor**→**setDrivingForce()****motor.set\_drivingForce()**

---

Changes immediately the power sent to the motor.

```
function set_drivingForce( ByVal newval As Double) As Integer
```

The value is a percentage between -100% to 100%. If you want go easy on your mechanics and avoid excessive current consumption, try to avoid brutal power changes. For example, immediate transition from forward full power to reverse full power is a very bad idea. Each time the driving power is modified, the braking power is set to zero.

**Parameters :**

**newval** a floating point number corresponding to immediately the power sent to the motor

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**motor**→**set\_failSafeTimeout()**

**YMotor**

**motor**→**setFailSafeTimeout()**

**motor.set\_failSafeTimeout()**

---

Changes the delay in milliseconds allowed for the controller to run autonomously without receiving any instruction from the control process.

```
function set_failSafeTimeout( ByVal newval As Integer) As Integer
```

When this delay has elapsed, the controller automatically stops the motor and switches to FAILSAFE error. Failsafe security is disabled when the value is zero.

**Parameters :**

**newval** an integer corresponding to the delay in milliseconds allowed for the controller to run autonomously without receiving any instruction from the control process

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**motor**→**set\_frequency()****YMotor****motor**→**setFrequency()****motor.set\_frequency()**

---

Changes the PWM frequency used to control the motor.

```
function set_frequency( ByVal newval As Double) As Integer
```

Low frequency is usually more efficient and may help the motor to start, but an audible noise might be generated. A higher frequency reduces the noise, but more energy is converted into heat.

**Parameters :**

**newval** a floating point number corresponding to the PWM frequency used to control the motor

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**motor**→**set\_logicalName()**

**YMotor**

**motor**→**setLogicalName()****motor.set\_logicalName()**

---

Changes the logical name of the motor.

```
function set_logicalName( ByVal newval As String) As Integer
```

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the motor.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.



---

**motor**→**set\_overCurrentLimit()****YMotor****motor**→**setOverCurrentLimit()****motor.set\_overCurrentLimit()**

---

Changes the current threshold (in mA) above which the controller automatically switches to error state.

```
function set_overCurrentLimit( ByVal newval As Integer) As Integer
```

A zero value means that there is no limit. Note that whatever the current limit is, the controller switches to OVERCURRENT status if the current goes above 32A, even for a very brief time.

**Parameters :**

**newval** an integer corresponding to the current threshold (in mA) above which the controller automatically switches to error state

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**motor**→**set\_starterTime()**

**YMotor**

**motor**→**setStarterTime()****motor.set\_starterTime()**

---

Changes the duration (in ms) during which the motor is driven at low frequency to help it start up.

```
function set_starterTime( ByVal newval As Integer) As Integer
```

**Parameters :**

**newval** an integer corresponding to the duration (in ms) during which the motor is driven at low frequency to help it start up

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**motor**→**set\_userData()****YMotor****motor**→**setUserData()****motor.set\_userData()**

---

Stores a user context provided as argument in the userData attribute of the function.

```
procedure set_userData( ByVal data As Object)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

## 3.28. Network function interface

YNetwork objects provide access to TCP/IP parameters of Yoctopuce modules that include a built-in network interface.

In order to use the functions described here, you should include:

js	<script type='text/javascript' src='yocto_network.js'></script>
nodejs	var yoctolib = require('yoctolib'); var YNetwork = yoctolib.YNetwork;
php	require_once('yocto_network.php');
c++	#include "yocto_network.h"
m	#import "yocto_network.h"
pas	uses yocto_network;
vb	yocto_network.vb
cs	yocto_network.cs
java	import com.yoctopuce.YoctoAPI.YNetwork;
py	from yocto_network import *

### Global functions

#### yFindNetwork(func)

Retrieves a network interface for a given identifier.

#### yFirstNetwork()

Starts the enumeration of network interfaces currently accessible.

### YNetwork methods

#### network→callbackLogin(username, password)

Connects to the notification callback and saves the credentials required to log into it.

#### network→describe()

Returns a short text that describes unambiguously the instance of the network interface in the form TYPE ( NAME ) = SERIAL . FUNCTIONID.

#### network→get\_adminPassword()

Returns a hash string if a password has been set for user "admin", or an empty string otherwise.

#### network→get\_advertisedValue()

Returns the current value of the network interface (no more than 6 characters).

#### network→get\_callbackCredentials()

Returns a hashed version of the notification callback credentials if set, or an empty string otherwise.

#### network→get\_callbackEncoding()

Returns the encoding standard to use for representing notification values.

#### network→get\_callbackMaxDelay()

Returns the maximum waiting time between two callback notifications, in seconds.

#### network→get\_callbackMethod()

Returns the HTTP method used to notify callbacks for significant state changes.

#### network→get\_callbackMinDelay()

Returns the minimum waiting time between two callback notifications, in seconds.

#### network→get\_callbackUrl()

Returns the callback URL to notify of significant state changes.

#### network→get\_discoverable()

Returns the activation state of the multicast announce protocols to allow easy discovery of the module in the network neighborhood (uPnP/Bonjour protocol).

**network→get\_errorMessage()**

Returns the error message of the latest error with the network interface.

**network→get\_errorType()**

Returns the numerical error code of the latest error with the network interface.

**network→get\_friendlyName()**

Returns a global identifier of the network interface in the format `MODULE_NAME . FUNCTION_NAME`.

**network→get\_functionDescriptor()**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

**network→get\_functionId()**

Returns the hardware identifier of the network interface, without reference to the module.

**network→get\_hardwareId()**

Returns the unique hardware identifier of the network interface in the form `SERIAL . FUNCTIONID`.

**network→get\_ipAddress()**

Returns the IP address currently in use by the device.

**network→get\_logicalName()**

Returns the logical name of the network interface.

**network→get\_macAddress()**

Returns the MAC address of the network interface.

**network→get\_module()**

Gets the `YModule` object for the device on which the function is located.

**network→get\_module\_async(callback, context)**

Gets the `YModule` object for the device on which the function is located (asynchronous version).

**network→get\_poeCurrent()**

Returns the current consumed by the module from Power-over-Ethernet (PoE), in milli-amps.

**network→get\_primaryDNS()**

Returns the IP address of the primary name server to be used by the module.

**network→get\_readiness()**

Returns the current established working mode of the network interface.

**network→get\_router()**

Returns the IP address of the router on the device subnet (default gateway).

**network→get\_secondaryDNS()**

Returns the IP address of the secondary name server to be used by the module.

**network→get\_subnetMask()**

Returns the subnet mask currently used by the device.

**network→get\_userData()**

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

**network→get\_userPassword()**

Returns a hash string if a password has been set for "user" user, or an empty string otherwise.

**network→get\_wwwWatchdogDelay()**

Returns the allowed downtime of the WWW link (in seconds) before triggering an automated reboot to try to recover Internet connectivity.

**network→isOnline()**

Checks if the network interface is currently reachable, without raising any error.

**network→isOnline\_async(callback, context)**

Checks if the network interface is currently reachable, without raising any error (asynchronous version).

**network→load(msValidity)**

Preloads the network interface cache with a specified validity duration.

**network→load\_async(msValidity, callback, context)**

Preloads the network interface cache with a specified validity duration (asynchronous version).

**network→nextNetwork()**

Continues the enumeration of network interfaces started using `yFirstNetwork()`.

**network→ping(host)**

Pings `str_host` to test the network connectivity.

**network→registerValueCallback(callback)**

Registers the callback function that is invoked on every change of advertised value.

**network→set\_adminPassword(newval)**

Changes the password for the "admin" user.

**network→set\_callbackCredentials(newval)**

Changes the credentials required to connect to the callback address.

**network→set\_callbackEncoding(newval)**

Changes the encoding standard to use for representing notification values.

**network→set\_callbackMaxDelay(newval)**

Changes the maximum waiting time between two callback notifications, in seconds.

**network→set\_callbackMethod(newval)**

Changes the HTTP method used to notify callbacks for significant state changes.

**network→set\_callbackMinDelay(newval)**

Changes the minimum waiting time between two callback notifications, in seconds.

**network→set\_callbackUrl(newval)**

Changes the callback URL to notify significant state changes.

**network→set\_discoverable(newval)**

Changes the activation state of the multicast announce protocols to allow easy discovery of the module in the network neighborhood (uPnP/Bonjour protocol).

**network→set\_logicalName(newval)**

Changes the logical name of the network interface.

**network→set\_primaryDNS(newval)**

Changes the IP address of the primary name server to be used by the module.

**network→set\_secondaryDNS(newval)**

Changes the IP address of the secondary name server to be used by the module.

**network→set\_userData(data)**

Stores a user context provided as argument in the `userData` attribute of the function.

**network→set\_userPassword(newval)**

Changes the password for the "user" user.

**network→set\_wwwWatchdogDelay(newval)**

Changes the allowed downtime of the WWW link (in seconds) before triggering an automated reboot to try to recover Internet connectivity.

**network→useDHCP(fallbackIpAddr, fallbackSubnetMaskLen, fallbackRouter)**

Changes the configuration of the network interface to enable the use of an IP address received from a DHCP server.

**network→useStaticIP(ipAddress, subnetMaskLen, router)**

Changes the configuration of the network interface to use a static IP address.

**network→wait\_async(callback, context)**

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.

## **YNetwork.FindNetwork() yFindNetwork()yFindNetwork()**

**YNetwork**

Retrieves a network interface for a given identifier.

```
function yFindNetwork( ByVal func As String) As YNetwork
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the network interface is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YNetwork.IsOnline()` to test if the network interface is indeed online at a given time. In case of ambiguity when looking for a network interface by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

**Parameters :**

**func** a string that uniquely characterizes the network interface

**Returns :**

a `YNetwork` object allowing you to drive the network interface.



---

**YNetwork.FirstNetwork()  
yFirstNetwork()yFirstNetwork()**

---

**YNetwork**

Starts the enumeration of network interfaces currently accessible.

```
function yFirstNetwork( ) As YNetwork
```

Use the method `YNetwork.nextNetwork( )` to iterate on next network interfaces.

**Returns :**

a pointer to a `YNetwork` object, corresponding to the first network interface currently online, or a `null` pointer if there are none.

**network**→**callbackLogin()****network.callbackLogin()****YNetwork**

Connects to the notification callback and saves the credentials required to log into it.

```
function callbackLogin( ByVal username As String,  
                        ByVal password As String) As Integer
```

The password is not stored into the module, only a hashed copy of the credentials are saved. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**username** username required to log to the callback

**password** password required to log to the callback

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**network**→**describe()****network.describe()****YNetwork**

Returns a short text that describes unambiguously the instance of the network interface in the form `TYPE (NAME) =SERIAL . FUNCTIONID`.

function **describe**( ) As String

More precisely, `TYPE` is the type of the function, `NAME` is the name used for the first access to the function, `SERIAL` is the serial number of the module if the module is connected or "unresolved", and `FUNCTIONID` is the hardware identifier of the function if the module is connected. For example, this method returns `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1` if the module is already connected or `Relay(BadCustomName.relay1)=unresolved` if the module has not yet been connected. This method does not trigger any USB or TCP transaction and can therefore be used in a debugger.

**Returns :**

a string that describes the network interface (ex: `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1`)

**network**→get\_adminPassword()

**YNetwork**

**network**→adminPassword()

**network.get\_adminPassword()**

---

Returns a hash string if a password has been set for user "admin", or an empty string otherwise.

```
function get_adminPassword( ) As String
```

**Returns :**

a string corresponding to a hash string if a password has been set for user "admin", or an empty string otherwise

On failure, throws an exception or returns Y\_ADMINPASSWORD\_INVALID.

---

**network**→**get\_advertisedValue()****YNetwork****network**→**advertisedValue()****network.get\_advertisedValue()**

---

Returns the current value of the network interface (no more than 6 characters).

```
function get_advertisedValue( ) As String
```

**Returns :**

a string corresponding to the current value of the network interface (no more than 6 characters).

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

**network**→**get\_callbackCredentials()**

**YNetwork**

**network**→**callbackCredentials()**

**network.get\_callbackCredentials()**

---

Returns a hashed version of the notification callback credentials if set, or an empty string otherwise.

```
function get_callbackCredentials( ) As String
```

**Returns :**

a string corresponding to a hashed version of the notification callback credentials if set, or an empty string otherwise

On failure, throws an exception or returns `Y_CALLBACKCREDENTIALS_INVALID`.

---

**network**→**get\_callbackEncoding()****YNetwork****network**→**callbackEncoding()****network.get\_callbackEncoding()**

---

Returns the encoding standard to use for representing notification values.

```
function get_callbackEncoding( ) As Integer
```

**Returns :**

a value among `Y_CALLBACKENCODING_FORM`, `Y_CALLBACKENCODING_JSON`, `Y_CALLBACKENCODING_JSON_ARRAY`, `Y_CALLBACKENCODING_CSV` and `Y_CALLBACKENCODING_YOCTO_API` corresponding to the encoding standard to use for representing notification values

On failure, throws an exception or returns `Y_CALLBACKENCODING_INVALID`.

**network**→**get\_callbackMaxDelay()**  
**network**→**callbackMaxDelay()**  
**network.get\_callbackMaxDelay()**

---

**YNetwork**

Returns the maximum waiting time between two callback notifications, in seconds.

```
function get_callbackMaxDelay( ) As Integer
```

**Returns :**

an integer corresponding to the maximum waiting time between two callback notifications, in seconds

On failure, throws an exception or returns `Y_CALLBACKMAXDELAY_INVALID`.



---

**network**→**get\_callbackMethod()****YNetwork****network**→**callbackMethod()****network.get\_callbackMethod()**

---

Returns the HTTP method used to notify callbacks for significant state changes.

```
function get_callbackMethod( ) As Integer
```

**Returns :**

a value among `Y_CALLBACKMETHOD_POST`, `Y_CALLBACKMETHOD_GET` and `Y_CALLBACKMETHOD_PUT` corresponding to the HTTP method used to notify callbacks for significant state changes

On failure, throws an exception or returns `Y_CALLBACKMETHOD_INVALID`.

**network**→**get\_callbackMinDelay()**  
**network**→**callbackMinDelay()**  
**network.get\_callbackMinDelay()**

---

**YNetwork**

Returns the minimum waiting time between two callback notifications, in seconds.

```
function get_callbackMinDelay( ) As Integer
```

**Returns :**

an integer corresponding to the minimum waiting time between two callback notifications, in seconds

On failure, throws an exception or returns `Y_CALLBACKMINDELAY_INVALID`.

---

**network**→**get\_callbackUrl()****YNetwork****network**→**callbackUrl()****network.get\_callbackUrl()**

---

Returns the callback URL to notify of significant state changes.

```
function get_callbackUrl( ) As String
```

**Returns :**

a string corresponding to the callback URL to notify of significant state changes

On failure, throws an exception or returns `Y_CALLBACKURL_INVALID`.

**network**→**get\_discoverable()**

**YNetwork**

**network**→**discoverable()****network.get\_discoverable()**

---

Returns the activation state of the multicast announce protocols to allow easy discovery of the module in the network neighborhood (uPnP/Bonjour protocol).

function **get\_discoverable**( ) As Integer

**Returns :**

either `Y_DISCOVERABLE_FALSE` or `Y_DISCOVERABLE_TRUE`, according to the activation state of the multicast announce protocols to allow easy discovery of the module in the network neighborhood (uPnP/Bonjour protocol)

On failure, throws an exception or returns `Y_DISCOVERABLE_INVALID`.

---

**network**→**get\_errorMessage()****YNetwork****network**→**errorMessage()****network.get\_errorMessage()**

---

Returns the error message of the latest error with the network interface.

```
function get_errorMessage( ) As String
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using the network interface object

**network**→**get\_errorType()**

**YNetwork**

**network**→**errorType()****network.get\_errorType()**

---

Returns the numerical error code of the latest error with the network interface.

function **get\_errorType**( ) As YRETCODE

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using the network interface object

---

**network**→**get\_functionDescriptor()****YNetwork****network**→**functionDescriptor()****network.get\_functionDescriptor()**

---

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

function **get\_functionDescriptor**( ) As `YFUN_DESCR`

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`.

If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

**network**→**get\_functionId()**

**YNetwork**

**network**→**functionId()****network.get\_functionId()**

---

Returns the hardware identifier of the network interface, without reference to the module.

function **get\_functionId**( ) As String

For example `relay1`

**Returns :**

a string that identifies the network interface (ex: `relay1`)

On failure, throws an exception or returns `Y_FUNCTIONID_INVALID`.



---

**network**→**get\_hardwareId()****YNetwork****network**→**hardwareId()****network.get\_hardwareId()**

---

Returns the unique hardware identifier of the network interface in the form `SERIAL.FUNCTIONID`.

function **get\_hardwareId()** As String

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the network interface (for example `RELAYLO1-123456.relay1`).

**Returns :**

a string that uniquely identifies the network interface (ex: `RELAYLO1-123456.relay1`)

On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

**network**→**get\_ipAddress()**

**YNetwork**

**network**→**ipAddress()****network.get\_ipAddress()**

---

Returns the IP address currently in use by the device.

function **get\_ipAddress**( ) As String

The address may have been configured statically, or provided by a DHCP server.

**Returns :**

a string corresponding to the IP address currently in use by the device

On failure, throws an exception or returns Y\_IPADDRESS\_INVALID.

---

**network**→**get\_logicalName()****YNetwork****network**→**logicalName()****network.get\_logicalName()**

---

Returns the logical name of the network interface.

```
function get_logicalName( ) As String
```

**Returns :**

a string corresponding to the logical name of the network interface.

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

**network**→**get\_macAddress()**

**YNetwork**

**network**→**macAddress()****network.get\_macAddress()**

---

Returns the MAC address of the network interface.

function **get\_macAddress()** As String

The MAC address is also available on a sticker on the module, in both numeric and barcode forms.

**Returns :**

a string corresponding to the MAC address of the network interface

On failure, throws an exception or returns Y\_MACADDRESS\_INVALID.

---

**network**→**get\_module()****YNetwork****network**→**module()****network.get\_module()**

---

Gets the `YModule` object for the device on which the function is located.

```
function get_module( ) As YModule
```

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

**Returns :**

an instance of `YModule`

**network**→**get\_poeCurrent()**

**YNetwork**

**network**→**poeCurrent()****network.get\_poeCurrent()**

---

Returns the current consumed by the module from Power-over-Ethernet (PoE), in milli-amps.

**function** **get\_poeCurrent()** As Integer

The current consumption is measured after converting PoE source to 5 Volt, and should never exceed 1800 mA.

**Returns :**

an integer corresponding to the current consumed by the module from Power-over-Ethernet (PoE), in milli-amps

On failure, throws an exception or returns `Y_POECURRENT_INVALID`.

---

**network**→**get\_primaryDNS()****YNetwork****network**→**primaryDNS()****network.get\_primaryDNS()**

---

Returns the IP address of the primary name server to be used by the module.

function **get\_primaryDNS**( ) As String

**Returns :**

a string corresponding to the IP address of the primary name server to be used by the module

On failure, throws an exception or returns `Y_PRIMARYDNS_INVALID`.

**network**→**get\_readiness()****YNetwork****network**→**readiness()****network.get\_readiness()**

Returns the current established working mode of the network interface.

function **get\_readiness( )** As Integer

Level zero (DOWN\_0) means that no hardware link has been detected. Either there is no signal on the network cable, or the selected wireless access point cannot be detected. Level 1 (LIVE\_1) is reached when the network is detected, but is not yet connected. For a wireless network, this shows that the requested SSID is present. Level 2 (LINK\_2) is reached when the hardware connection is established. For a wired network connection, level 2 means that the cable is attached at both ends. For a connection to a wireless access point, it shows that the security parameters are properly configured. For an ad-hoc wireless connection, it means that there is at least one other device connected on the ad-hoc network. Level 3 (DHCP\_3) is reached when an IP address has been obtained using DHCP. Level 4 (DNS\_4) is reached when the DNS server is reachable on the network. Level 5 (WWW\_5) is reached when global connectivity is demonstrated by properly loading the current time from an NTP server.

**Returns :**

a value among Y\_READINESS\_DOWN, Y\_READINESS\_EXISTS, Y\_READINESS\_LINKED, Y\_READINESS\_LAN\_OK and Y\_READINESS\_WWW\_OK corresponding to the current established working mode of the network interface

On failure, throws an exception or returns Y\_READINESS\_INVALID.



---

**network**→**get\_router()****YNetwork****network**→**router()****network.get\_router()**

---

Returns the IP address of the router on the device subnet (default gateway).

function **get\_router**( ) As String

**Returns :**

a string corresponding to the IP address of the router on the device subnet (default gateway)

On failure, throws an exception or returns `Y_ROUTER_INVALID`.

**network→get\_secondaryDNS()**  
**network→secondaryDNS()**  
**network.get\_secondaryDNS()**

---

**YNetwork**

Returns the IP address of the secondary name server to be used by the module.

```
function get_secondaryDNS( ) As String
```

**Returns :**

a string corresponding to the IP address of the secondary name server to be used by the module

On failure, throws an exception or returns Y\_SECONDARYDNS\_INVALID.

---

**network**→**get\_subnetMask()****YNetwork****network**→**subnetMask()****network.get\_subnetMask()**

---

Returns the subnet mask currently used by the device.

```
function get_subnetMask( ) As String
```

**Returns :**

a string corresponding to the subnet mask currently used by the device

On failure, throws an exception or returns `Y_SUBNETMASK_INVALID`.

**network**→**get\_userData()**

**YNetwork**

**network**→**userData()****network.get\_userData()**

---

Returns the value of the userData attribute, as previously stored using method `set_userData`.

function **get\_userData**( ) As Object

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

---

**network**→**get\_userPassword()****YNetwork****network**→**userPassword()****network.get\_userPassword()**

---

Returns a hash string if a password has been set for "user" user, or an empty string otherwise.

```
function get_userPassword( ) As String
```

**Returns :**

a string corresponding to a hash string if a password has been set for "user" user, or an empty string otherwise

On failure, throws an exception or returns `Y_USERPASSWORD_INVALID`.

**network**→**get\_wwwWatchdogDelay()**

**YNetwork**

**network**→**wwwWatchdogDelay()**

**network.get\_wwwWatchdogDelay()**

---

Returns the allowed downtime of the WWW link (in seconds) before triggering an automated reboot to try to recover Internet connectivity.

```
function get_wwwWatchdogDelay( ) As Integer
```

A zero value disables automated reboot in case of Internet connectivity loss.

**Returns :**

an integer corresponding to the allowed downtime of the WWW link (in seconds) before triggering an automated reboot to try to recover Internet connectivity

On failure, throws an exception or returns `Y_WWWWATCHDOGDELAY_INVALID`.

---

**network**→**isOnline()****network.isOnline()****YNetwork**

---

Checks if the network interface is currently reachable, without raising any error.

```
function isOnline( ) As Boolean
```

If there is a cached value for the network interface in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the network interface.

**Returns :**

`true` if the network interface can be reached, and `false` otherwise

**network**→**load()****network.load()****YNetwork**

Preloads the network interface cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.



---

**network**→**nextNetwork()****network.nextNetwork()****YNetwork**

---

Continues the enumeration of network interfaces started using `yFirstNetwork()`.

```
function nextNetwork( ) As YNetwork
```

**Returns :**

a pointer to a `YNetwork` object, corresponding to a network interface currently online, or a null pointer if there are no more network interfaces to enumerate.

## network→ping()network.ping()

YNetwork

---

Pings str\_host to test the network connectivity.

function ping( ) As String

Sends four ICMP ECHO\_REQUEST requests from the module to the target str\_host. This method returns a string with the result of the 4 ICMP ECHO\_REQUEST requests.

**Parameters :**

**host** the hostname or the IP address of the target

**Returns :**

a string with the result of the ping.

---

**network→registerValueCallback()**  
**network.registerValueCallback()**

---

**YNetwork**

Registers the callback function that is invoked on every change of advertised value.

```
function registerValueCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

**network**→**set\_adminPassword()**  
**network**→**setAdminPassword()**  
**network.set\_adminPassword()**

**YNetwork**

Changes the password for the "admin" user.

```
function set_adminPassword( ByVal newval As String) As Integer
```

This password becomes instantly required to perform any change of the module state. If the specified value is an empty string, a password is not required anymore. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the password for the "admin" user

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**network**→**set\_callbackCredentials()**  
**network**→**setCallbackCredentials()**  
**network.set\_callbackCredentials()**

---

**YNetwork**

Changes the credentials required to connect to the callback address.

```
function set_callbackCredentials( ByVal newval As String) As Integer
```

The credentials must be provided as returned by function `get_callbackCredentials`, in the form `username:hash`. The method used to compute the hash varies according to the authentication scheme implemented by the callback, For Basic authentication, the hash is the MD5 of the string `username:password`. For Digest authentication, the hash is the MD5 of the string `username:realm:password`. For a simpler way to configure callback credentials, use function `callbackLogin` instead. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the credentials required to connect to the callback address

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**network**→**set\_callbackEncoding()**  
**network**→**setCallbackEncoding()**  
**network.set\_callbackEncoding()**

**YNetwork**

Changes the encoding standard to use for representing notification values.

```
function set_callbackEncoding( ByVal newval As Integer) As Integer
```

**Parameters :**

**newval** a value among Y\_CALLBACKENCODING\_FORM, Y\_CALLBACKENCODING\_JSON, Y\_CALLBACKENCODING\_JSON\_ARRAY, Y\_CALLBACKENCODING\_CSV and Y\_CALLBACKENCODING\_YOCTO\_API corresponding to the encoding standard to use for representing notification values

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**network**→**set\_callbackMaxDelay()****YNetwork****network**→**setCallbackMaxDelay()****network.set\_callbackMaxDelay()**

---

Changes the maximum waiting time between two callback notifications, in seconds.

```
function set_callbackMaxDelay( ByVal newval As Integer) As Integer
```

**Parameters :**

**newval** an integer corresponding to the maximum waiting time between two callback notifications, in seconds

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**network**→**set\_callbackMethod()****YNetwork****network**→**setCallbackMethod()****network.set\_callbackMethod()**

Changes the HTTP method used to notify callbacks for significant state changes.

```
function set_callbackMethod( ByVal newval As Integer) As Integer
```

**Parameters :**

**newval** a value among Y\_CALLBACKMETHOD\_POST, Y\_CALLBACKMETHOD\_GET and Y\_CALLBACKMETHOD\_PUT corresponding to the HTTP method used to notify callbacks for significant state changes

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.



---

**network**→**set\_callbackMinDelay()****YNetwork****network**→**setCallbackMinDelay()****network.set\_callbackMinDelay()**

---

Changes the minimum waiting time between two callback notifications, in seconds.

```
function set_callbackMinDelay( ByVal newval As Integer) As Integer
```

**Parameters :**

**newval** an integer corresponding to the minimum waiting time between two callback notifications, in seconds

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**network**→**set\_callbackUrl()**

**YNetwork**

**network**→**setCallbackUrl()****network.set\_callbackUrl()**

---

Changes the callback URL to notify significant state changes.

```
function set_callbackUrl( ByVal newval As String) As Integer
```

Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the callback URL to notify significant state changes

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**network**→**set\_discoverable()****YNetwork****network**→**setDiscoverable()****network.set\_discoverable()**

---

Changes the activation state of the multicast announce protocols to allow easy discovery of the module in the network neighborhood (uPnP/Bonjour protocol).

```
function set_discoverable( ByVal newval As Integer) As Integer
```

**Parameters :**

**newval** either `Y_DISCOVERABLE_FALSE` or `Y_DISCOVERABLE_TRUE`, according to the activation state of the multicast announce protocols to allow easy discovery of the module in the network neighborhood (uPnP/Bonjour protocol)

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

**network**→**set\_logicalName()****YNetwork****network**→**setLogicalName()****network.set\_logicalName()**

---

Changes the logical name of the network interface.

```
function set_logicalName( ByVal newval As String) As Integer
```

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the network interface.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**network**→**set\_primaryDNS()****YNetwork****network**→**setPrimaryDNS()****network.set\_primaryDNS()**

---

Changes the IP address of the primary name server to be used by the module.

```
function set_primaryDNS( ByVal newval As String) As Integer
```

When using DHCP, if a value is specified, it overrides the value received from the DHCP server. Remember to call the `saveToFlash()` method and then to reboot the module to apply this setting.

**Parameters :**

**newval** a string corresponding to the IP address of the primary name server to be used by the module

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**network**→**set\_secondaryDNS()****YNetwork****network**→**setSecondaryDNS()****network.set\_secondaryDNS()**

Changes the IP address of the secondary name server to be used by the module.

```
function set_secondaryDNS( ByVal newval As String) As Integer
```

When using DHCP, if a value is specified, it overrides the value received from the DHCP server. Remember to call the `saveToFlash()` method and then to reboot the module to apply this setting.

**Parameters :**

**newval** a string corresponding to the IP address of the secondary name server to be used by the module

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**network**→**set\_userData()****YNetwork****network**→**setUserData()****network.set\_userData()**

---

Stores a user context provided as argument in the userData attribute of the function.

procedure **set\_userData**( ByVal **data** As Object)

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

**network**→**set\_userPassword()**  
**network**→**setUserPassword()**  
**network.set\_userPassword()**

**YNetwork**

Changes the password for the "user" user.

```
function set_userPassword( ByVal newval As String) As Integer
```

This password becomes instantly required to perform any use of the module. If the specified value is an empty string, a password is not required anymore. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the password for the "user" user

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.



---

**network**→**set\_wwwWatchdogDelay()****YNetwork****network**→**setWwwWatchdogDelay()****network.set\_wwwWatchdogDelay()**

---

Changes the allowed downtime of the WWW link (in seconds) before triggering an automated reboot to try to recover Internet connectivity.

```
function set_wwwWatchdogDelay( ByVal newval As Integer) As Integer
```

A zero value disables automated reboot in case of Internet connectivity loss. The smallest valid non-zero timeout is 90 seconds.

**Parameters :**

**newval** an integer corresponding to the allowed downtime of the WWW link (in seconds) before triggering an automated reboot to try to recover Internet connectivity

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**network→useDHCP()****network.useDHCP()****YNetwork**

Changes the configuration of the network interface to enable the use of an IP address received from a DHCP server.

```
function useDHCP( ) As Integer
```

Until an address is received from a DHCP server, the module uses the IP parameters specified to this function. Remember to call the `saveToFlash()` method and then to reboot the module to apply this setting.

**Parameters :**

- |                              |  |
|------------------------------|--|
| <b>fallbackIpAddr</b>        | fallback IP address, to be used when no DHCP reply is received   |
| <b>fallbackSubnetMaskLen</b> | fallback subnet mask length when no DHCP reply is received, as an integer (eg. 24 means 255.255.255.0) |
| <b>fallbackRouter</b>        | fallback router IP address, to be used when no DHCP reply is received                                  |

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**network→useStaticIP(network.useStaticIP())**

---

**YNetwork**

Changes the configuration of the network interface to use a static IP address.

```
function useStaticIP( ) As Integer
```

Remember to call the `saveToFlash()` method and then to reboot the module to apply this setting.

**Parameters :**

**ipAddress** device IP address  
**subnetMaskLen** subnet mask length, as an integer (eg. 24 means 255.255.255.0)  
**router** router IP address (default gateway)

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

## 3.29. OS control

The OScontrol object allows some control over the operating system running a VirtualHub. OsControl is available on the VirtualHub software only. This feature must be activated at the VirtualHub start up with -o option.

In order to use the functions described here, you should include:

js	<script type='text/javascript' src='yocto_oscontrol.js'></script>
nodejs	var yoctolib = require('yoctolib'); var YOsControl = yoctolib.YOsControl;
php	require_once('yocto_oscontrol.php');
c++	#include "yocto_oscontrol.h"
m	#import "yocto_oscontrol.h"
pas	uses yocto_oscontrol;
vb	yocto_oscontrol.vb
cs	yocto_oscontrol.cs
java	import com.yoctopuce.YoctoAPI.YOsControl;
py	from yocto_oscontrol import *

### Global functions

#### yFindOsControl(func)

Retrieves OS control for a given identifier.

#### yFirstOsControl()

Starts the enumeration of OS control currently accessible.

### YOsControl methods

#### oscontrol→describe()

Returns a short text that describes unambiguously the instance of the OS control in the form `TYPE ( NAME ) =SERIAL . FUNCTIONID`.

#### oscontrol→get\_advertisedValue()

Returns the current value of the OS control (no more than 6 characters).

#### oscontrol→get\_errorMessage()

Returns the error message of the latest error with the OS control.

#### oscontrol→get\_errorType()

Returns the numerical error code of the latest error with the OS control.

#### oscontrol→get\_friendlyName()

Returns a global identifier of the OS control in the format `MODULE_NAME . FUNCTION_NAME`.

#### oscontrol→get\_functionDescriptor()

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

#### oscontrol→get\_functionId()

Returns the hardware identifier of the OS control, without reference to the module.

#### oscontrol→get\_hardwareId()

Returns the unique hardware identifier of the OS control in the form `SERIAL . FUNCTIONID`.

#### oscontrol→get\_logicalName()

Returns the logical name of the OS control.

#### oscontrol→get\_module()

Gets the `YModule` object for the device on which the function is located.

#### oscontrol→get\_module\_async(callback, context)

Gets the `YModule` object for the device on which the function is located (asynchronous version).

**oscontrol**→**get\_shutdownCountdown()**

Returns the remaining number of seconds before the OS shutdown, or zero when no shutdown has been scheduled.

**oscontrol**→**get\_userData()**

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

**oscontrol**→**isOnline()**

Checks if the OS control is currently reachable, without raising any error.

**oscontrol**→**isOnline\_async(callback, context)**

Checks if the OS control is currently reachable, without raising any error (asynchronous version).

**oscontrol**→**load(msValidity)**

Preloads the OS control cache with a specified validity duration.

**oscontrol**→**load\_async(msValidity, callback, context)**

Preloads the OS control cache with a specified validity duration (asynchronous version).

**oscontrol**→**nextOsControl()**

Continues the enumeration of OS control started using `yFirstOsControl()`.

**oscontrol**→**registerValueCallback(callback)**

Registers the callback function that is invoked on every change of advertised value.

**oscontrol**→**set\_logicalName(newval)**

Changes the logical name of the OS control.

**oscontrol**→**set\_userData(data)**

Stores a user context provided as argument in the `userData` attribute of the function.

**oscontrol**→**shutdown(secBeforeShutDown)**

Schedules an OS shutdown after a given number of seconds.

**oscontrol**→**wait\_async(callback, context)**

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.

## YOsControl.FindOsControl() yFindOsControl()yFindOsControl()

YOsControl

Retrieves OS control for a given identifier.

```
function yFindOsControl( ByVal func As String) As YOsControl
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the OS control is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YOsControl.IsOnline()` to test if the OS control is indeed online at a given time. In case of ambiguity when looking for OS control by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

**Parameters :**

**func** a string that uniquely characterizes the OS control

**Returns :**

a `YOsControl` object allowing you to drive the OS control.

---

**YOsControl.FirstOsControl()  
yFirstOsControl()yFirstOsControl()**

---

**YOsControl**

Starts the enumeration of OS control currently accessible.

```
function yFirstOsControl( ) As YOsControl
```

Use the method `YOsControl.nextOsControl()` to iterate on next OS control.

**Returns :**

a pointer to a `YOsControl` object, corresponding to the first OS control currently online, or a `null` pointer if there are none.

**oscontrol**→**describe()****oscontrol.describe()****YOsControl**

Returns a short text that describes unambiguously the instance of the OS control in the form `TYPE (NAME) =SERIAL . FUNCTIONID`.

function **describe**( ) As String

More precisely, `TYPE` is the type of the function, `NAME` it the name used for the first access to the function, `SERIAL` is the serial number of the module if the module is connected or "unresolved", and `FUNCTIONID` is the hardware identifier of the function if the module is connected. For example, this method returns `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1` if the module is already connected or `Relay(BadCustomeName.relay1)=unresolved` if the module has not yet been connected. This method does not trigger any USB or TCP transaction and can therefore be used in a debugger.

**Returns :**

a string that describes the OS control (ex: `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1`)



---

**oscontrol**→**get\_advertisedValue()****YOsControl****oscontrol**→**advertisedValue()****oscontrol.get\_advertisedValue()**

---

Returns the current value of the OS control (no more than 6 characters).

```
function get_advertisedValue( ) As String
```

**Returns :**

a string corresponding to the current value of the OS control (no more than 6 characters).

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

**oscontrol→get\_errorMessage()**  
**oscontrol→errorMessage()**  
**oscontrol.get\_errorMessage()**

---

**YOsControl**

Returns the error message of the latest error with the OS control.

```
function get_errorMessage( ) As String
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using the OS control object

---

**oscontrol**→**get\_errorType()****YOsControl****oscontrol**→**errorType()****oscontrol.get\_errorType()**

---

Returns the numerical error code of the latest error with the OS control.

function **get\_errorType()** As YRETCODE

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using the OS control object

**oscontrol**→**get\_functionDescriptor()**  
**oscontrol**→**functionDescriptor()**  
**oscontrol.get\_functionDescriptor()**

---

**YOsControl**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

`function get_functionDescriptor( ) As YFUN_DESCR`

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`.

If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

---

**oscontrol**→**get\_functionId()****YOsControl****oscontrol**→**functionId()****oscontrol.get\_functionId()**

---

Returns the hardware identifier of the OS control, without reference to the module.

function **get\_functionId**( ) As String

For example `relay1`

**Returns :**

a string that identifies the OS control (ex: `relay1`)

On failure, throws an exception or returns `Y_FUNCTIONID_INVALID`.

**oscontrol**→**get\_hardwareId()**

**YOsControl**

**oscontrol**→**hardwareId()****oscontrol.get\_hardwareId()**

---

Returns the unique hardware identifier of the OS control in the form `SERIAL.FUNCTIONID`.

function **get\_hardwareId()** As String

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the OS control (for example `RELAYLO1-123456.relay1`).

**Returns :**

a string that uniquely identifies the OS control (ex: `RELAYLO1-123456.relay1`)

On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

---

**oscontrol**→**get\_logicalName()****YOsControl****oscontrol**→**logicalName()****oscontrol.get\_logicalName()**

---

Returns the logical name of the OS control.

```
function get_logicalName( ) As String
```

**Returns :**

a string corresponding to the logical name of the OS control.

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

**oscontrol**→**get\_module()**

**YOsControl**

**oscontrol**→**module()****oscontrol.get\_module()**

---

Gets the `YModule` object for the device on which the function is located.

function **get\_module()** As `YModule`

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

**Returns :**

an instance of `YModule`



---

**oscontrol**→**get\_shutdownCountdown()****YOsControl****oscontrol**→**shutdownCountdown()****oscontrol.get\_shutdownCountdown()**

---

Returns the remaining number of seconds before the OS shutdown, or zero when no shutdown has been scheduled.

```
function get_shutdownCountdown( ) As Integer
```

**Returns :**

an integer corresponding to the remaining number of seconds before the OS shutdown, or zero when no shutdown has been scheduled

On failure, throws an exception or returns `Y_SHUTDOWNCOUNTDOWN_INVALID`.

**oscontrol**→**get\_userData()**

**YOsControl**

**oscontrol**→**userData()****oscontrol.get\_userData()**

---

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

function **get\_userData**( ) As Object

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

---

**oscontrol**→**isOnline()****oscontrol.isOnline()****YOsControl**

---

Checks if the OS control is currently reachable, without raising any error.

```
function isOnline( ) As Boolean
```

If there is a cached value for the OS control in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the OS control.

**Returns :**

`true` if the OS control can be reached, and `false` otherwise

**oscontrol**→**load()****oscontrol.load()****YOsControl**

Preloads the OS control cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**oscontrol→nextOsControl()**  
**oscontrol.nextOsControl()**

---

**YOsControl**

Continues the enumeration of OS control started using `yFirstOsControl()`.

```
function nextOsControl( ) As YOsControl
```

**Returns :**

a pointer to a `YOsControl` object, corresponding to OS control currently online, or a `null` pointer if there are no more OS control to enumerate.

**oscontrol**→**registerValueCallback()**  
**oscontrol.registerValueCallback()**

YOsControl

Registers the callback function that is invoked on every change of advertised value.

```
function registerValueCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

---

**oscontrol**→**set\_logicalName()****YOsControl****oscontrol**→**setLogicalName()****oscontrol.set\_logicalName()**

---

Changes the logical name of the OS control.

```
function set_logicalName( ByVal newval As String) As Integer
```

You can use `yCheckLogicalName( )` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash( )` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the OS control.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**oscontrol**→**set\_userData()**

**YOsControl**

**oscontrol**→**setUserData()****oscontrol.set\_userData()**

---

Stores a user context provided as argument in the `userData` attribute of the function.

```
procedure set_userData( ByVal data As Object)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored



---

**oscontrol→shutdown()oscontrol.shutdown()****YOsControl**

---

Schedules an OS shutdown after a given number of seconds.

function **shutdown**( ) As Integer

**Parameters :**

**secBeforeShutDown** number of seconds before shutdown

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

## 3.30. Power function interface

The Yoctopuce application programming interface allows you to read an instant measure of the sensor, as well as the minimal and maximal values observed.

In order to use the functions described here, you should include:

js	<script type='text/javascript' src='yocto_power.js'></script>
nodejs	var yoctolib = require('yoctolib'); var YPower = yoctolib.YPower;
php	require_once('yocto_power.php');
c++	#include "yocto_power.h"
m	#import "yocto_power.h"
pas	uses yocto_power;
vb	yocto_power.vb
cs	yocto_power.cs
java	import com.yoctopuce.YoctoAPI.YPower;
py	from yocto_power import *

### Global functions

#### yFindPower(func)

Retrieves a electrical power sensor for a given identifier.

#### yFirstPower()

Starts the enumeration of electrical power sensors currently accessible.

### YPower methods

#### power→calibrateFromPoints(rawValues, refValues)

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

#### power→describe()

Returns a short text that describes unambiguously the instance of the electrical power sensor in the form `TYPE ( NAME ) = SERIAL . FUNCTIONID`.

#### power→get\_advertisedValue()

Returns the current value of the electrical power sensor (no more than 6 characters).

#### power→get\_cosPhi()

Returns the power factor (the ratio between the real power consumed, measured in W, and the apparent power provided, measured in VA).

#### power→get\_currentRawValue()

Returns the uncalibrated, unrounded raw value returned by the sensor, in Watt, as a floating point number.

#### power→get\_currentValue()

Returns the current value of the electrical power, in Watt, as a floating point number.

#### power→get\_errorMessage()

Returns the error message of the latest error with the electrical power sensor.

#### power→get\_errorType()

Returns the numerical error code of the latest error with the electrical power sensor.

#### power→get\_friendlyName()

Returns a global identifier of the electrical power sensor in the format `MODULE_NAME . FUNCTION_NAME`.

#### power→get\_functionDescriptor()

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

#### power→get\_functionId()

Returns the hardware identifier of the electrical power sensor, without reference to the module.

**power**→**get\_hardwareId()**

Returns the unique hardware identifier of the electrical power sensor in the form `SERIAL.FUNCTIONID`.

**power**→**get\_highestValue()**

Returns the maximal value observed for the electrical power since the device was started.

**power**→**get\_logFrequency()**

Returns the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory.

**power**→**get\_logicalName()**

Returns the logical name of the electrical power sensor.

**power**→**get\_lowestValue()**

Returns the minimal value observed for the electrical power since the device was started.

**power**→**get\_meter()**

Returns the energy counter, maintained by the wattmeter by integrating the power consumption over time.

**power**→**get\_meterTimer()**

Returns the elapsed time since last energy counter reset, in seconds.

**power**→**get\_module()**

Gets the `YModule` object for the device on which the function is located.

**power**→**get\_module\_async(callback, context)**

Gets the `YModule` object for the device on which the function is located (asynchronous version).

**power**→**get\_recordedData(startTime, endTime)**

Retrieves a `DataSet` object holding historical data for this sensor, for a specified time interval.

**power**→**get\_reportFrequency()**

Returns the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function.

**power**→**get\_resolution()**

Returns the resolution of the measured values.

**power**→**get\_unit()**

Returns the measuring unit for the electrical power.

**power**→**get\_userData()**

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

**power**→**isOnline()**

Checks if the electrical power sensor is currently reachable, without raising any error.

**power**→**isOnline\_async(callback, context)**

Checks if the electrical power sensor is currently reachable, without raising any error (asynchronous version).

**power**→**load(msValidity)**

Preloads the electrical power sensor cache with a specified validity duration.

**power**→**loadCalibrationPoints(rawValues, refValues)**

Retrieves error correction data points previously entered using the method `calibrateFromPoints`.

**power**→**load\_async(msValidity, callback, context)**

Preloads the electrical power sensor cache with a specified validity duration (asynchronous version).

**power**→**nextPower()**

Continues the enumeration of electrical power sensors started using `yFirstPower()`.

**power**→**registerTimedReportCallback(callback)**

Registers the callback function that is invoked on every periodic timed notification.

**power**→**registerValueCallback(callback)**

### 3. Reference

Registers the callback function that is invoked on every change of advertised value.

#### **power**→**reset()**

Resets the energy counter.

#### **power**→**set\_highestValue(newval)**

Changes the recorded maximal value observed.

#### **power**→**set\_logFrequency(newval)**

Changes the datalogger recording frequency for this function.

#### **power**→**set\_logicalName(newval)**

Changes the logical name of the electrical power sensor.

#### **power**→**set\_lowestValue(newval)**

Changes the recorded minimal value observed.

#### **power**→**set\_reportFrequency(newval)**

Changes the timed value notification frequency for this function.

#### **power**→**set\_resolution(newval)**

Changes the resolution of the measured physical values.

#### **power**→**set\_userData(data)**

Stores a user context provided as argument in the userData attribute of the function.

#### **power**→**wait\_async(callback, context)**

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.

## YPower.FindPower() yFindPower()yFindPower()

YPower

Retrieves a electrical power sensor for a given identifier.

```
function yFindPower( ByVal func As String) As YPower
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the electrical power sensor is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YPower.IsOnline()` to test if the electrical power sensor is indeed online at a given time. In case of ambiguity when looking for a electrical power sensor by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

### Parameters :

**func** a string that uniquely characterizes the electrical power sensor

### Returns :

a `YPower` object allowing you to drive the electrical power sensor.

**YPower.FirstPower()**

**YPower**

**yFirstPower()**yFirstPower()

---

Starts the enumeration of electrical power sensors currently accessible.

```
function yFirstPower( ) As YPower
```

Use the method `YPower.NextPower()` to iterate on next electrical power sensors.

**Returns :**

a pointer to a `YPower` object, corresponding to the first electrical power sensor currently online, or a `null` pointer if there are none.

---

**power→calibrateFromPoints()**  
**power.calibrateFromPoints()**

---

**YPower**

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

**procedure calibrateFromPoints( )**

It is possible to configure up to five correction points. Correction points must be provided in ascending order, and be in the range of the sensor. The device will automatically perform a linear interpolation of the error correction between specified points. Remember to call the `saveToFlash( )` method of the module if the modification must be kept.

For more information on advanced capabilities to refine the calibration of sensors, please contact [support@yoctopuce.com](mailto:support@yoctopuce.com).

**Parameters :**

**rawValues** array of floating point numbers, corresponding to the raw values returned by the sensor for the correction points.

**refValues** array of floating point numbers, corresponding to the corrected values for the correction points.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**power→describe()****power.describe()****YPower**

Returns a short text that describes unambiguously the instance of the electrical power sensor in the form `TYPE (NAME) =SERIAL . FUNCTIONID`.

function **describe**( ) As String

More precisely, `TYPE` is the type of the function, `NAME` is the name used for the first access to the function, `SERIAL` is the serial number of the module if the module is connected or "unresolved", and `FUNCTIONID` is the hardware identifier of the function if the module is connected. For example, this method returns `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1` if the module is already connected or `Relay(BadCustomName.relay1)=unresolved` if the module has not yet been connected. This method does not trigger any USB or TCP transaction and can therefore be used in a debugger.

**Returns :**

a string that describes the electrical power sensor (ex:  
`Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1`)



---

**power**→**get\_advertisedValue()****YPower****power**→**advertisedValue()****power.get\_advertisedValue()**

---

Returns the current value of the electrical power sensor (no more than 6 characters).

```
function get_advertisedValue( ) As String
```

**Returns :**

a string corresponding to the current value of the electrical power sensor (no more than 6 characters).

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

**power**→**get\_cosPhi()**

**YPower**

**power**→**cosPhi()****power.get\_cosPhi()**

---

Returns the power factor (the ratio between the real power consumed, measured in W, and the apparent power provided, measured in VA).

function **get\_cosPhi**( ) As Double

**Returns :**

a floating point number corresponding to the power factor (the ratio between the real power consumed, measured in W, and the apparent power provided, measured in VA)

On failure, throws an exception or returns Y\_COSPHI\_INVALID.

---

**power**→**get\_currentRawValue()****YPower****power**→**currentRawValue()****power.get\_currentRawValue()**

---

Returns the uncalibrated, unrounded raw value returned by the sensor, in Watt, as a floating point number.

```
function get_currentRawValue( ) As Double
```

**Returns :**

a floating point number corresponding to the uncalibrated, unrounded raw value returned by the sensor, in Watt, as a floating point number

On failure, throws an exception or returns `Y_CURRENTRAWVALUE_INVALID`.

**power**→**get\_currentValue()**

**YPower**

**power**→**currentValue()****power.get\_currentValue()**

---

Returns the current value of the electrical power, in Watt, as a floating point number.

function **get\_currentValue**( ) As Double

**Returns :**

a floating point number corresponding to the current value of the electrical power, in Watt, as a floating point number

On failure, throws an exception or returns `Y_CURRENTVALUE_INVALID`.

---

**power**→**get\_errorMessage()****YPower****power**→**errorMessage()****power**.**get\_errorMessage()**

---

Returns the error message of the latest error with the electrical power sensor.

function **get\_errorMessage**( ) As String

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using the electrical power sensor object

**power**→**get\_errorType()**

**YPower**

**power**→**errorType()****power.get\_errorType()**

---

Returns the numerical error code of the latest error with the electrical power sensor.

function **get\_errorType**( ) As YRETCODE

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using the electrical power sensor object

---

**power**→**get\_functionDescriptor()****YPower****power**→**functionDescriptor()****power.get\_functionDescriptor()**

---

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

function **get\_functionDescriptor**( ) As `YFUN_DESCR`

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`.

If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

**power**→**get\_functionId()**

**YPower**

**power**→**functionId()****power.get\_functionId()**

---

Returns the hardware identifier of the electrical power sensor, without reference to the module.

function **get\_functionId**( ) As String

For example `relay1`

**Returns :**

a string that identifies the electrical power sensor (ex: `relay1`)

On failure, throws an exception or returns `Y_FUNCTIONID_INVALID`.



---

**power**→**get\_hardwareId()****YPower****power**→**hardwareId()****power.get\_hardwareId()**

---

Returns the unique hardware identifier of the electrical power sensor in the form `SERIAL.FUNCTIONID`.

function **get\_hardwareId**( ) As String

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the electrical power sensor (for example `RELAYLO1-123456.relay1`).

**Returns :**

a string that uniquely identifies the electrical power sensor (ex: `RELAYLO1-123456.relay1`)

On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

**power**→**get\_highestValue()**

**YPower**

**power**→**highestValue()****power.get\_highestValue()**

---

Returns the maximal value observed for the electrical power since the device was started.

function **get\_highestValue**( ) As Double

**Returns :**

a floating point number corresponding to the maximal value observed for the electrical power since the device was started

On failure, throws an exception or returns `Y_HIGHESTVALUE_INVALID`.

---

**power**→**get\_logFrequency()****YPower****power**→**logFrequency()****power.get\_logFrequency()**

---

Returns the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory.

function **get\_logFrequency()** As String

**Returns :**

a string corresponding to the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory

On failure, throws an exception or returns `Y_LOGFREQUENCY_INVALID`.

**power**→**get\_logicalName()**

**YPower**

**power**→**logicalName()****power.get\_logicalName()**

---

Returns the logical name of the electrical power sensor.

function **get\_logicalName**( ) As String

**Returns :**

a string corresponding to the logical name of the electrical power sensor.

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

---

**power**→**get\_lowestValue()****YPower****power**→**lowestValue()****power.get\_lowestValue()**

---

Returns the minimal value observed for the electrical power since the device was started.

function **get\_lowestValue()** As Double

**Returns :**

a floating point number corresponding to the minimal value observed for the electrical power since the device was started

On failure, throws an exception or returns `Y_LOWESTVALUE_INVALID`.

**power**→**get\_meter()**

**YPower**

**power**→**meter()****power.get\_meter()**

---

Returns the energy counter, maintained by the wattmeter by integrating the power consumption over time.

```
function get_meter( ) As Double
```

Note that this counter is reset at each start of the device.

**Returns :**

a floating point number corresponding to the energy counter, maintained by the wattmeter by integrating the power consumption over time

On failure, throws an exception or returns `Y_METER_INVALID`.

---

**power**→**get\_meterTimer()****YPower****power**→**meterTimer()****power.get\_meterTimer()**

---

Returns the elapsed time since last energy counter reset, in seconds.

function **get\_meterTimer**( ) As Integer

**Returns :**

an integer corresponding to the elapsed time since last energy counter reset, in seconds

On failure, throws an exception or returns `Y_METERTIMER_INVALID`.

**power**→**get\_module()**

**YPower**

**power**→**module()****power.get\_module()**

---

Gets the YModule object for the device on which the function is located.

function **get\_module()** As YModule

If the function cannot be located on any module, the returned instance of YModule is not shown as on-line.

**Returns :**

an instance of YModule



---

**power**→**get\_recordedData()****YPower****power**→**recordedData()****power.get\_recordedData()**

---

Retrieves a DataSet object holding historical data for this sensor, for a specified time interval.

```
function get_recordedData( ) As YDataSet
```

The measures will be retrieved from the data logger, which must have been turned on at the desired time. See the documentation of the DataSet class for information on how to get an overview of the recorded data, and how to load progressively a large set of measures from the data logger.

This function only works if the device uses a recent firmware, as DataSet objects are not supported by firmwares older than version 13000.

**Parameters :**

- startTime** the start of the desired measure time interval, as a Unix timestamp, i.e. the number of seconds since January 1, 1970 UTC. The special value 0 can be used to include any measure, without initial limit.
- endTime** the end of the desired measure time interval, as a Unix timestamp, i.e. the number of seconds since January 1, 1970 UTC. The special value 0 can be used to include any measure, without ending limit.

**Returns :**

an instance of YDataSet, providing access to historical data. Past measures can be loaded progressively using methods from the YDataSet object.

**power**→**get\_reportFrequency()**

**YPower**

**power**→**reportFrequency()**

**power.get\_reportFrequency()**

---

Returns the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function.

```
function get_reportFrequency( ) As String
```

**Returns :**

a string corresponding to the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function

On failure, throws an exception or returns `Y_REPORTFREQUENCY_INVALID`.

---

**power**→**get\_resolution()****YPower****power**→**resolution()****power.get\_resolution()**

---

Returns the resolution of the measured values.

function **get\_resolution**( ) As Double

The resolution corresponds to the numerical precision of the measures, which is not always the same as the actual precision of the sensor.

**Returns :**

a floating point number corresponding to the resolution of the measured values

On failure, throws an exception or returns `Y_RESOLUTION_INVALID`.

**power**→**get\_unit()**

**YPower**

**power**→**unit()****power.get\_unit()**

---

Returns the measuring unit for the electrical power.

function **get\_unit**( ) As String

**Returns :**

a string corresponding to the measuring unit for the electrical power

On failure, throws an exception or returns `Y_UNIT_INVALID`.

---

**power**→**get\_userData()****YPower****power**→**userData()****power.get\_userData()**

---

Returns the value of the userData attribute, as previously stored using method `set_userData`.

```
function get_userData( ) As Object
```

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

**power**→**isOnline()****power.isOnline()**

**YPower**

---

Checks if the electrical power sensor is currently reachable, without raising any error.

function **isOnline**( ) As Boolean

If there is a cached value for the electrical power sensor in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the electrical power sensor.

**Returns :**

`true` if the electrical power sensor can be reached, and `false` otherwise

**power→load()power.load()****YPower**

Preloads the electrical power sensor cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

**power→loadCalibrationPoints()  
power.loadCalibrationPoints()**

**YPower**

Retrieves error correction data points previously entered using the method `calibrateFromPoints`.

procedure **loadCalibrationPoints( )**

**Parameters :**

**rawValues** array of floating point numbers, that will be filled by the function with the raw sensor values for the correction points.

**refValues** array of floating point numbers, that will be filled by the function with the desired values for the correction points.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.



---

**power**→**nextPower()****power.nextPower()****YPower**

---

Continues the enumeration of electrical power sensors started using `yFirstPower()`.

```
function nextPower( ) As YPower
```

**Returns :**

a pointer to a `YPower` object, corresponding to a electrical power sensor currently online, or a `null` pointer if there are no more electrical power sensors to enumerate.

**power**→**registerTimedReportCallback()**  
**power.registerTimedReportCallback()**

YPower

Registers the callback function that is invoked on every periodic timed notification.

```
function registerTimedReportCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and an YMeasure object describing the new advertised value.

---

**power**→**registerValueCallback()**  
**power.registerValueCallback()**

---

**YPower**

Registers the callback function that is invoked on every change of advertised value.

function **registerValueCallback**( ) As Integer

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

**power**→**reset()****power.reset()**

**YPower**

---

Resets the energy counter.

function **reset**( ) As Integer

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**power**→**set\_highestValue()****YPower****power**→**setHighestValue()****power.set\_highestValue()**

---

Changes the recorded maximal value observed.

```
function set_highestValue( ByVal newval As Double) As Integer
```

**Parameters :**

**newval** a floating point number corresponding to the recorded maximal value observed

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**power**→**set\_logFrequency()**

**YPower**

**power**→**setLogFrequency()****power.set\_logFrequency()**

---

Changes the datalogger recording frequency for this function.

```
function set_logFrequency( ByVal newval As String) As Integer
```

The frequency can be specified as samples per second, as sample per minute (for instance "15/m") or in samples per hour (eg. "4/h"). To disable recording for this function, use the value "OFF".

**Parameters :**

**newval** a string corresponding to the datalogger recording frequency for this function

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**power**→**set\_logicalName()****YPower****power**→**setLogicalName()****power.set\_logicalName()**

---

Changes the logical name of the electrical power sensor.

```
function set_logicalName( ByVal newval As String) As Integer
```

You can use `yCheckLogicalName( )` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash( )` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the electrical power sensor.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**power**→**set\_lowestValue()**

**YPower**

**power**→**setLowestValue()****power.set\_lowestValue()**

---

Changes the recorded minimal value observed.

```
function set_lowestValue( ByVal newval As Double) As Integer
```

**Parameters :**

**newval** a floating point number corresponding to the recorded minimal value observed

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.



---

**power**→**set\_reportFrequency()**  
**power**→**setReportFrequency()**  
**power.set\_reportFrequency()**

---

**YPower**

Changes the timed value notification frequency for this function.

```
function set_reportFrequency( ByVal newval As String) As Integer
```

The frequency can be specified as samples per second, as sample per minute (for instance "15/m") or in samples per hour (eg. "4/h"). To disable timed value notifications for this function, use the value "OFF".

**Parameters :**

**newval** a string corresponding to the timed value notification frequency for this function

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**power**→**set\_resolution()**

**YPower**

**power**→**setResolution()****power.set\_resolution()**

---

Changes the resolution of the measured physical values.

```
function set_resolution( ByVal newval As Double) As Integer
```

The resolution corresponds to the numerical precision when displaying value. It does not change the precision of the measure itself.

**Parameters :**

**newval** a floating point number corresponding to the resolution of the measured physical values

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**power**→**set\_userData()****YPower****power**→**setUserData()****power.set\_userData()**

---

Stores a user context provided as argument in the userData attribute of the function.

```
procedure set_userData( ByVal data As Object)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

## 3.31. Pressure function interface

The Yoctopuce application programming interface allows you to read an instant measure of the sensor, as well as the minimal and maximal values observed.

In order to use the functions described here, you should include:

js	<code>&lt;script type='text/javascript' src='yocto_pressure.js'&gt;&lt;/script&gt;</code>
nodejs	<code>var yoctolib = require('yoctolib');</code> <code>var YPressure = yoctolib.YPressure;</code>
php	<code>require_once('yocto_pressure.php');</code>
c++	<code>#include "yocto_pressure.h"</code>
m	<code>#import "yocto_pressure.h"</code>
pas	<code>uses yocto_pressure;</code>
vb	<code>yocto_pressure.vb</code>
cs	<code>yocto_pressure.cs</code>
java	<code>import com.yoctopuce.YoctoAPI.YPressure;</code>
py	<code>from yocto_pressure import *</code>

### Global functions

#### **yFindPressure(func)**

Retrieves a pressure sensor for a given identifier.

#### **yFirstPressure()**

Starts the enumeration of pressure sensors currently accessible.

### YPressure methods

#### **pressure→calibrateFromPoints(rawValues, refValues)**

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

#### **pressure→describe()**

Returns a short text that describes unambiguously the instance of the pressure sensor in the form `TYPE ( NAME ) = SERIAL . FUNCTIONID`.

#### **pressure→get\_advertisedValue()**

Returns the current value of the pressure sensor (no more than 6 characters).

#### **pressure→get\_currentRawValue()**

Returns the uncalibrated, unrounded raw value returned by the sensor, in millibar (hPa), as a floating point number.

#### **pressure→get\_currentValue()**

Returns the current value of the pressure, in millibar (hPa), as a floating point number.

#### **pressure→get\_errorMessage()**

Returns the error message of the latest error with the pressure sensor.

#### **pressure→get\_errorType()**

Returns the numerical error code of the latest error with the pressure sensor.

#### **pressure→get\_friendlyName()**

Returns a global identifier of the pressure sensor in the format `MODULE_NAME . FUNCTION_NAME`.

#### **pressure→get\_functionDescriptor()**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

#### **pressure→get\_functionId()**

Returns the hardware identifier of the pressure sensor, without reference to the module.

#### **pressure→get\_hardwareId()**

Returns the unique hardware identifier of the pressure sensor in the form `SERIAL.FUNCTIONID`.

**pressure→get\_highestValue()**

Returns the maximal value observed for the pressure since the device was started.

**pressure→get\_logFrequency()**

Returns the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory.

**pressure→get\_logicalName()**

Returns the logical name of the pressure sensor.

**pressure→get\_lowestValue()**

Returns the minimal value observed for the pressure since the device was started.

**pressure→get\_module()**

Gets the `YModule` object for the device on which the function is located.

**pressure→get\_module\_async(callback, context)**

Gets the `YModule` object for the device on which the function is located (asynchronous version).

**pressure→get\_recordedData(startTime, endTime)**

Retrieves a `DataSet` object holding historical data for this sensor, for a specified time interval.

**pressure→get\_reportFrequency()**

Returns the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function.

**pressure→get\_resolution()**

Returns the resolution of the measured values.

**pressure→get\_unit()**

Returns the measuring unit for the pressure.

**pressure→get\_userData()**

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

**pressure→isOnline()**

Checks if the pressure sensor is currently reachable, without raising any error.

**pressure→isOnline\_async(callback, context)**

Checks if the pressure sensor is currently reachable, without raising any error (asynchronous version).

**pressure→load(msValidity)**

Preloads the pressure sensor cache with a specified validity duration.

**pressure→loadCalibrationPoints(rawValues, refValues)**

Retrieves error correction data points previously entered using the method `calibrateFromPoints`.

**pressure→load\_async(msValidity, callback, context)**

Preloads the pressure sensor cache with a specified validity duration (asynchronous version).

**pressure→nextPressure()**

Continues the enumeration of pressure sensors started using `yFirstPressure()`.

**pressure→registerTimedReportCallback(callback)**

Registers the callback function that is invoked on every periodic timed notification.

**pressure→registerValueCallback(callback)**

Registers the callback function that is invoked on every change of advertised value.

**pressure→set\_highestValue(newval)**

Changes the recorded maximal value observed.

**pressure→set\_logFrequency(newval)**

Changes the datalogger recording frequency for this function.

**pressure→set\_logicalName(newval)**

### 3. Reference

---

Changes the logical name of the pressure sensor.

**pressure**→**set\_lowestValue(newval)**

Changes the recorded minimal value observed.

**pressure**→**set\_reportFrequency(newval)**

Changes the timed value notification frequency for this function.

**pressure**→**set\_resolution(newval)**

Changes the resolution of the measured physical values.

**pressure**→**set\_userData(data)**

Stores a user context provided as argument in the userData attribute of the function.

**pressure**→**wait\_async(callback, context)**

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.

## YPressure.FindPressure() yFindPressure()yFindPressure()

YPressure

Retrieves a pressure sensor for a given identifier.

```
function yFindPressure( ByVal func As String) As YPressure
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the pressure sensor is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YPressure.IsOnline()` to test if the pressure sensor is indeed online at a given time. In case of ambiguity when looking for a pressure sensor by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

### Parameters :

**func** a string that uniquely characterizes the pressure sensor

### Returns :

a `YPressure` object allowing you to drive the pressure sensor.

## **YPressure.FirstPressure() yFirstPressure()yFirstPressure()**

---

**YPressure**

Starts the enumeration of pressure sensors currently accessible.

```
function yFirstPressure( ) As YPressure
```

Use the method `YPressure.nextPressure()` to iterate on next pressure sensors.

**Returns :**

a pointer to a `YPressure` object, corresponding to the first pressure sensor currently online, or a `null` pointer if there are none.



---

**pressure**→**calibrateFromPoints()**  
**pressure.calibrateFromPoints()****YPressure**

---

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

**procedure calibrateFromPoints( )**

It is possible to configure up to five correction points. Correction points must be provided in ascending order, and be in the range of the sensor. The device will automatically perform a linear interpolation of the error correction between specified points. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

For more information on advanced capabilities to refine the calibration of sensors, please contact [support@yoctopuce.com](mailto:support@yoctopuce.com).

**Parameters :**

**rawValues** array of floating point numbers, corresponding to the raw values returned by the sensor for the correction points.

**refValues** array of floating point numbers, corresponding to the corrected values for the correction points.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**pressure**→**describe()****pressure.describe()****YPressure**

Returns a short text that describes unambiguously the instance of the pressure sensor in the form `TYPE (NAME) =SERIAL . FUNCTIONID`.

function **describe**( ) As String

More precisely, `TYPE` is the type of the function, `NAME` is the name used for the first access to the function, `SERIAL` is the serial number of the module if the module is connected or "unresolved", and `FUNCTIONID` is the hardware identifier of the function if the module is connected. For example, this method returns `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1` if the module is already connected or `Relay(BadCustomeName.relay1)=unresolved` if the module has not yet been connected. This method does not trigger any USB or TCP transaction and can therefore be used in a debugger.

**Returns :**

a string that describes the pressure sensor (ex: `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1`)

---

**pressure**→**get\_advertisedValue()**

**YPressure**

**pressure**→**advertisedValue()**

**pressure.get\_advertisedValue()**

---

Returns the current value of the pressure sensor (no more than 6 characters).

```
function get_advertisedValue( ) As String
```

**Returns :**

a string corresponding to the current value of the pressure sensor (no more than 6 characters).

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

**pressure**→**get\_currentRawValue()**

**YPressure**

**pressure**→**currentRawValue()**

**pressure.get\_currentRawValue()**

---

Returns the uncalibrated, unrounded raw value returned by the sensor, in millibar (hPa), as a floating point number.

```
function get_currentRawValue( ) As Double
```

**Returns :**

a floating point number corresponding to the uncalibrated, unrounded raw value returned by the sensor, in millibar (hPa), as a floating point number

On failure, throws an exception or returns `Y_CURRENTRAWVALUE_INVALID`.

---

**pressure**→**get\_currentValue()**

**YPressure**

**pressure**→**currentValue()****pressure.get\_currentValue()**

---

Returns the current value of the pressure, in millibar (hPa), as a floating point number.

function **get\_currentValue()** As Double

**Returns :**

a floating point number corresponding to the current value of the pressure, in millibar (hPa), as a floating point number

On failure, throws an exception or returns **Y\_CURRENTVALUE\_INVALID**.

**pressure**→**get\_errorMessage()**

**YPressure**

**pressure**→**errorMessage()**

**pressure**.**get\_errorMessage()**

---

Returns the error message of the latest error with the pressure sensor.

```
function get_errorMessage( ) As String
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using the pressure sensor object

---

**pressure**→**get\_errorType()****YPressure****pressure**→**errorType()****pressure.get\_errorType()**

---

Returns the numerical error code of the latest error with the pressure sensor.

```
function get_errorType( ) As YRETCODE
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using the pressure sensor object

**pressure**→**get\_functionDescriptor()**  
**pressure**→**functionDescriptor()**  
**pressure.get\_functionDescriptor()**

---

**YPressure**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

`function get_functionDescriptor( )` As `YFUN_DESCR`

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`.

If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.



---

**pressure**→**get\_functionId()****YPressure****pressure**→**functionId()****pressure.get\_functionId()**

---

Returns the hardware identifier of the pressure sensor, without reference to the module.

function **get\_functionId()** As String

For example `relay1`

**Returns :**

a string that identifies the pressure sensor (ex: `relay1`)

On failure, throws an exception or returns `Y_FUNCTIONID_INVALID`.

**pressure**→**get\_hardwareId()**

**YPressure**

**pressure**→**hardwareId()****pressure.get\_hardwareId()**

---

Returns the unique hardware identifier of the pressure sensor in the form `SERIAL.FUNCTIONID`.

function **get\_hardwareId()** As String

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the pressure sensor (for example `RELAYLO1-123456.relay1`).

**Returns :**

a string that uniquely identifies the pressure sensor (ex: `RELAYLO1-123456.relay1`)

On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

---

**pressure**→**get\_highestValue()**

**YPressure**

**pressure**→**highestValue()**

**pressure.get\_highestValue()**

---

Returns the maximal value observed for the pressure since the device was started.

```
function get_highestValue( ) As Double
```

**Returns :**

a floating point number corresponding to the maximal value observed for the pressure since the device was started

On failure, throws an exception or returns `Y_HIGHESTVALUE_INVALID`.

**pressure**→**get\_logFrequency()**

**YPressure**

**pressure**→**logFrequency()**

**pressure.get\_logFrequency()**

---

Returns the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory.

function **get\_logFrequency()** As String

**Returns :**

a string corresponding to the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory

On failure, throws an exception or returns `Y_LOGFREQUENCY_INVALID`.

---

**pressure**→**get\_logicalName()****YPressure****pressure**→**logicalName()****pressure.get\_logicalName()**

---

Returns the logical name of the pressure sensor.

```
function get_logicalName( ) As String
```

**Returns :**

a string corresponding to the logical name of the pressure sensor.

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

**pressure**→**get\_lowestValue()**

**YPressure**

**pressure**→**lowestValue()****pressure.get\_lowestValue()**

---

Returns the minimal value observed for the pressure since the device was started.

function **get\_lowestValue()** As Double

**Returns :**

a floating point number corresponding to the minimal value observed for the pressure since the device was started

On failure, throws an exception or returns `Y_LOWESTVALUE_INVALID`.

---

**pressure**→**get\_module()****YPressure****pressure**→**module()****pressure.get\_module()**

---

Gets the `YModule` object for the device on which the function is located.

function `get_module( )` As `YModule`

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

**Returns :**

an instance of `YModule`

**pressure**→**get\_recordedData()****YPressure****pressure**→**recordedData()****pressure.get\_recordedData()**

Retrieves a DataSet object holding historical data for this sensor, for a specified time interval.

```
function get_recordedData( ) As YDataSet
```

The measures will be retrieved from the data logger, which must have been turned on at the desired time. See the documentation of the DataSet class for information on how to get an overview of the recorded data, and how to load progressively a large set of measures from the data logger.

This function only works if the device uses a recent firmware, as DataSet objects are not supported by firmwares older than version 13000.

**Parameters :**

**startTime** the start of the desired measure time interval, as a Unix timestamp, i.e. the number of seconds since January 1, 1970 UTC. The special value 0 can be used to include any measure, without initial limit.

**endTime** the end of the desired measure time interval, as a Unix timestamp, i.e. the number of seconds since January 1, 1970 UTC. The special value 0 can be used to include any measure, without ending limit.

**Returns :**

an instance of YDataSet, providing access to historical data. Past measures can be loaded progressively using methods from the YDataSet object.



---

**pressure**→**get\_reportFrequency()**

**YPressure**

**pressure**→**reportFrequency()**

**pressure.get\_reportFrequency()**

---

Returns the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function.

function **get\_reportFrequency( )** As String

**Returns :**

a string corresponding to the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function

On failure, throws an exception or returns `Y_REPORTFREQUENCY_INVALID`.

**pressure**→**get\_resolution()**

**YPressure**

**pressure**→**resolution()****pressure.get\_resolution()**

---

Returns the resolution of the measured values.

```
function get_resolution( ) As Double
```

The resolution corresponds to the numerical precision of the measures, which is not always the same as the actual precision of the sensor.

**Returns :**

a floating point number corresponding to the resolution of the measured values

On failure, throws an exception or returns `Y_RESOLUTION_INVALID`.

---

**pressure**→**get\_unit()****YPressure****pressure**→**unit()****pressure.get\_unit()**

---

Returns the measuring unit for the pressure.

function **get\_unit**( ) As String

**Returns :**

a string corresponding to the measuring unit for the pressure

On failure, throws an exception or returns `Y_UNIT_INVALID`.

**pressure**→**get\_userData()**

**YPressure**

**pressure**→**userData()****pressure.get\_userData()**

---

Returns the value of the userData attribute, as previously stored using method `set_userData`.

function **get\_userData**( ) As Object

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

---

**pressure**→**isOnline()****pressure.isOnline()****YPressure**

---

Checks if the pressure sensor is currently reachable, without raising any error.

```
function isOnline( ) As Boolean
```

If there is a cached value for the pressure sensor in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the pressure sensor.

**Returns :**

`true` if the pressure sensor can be reached, and `false` otherwise

**pressure**→**load()****pressure.load()****YPressure**

Preloads the pressure sensor cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**pressure**→**loadCalibrationPoints()**  
**pressure.loadCalibrationPoints()****YPressure**

---

Retrieves error correction data points previously entered using the method `calibrateFromPoints`.

procedure **loadCalibrationPoints()**

**Parameters :**

**rawValues** array of floating point numbers, that will be filled by the function with the raw sensor values for the correction points.

**refValues** array of floating point numbers, that will be filled by the function with the desired values for the correction points.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**pressure**→**nextPressure()****pressure.nextPressure()**

**YPressure**

---

Continues the enumeration of pressure sensors started using `yFirstPressure()`.

function **nextPressure()** As YPressure

**Returns :**

a pointer to a YPressure object, corresponding to a pressure sensor currently online, or a null pointer if there are no more pressure sensors to enumerate.



---

**pressure**→**registerTimedReportCallback()**  
**pressure.registerTimedReportCallback()**

---

**YPressure**

Registers the callback function that is invoked on every periodic timed notification.

```
function registerTimedReportCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and an `YMeasure` object describing the new advertised value.

**pressure**→**registerValueCallback()**  
**pressure.registerValueCallback()****YPressure**

Registers the callback function that is invoked on every change of advertised value.

```
function registerValueCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

---

**pressure**→**set\_highestValue()**

**YPressure**

**pressure**→**setHighestValue()**

**pressure.set\_highestValue()**

---

Changes the recorded maximal value observed.

```
function set_highestValue( ByVal newval As Double) As Integer
```

**Parameters :**

**newval** a floating point number corresponding to the recorded maximal value observed

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**pressure**→**set\_logFrequency()**

**YPressure**

**pressure**→**setLogFrequency()**

**pressure.set\_logFrequency()**

---

Changes the datalogger recording frequency for this function.

```
function set_logFrequency( ByVal newval As String) As Integer
```

The frequency can be specified as samples per second, as sample per minute (for instance "15/m") or in samples per hour (eg. "4/h"). To disable recording for this function, use the value "OFF".

**Parameters :**

**newval** a string corresponding to the datalogger recording frequency for this function

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**pressure**→**set\_logicalName()**  
**pressure**→**setLogicalName()**  
**pressure.set\_logicalName()**

---

**YPressure**

Changes the logical name of the pressure sensor.

```
function set_logicalName( ByVal newval As String) As Integer
```

You can use `yCheckLogicalName( )` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash( )` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the pressure sensor.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**pressure**→**set\_lowestValue()**  
**pressure**→**setLowestValue()**  
**pressure.set\_lowestValue()**

**YPressure**

---

Changes the recorded minimal value observed.

```
function set_lowestValue( ByVal newval As Double) As Integer
```

**Parameters :**

**newval** a floating point number corresponding to the recorded minimal value observed

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**pressure**→**set\_reportFrequency()****YPressure****pressure**→**setReportFrequency()****pressure.set\_reportFrequency()**

---

Changes the timed value notification frequency for this function.

```
function set_reportFrequency( ByVal newval As String) As Integer
```

The frequency can be specified as samples per second, as sample per minute (for instance "15/m") or in samples per hour (eg. "4/h"). To disable timed value notifications for this function, use the value "OFF".

**Parameters :**

**newval** a string corresponding to the timed value notification frequency for this function

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**pressure**→**set\_resolution()**

**YPressure**

**pressure**→**setResolution()****pressure.set\_resolution()**

---

Changes the resolution of the measured physical values.

```
function set_resolution( ByVal newval As Double) As Integer
```

The resolution corresponds to the numerical precision when displaying value. It does not change the precision of the measure itself.

**Parameters :**

**newval** a floating point number corresponding to the resolution of the measured physical values

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.



---

**pressure**→**set\_userData()****YPressure****pressure**→**setUserData()****pressure.set\_userData()**

---

Stores a user context provided as argument in the `userData` attribute of the function.

```
procedure set_userData( ByVal data As Object)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

## 3.32. PwmInput function interface

The Yoctopuce application programming interface allows you to read an instant measure of the sensor, as well as the minimal and maximal values observed.

In order to use the functions described here, you should include:

js	<script type='text/javascript' src='yocto_pwminput.js'></script>
nodejs	var yoctolib = require('yoctolib'); var YPwmInput = yoctolib.YPwmInput;
php	require_once('yocto_pwminput.php');
c++	#include "yocto_pwminput.h"
m	#import "yocto_pwminput.h"
pas	uses yocto_pwminput;
vb	yocto_pwminput.vb
cs	yocto_pwminput.cs
java	import com.yoctopuce.YoctoAPI.YPwmInput;
py	from yocto_pwminput import *

### Global functions

#### yFindPwmInput(func)

Retrieves a voltage sensor for a given identifier.

#### yFirstPwmInput()

Starts the enumeration of voltage sensors currently accessible.

### YPwmInput methods

#### pwminput→calibrateFromPoints(rawValues, refValues)

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

#### pwminput→describe()

Returns a short text that describes unambiguously the instance of the voltage sensor in the form TYPE ( NAME ) = SERIAL . FUNCTIONID.

#### pwminput→get\_advertisedValue()

Returns the current value of the voltage sensor (no more than 6 characters).

#### pwminput→get\_currentRawValue()

Returns the uncalibrated, unrounded raw value returned by the sensor, in Volt, as a floating point number.

#### pwminput→get\_currentValue()

Returns the current value of PwmInput feature as a floating point number.

#### pwminput→get\_dutyCycle()

Returns the PWM duty cycle, in per cents.

#### pwminput→get\_errorMessage()

Returns the error message of the latest error with the voltage sensor.

#### pwminput→get\_errorType()

Returns the numerical error code of the latest error with the voltage sensor.

#### pwminput→get\_frequency()

Returns the PWM frequency in Hz.

#### pwminput→get\_friendlyName()

Returns a global identifier of the voltage sensor in the format MODULE\_NAME . FUNCTION\_NAME.

#### pwminput→get\_functionDescriptor()

Returns a unique identifier of type YFUN\_DESCR corresponding to the function.

**pwminput→get\_functionId()**

Returns the hardware identifier of the voltage sensor, without reference to the module.

**pwminput→get\_hardwareId()**

Returns the unique hardware identifier of the voltage sensor in the form `SERIAL.FUNCTIONID`.

**pwminput→get\_highestValue()**

Returns the maximal value observed for the voltage since the device was started.

**pwminput→get\_logFrequency()**

Returns the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory.

**pwminput→get\_logicalName()**

Returns the logical name of the voltage sensor.

**pwminput→get\_lowestValue()**

Returns the minimal value observed for the voltage since the device was started.

**pwminput→get\_module()**

Gets the `YModule` object for the device on which the function is located.

**pwminput→get\_module\_async(callback, context)**

Gets the `YModule` object for the device on which the function is located (asynchronous version).

**pwminput→get\_period()**

Returns the PWM period in milliseconds.

**pwminput→get\_pulseCounter()**

Returns the pulse counter value.

**pwminput→get\_pulseDuration()**

Returns the PWM pulse length in milliseconds, as a floating point number.

**pwminput→get\_pulseTimer()**

Returns the timer of the pulses counter (ms)

**pwminput→get\_pwmReportMode()**

Returns the parameter (frequency/duty cycle, pulse width, edges count) returned by the `get_currentValue` function and callbacks.

**pwminput→get\_recordedData(startTime, endTime)**

Retrieves a `DataSet` object holding historical data for this sensor, for a specified time interval.

**pwminput→get\_reportFrequency()**

Returns the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function.

**pwminput→get\_resolution()**

Returns the resolution of the measured values.

**pwminput→get\_unit()**

Returns the measuring unit for the values returned by `get_currentValue` and callbacks.

**pwminput→get\_userData()**

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

**pwminput→isOnline()**

Checks if the voltage sensor is currently reachable, without raising any error.

**pwminput→isOnline\_async(callback, context)**

Checks if the voltage sensor is currently reachable, without raising any error (asynchronous version).

**pwminput→load(msValidity)**

Preloads the voltage sensor cache with a specified validity duration.

**pwminput→loadCalibrationPoints(rawValues, refValues)**

### 3. Reference

Retrieves error correction data points previously entered using the method `calibrateFromPoints`.

**`pwminput→load_async(msValidity, callback, context)`**

Preloads the voltage sensor cache with a specified validity duration (asynchronous version).

**`pwminput→nextPwmInput()`**

Continues the enumeration of voltage sensors started using `yFirstPwmInput()`.

**`pwminput→registerTimedReportCallback(callback)`**

Registers the callback function that is invoked on every periodic timed notification.

**`pwminput→registerValueCallback(callback)`**

Registers the callback function that is invoked on every change of advertised value.

**`pwminput→resetCounter()`**

Returns the pulse counter value as well as his timer

**`pwminput→set_highestValue(newval)`**

Changes the recorded maximal value observed.

**`pwminput→set_logFrequency(newval)`**

Changes the datalogger recording frequency for this function.

**`pwminput→set_logicalName(newval)`**

Changes the logical name of the voltage sensor.

**`pwminput→set_lowestValue(newval)`**

Changes the recorded minimal value observed.

**`pwminput→set_pwmReportMode(newval)`**

Modify the parameter type(frequency/duty cycle, pulse width ou edge count) returned by the `get_currentValue` function and callbacks.

**`pwminput→set_reportFrequency(newval)`**

Changes the timed value notification frequency for this function.

**`pwminput→set_resolution(newval)`**

Changes the resolution of the measured physical values.

**`pwminput→set_userData(data)`**

Stores a user context provided as argument in the `userData` attribute of the function.

**`pwminput→wait_async(callback, context)`**

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.

## YPwmInput.FindPwmInput() yFindPwmInput()yFindPwmInput()

YPwmInput

Retrieves a voltage sensor for a given identifier.

```
function yFindPwmInput( ByVal func As String) As YPwmInput
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the voltage sensor is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YPwmInput.IsOnline()` to test if the voltage sensor is indeed online at a given time. In case of ambiguity when looking for a voltage sensor by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

### Parameters :

**func** a string that uniquely characterizes the voltage sensor

### Returns :

a `YPwmInput` object allowing you to drive the voltage sensor.

## YPwmInput.FirstPwmInput() yFirstPwmInput()yFirstPwmInput()

---

YPwmInput

Starts the enumeration of voltage sensors currently accessible.

```
function yFirstPwmInput( ) As YPwmInput
```

Use the method `YPwmInput.nextPwmInput( )` to iterate on next voltage sensors.

**Returns :**

a pointer to a `YPwmInput` object, corresponding to the first voltage sensor currently online, or a `null` pointer if there are none.

---

**pwminput**→**calibrateFromPoints()**  
**pwminput.calibrateFromPoints()****YPwmInput**

---

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

procedure **calibrateFromPoints()** ( )

It is possible to configure up to five correction points. Correction points must be provided in ascending order, and be in the range of the sensor. The device will automatically perform a linear interpolation of the error correction between specified points. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

For more information on advanced capabilities to refine the calibration of sensors, please contact [support@yoctopuce.com](mailto:support@yoctopuce.com).

**Parameters :**

**rawValues** array of floating point numbers, corresponding to the raw values returned by the sensor for the correction points.

**refValues** array of floating point numbers, corresponding to the corrected values for the correction points.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**pwminput**→**describe()****pwminput.describe()****YPwmInput**

Returns a short text that describes unambiguously the instance of the voltage sensor in the form `TYPE (NAME) =SERIAL . FUNCTIONID`.

function **describe**( ) As String

More precisely, `TYPE` is the type of the function, `NAME` it the name used for the first access to the function, `SERIAL` is the serial number of the module if the module is connected or "unresolved", and `FUNCTIONID` is the hardware identifier of the function if the module is connected. For example, this method returns `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1` if the module is already connected or `Relay(BadCustomeName.relay1)=unresolved` if the module has not yet been connected. This method does not trigger any USB or TCP transaction and can therefore be used in a debugger.

**Returns :**

a string that describes the voltage sensor (ex: `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1`)



---

**pwminput→get\_advertisedValue()**

**YPwmInput**

**pwminput→advertisedValue()**

**pwminput.get\_advertisedValue()**

---

Returns the current value of the voltage sensor (no more than 6 characters).

```
function get_advertisedValue( ) As String
```

**Returns :**

a string corresponding to the current value of the voltage sensor (no more than 6 characters).

On failure, throws an exception or returns Y\_ADVERTISEDVALUE\_INVALID.

`pwminput`→`get_currentRawValue()`

**YPwmInput**

`pwminput`→`currentRawValue()`

`pwminput.get_currentRawValue()`

---

Returns the uncalibrated, unrounded raw value returned by the sensor, in Volt, as a floating point number.

```
function get_currentRawValue( ) As Double
```

**Returns :**

a floating point number corresponding to the uncalibrated, unrounded raw value returned by the sensor, in Volt, as a floating point number

On failure, throws an exception or returns `Y_CURRENTRAWVALUE_INVALID`.

---

**pwminput→get\_currentValue()****YPwmInput****pwminput→currentValue()****pwminput.get\_currentValue()**

---

Returns the current value of PwmInput feature as a floating point number.

```
function get_currentValue( ) As Double
```

Depending on the pwmReportMode setting, this can be the frequency, in Hz, the duty cycle in % or the pulse length.

**Returns :**

a floating point number corresponding to the current value of PwmInput feature as a floating point number

On failure, throws an exception or returns Y\_CURRENTVALUE\_INVALID.

**pwminput**→**get\_dutyCycle()**

**YPwmInput**

**pwminput**→**dutyCycle()****pwminput.get\_dutyCycle()**

---

Returns the PWM duty cycle, in per cents.

function **get\_dutyCycle**( ) As Double

**Returns :**

a floating point number corresponding to the PWM duty cycle, in per cents

On failure, throws an exception or returns `Y_DUTYCYCLE_INVALID`.

---

**pwminput→get\_errorMessage()**  
**pwminput→errorMessage()**  
**pwminput.get\_errorMessage()**

---

**YPwmInput**

Returns the error message of the latest error with the voltage sensor.

```
function get_errorMessage( ) As String
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using the voltage sensor object

**pwminput**→**get\_errorType()**

**YPwmInput**

**pwminput**→**errorType()****pwminput.get\_errorType()**

---

Returns the numerical error code of the latest error with the voltage sensor.

```
function get_errorType( ) As YRETCODE
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using the voltage sensor object

---

**pwminput**→**get\_frequency()****YPwmInput****pwminput**→**frequency()****pwminput.get\_frequency()**

---

Returns the PWM frequency in Hz.

function **get\_frequency**( ) As Double

**Returns :**

a floating point number corresponding to the PWM frequency in Hz

On failure, throws an exception or returns `Y_FREQUENCY_INVALID`.

`pwminput`→`get_functionDescriptor()`

**YPwmInput**

`pwminput`→`functionDescriptor()`

`pwminput.get_functionDescriptor()`

---

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

`function get_functionDescriptor( )` As `YFUN_DESCR`

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`.

If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.



---

**pwminput**→**get\_functionId()****YPwmInput****pwminput**→**functionId()****pwminput.get\_functionId()**

---

Returns the hardware identifier of the voltage sensor, without reference to the module.

function **get\_functionId()** As String

For example `relay1`

**Returns :**

a string that identifies the voltage sensor (ex: `relay1`)

On failure, throws an exception or returns `Y_FUNCTIONID_INVALID`.

**pwminput**→**get\_hardwareId()**

**YPwmInput**

**pwminput**→**hardwareId()****pwminput.get\_hardwareId()**

---

Returns the unique hardware identifier of the voltage sensor in the form `SERIAL.FUNCTIONID`.

function **get\_hardwareId()** As String

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the voltage sensor (for example `RELAYLO1-123456.relay1`).

**Returns :**

a string that uniquely identifies the voltage sensor (ex: `RELAYLO1-123456.relay1`)

On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

---

**pwminput→get\_highestValue()**

**YPwmInput**

**pwminput→highestValue()**

**pwminput.get\_highestValue()**

---

Returns the maximal value observed for the voltage since the device was started.

```
function get_highestValue( ) As Double
```

**Returns :**

a floating point number corresponding to the maximal value observed for the voltage since the device was started

On failure, throws an exception or returns Y\_HIGHESTVALUE\_INVALID.

**pwminput**→**get\_logFrequency()**

**YPwmInput**

**pwminput**→**logFrequency()**

**pwminput**.**get\_logFrequency()**

---

Returns the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory.

```
function get_logFrequency( ) As String
```

**Returns :**

a string corresponding to the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory

On failure, throws an exception or returns `Y_LOGFREQUENCY_INVALID`.

---

**pwminput**→**get\_logicalName()****YPwmInput****pwminput**→**logicalName()****pwminput.get\_logicalName()**

---

Returns the logical name of the voltage sensor.

```
function get_logicalName( ) As String
```

**Returns :**

a string corresponding to the logical name of the voltage sensor.

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

**pwminput→get\_lowestValue()**

**YPwmInput**

**pwminput→lowestValue()**

**pwminput.get\_lowestValue()**

---

Returns the minimal value observed for the voltage since the device was started.

```
function get_lowestValue( ) As Double
```

**Returns :**

a floating point number corresponding to the minimal value observed for the voltage since the device was started

On failure, throws an exception or returns Y\_LOWESTVALUE\_INVALID.

---

**pwminput**→**get\_module()****YPwmInput****pwminput**→**module()****pwminput.get\_module()**

---

Gets the `YModule` object for the device on which the function is located.

function **get\_module()** As `YModule`

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

**Returns :**

an instance of `YModule`

**pwminput**→**get\_period()**

**YPwmInput**

**pwminput**→**period()****pwminput.get\_period()**

---

Returns the PWM period in milliseconds.

function **get\_period**( ) As Double

**Returns :**

a floating point number corresponding to the PWM period in milliseconds

On failure, throws an exception or returns `Y_PERIOD_INVALID`.



---

**pwminput**→**get\_pulseCounter()**  
**pwminput**→**pulseCounter()**  
**pwminput.get\_pulseCounter()**

---

**YPwmInput**

Returns the pulse counter value.

```
function get_pulseCounter( ) As Long
```

Actually that counter is incremented twice per period. That counter is limited to 1 billions

**Returns :**

an integer corresponding to the pulse counter value

On failure, throws an exception or returns `Y_PULSECOUNTER_INVALID`.

**pwminput→get\_pulseDuration()**  
**pwminput→pulseDuration()**  
**pwminput.get\_pulseDuration()**

---

**YPwmInput**

Returns the PWM pulse length in milliseconds, as a floating point number.

```
function get_pulseDuration( ) As Double
```

**Returns :**

a floating point number corresponding to the PWM pulse length in milliseconds, as a floating point number

On failure, throws an exception or returns Y\_PULSEDURATION\_INVALID.

---

**pwminput**→**get\_pulseTimer()****YPwmInput****pwminput**→**pulseTimer()****pwminput.get\_pulseTimer()**

---

Returns the timer of the pulses counter (ms)

function **get\_pulseTimer( )** As Long

**Returns :**

an integer corresponding to the timer of the pulses counter (ms)

On failure, throws an exception or returns `Y_PULSETIMER_INVALID`.

`pwminput`→`get_pwmReportMode()`

**YPwmInput**

`pwminput`→`pwmReportMode()`

`pwminput.get_pwmReportMode()`

Returns the parameter (frequency/duty cycle, pulse width, edges count) returned by the `get_currentValue` function and callbacks.

```
function get_pwmReportMode( ) As Integer
```

Attention

**Returns :**

a value among `Y_PWMREPORTMODE_PWM_DUTYCYCLE`, `Y_PWMREPORTMODE_PWM_FREQUENCY`, `Y_PWMREPORTMODE_PWM_PULSEDURATION` and `Y_PWMREPORTMODE_PWM_EDGECOUNT` corresponding to the parameter (frequency/duty cycle, pulse width, edges count) returned by the `get_currentValue` function and callbacks

On failure, throws an exception or returns `Y_PWMREPORTMODE_INVALID`.

---

**pwminput→get\_recordedData()****YPwmInput****pwminput→recordedData()****pwminput.get\_recordedData()**

---

Retrieves a DataSet object holding historical data for this sensor, for a specified time interval.

```
function get_recordedData( ) As YDataSet
```

The measures will be retrieved from the data logger, which must have been turned on at the desired time. See the documentation of the DataSet class for information on how to get an overview of the recorded data, and how to load progressively a large set of measures from the data logger.

This function only works if the device uses a recent firmware, as DataSet objects are not supported by firmwares older than version 13000.

**Parameters :**

**startTime** the start of the desired measure time interval, as a Unix timestamp, i.e. the number of seconds since January 1, 1970 UTC. The special value 0 can be used to include any meaasure, without initial limit.

**endTime** the end of the desired measure time interval, as a Unix timestamp, i.e. the number of seconds since January 1, 1970 UTC. The special value 0 can be used to include any meaasure, without ending limit.

**Returns :**

an instance of YDataSet, providing access to historical data. Past measures can be loaded progressively using methods from the YDataSet object.

**pwminput→get\_reportFrequency()**

**YPwmInput**

**pwminput→reportFrequency()**

**pwminput.get\_reportFrequency()**

---

Returns the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function.

```
function get_reportFrequency( ) As String
```

**Returns :**

a string corresponding to the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function

On failure, throws an exception or returns Y\_REPORTFREQUENCY\_INVALID.

---

**pwminput**→**get\_resolution()****YPwmInput****pwminput**→**resolution()****pwminput.get\_resolution()**

---

Returns the resolution of the measured values.

function **get\_resolution**( ) As Double

The resolution corresponds to the numerical precision of the measures, which is not always the same as the actual precision of the sensor.

**Returns :**

a floating point number corresponding to the resolution of the measured values

On failure, throws an exception or returns `Y_RESOLUTION_INVALID`.

**pwminput**→**get\_unit()**

**YPwmInput**

**pwminput**→**unit()****pwminput.get\_unit()**

---

Returns the measuring unit for the values returned by `get_currentValue` and callbacks.

function **get\_unit**( ) As String

That unit will change according to the `pwmReportMode` settings.

**Returns :**

a string corresponding to the measuring unit for the values returned by `get_currentValue` and callbacks

On failure, throws an exception or returns `Y_UNIT_INVALID`.



---

**pwminput**→**get\_userdata()****YPwmInput****pwminput**→**userData()****pwminput.get\_userdata()**

---

Returns the value of the `userData` attribute, as previously stored using method `set_userdata`.

```
function get_userdata( ) As Object
```

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

**pwminput**→**isOnline()****pwminput.isOnline()**

**YPwmInput**

---

Checks if the voltage sensor is currently reachable, without raising any error.

function **isOnline**( ) As Boolean

If there is a cached value for the voltage sensor in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the voltage sensor.

**Returns :**

`true` if the voltage sensor can be reached, and `false` otherwise

---

**pwminput**→**load()****pwminput.load()****YPwmInput**

---

Preloads the voltage sensor cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

**pwminput**→**loadCalibrationPoints()**  
**pwminput.loadCalibrationPoints()**

**YPwmInput**

Retrieves error correction data points previously entered using the method `calibrateFromPoints`.

procedure **loadCalibrationPoints**( )

**Parameters :**

**rawValues** array of floating point numbers, that will be filled by the function with the raw sensor values for the correction points.

**refValues** array of floating point numbers, that will be filled by the function with the desired values for the correction points.

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**pwminput**→**nextPwmInput()**  
**pwminput.nextPwmInput()**

---

**YPwmInput**

Continues the enumeration of voltage sensors started using `yFirstPwmInput()`.

```
function nextPwmInput( ) As YPwmInput
```

**Returns :**

a pointer to a `YPwmInput` object, corresponding to a voltage sensor currently online, or a `null` pointer if there are no more voltage sensors to enumerate.

**pwminput**→**registerTimedReportCallback()**  
**pwminput.registerTimedReportCallback()****YPwmInput**

Registers the callback function that is invoked on every periodic timed notification.

```
function registerTimedReportCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and an `YMeasure` object describing the new advertised value.

---

**pwminput→registerValueCallback()**  
**pwminput.registerValueCallback()****YPwmInput**

---

Registers the callback function that is invoked on every change of advertised value.

```
function registerValueCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

**pwminput**→**resetCounter()****pwminput.resetCounter()**

---

**YPwmInput**

Returns the pulse counter value as well as his timer

```
function resetCounter( ) As Integer
```

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.



---

**pwminput**→**set\_highestValue()**

**YPwmInput**

**pwminput**→**setHighestValue()**

**pwminput.set\_highestValue()**

---

Changes the recorded maximal value observed.

```
function set_highestValue( ByVal newval As Double) As Integer
```

**Parameters :**

**newval** a floating point number corresponding to the recorded maximal value observed

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**pwminput→set\_logFrequency()****YPwmInput****pwminput→setLogFrequency()****pwminput.set\_logFrequency()**

---

Changes the datalogger recording frequency for this function.

```
function set_logFrequency( ByVal newval As String) As Integer
```

The frequency can be specified as samples per second, as sample per minute (for instance "15/m") or in samples per hour (eg. "4/h"). To disable recording for this function, use the value "OFF".

**Parameters :**

**newval** a string corresponding to the datalogger recording frequency for this function

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**pwminput**→**set\_logicalName()****YPwmInput****pwminput**→**setLogicalName()****pwminput.set\_logicalName()**

---

Changes the logical name of the voltage sensor.

```
function set_logicalName( ByVal newval As String) As Integer
```

You can use `yCheckLogicalName( )` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash( )` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the voltage sensor.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**pwminput**→**set\_lowestValue()**  
**pwminput**→**setLowestValue()**  
**pwminput.set\_lowestValue()**

**YPwmInput**

---

Changes the recorded minimal value observed.

```
function set_lowestValue( ByVal newval As Double) As Integer
```

**Parameters :**

**newval** a floating point number corresponding to the recorded minimal value observed

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**pwminput**→**set\_pwmReportMode()****YPwmInput****pwminput**→**setPwmReportMode()****pwminput.set\_pwmReportMode()**

Modify the parameter type(frequency/duty cycle, pulse width ou edge count) returned by the `get_currentValue` function and callbacks.

```
function set_pwmReportMode( ByVal newval As Integer) As Integer
```

The edge count value will be limited to the 6 lowest digit, for values greater than one million, use `get_pulseCounter()`.

**Parameters :**

```
newval a value among Y_PWMREPORTMODE_PWM_DUTYCYCLE,
Y_PWMREPORTMODE_PWM_FREQUENCY,
Y_PWMREPORTMODE_PWM_PULSEDURATION and
Y_PWMREPORTMODE_PWM_EDGECOUNT
```

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**pwminput**→**set\_reportFrequency()****YPwmInput****pwminput**→**setReportFrequency()****pwminput.set\_reportFrequency()**

---

Changes the timed value notification frequency for this function.

```
function set_reportFrequency( ByVal newval As String) As Integer
```

The frequency can be specified as samples per second, as sample per minute (for instance "15/m") or in samples per hour (eg. "4/h"). To disable timed value notifications for this function, use the value "OFF".

**Parameters :**

**newval** a string corresponding to the timed value notification frequency for this function

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**pwminput**→**set\_resolution()**  
**pwminput**→**setResolution()**  
**pwminput.set\_resolution()**

---

**YPwmInput**

Changes the resolution of the measured physical values.

```
function set_resolution( ByVal newval As Double) As Integer
```

The resolution corresponds to the numerical precision when displaying value. It does not change the precision of the measure itself.

**Parameters :**

**newval** a floating point number corresponding to the resolution of the measured physical values

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**pwminput**→**set\_userData()**

**YPwmInput**

**pwminput**→**setUserData()****pwminput.set\_userData()**

---

Stores a user context provided as argument in the `userData` attribute of the function.

```
procedure set_userData( ByVal data As Object)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored



### 3.33. Pwm function interface

The Yoctopuce application programming interface allows you to configure, start, and stop the PWM.

In order to use the functions described here, you should include:

js	<code>&lt;script type='text/javascript' src='yocto_pwmoutput.js'&gt;&lt;/script&gt;</code>
nodejs	<code>var yoctolib = require('yoctolib'); var YPwmOutput = yoctolib.YPwmOutput;</code>
php	<code>require_once('yocto_pwmoutput.php');</code>
c++	<code>#include "yocto_pwmoutput.h"</code>
m	<code>#import "yocto_pwmoutput.h"</code>
pas	<code>uses yocto_pwmoutput;</code>
vb	<code>yocto_pwmoutput.vb</code>
cs	<code>yocto_pwmoutput.cs</code>
java	<code>import com.yoctopuce.YoctoAPI.YPwmOutput;</code>
py	<code>from yocto_pwmoutput import *</code>

#### Global functions

##### **yFindPwmOutput(func)**

Retrieves a PWM for a given identifier.

##### **yFirstPwmOutput()**

Starts the enumeration of PWMs currently accessible.

#### YPwmOutput methods

##### **pwmoutput→describe()**

Returns a short text that describes unambiguously the instance of the PWM in the form `TYPE ( NAME ) = SERIAL . FUNCTIONID`.

##### **pwmoutput→dutyCycleMove(target, ms\_duration)**

Performs a smooth change of the pulse duration toward a given value.

##### **pwmoutput→get\_advertisedValue()**

Returns the current value of the PWM (no more than 6 characters).

##### **pwmoutput→get\_dutyCycle()**

Returns the PWM duty cycle, in per cents.

##### **pwmoutput→get\_dutyCycleAtPowerOn()**

Returns the PWMs duty cycle at device power on as a floating point number between 0 and 100

##### **pwmoutput→get\_enabled()**

Returns the state of the PWMs.

##### **pwmoutput→get\_enabledAtPowerOn()**

Returns the state of the PWM at device power on.

##### **pwmoutput→get\_errorMessage()**

Returns the error message of the latest error with the PWM.

##### **pwmoutput→get\_errorType()**

Returns the numerical error code of the latest error with the PWM.

##### **pwmoutput→get\_frequency()**

Returns the PWM frequency in Hz.

##### **pwmoutput→get\_friendlyName()**

Returns a global identifier of the PWM in the format `MODULE_NAME . FUNCTION_NAME`.

##### **pwmoutput→get\_functionDescriptor()**

### 3. Reference

Returns a unique identifier of type <code>YFUN_DESCR</code> corresponding to the function.
<b><code>pwmoutput→get_functionId()</code></b>
Returns the hardware identifier of the PWM, without reference to the module.
<b><code>pwmoutput→get_hardwareId()</code></b>
Returns the unique hardware identifier of the PWM in the form <code>SERIAL.FUNCTIONID</code> .
<b><code>pwmoutput→get_logicalName()</code></b>
Returns the logical name of the PWM.
<b><code>pwmoutput→get_module()</code></b>
Gets the <code>YModule</code> object for the device on which the function is located.
<b><code>pwmoutput→get_module_async(callback, context)</code></b>
Gets the <code>YModule</code> object for the device on which the function is located (asynchronous version).
<b><code>pwmoutput→get_period()</code></b>
Returns the PWM period in milliseconds.
<b><code>pwmoutput→get_pulseDuration()</code></b>
Returns the PWM pulse length in milliseconds, as a floating point number.
<b><code>pwmoutput→get_userData()</code></b>
Returns the value of the <code>userData</code> attribute, as previously stored using method <code>set_userData</code> .
<b><code>pwmoutput→isOnline()</code></b>
Checks if the PWM is currently reachable, without raising any error.
<b><code>pwmoutput→isOnline_async(callback, context)</code></b>
Checks if the PWM is currently reachable, without raising any error (asynchronous version).
<b><code>pwmoutput→load(msValidity)</code></b>
Preloads the PWM cache with a specified validity duration.
<b><code>pwmoutput→load_async(msValidity, callback, context)</code></b>
Preloads the PWM cache with a specified validity duration (asynchronous version).
<b><code>pwmoutput→nextPwmOutput()</code></b>
Continues the enumeration of PWMs started using <code>yFirstPwmOutput()</code> .
<b><code>pwmoutput→pulseDurationMove(ms_target, ms_duration)</code></b>
Performs a smooth transistion of the pulse duration toward a given value.
<b><code>pwmoutput→registerValueCallback(callback)</code></b>
Registers the callback function that is invoked on every change of advertised value.
<b><code>pwmoutput→set_dutyCycle(newval)</code></b>
Changes the PWM duty cycle, in per cents.
<b><code>pwmoutput→set_dutyCycleAtPowerOn(newval)</code></b>
Changes the PWM duty cycle at device power on.
<b><code>pwmoutput→set_enabled(newval)</code></b>
Stops or starts the PWM.
<b><code>pwmoutput→set_enabledAtPowerOn(newval)</code></b>
Changes the state of the PWM at device power on.
<b><code>pwmoutput→set_frequency(newval)</code></b>
Changes the PWM frequency.
<b><code>pwmoutput→set_logicalName(newval)</code></b>
Changes the logical name of the PWM.
<b><code>pwmoutput→set_period(newval)</code></b>
Changes the PWM period in milliseconds.

**pwmoutput→set\_pulseDuration(newval)**

Changes the PWM pulse length, in milliseconds.

**pwmoutput→set\_userData(data)**

Stores a user context provided as argument in the userData attribute of the function.

**pwmoutput→wait\_async(callback, context)**

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.

## YPwmOutput.FindPwmOutput() yFindPwmOutput()yFindPwmOutput()

YPwmOutput

Retrieves a PWM for a given identifier.

```
function yFindPwmOutput( ByVal func As String ) As YPwmOutput
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the PWM is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YPwmOutput.IsOnline()` to test if the PWM is indeed online at a given time. In case of ambiguity when looking for a PWM by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

### Parameters :

**func** a string that uniquely characterizes the PWM

### Returns :

a `YPwmOutput` object allowing you to drive the PWM.

---

**YPwmOutput.FirstPwmOutput()  
yFirstPwmOutput(yFirstPwmOutput())**

---

**YPwmOutput**

Starts the enumeration of PWMs currently accessible.

```
function yFirstPwmOutput( ) As YPwmOutput
```

Use the method `YPwmOutput.nextPwmOutput()` to iterate on next PWMs.

**Returns :**

a pointer to a `YPwmOutput` object, corresponding to the first PWM currently online, or a `null` pointer if there are none.

**pwmoutput→describe()****pwmoutput.describe()****YPwmOutput**

Returns a short text that describes unambiguously the instance of the PWM in the form `TYPE (NAME) =SERIAL.FUNCTIONID`.

function **describe**( ) As String

More precisely, `TYPE` is the type of the function, `NAME` it the name used for the first access to the function, `SERIAL` is the serial number of the module if the module is connected or "unresolved", and `FUNCTIONID` is the hardware identifier of the function if the module is connected. For example, this method returns `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1` if the module is already connected or `Relay(BadCustomeName.relay1)=unresolved` if the module has not yet been connected. This method does not trigger any USB or TCP transaction and can therefore be used in a debugger.

**Returns :**

a string that describes the PWM (ex: `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1`)

---

**pwmoutput→dutyCycleMove()**  
**pwmoutput.dutyCycleMove()****YPwmOutput**

---

Performs a smooth change of the pulse duration toward a given value.

```
function dutyCycleMove( ) As Integer
```

**Parameters :**

**target** new duty cycle at the end of the transition (floating-point number, between 0 and 1)  
**ms\_duration** total duration of the transition, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

`pwmoutput→get_advertisedValue()`

**YPwmOutput**

`pwmoutput→advertisedValue()`

`pwmoutput.get_advertisedValue()`

---

Returns the current value of the PWM (no more than 6 characters).

```
function get_advertisedValue( ) As String
```

**Returns :**

a string corresponding to the current value of the PWM (no more than 6 characters).

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.



---

**pwmoutput**→**get\_dutyCycle()****YPwmOutput****pwmoutput**→**dutyCycle()****pwmoutput.get\_dutyCycle()**

---

Returns the PWM duty cycle, in per cents.

function **get\_dutyCycle**( ) As Double

**Returns :**

a floating point number corresponding to the PWM duty cycle, in per cents

On failure, throws an exception or returns `Y_DUTYCYCLE_INVALID`.

`pwmoutput→get_dutyCycleAtPowerOn()`

**YPwmOutput**

`pwmoutput→dutyCycleAtPowerOn()`

`pwmoutput.get_dutyCycleAtPowerOn()`

---

Returns the PWMs duty cycle at device power on as a floating point number between 0 and 100

function `get_dutyCycleAtPowerOn( )` As Double

**Returns :**

a floating point number corresponding to the PWMs duty cycle at device power on as a floating point number between 0 and 100

On failure, throws an exception or returns `Y_DUTYCYCLEATPOWERON_INVALID`.

---

**pwmoutput**→**get\_enabled()****YPwmOutput****pwmoutput**→**enabled()****pwmoutput.get\_enabled()**

---

Returns the state of the PWMs.

function **get\_enabled**( ) As Integer

**Returns :**

either `Y_ENABLED_FALSE` or `Y_ENABLED_TRUE`, according to the state of the PWMs

On failure, throws an exception or returns `Y_ENABLED_INVALID`.

`pwmoutput→get_enabledAtPowerOn()`

**YPwmOutput**

`pwmoutput→enabledAtPowerOn()`

`pwmoutput.get_enabledAtPowerOn()`

---

Returns the state of the PWM at device power on.

```
function get_enabledAtPowerOn( ) As Integer
```

**Returns :**

either `Y_ENABLEDATPOWERON_FALSE` or `Y_ENABLEDATPOWERON_TRUE`, according to the state of the PWM at device power on

On failure, throws an exception or returns `Y_ENABLEDATPOWERON_INVALID`.

---

**pwmoutput**→**get\_errorMessage()****YPwmOutput****pwmoutput**→**errorMessage()****pwmoutput.get\_errorMessage()**

---

Returns the error message of the latest error with the PWM.

```
function get_errorMessage( ) As String
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using the PWM object

**pwmoutput→get\_errorType()**

**YPwmOutput**

**pwmoutput→errorType()pwmoutput.get\_errorType()**

---

Returns the numerical error code of the latest error with the PWM.

function **get\_errorType**( ) As YRETCODE

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using the PWM object

---

**pwmoutput**→**get\_frequency()****YPwmOutput****pwmoutput**→**frequency()****pwmoutput.get\_frequency()**

---

Returns the PWM frequency in Hz.

function **get\_frequency**( ) As Double

**Returns :**

a floating point number corresponding to the PWM frequency in Hz

On failure, throws an exception or returns `Y_FREQUENCY_INVALID`.

---

**pwmoutput→get\_functionDescriptor()**  
**pwmoutput→functionDescriptor()**  
**pwmoutput.get\_functionDescriptor()**

---

**YPwmOutput**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

```
function get_functionDescriptor( ) As YFUN_DESCR
```

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`.

If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.



---

**pwmoutput**→**get\_functionId()****YPwmOutput****pwmoutput**→**functionId()****pwmoutput.get\_functionId()**

---

Returns the hardware identifier of the PWM, without reference to the module.

function **get\_functionId**( ) As String

For example `relay1`

**Returns :**

a string that identifies the PWM (ex: `relay1`)

On failure, throws an exception or returns `Y_FUNCTIONID_INVALID`.

`pwmoutput→get_hardwareId()`  
`pwmoutput→hardwareId()`  
`pwmoutput.get_hardwareId()`

---

**YPwmOutput**

Returns the unique hardware identifier of the PWM in the form `SERIAL.FUNCTIONID`.

```
function get_hardwareId( ) As String
```

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the PWM (for example `RELAYLO1-123456.relay1`).

**Returns :**

a string that uniquely identifies the PWM (ex: `RELAYLO1-123456.relay1`)

On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

---

**pwmoutput→get\_logicalName()**

**YPwmOutput**

**pwmoutput→logicalName()**

**pwmoutput.get\_logicalName()**

---

Returns the logical name of the PWM.

```
function get_logicalName( ) As String
```

**Returns :**

a string corresponding to the logical name of the PWM.

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

**pwmoutput→get\_module()**

**YPwmOutput**

**pwmoutput→module()pwmoutput.get\_module()**

---

Gets the YModule object for the device on which the function is located.

function **get\_module( )** As YModule

If the function cannot be located on any module, the returned instance of YModule is not shown as on-line.

**Returns :**

an instance of YModule

---

**pwmoutput**→**get\_period()****YPwmOutput****pwmoutput**→**period()****pwmoutput.get\_period()**

---

Returns the PWM period in milliseconds.

function **get\_period()** As Double

**Returns :**

a floating point number corresponding to the PWM period in milliseconds

On failure, throws an exception or returns `Y_PERIOD_INVALID`.

**pwmoutput→get\_pulseDuration()**  
**pwmoutput→pulseDuration()**  
**pwmoutput.get\_pulseDuration()**

---

**YPwmOutput**

Returns the PWM pulse length in milliseconds, as a floating point number.

```
function get_pulseDuration( ) As Double
```

**Returns :**

a floating point number corresponding to the PWM pulse length in milliseconds, as a floating point number

On failure, throws an exception or returns Y\_PULSEDURATION\_INVALID.

---

**pwmoutput**→**get\_userData()****YPwmOutput****pwmoutput**→**userData()****pwmoutput.get\_userData()**

---

Returns the value of the userData attribute, as previously stored using method `set_userData`.

```
function get_userData( ) As Object
```

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

## `pwmoutput→isOnline()``pwmoutput.isOnline()`

YPwmOutput

---

Checks if the PWM is currently reachable, without raising any error.

```
function isOnline( ) As Boolean
```

If there is a cached value for the PWM in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the PWM.

**Returns :**

`true` if the PWM can be reached, and `false` otherwise



**pwmoutput**→**load()****pwmoutput.load()****YPwmOutput**

Preloads the PWM cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

**pwmoutput→nextPwmOutput()**  
**pwmoutput.nextPwmOutput()**

**YPwmOutput**

---

Continues the enumeration of PWMs started using `yFirstPwmOutput()`.

function **nextPwmOutput()** As YPwmOutput

**Returns :**

a pointer to a `YPwmOutput` object, corresponding to a PWM currently online, or a `null` pointer if there are no more PWMs to enumerate.

---

**pwmoutput→pulseDurationMove()  
pwmoutput.pulseDurationMove()**

---

**YPwmOutput**

Performs a smooth transition of the pulse duration toward a given value.

```
function pulseDurationMove( ) As Integer
```

Any period, frequency, duty cycle or pulse width change will cancel any ongoing transition process.

**Parameters :**

**ms\_target** new pulse duration at the end of the transition (floating-point number, representing the pulse duration in milliseconds)

**ms\_duration** total duration of the transition, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

**pwmoutput→registerValueCallback()**  
**pwmoutput.registerValueCallback()****YPwmOutput**

Registers the callback function that is invoked on every change of advertised value.

```
function registerValueCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

---

**pwmoutput→set\_dutyCycle()**  
**pwmoutput→setDutyCycle()**  
**pwmoutput.set\_dutyCycle()**

---

**YPwmOutput**

Changes the PWM duty cycle, in per cents.

```
function set_dutyCycle( ByVal newval As Double) As Integer
```

**Parameters :**

**newval** a floating point number corresponding to the PWM duty cycle, in per cents

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**pwmoutput→set\_dutyCycleAtPowerOn()**  
**pwmoutput→setDutyCycleAtPowerOn()**  
**pwmoutput.set\_dutyCycleAtPowerOn()**

**YPwmOutput**

---

Changes the PWM duty cycle at device power on.

```
function set_dutyCycleAtPowerOn( ByVal newval As Double) As Integer
```

Remember to call the matching module `saveToFlash()` method, otherwise this call will have no effect.

**Parameters :**

**newval** a floating point number corresponding to the PWM duty cycle at device power on

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**pwmoutput**→**set\_enabled()****YPwmOutput****pwmoutput**→**setEnabled()****pwmoutput.set\_enabled()**

---

Stops or starts the PWM.

```
function set_enabled( ByVal newval As Integer) As Integer
```

**Parameters :**

**newval** either Y\_ENABLED\_FALSE or Y\_ENABLED\_TRUE

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**pwmoutput→set\_enabledAtPowerOn()**  
**pwmoutput→setEnabledAtPowerOn()**  
**pwmoutput.set\_enabledAtPowerOn()**

**YPwmOutput**

---

Changes the state of the PWM at device power on.

```
function set_enabledAtPowerOn( ByVal newval As Integer) As Integer
```

Remember to call the matching module `saveToFlash()` method, otherwise this call will have no effect.

**Parameters :**

**newval** either `Y_ENABLEDATPOWERON_FALSE` or `Y_ENABLEDATPOWERON_TRUE`, according to the state of the PWM at device power on

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.



---

**pwmoutput→set\_frequency()**  
**pwmoutput→setFrequency()**  
**pwmoutput.set\_frequency()**

---

**YPwmOutput**

Changes the PWM frequency.

```
function set_frequency( ByVal newval As Double) As Integer
```

The duty cycle is kept unchanged thanks to an automatic pulse width change.

**Parameters :**

**newval** a floating point number corresponding to the PWM frequency

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**pwmoutput→set\_logicalName()**

**YPwmOutput**

**pwmoutput→setLogicalName()**

**pwmoutput.set\_logicalName()**

---

Changes the logical name of the PWM.

```
function set_logicalName( ByVal newval As String) As Integer
```

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the PWM.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**pwmoutput**→**set\_period()****YPwmOutput****pwmoutput**→**setPeriod()****pwmoutput.set\_period()**

---

Changes the PWM period in milliseconds.

```
function set_period( ByVal newval As Double) As Integer
```

**Parameters :**

**newval** a floating point number corresponding to the PWM period in milliseconds

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**pwmoutput→set\_pulseDuration()**  
**pwmoutput→setPulseDuration()**  
**pwmoutput.set\_pulseDuration()**

**YPwmOutput**

---

Changes the PWM pulse length, in milliseconds.

```
function set_pulseDuration( ByVal newval As Double) As Integer
```

A pulse length cannot be longer than period, otherwise it is truncated.

**Parameters :**

**newval** a floating point number corresponding to the PWM pulse length, in milliseconds

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**pwmoutput→set\_userData()**  
**pwmoutput→setUserData()**  
**pwmoutput.set\_userData()**

---

**YPwmOutput**

Stores a user context provided as argument in the userData attribute of the function.

```
procedure set_userData( ByVal data As Object)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

## 3.34. PwmPowerSource function interface

The Yoctopuce application programming interface allows you to configure the voltage source used by all PWM on the same device.

In order to use the functions described here, you should include:

js	<script type='text/javascript' src='yocto_pwmpowersource.js'></script>
nodejs	var yoctolib = require('yoctolib'); var YPwmPowerSource = yoctolib.YPwmPowerSource;
php	require_once('yocto_pwmpowersource.php');
c++	#include "yocto_pwmpowersource.h"
m	#import "yocto_pwmpowersource.h"
pas	uses yocto_pwmpowersource;
vb	yocto_pwmpowersource.vb
cs	yocto_pwmpowersource.cs
java	import com.yoctopuce.YoctoAPI.YPwmPowerSource;
py	from yocto_pwmpowersource import *

### Global functions

#### yFindPwmPowerSource(func)

Retrieves a voltage source for a given identifier.

#### yFirstPwmPowerSource()

Starts the enumeration of Voltage sources currently accessible.

### YPwmPowerSource methods

#### pwmpowersource→describe()

Returns a short text that describes unambiguously the instance of the voltage source in the form `TYPE ( NAME ) =SERIAL . FUNCTIONID`.

#### pwmpowersource→get\_advertisedValue()

Returns the current value of the voltage source (no more than 6 characters).

#### pwmpowersource→get\_errorMessage()

Returns the error message of the latest error with the voltage source.

#### pwmpowersource→get\_errorType()

Returns the numerical error code of the latest error with the voltage source.

#### pwmpowersource→get\_friendlyName()

Returns a global identifier of the voltage source in the format `MODULE_NAME . FUNCTION_NAME`.

#### pwmpowersource→get\_functionDescriptor()

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

#### pwmpowersource→get\_functionId()

Returns the hardware identifier of the voltage source, without reference to the module.

#### pwmpowersource→get\_hardwareId()

Returns the unique hardware identifier of the voltage source in the form `SERIAL . FUNCTIONID`.

#### pwmpowersource→get\_logicalName()

Returns the logical name of the voltage source.

#### pwmpowersource→get\_module()

Gets the `YModule` object for the device on which the function is located.

#### pwmpowersource→get\_module\_async(callback, context)

Gets the `YModule` object for the device on which the function is located (asynchronous version).

**pwmpowersource**→**get\_powerMode()**

Returns the selected power source for the PWM on the same device

**pwmpowersource**→**get\_userData()**

Returns the value of the userData attribute, as previously stored using method `set_userData`.

**pwmpowersource**→**isOnline()**

Checks if the voltage source is currently reachable, without raising any error.

**pwmpowersource**→**isOnline\_async(callback, context)**

Checks if the voltage source is currently reachable, without raising any error (asynchronous version).

**pwmpowersource**→**load(msValidity)**

Preloads the voltage source cache with a specified validity duration.

**pwmpowersource**→**load\_async(msValidity, callback, context)**

Preloads the voltage source cache with a specified validity duration (asynchronous version).

**pwmpowersource**→**nextPwmPowerSource()**

Continues the enumeration of Voltage sources started using `yFirstPwmPowerSource()`.

**pwmpowersource**→**registerValueCallback(callback)**

Registers the callback function that is invoked on every change of advertised value.

**pwmpowersource**→**set\_logicalName(newval)**

Changes the logical name of the voltage source.

**pwmpowersource**→**set\_powerMode(newval)**

Changes the PWM power source.

**pwmpowersource**→**set\_userData(data)**

Stores a user context provided as argument in the userData attribute of the function.

**pwmpowersource**→**wait\_async(callback, context)**

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.

## YPwmPowerSource.FindPwmPowerSource() yFindPwmPowerSource()yFindPwmPowerSource()

YPwmPowerSource

Retrieves a voltage source for a given identifier.

```
function yFindPwmPowerSource( ByVal func As String) As YPwmPowerSource
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the voltage source is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YPwmPowerSource.IsOnline()` to test if the voltage source is indeed online at a given time. In case of ambiguity when looking for a voltage source by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

### Parameters :

**func** a string that uniquely characterizes the voltage source

### Returns :

a `YPwmPowerSource` object allowing you to drive the voltage source.



---

**YPwmPowerSource.FirstPwmPowerSource()  
yFirstPwmPowerSource()yFirstPwmPowerSource()**

---

**YPwmPowerSource**

Starts the enumeration of Voltage sources currently accessible.

```
function yFirstPwmPowerSource( ) As YPwmPowerSource
```

Use the method `YPwmPowerSource.nextPwmPowerSource()` to iterate on next Voltage sources.

**Returns :**

a pointer to a `YPwmPowerSource` object, corresponding to the first source currently online, or a `null` pointer if there are none.

**pwmpowersource→describe()**  
**pwmpowersource.describe()****YPwmPowerSource**

Returns a short text that describes unambiguously the instance of the voltage source in the form `TYPE (NAME) =SERIAL . FUNCTIONID`.

function **describe**( ) As String

More precisely, `TYPE` is the type of the function, `NAME` it the name used for the first access to the function, `SERIAL` is the serial number of the module if the module is connected or "unresolved", and `FUNCTIONID` is the hardware identifier of the function if the module is connected. For example, this method returns `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1` if the module is already connected or `Relay(BadCustomeName.relay1)=unresolved` if the module has not yet been connected. This method does not trigger any USB or TCP transaction and can therefore be used in a debugger.

**Returns :**

a string that describes the voltage source (ex: `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1`)

---

**pwmpowersource→get\_advertisedValue()**

**YPwmPowerSource**

**pwmpowersource→advertisedValue()**

**pwmpowersource.get\_advertisedValue()**

---

Returns the current value of the voltage source (no more than 6 characters).

```
function get_advertisedValue( ) As String
```

**Returns :**

a string corresponding to the current value of the voltage source (no more than 6 characters).

On failure, throws an exception or returns Y\_ADVERTISEDVALUE\_INVALID.

`pwmpowersource→get_errorMessage()`

**YPwmPowerSource**

`pwmpowersource→errorMessage()`

`pwmpowersource.get_errorMessage()`

---

Returns the error message of the latest error with the voltage source.

```
function get_errorMessage( ) As String
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using the voltage source object

---

`pwmpowersource`→`get_errorType()`  
`pwmpowersource`→`errorType()`  
`pwmpowersource.get_errorType()`

---

**YPwmPowerSource**

Returns the numerical error code of the latest error with the voltage source.

```
function get_errorType( ) As YRETCODE
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using the voltage source object

**pwmpowersource**→**get\_functionDescriptor()**  
**pwmpowersource**→**functionDescriptor()**  
**pwmpowersource.get\_functionDescriptor()**

---

**YPwmPowerSource**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

`function get_functionDescriptor( )` As `YFUN_DESCR`

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`.

If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

---

**pwmpowersource→get\_functionId()**  
**pwmpowersource→functionId()**  
**pwmpowersource.get\_functionId()**

---

**YPwmPowerSource**

Returns the hardware identifier of the voltage source, without reference to the module.

```
function get_functionId( ) As String
```

For example `relay1`

**Returns :**

a string that identifies the voltage source (ex: `relay1`)

On failure, throws an exception or returns `Y_FUNCTIONID_INVALID`.

`pwmpowersource`→`get_hardwareId()`

`YPwmPowerSource`

`pwmpowersource`→`hardwareId()`

`pwmpowersource.get_hardwareId()`

---

Returns the unique hardware identifier of the voltage source in the form `SERIAL.FUNCTIONID`.

```
function get_hardwareId( ) As String
```

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the voltage source (for example `RELAYLO1-123456.relay1`).

**Returns :**

a string that uniquely identifies the voltage source (ex: `RELAYLO1-123456.relay1`)

On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.



---

**pwmpowersource→get\_logicalName()**

**YPwmPowerSource**

**pwmpowersource→logicalName()**

**pwmpowersource.get\_logicalName()**

---

Returns the logical name of the voltage source.

```
function get_logicalName( ) As String
```

**Returns :**

a string corresponding to the logical name of the voltage source.

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

**pwmpowersource→get\_module()**

**YPwmPowerSource**

**pwmpowersource→module()**

**pwmpowersource.get\_module()**

---

Gets the YModule object for the device on which the function is located.

function **get\_module()** As YModule

If the function cannot be located on any module, the returned instance of YModule is not shown as on-line.

**Returns :**

an instance of YModule

---

**pwmpowersource**→**get\_powerMode()**

**YPwmPowerSource**

**pwmpowersource**→**powerMode()**

**pwmpowersource.get\_powerMode()**

---

Returns the selected power source for the PWM on the same device

```
function get_powerMode( ) As Integer
```

**Returns :**

a value among Y\_POWERMODE\_USB\_5V, Y\_POWERMODE\_USB\_3V, Y\_POWERMODE\_EXT\_V and Y\_POWERMODE\_OPNDRN corresponding to the selected power source for the PWM on the same device

On failure, throws an exception or returns Y\_POWERMODE\_INVALID.

**pwmpowersource→get\_userData()**

**YPwmPowerSource**

**pwmpowersource→userData()**

**pwmpowersource.get\_userData()**

---

Returns the value of the userData attribute, as previously stored using method `set_userData`.

```
function get_userData( ) As Object
```

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

---

**pwmpowersource→isOnline()  
pwmpowersource.isOnline()**

---

**YPwmPowerSource**

Checks if the voltage source is currently reachable, without raising any error.

```
function isOnline( ) As Boolean
```

If there is a cached value for the voltage source in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the voltage source.

**Returns :**

`true` if the voltage source can be reached, and `false` otherwise

---

**pwmpowersource**→**load()****pwmpowersource.load()**

**YPwmPowerSource**

---

Preloads the voltage source cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**pwmpowersource→nextPwmPowerSource()**  
**pwmpowersource.nextPwmPowerSource()**

---

**YPwmPowerSource**

Continues the enumeration of Voltage sources started using `yFirstPwmPowerSource()`.

```
function nextPwmPowerSource( ) As YPwmPowerSource
```

**Returns :**

a pointer to a `YPwmPowerSource` object, corresponding to a voltage source currently online, or a `null` pointer if there are no more Voltage sources to enumerate.

**pwmpowersource**→**registerValueCallback()**  
**pwmpowersource.registerValueCallback()**

**YPwmPowerSource**

Registers the callback function that is invoked on every change of advertised value.

```
function registerValueCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.



---

**pwmpowersource**→**set\_logicalName()****YPwmPowerSource****pwmpowersource**→**setLogicalName()****pwmpowersource.set\_logicalName()**

---

Changes the logical name of the voltage source.

```
function set_logicalName( ByVal newval As String) As Integer
```

You can use `yCheckLogicalName( )` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash( )` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the voltage source.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**pwmpowersource**→**set\_powerMode()**  
**pwmpowersource**→**setPowerMode()**  
**pwmpowersource.set\_powerMode()**

**YPwmPowerSource**

Changes the PWM power source.

```
function set_powerMode( ByVal newval As Integer) As Integer
```

PWM can use isolated 5V from USB, isolated 3V from USB or voltage from an external power source. The PWM can also work in open drain mode. In that mode, the PWM actively pulls the line down. Warning: this setting is common to all PWM on the same device. If you change that parameter, all PWM located on the same device are affected. If you want the change to be kept after a device reboot, make sure to call the matching module `saveToFlash()`.

**Parameters :**

**newval** a value among `Y_POWERMODE_USB_5V`, `Y_POWERMODE_USB_3V`, `Y_POWERMODE_EXT_V` and `Y_POWERMODE_OPNDRN` corresponding to the PWM power source

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**pwmpowersource→set\_userdata()**

**YPwmPowerSource**

**pwmpowersource→setUserData()**

**pwmpowersource.set\_userdata()**

---

Stores a user context provided as argument in the `userData` attribute of the function.

```
procedure set_userdata( ByVal data As Object)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

## 3.35. Quaternion interface

The Yoctopuce API YQt class provides direct access to the Yocto3D attitude estimation using a quaternion. It is usually not needed to use the YQt class directly, as the YGyro class provides a more convenient higher-level interface.

In order to use the functions described here, you should include:

js	<code>&lt;script type='text/javascript' src='yocto_gyro.js'&gt;&lt;/script&gt;</code>
nodejs	<code>var yoctolib = require('yoctolib');</code> <code>var YGyro = yoctolib.YGyro;</code>
php	<code>require_once('yocto_gyro.php');</code>
cpp	<code>#include "yocto_gyro.h"</code>
m	<code>#import "yocto_gyro.h"</code>
pas	<code>uses yocto_gyro;</code>
vb	<code>yocto_gyro.vb</code>
cs	<code>yocto_gyro.cs</code>
java	<code>import com.yoctopuce.YoctoAPI.YGyro;</code>
py	<code>from yocto_gyro import *</code>

### Global functions

#### yFindQt(func)

Retrieves a quaternion component for a given identifier.

#### yFirstQt()

Starts the enumeration of quaternion components currently accessible.

### YQt methods

#### qt→calibrateFromPoints(rawValues, refValues)

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

#### qt→describe()

Returns a short text that describes unambiguously the instance of the quaternion component in the form `TYPE ( NAME ) =SERIAL . FUNCTIONID`.

#### qt→get\_advertisedValue()

Returns the current value of the quaternion component (no more than 6 characters).

#### qt→get\_currentRawValue()

Returns the uncalibrated, unrounded raw value returned by the sensor, in units, as a floating point number.

#### qt→get\_currentValue()

Returns the current value of the value, in units, as a floating point number.

#### qt→get\_errorMessage()

Returns the error message of the latest error with the quaternion component.

#### qt→get\_errorType()

Returns the numerical error code of the latest error with the quaternion component.

#### qt→get\_friendlyName()

Returns a global identifier of the quaternion component in the format `MODULE_NAME . FUNCTION_NAME`.

#### qt→get\_functionDescriptor()

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

#### qt→get\_functionId()

Returns the hardware identifier of the quaternion component, without reference to the module.

#### qt→get\_hardwareId()

Returns the unique hardware identifier of the quaternion component in the form SERIAL . FUNCTIONID.

**qt→get\_highestValue()**

Returns the maximal value observed for the value since the device was started.

**qt→get\_logFrequency()**

Returns the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory.

**qt→get\_logicalName()**

Returns the logical name of the quaternion component.

**qt→get\_lowestValue()**

Returns the minimal value observed for the value since the device was started.

**qt→get\_module()**

Gets the YModule object for the device on which the function is located.

**qt→get\_module\_async(callback, context)**

Gets the YModule object for the device on which the function is located (asynchronous version).

**qt→get\_recordedData(startTime, endTime)**

Retrieves a DataSet object holding historical data for this sensor, for a specified time interval.

**qt→get\_reportFrequency()**

Returns the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function.

**qt→get\_resolution()**

Returns the resolution of the measured values.

**qt→get\_unit()**

Returns the measuring unit for the value.

**qt→get\_userData()**

Returns the value of the userData attribute, as previously stored using method set\_userData.

**qt→isOnline()**

Checks if the quaternion component is currently reachable, without raising any error.

**qt→isOnline\_async(callback, context)**

Checks if the quaternion component is currently reachable, without raising any error (asynchronous version).

**qt→load(msValidity)**

Preloads the quaternion component cache with a specified validity duration.

**qt→loadCalibrationPoints(rawValues, refValues)**

Retrieves error correction data points previously entered using the method calibrateFromPoints.

**qt→load\_async(msValidity, callback, context)**

Preloads the quaternion component cache with a specified validity duration (asynchronous version).

**qt→nextQt()**

Continues the enumeration of quaternion components started using yFirstQt().

**qt→registerTimedReportCallback(callback)**

Registers the callback function that is invoked on every periodic timed notification.

**qt→registerValueCallback(callback)**

Registers the callback function that is invoked on every change of advertised value.

**qt→set\_highestValue(newval)**

Changes the recorded maximal value observed.

**qt→set\_logFrequency(newval)**

Changes the datalogger recording frequency for this function.

**qt→set\_logicalName(newval)**

### 3. Reference

---

Changes the logical name of the quaternion component.

**qt**→**set\_lowestValue(newval)**

Changes the recorded minimal value observed.

**qt**→**set\_reportFrequency(newval)**

Changes the timed value notification frequency for this function.

**qt**→**set\_resolution(newval)**

Changes the resolution of the measured physical values.

**qt**→**set\_userData(data)**

Stores a user context provided as argument in the userData attribute of the function.

**qt**→**wait\_async(callback, context)**

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.

## YQt.FindQt() yFindQt()yFindQt()

YQt

Retrieves a quaternion component for a given identifier.

```
function yFindQt( ByVal func As String) As YQt
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the quaternion component is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YQt.IsOnline()` to test if the quaternion component is indeed online at a given time. In case of ambiguity when looking for a quaternion component by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

### Parameters :

**func** a string that uniquely characterizes the quaternion component

### Returns :

a `YQt` object allowing you to drive the quaternion component.

## YQt.FirstQt() yFirstQt()yFirstQt()

---

YQt

Starts the enumeration of quaternion components currently accessible.

```
function yFirstQt( ) As YQt
```

Use the method `YQt.nextQt( )` to iterate on next quaternion components.

**Returns :**

a pointer to a `YQt` object, corresponding to the first quaternion component currently online, or a `null` pointer if there are none.



---

**qt→calibrateFromPoints()****qt.calibrateFromPoints()**YQt

---

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

procedure **calibrateFromPoints()**

It is possible to configure up to five correction points. Correction points must be provided in ascending order, and be in the range of the sensor. The device will automatically perform a linear interpolation of the error correction between specified points. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

For more information on advanced capabilities to refine the calibration of sensors, please contact [support@yoctopuce.com](mailto:support@yoctopuce.com).

**Parameters :**

**rawValues** array of floating point numbers, corresponding to the raw values returned by the sensor for the correction points.

**refValues** array of floating point numbers, corresponding to the corrected values for the correction points.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**qt→describe()qt.describe()**

YQt

Returns a short text that describes unambiguously the instance of the quaternion component in the form `TYPE (NAME) =SERIAL . FUNCTIONID`.

function **describe**( ) As String

More precisely, `TYPE` is the type of the function, `NAME` is the name used for the first access to the function, `SERIAL` is the serial number of the module if the module is connected or "unresolved", and `FUNCTIONID` is the hardware identifier of the function if the module is connected. For example, this method returns `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1` if the module is already connected or `Relay(BadCustomeName.relay1)=unresolved` if the module has not yet been connected. This method does not trigger any USB or TCP transaction and can therefore be used in a debugger.

**Returns :**

a string that describes the quaternion component (ex:  
`Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1`)

---

**qt**→**get\_advertisedValue()****YQt****qt**→**advertisedValue()****qt.get\_advertisedValue()**

---

Returns the current value of the quaternion component (no more than 6 characters).

function **get\_advertisedValue( )** As String

**Returns :**

a string corresponding to the current value of the quaternion component (no more than 6 characters).

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

**qt**→**get\_currentRawValue()**

**YQt**

**qt**→**currentRawValue()****qt.get\_currentRawValue()**

---

Returns the uncalibrated, unrounded raw value returned by the sensor, in units, as a floating point number.

```
function get_currentRawValue( ) As Double
```

**Returns :**

a floating point number corresponding to the uncalibrated, unrounded raw value returned by the sensor, in units, as a floating point number

On failure, throws an exception or returns `Y_CURRENTRAWVALUE_INVALID`.

---

**qt**→**get\_currentValue()**

YQt

**qt**→**currentValue()****qt.get\_currentValue()**

---

Returns the current value of the value, in units, as a floating point number.

function **get\_currentValue()** As Double

**Returns :**

a floating point number corresponding to the current value of the value, in units, as a floating point number

On failure, throws an exception or returns `Y_CURRENTVALUE_INVALID`.

**qt→get\_errorMessage()**

**YQt**

**qt→errorMessage()qt.get\_errorMessage()**

---

Returns the error message of the latest error with the quaternion component.

function **get\_errorMessage**( ) As String

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using the quaternion component object

---

**qt**→**get\_errorType()**

YQt

**qt**→**errorType()****qt.get\_errorType()**

---

Returns the numerical error code of the latest error with the quaternion component.

```
function get_errorType( ) As YRETCODE
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using the quaternion component object

**qt**→**get\_functionDescriptor()****YQt****qt**→**functionDescriptor()****qt.get\_functionDescriptor()**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

function **get\_functionDescriptor()** As `YFUN_DESCR`

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`.

If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.



---

**qt**→**get\_functionId()**

YQt

**qt**→**functionId()****qt.get\_functionId()**

---

Returns the hardware identifier of the quaternion component, without reference to the module.

function **get\_functionId**( ) As String

For example `relay1`

**Returns :**

a string that identifies the quaternion component (ex: `relay1`)

On failure, throws an exception or returns `Y_FUNCTIONID_INVALID`.

**qt**→**get\_hardwareId()**

**YQt**

**qt**→**hardwareId()****qt.get\_hardwareId()**

---

Returns the unique hardware identifier of the quaternion component in the form `SERIAL.FUNCTIONID`.

```
function get_hardwareId( ) As String
```

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the quaternion component (for example `RELAYLO1-123456.relay1`).

**Returns :**

a string that uniquely identifies the quaternion component (ex: `RELAYLO1-123456.relay1`)

On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

---

**qt**→**get\_highestValue()**

YQt

**qt**→**highestValue()****qt.get\_highestValue()**

---

Returns the maximal value observed for the value since the device was started.

```
function get_highestValue( ) As Double
```

**Returns :**

a floating point number corresponding to the maximal value observed for the value since the device was started

On failure, throws an exception or returns `Y_HIGHESTVALUE_INVALID`.

**qt**→**get\_logFrequency()**

**YQt**

**qt**→**logFrequency()****qt.get\_logFrequency()**

---

Returns the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory.

function **get\_logFrequency()** As String

**Returns :**

a string corresponding to the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory

On failure, throws an exception or returns `Y_LOGFREQUENCY_INVALID`.

---

**qt**→**get\_logicalName()**

YQt

**qt**→**logicalName()****qt.get\_logicalName()**

---

Returns the logical name of the quaternion component.

```
function get_logicalName( ) As String
```

**Returns :**

a string corresponding to the logical name of the quaternion component.

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

**qt**→**get\_lowestValue()**

**YQt**

**qt**→**lowestValue()****qt.get\_lowestValue()**

---

Returns the minimal value observed for the value since the device was started.

function **get\_lowestValue( )** As Double

**Returns :**

a floating point number corresponding to the minimal value observed for the value since the device was started

On failure, throws an exception or returns `Y_LOWESTVALUE_INVALID`.

---

**qt→get\_module()**

YQt

**qt→module()qt.get\_module()**

---

Gets the YModule object for the device on which the function is located.

function **get\_module()** As YModule

If the function cannot be located on any module, the returned instance of YModule is not shown as on-line.

**Returns :**

an instance of YModule

**qt**→**get\_recordedData()**

YQt

**qt**→**recordedData()****qt.get\_recordedData()**

Retrieves a DataSet object holding historical data for this sensor, for a specified time interval.

```
function get_recordedData( ) As YDataSet
```

The measures will be retrieved from the data logger, which must have been turned on at the desired time. See the documentation of the DataSet class for information on how to get an overview of the recorded data, and how to load progressively a large set of measures from the data logger.

This function only works if the device uses a recent firmware, as DataSet objects are not supported by firmwares older than version 13000.

**Parameters :**

- startTime** the start of the desired measure time interval, as a Unix timestamp, i.e. the number of seconds since January 1, 1970 UTC. The special value 0 can be used to include any measure, without initial limit.
- endTime** the end of the desired measure time interval, as a Unix timestamp, i.e. the number of seconds since January 1, 1970 UTC. The special value 0 can be used to include any measure, without ending limit.

**Returns :**

an instance of YDataSet, providing access to historical data. Past measures can be loaded progressively using methods from the YDataSet object.



---

**qt**→**get\_reportFrequency()**

YQt

**qt**→**reportFrequency()****qt.get\_reportFrequency()**

---

Returns the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function.

```
function get_reportFrequency( ) As String
```

**Returns :**

a string corresponding to the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function

On failure, throws an exception or returns `Y_REPORTFREQUENCY_INVALID`.

**qt**→**get\_resolution()**

**YQt**

**qt**→**resolution()****qt.get\_resolution()**

---

Returns the resolution of the measured values.

```
function get_resolution( ) As Double
```

The resolution corresponds to the numerical precision of the measures, which is not always the same as the actual precision of the sensor.

**Returns :**

a floating point number corresponding to the resolution of the measured values

On failure, throws an exception or returns `Y_RESOLUTION_INVALID`.

---

**qt→get\_unit()**

YQt

**qt→unit()qt.get\_unit()**

---

Returns the measuring unit for the value.

function **get\_unit**( ) As String

**Returns :**

a string corresponding to the measuring unit for the value

On failure, throws an exception or returns Y\_UNIT\_INVALID.

**qt**→**get\_userdata()**

**YQt**

**qt**→**userData()****qt.get\_userdata()**

---

Returns the value of the `userData` attribute, as previously stored using method `set_userdata`.

function `get_userdata( )` As Object

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

---

**qt→isOnline()qt.isOnline()**

---

YQt

Checks if the quaternion component is currently reachable, without raising any error.

```
function isOnline( ) As Boolean
```

If there is a cached value for the quaternion component in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the quaternion component.

**Returns :**

`true` if the quaternion component can be reached, and `false` otherwise

**qt→load()qt.load()**

YQt

Preloads the quaternion component cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**qt→loadCalibrationPoints()qt.loadCalibrationPoints()****YQt**

---

Retrieves error correction data points previously entered using the method `calibrateFromPoints`.

procedure **loadCalibrationPoints( )**

**Parameters :**

**rawValues** array of floating point numbers, that will be filled by the function with the raw sensor values for the correction points.

**refValues** array of floating point numbers, that will be filled by the function with the desired values for the correction points.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**qt**→**nextQt()****qt.nextQt()**

**YQt**

---

Continues the enumeration of quaternion components started using `yFirstQt()`.

```
function nextQt( ) As YQt
```

**Returns :**

a pointer to a `YQt` object, corresponding to a quaternion component currently online, or a `null` pointer if there are no more quaternion components to enumerate.



---

**qt→registerTimedReportCallback()**  
**qt.registerTimedReportCallback()**

---

YQt

Registers the callback function that is invoked on every periodic timed notification.

```
function registerTimedReportCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and an `YMeasure` object describing the new advertised value.

**qt→registerValueCallback()  
qt.registerValueCallback()**

YQt

Registers the callback function that is invoked on every change of advertised value.

```
function registerValueCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

---

**qt**→**set\_highestValue()**

YQt

**qt**→**setHighestValue()****qt.set\_highestValue()**

---

Changes the recorded maximal value observed.

```
function set_highestValue( ByVal newval As Double) As Integer
```

**Parameters :**

**newval** a floating point number corresponding to the recorded maximal value observed

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**qt**→**set\_logFrequency()**

YQt

**qt**→**setLogFrequency()****qt.set\_logFrequency()**

Changes the datalogger recording frequency for this function.

```
function set_logFrequency( ByVal newval As String) As Integer
```

The frequency can be specified as samples per second, as sample per minute (for instance "15/m") or in samples per hour (eg. "4/h"). To disable recording for this function, use the value "OFF".

**Parameters :**

**newval** a string corresponding to the datalogger recording frequency for this function

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**qt**→**set\_logicalName()**

YQt

**qt**→**setLogicalName()****qt.set\_logicalName()**

Changes the logical name of the quaternion component.

```
function set_logicalName( ByVal newval As String) As Integer
```

You can use `yCheckLogicalName( )` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash( )` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the quaternion component.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**qt**→**set\_lowestValue()**

YQt

**qt**→**setLowestValue()****qt.set\_lowestValue()**

Changes the recorded minimal value observed.

```
function set_lowestValue( ByVal newval As Double) As Integer
```

**Parameters :**

**newval** a floating point number corresponding to the recorded minimal value observed

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**qt**→**set\_reportFrequency()**

YQt

**qt**→**setReportFrequency()****qt.set\_reportFrequency()**

---

Changes the timed value notification frequency for this function.

```
function set_reportFrequency( ByVal newval As String) As Integer
```

The frequency can be specified as samples per second, as sample per minute (for instance "15/m") or in samples per hour (eg. "4/h"). To disable timed value notifications for this function, use the value "OFF".

**Parameters :**

**newval** a string corresponding to the timed value notification frequency for this function

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**qt**→**set\_resolution()**

YQt

**qt**→**setResolution()****qt.set\_resolution()**

Changes the resolution of the measured physical values.

```
function set_resolution( ByVal newval As Double) As Integer
```

The resolution corresponds to the numerical precision when displaying value. It does not change the precision of the measure itself.

**Parameters :**

**newval** a floating point number corresponding to the resolution of the measured physical values

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.



---

**qt**→**set\_userdata()**

YQt

**qt**→**setUserData()****qt.set\_userdata()**

---

Stores a user context provided as argument in the `userData` attribute of the function.

```
procedure set_userdata( ByVal data As Object)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

## 3.36. Real Time Clock function interface

The RealTimeClock function maintains and provides current date and time, even accross power cut lasting several days. It is the base for automated wake-up functions provided by the WakeUpScheduler. The current time may represent a local time as well as an UTC time, but no automatic time change will occur to account for daylight saving time.

In order to use the functions described here, you should include:

js	<script type='text/javascript' src='yocto_realtimelock.js'></script>
nodejs	var yoctolib = require('yoctolib'); var YRealTimeClock = yoctolib.YRealTimeClock;
php	require_once('yocto_realtimelock.php');
c++	#include "yocto_realtimelock.h"
m	#import "yocto_realtimelock.h"
pas	uses yocto_realtimelock;
vb	yocto_realtimelock.vb
cs	yocto_realtimelock.cs
java	import com.yoctopuce.YoctoAPI.YRealTimeClock;
py	from yocto_realtimelock import *

### Global functions

#### yFindRealTimeClock(func)

Retrieves a clock for a given identifier.

#### yFirstRealTimeClock()

Starts the enumeration of clocks currently accessible.

### YRealTimeClock methods

#### realtimelock→describe()

Returns a short text that describes unambiguously the instance of the clock in the form TYPE ( NAME ) =SERIAL . FUNCTIONID.

#### realtimelock→get\_advertisedValue()

Returns the current value of the clock (no more than 6 characters).

#### realtimelock→get\_dateTime()

Returns the current time in the form "YYYY/MM/DD hh:mm:ss"

#### realtimelock→get\_errorMessage()

Returns the error message of the latest error with the clock.

#### realtimelock→get\_errorType()

Returns the numerical error code of the latest error with the clock.

#### realtimelock→get\_friendlyName()

Returns a global identifier of the clock in the format MODULE\_NAME . FUNCTION\_NAME.

#### realtimelock→get\_functionDescriptor()

Returns a unique identifier of type YFUN\_DESCR corresponding to the function.

#### realtimelock→get\_functionId()

Returns the hardware identifier of the clock, without reference to the module.

#### realtimelock→get\_hardwareId()

Returns the unique hardware identifier of the clock in the form SERIAL . FUNCTIONID.

#### realtimelock→get\_logicalName()

Returns the logical name of the clock.

#### realtimelock→get\_module()

Gets the `YModule` object for the device on which the function is located.

**`realtimeclock→get_module_async(callback, context)`**

Gets the `YModule` object for the device on which the function is located (asynchronous version).

**`realtimeclock→get_timeSet()`**

Returns true if the clock has been set, and false otherwise.

**`realtimeclock→get_unixTime()`**

Returns the current time in Unix format (number of elapsed seconds since Jan 1st, 1970).

**`realtimeclock→get_userData()`**

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

**`realtimeclock→get_utcOffset()`**

Returns the number of seconds between current time and UTC time (time zone).

**`realtimeclock→isOnline()`**

Checks if the clock is currently reachable, without raising any error.

**`realtimeclock→isOnline_async(callback, context)`**

Checks if the clock is currently reachable, without raising any error (asynchronous version).

**`realtimeclock→load(msValidity)`**

Preloads the clock cache with a specified validity duration.

**`realtimeclock→load_async(msValidity, callback, context)`**

Preloads the clock cache with a specified validity duration (asynchronous version).

**`realtimeclock→nextRealTimeClock()`**

Continues the enumeration of clocks started using `yFirstRealTimeClock()`.

**`realtimeclock→registerValueCallback(callback)`**

Registers the callback function that is invoked on every change of advertised value.

**`realtimeclock→set_logicalName(newval)`**

Changes the logical name of the clock.

**`realtimeclock→set_unixTime(newval)`**

Changes the current time.

**`realtimeclock→set_userData(data)`**

Stores a user context provided as argument in the `userData` attribute of the function.

**`realtimeclock→set_utcOffset(newval)`**

Changes the number of seconds between current time and UTC time (time zone).

**`realtimeclock→wait_async(callback, context)`**

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.

## YRealTimeClock.FindRealTimeClock() yFindRealTimeClock()yFindRealTimeClock()

YRealTimeClock

Retrieves a clock for a given identifier.

```
function yFindRealTimeClock( ByVal func As String) As YRealTimeClock
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the clock is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YRealTimeClock.isOnline()` to test if the clock is indeed online at a given time. In case of ambiguity when looking for a clock by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

**Parameters :**

**func** a string that uniquely characterizes the clock

**Returns :**

a `YRealTimeClock` object allowing you to drive the clock.

---

**YRealTimeClock.FirstRealTimeClock()  
yFirstRealTimeClock()yFirstRealTimeClock()**

---

**YRealTimeClock**

Starts the enumeration of clocks currently accessible.

```
function yFirstRealTimeClock( ) As YRealTimeClock
```

Use the method `YRealTimeClock.nextRealTimeClock( )` to iterate on next clocks.

**Returns :**

a pointer to a `YRealTimeClock` object, corresponding to the first clock currently online, or a `null` pointer if there are none.

**realtimeclock→describe()****realtimeclock.describe()****YRealTimeClock**

Returns a short text that describes unambiguously the instance of the clock in the form `TYPE (NAME) =SERIAL.FUNCTIONID`.

function **describe**( ) As String

More precisely, `TYPE` is the type of the function, `NAME` is the name used for the first access to the function, `SERIAL` is the serial number of the module if the module is connected or "unresolved", and `FUNCTIONID` is the hardware identifier of the function if the module is connected. For example, this method returns `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1` if the module is already connected or `Relay(BadCustomeName.relay1)=unresolved` if the module has not yet been connected. This method does not trigger any USB or TCP transaction and can therefore be used in a debugger.

**Returns :**

a string that describes the clock (ex: `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1`)

---

**realtimeclock**→**get\_advertisedValue()****YRealTimeClock****realtimeclock**→**advertisedValue()****realtimeclock.get\_advertisedValue()**

---

Returns the current value of the clock (no more than 6 characters).

```
function get_advertisedValue( ) As String
```

**Returns :**

a string corresponding to the current value of the clock (no more than 6 characters).

On failure, throws an exception or returns Y\_ADVERTISEDVALUE\_INVALID.

`realtimeclock→get_dateTime()`

**YRealTimeClock**

`realtimeclock→dateTime()`

`realtimeclock.get_dateTime()`

---

Returns the current time in the form "YYYY/MM/DD hh:mm:ss"

```
function get_dateTime( ) As String
```

**Returns :**

a string corresponding to the current time in the form "YYYY/MM/DD hh:mm:ss"

On failure, throws an exception or returns `Y_DATETIME_INVALID`.



---

**realtimeclock→get\_errorMessage()****YRealTimeClock****realtimeclock→errorMessage()****realtimeclock.get\_errorMessage()**

---

Returns the error message of the latest error with the clock.

```
function get_errorMessage( ) As String
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using the clock object

`realtimeclock→get_errorType()`  
`realtimeclock→errorType()`  
`realtimeclock.get_errorType()`

---

**YRealTimeClock**

Returns the numerical error code of the latest error with the clock.

```
function get_errorType( ) As YRETCODE
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using the clock object

---

**realtimeclock→get\_functionDescriptor()****YRealTimeClock****realtimeclock→functionDescriptor()****realtimeclock.get\_functionDescriptor()**

---

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

function `get_functionDescriptor( )` As `YFUN_DESCR`

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`.

If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

`realtimeclock→get_functionId()`  
`realtimeclock→functionId()`  
`realtimeclock.get_functionId()`

**YRealTimeClock**

---

Returns the hardware identifier of the clock, without reference to the module.

```
function get_functionId( ) As String
```

For example `relay1`

**Returns :**

a string that identifies the clock (ex: `relay1`)

On failure, throws an exception or returns `Y_FUNCTIONID_INVALID`.

---

**realtimedclock**→**get\_hardwareId()****YRealTimeClock****realtimedclock**→**hardwareId()****realtimedclock.get\_hardwareId()**

---

Returns the unique hardware identifier of the clock in the form `SERIAL.FUNCTIONID`.

```
function get_hardwareId( ) As String
```

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the clock (for example `RELAYLO1-123456.relay1`).

**Returns :**

a string that uniquely identifies the clock (ex: `RELAYLO1-123456.relay1`)

On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

**realtimeclock→get\_logicalName()**  
**realtimeclock→logicalName()**  
**realtimeclock.get\_logicalName()**

---

**YRealTimeClock**

Returns the logical name of the clock.

```
function get_logicalName( ) As String
```

**Returns :**

a string corresponding to the logical name of the clock.

On failure, throws an exception or returns Y\_LOGICALNAME\_INVALID.

---

**realtimeclock**→**get\_module()****YRealTimeClock****realtimeclock**→**module()****realtimeclock.get\_module()**

---

Gets the `YModule` object for the device on which the function is located.

```
function get_module( ) As YModule
```

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

**Returns :**

an instance of `YModule`

**realtimeclock→get\_timeSet()**

**YRealTimeClock**

**realtimeclock→timeSet()realtimeclock.get\_timeSet()**

---

Returns true if the clock has been set, and false otherwise.

function **get\_timeSet( )** As Integer

**Returns :**

either Y\_TIMESET\_FALSE or Y\_TIMESET\_TRUE, according to true if the clock has been set, and false otherwise

On failure, throws an exception or returns Y\_TIMESET\_INVALID.



---

**realtimeclock→get\_unixTime()****YRealTimeClock****realtimeclock→unixTime()****realtimeclock.get\_unixTime()**

---

Returns the current time in Unix format (number of elapsed seconds since Jan 1st, 1970).

```
function get_unixTime( ) As Long
```

**Returns :**

an integer corresponding to the current time in Unix format (number of elapsed seconds since Jan 1st, 1970)

On failure, throws an exception or returns Y\_UNIXTIME\_INVALID.

**realtimeclock→get\_userData()**

**YRealTimeClock**

**realtimeclock→userData()**

**realtimeclock.get\_userData()**

---

Returns the value of the userData attribute, as previously stored using method `set_userData`.

```
function get_userData( ) As Object
```

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

---

**realtimeclock**→**get\_utcOffset()****YRealTimeClock****realtimeclock**→**utcOffset()****realtimeclock.get\_utcOffset()**

---

Returns the number of seconds between current time and UTC time (time zone).

```
function get_utcOffset( ) As Integer
```

**Returns :**

an integer corresponding to the number of seconds between current time and UTC time (time zone)

On failure, throws an exception or returns `Y_UTCOffset_INVALID`.

**realtimeclock→isOnline()realtimeclock.isOnline()**

**YRealTimeClock**

---

Checks if the clock is currently reachable, without raising any error.

```
function isOnline( ) As Boolean
```

If there is a cached value for the clock in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the clock.

**Returns :**

`true` if the clock can be reached, and `false` otherwise

**realtimeclock→load()realtimeclock.load()****YRealTimeClock**

Preloads the clock cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

**realtimeclock→nextRealTimeClock()**  
**realtimeclock.nextRealTimeClock()**

**YRealTimeClock**

---

Continues the enumeration of clocks started using `yFirstRealTimeClock()`.

function **nextRealTimeClock()** As YRealTimeClock

**Returns :**

a pointer to a YRealTimeClock object, corresponding to a clock currently online, or a null pointer if there are no more clocks to enumerate.

---

**realtimedclock**→**registerValueCallback()**  
**realtimedclock.registerValueCallback()**

---

**YRealTimeClock**

Registers the callback function that is invoked on every change of advertised value.

```
function registerValueCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

**realtimeclock→set\_logicalName()**  
**realtimeclock→setLogicalName()**  
**realtimeclock.set\_logicalName()**

---

**YRealTimeClock**

Changes the logical name of the clock.

```
function set_logicalName( ByVal newval As String) As Integer
```

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the clock.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.



---

**realtimeclock**→**set\_unixTime()**  
**realtimeclock**→**setUnixTime()**  
**realtimeclock.set\_unixTime()**

---

**YRealTimeClock**

Changes the current time.

```
function set_unixTime( ByVal newval As Long) As Integer
```

Time is specified in Unix format (number of elapsed seconds since Jan 1st, 1970). If current UTC time is known, utcOffset will be automatically adjusted for the new specified time.

**Parameters :**

**newval** an integer corresponding to the current time

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**realtimeclock→set\_userdata()**  
**realtimeclock→setUserData()**  
**realtimeclock.set\_userdata()**

---

**YRealTimeClock**

Stores a user context provided as argument in the `userData` attribute of the function.

```
procedure set_userdata( ByVal data As Object)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

---

**realtimeclock→set\_utcOffset()****YRealTimeClock****realtimeclock→setUtcOffset()****realtimeclock.set\_utcOffset()**

---

Changes the number of seconds between current time and UTC time (time zone).

```
function set_utcOffset( ByVal newval As Integer) As Integer
```

The timezone is automatically rounded to the nearest multiple of 15 minutes. If current UTC time is known, the current time will automatically be updated according to the selected time zone.

**Parameters :**

**newval** an integer corresponding to the number of seconds between current time and UTC time (time zone)

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

## 3.37. Reference frame configuration

This class is used to setup the base orientation of the Yocto-3D, so that the orientation functions, relative to the earth surface plane, use the proper reference frame. The class also implements a tridimensional sensor calibration process, which can compensate for local variations of standard gravity and improve the precision of the tilt sensors.

In order to use the functions described here, you should include:

js	<code>&lt;script type='text/javascript' src='yocto_refframe.js'&gt;&lt;/script&gt;</code>
nodejs	<code>var yoctolib = require('yoctolib'); var YRefFrame = yoctolib.YRefFrame;</code>
php	<code>require_once('yocto_refframe.php');</code>
cpp	<code>#include "yocto_refframe.h"</code>
m	<code>#import "yocto_refframe.h"</code>
pas	<code>uses yocto_refframe;</code>
vb	<code>yocto_refframe.vb</code>
cs	<code>yocto_refframe.cs</code>
java	<code>import com.yoctopuce.YoctoAPI.YRefFrame;</code>
py	<code>from yocto_refframe import *</code>

### Global functions

#### **yFindRefFrame(func)**

Retrieves a reference frame for a given identifier.

#### **yFirstRefFrame()**

Starts the enumeration of reference frames currently accessible.

### YRefFrame methods

#### **refframe→cancel3DCalibration()**

Aborts the sensors tridimensional calibration process et restores normal settings.

#### **refframe→describe()**

Returns a short text that describes unambiguously the instance of the reference frame in the form `TYPE (NAME) =SERIAL.FUNCTIONID`.

#### **refframe→get\_3DCalibrationHint()**

Returns instructions to proceed to the tridimensional calibration initiated with method `start3DCalibration`.

#### **refframe→get\_3DCalibrationLogMsg()**

Returns the latest log message from the calibration process.

#### **refframe→get\_3DCalibrationProgress()**

Returns the global process indicator for the tridimensional calibration initiated with method `start3DCalibration`.

#### **refframe→get\_3DCalibrationStage()**

Returns index of the current stage of the calibration initiated with method `start3DCalibration`.

#### **refframe→get\_3DCalibrationStageProgress()**

Returns the process indicator for the current stage of the calibration initiated with method `start3DCalibration`.

#### **refframe→get\_advertisedValue()**

Returns the current value of the reference frame (no more than 6 characters).

#### **refframe→get\_bearing()**

Returns the reference bearing used by the compass.

**refframe→get\_errorMessage()**

Returns the error message of the latest error with the reference frame.

**refframe→get\_errorType()**

Returns the numerical error code of the latest error with the reference frame.

**refframe→get\_friendlyName()**

Returns a global identifier of the reference frame in the format `MODULE_NAME . FUNCTION_NAME`.

**refframe→get\_functionDescriptor()**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

**refframe→get\_functionId()**

Returns the hardware identifier of the reference frame, without reference to the module.

**refframe→get\_hardwareId()**

Returns the unique hardware identifier of the reference frame in the form `SERIAL . FUNCTIONID`.

**refframe→get\_logicalName()**

Returns the logical name of the reference frame.

**refframe→get\_module()**

Gets the `YModule` object for the device on which the function is located.

**refframe→get\_module\_async(callback, context)**

Gets the `YModule` object for the device on which the function is located (asynchronous version).

**refframe→get\_mountOrientation()**

Returns the installation orientation of the device, as configured in order to define the reference frame for the compass and the pitch/roll tilt sensors.

**refframe→get\_mountPosition()**

Returns the installation position of the device, as configured in order to define the reference frame for the compass and the pitch/roll tilt sensors.

**refframe→get\_userData()**

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

**refframe→isOnline()**

Checks if the reference frame is currently reachable, without raising any error.

**refframe→isOnline\_async(callback, context)**

Checks if the reference frame is currently reachable, without raising any error (asynchronous version).

**refframe→load(msValidity)**

Preloads the reference frame cache with a specified validity duration.

**refframe→load\_async(msValidity, callback, context)**

Preloads the reference frame cache with a specified validity duration (asynchronous version).

**refframe→more3DCalibration()**

Continues the sensors tridimensional calibration process previously initiated using method `start3DCalibration`.

**refframe→nextRefFrame()**

Continues the enumeration of reference frames started using `yFirstRefFrame()`.

**refframe→registerValueCallback(callback)**

Registers the callback function that is invoked on every change of advertised value.

**refframe→save3DCalibration()**

Applies the sensors tridimensional calibration parameters that have just been computed.

**refframe→set\_bearing(newval)**

Changes the reference bearing used by the compass.

**refframe→set\_logicalName(newval)**

### 3. Reference

---

Changes the logical name of the reference frame.

**reframe**→**set\_mountPosition(position, orientation)**

Changes the compass and tilt sensor frame of reference.

**reframe**→**set\_userData(data)**

Stores a user context provided as argument in the userData attribute of the function.

**reframe**→**start3DCalibration()**

Initiates the sensors tridimensional calibration process.

**reframe**→**wait\_async(callback, context)**

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.

## YRefFrame.FindRefFrame() yFindRefFrame()yFindRefFrame()

YRefFrame

Retrieves a reference frame for a given identifier.

```
function yFindRefFrame( ByVal func As String) As YRefFrame
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the reference frame is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YRefFrame.IsOnline()` to test if the reference frame is indeed online at a given time. In case of ambiguity when looking for a reference frame by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

### Parameters :

**func** a string that uniquely characterizes the reference frame

### Returns :

a `YRefFrame` object allowing you to drive the reference frame.

## **YRefFrame.FirstRefFrame() yFirstRefFrame()yFirstRefFrame()**

---

**YRefFrame**

Starts the enumeration of reference frames currently accessible.

```
function yFirstRefFrame( ) As YRefFrame
```

Use the method `YRefFrame.nextRefFrame()` to iterate on next reference frames.

**Returns :**

a pointer to a `YRefFrame` object, corresponding to the first reference frame currently online, or a `null` pointer if there are none.



---

**refframe**→**cancel3DCalibration()**  
**refframe.cancel3DCalibration()**

---

**YRefFrame**

Aborts the sensors tridimensional calibration process et restores normal settings.

function **cancel3DCalibration**( ) As Integer

On failure, throws an exception or returns a negative error code.

**refframe**→**describe()****refframe.describe()****YRefFrame**

Returns a short text that describes unambiguously the instance of the reference frame in the form `TYPE (NAME) =SERIAL . FUNCTIONID`.

function **describe**( ) As String

More precisely, `TYPE` is the type of the function, `NAME` is the name used for the first access to the function, `SERIAL` is the serial number of the module if the module is connected or "unresolved", and `FUNCTIONID` is the hardware identifier of the function if the module is connected. For example, this method returns `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1` if the module is already connected or `Relay(BadCustomeName.relay1)=unresolved` if the module has not yet been connected. This method does not trigger any USB or TCP transaction and can therefore be used in a debugger.

**Returns :**

a string that describes the reference frame (ex: `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1`)

---

**refframe**→**get\_3DCalibrationHint()****YRefFrame****refframe**→**3DCalibrationHint()****refframe.get\_3DCalibrationHint()**

---

Returns instructions to proceed to the tridimensional calibration initiated with method `start3DCalibration`.

```
function get_3DCalibrationHint( ) As String
```

**Returns :**

a character string.

**refframe**→**get\_3DCalibrationLogMsg()**  
**refframe**→**3DCalibrationLogMsg()**  
**refframe.get\_3DCalibrationLogMsg()**

---

**YRefFrame**

Returns the latest log message from the calibration process.

```
function get_3DCalibrationLogMsg( ) As String
```

When no new message is available, returns an empty string.

**Returns :**

a character string.

---

**refframe→get\_3DCalibrationProgress()****YRefFrame****refframe→3DCalibrationProgress()****refframe.get\_3DCalibrationProgress()**

---

Returns the global process indicator for the tridimensional calibration initiated with method `start3DCalibration`.

```
function get_3DCalibrationProgress( ) As Integer
```

**Returns :**

an integer between 0 (not started) and 100 (stage completed).

**refframe**→**get\_3DCalibrationStage()**  
**refframe**→**3DCalibrationStage()**  
**refframe.get\_3DCalibrationStage()**

**YRefFrame**

---

Returns index of the current stage of the calibration initiated with method `start3DCalibration`.

```
function get_3DCalibrationStage( ) As Integer
```

**Returns :**

an integer, growing each time a calibration stage is completed.

---

**refframe**→**get\_3DCalibrationStageProgress()****YRefFrame****refframe**→**3DCalibrationStageProgress()****refframe.get\_3DCalibrationStageProgress()**

---

Returns the process indicator for the current stage of the calibration initiated with method `start3DCalibration`.

```
function get_3DCalibrationStageProgress( ) As Integer
```

**Returns :**

an integer between 0 (not started) and 100 (stage completed).

**refframe**→**get\_advertisedValue()**  
**refframe**→**advertisedValue()**  
**refframe.get\_advertisedValue()**

---

**YRefFrame**

Returns the current value of the reference frame (no more than 6 characters).

function **get\_advertisedValue( )** As String

**Returns :**

a string corresponding to the current value of the reference frame (no more than 6 characters).

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.



---

**refframe**→**get\_bearing()****YRefFrame****refframe**→**bearing()****refframe.get\_bearing()**

---

Returns the reference bearing used by the compass.

function **get\_bearing**( ) As Double

The relative bearing indicated by the compass is the difference between the measured magnetic heading and the reference bearing indicated here.

**Returns :**

a floating point number corresponding to the reference bearing used by the compass

On failure, throws an exception or returns `Y_BEARING_INVALID`.

**refframe**→**get\_errorMessage()**  
**refframe**→**errorMessage()**  
**refframe.get\_errorMessage()**

---

**YRefFrame**

Returns the error message of the latest error with the reference frame.

```
function get_errorMessage( ) As String
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using the reference frame object

---

**refframe**→**get\_errorType()****YRefFrame****refframe**→**errorType()****refframe.get\_errorType()**

---

Returns the numerical error code of the latest error with the reference frame.

```
function get_errorType( ) As YRETCODE
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using the reference frame object

**refframe**→**get\_functionDescriptor()**

**YRefFrame**

**refframe**→**functionDescriptor()**

**refframe.get\_functionDescriptor()**

---

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

`function get_functionDescriptor( )` As `YFUN_DESCR`

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`.

If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

---

**refframe**→**get\_functionId()****YRefFrame****refframe**→**functionId()****refframe.get\_functionId()**

---

Returns the hardware identifier of the reference frame, without reference to the module.

function **get\_functionId**( ) As String

For example `relay1`

**Returns :**

a string that identifies the reference frame (ex: `relay1`)

On failure, throws an exception or returns `Y_FUNCTIONID_INVALID`.

refframe→get\_hardwareId()

YRefFrame

refframe→hardwareId()refframe.get\_hardwareId()

---

Returns the unique hardware identifier of the reference frame in the form SERIAL.FUNCTIONID.

function **get\_hardwareId**( ) As String

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the reference frame (for example RELAYLO1-123456.relay1).

**Returns :**

a string that uniquely identifies the reference frame (ex: RELAYLO1-123456.relay1)

On failure, throws an exception or returns Y\_HARDWAREID\_INVALID.

---

**refframe**→**get\_logicalName()****YRefFrame****refframe**→**logicalName()****refframe.get\_logicalName()**

---

Returns the logical name of the reference frame.

```
function get_logicalName( ) As String
```

**Returns :**

a string corresponding to the logical name of the reference frame.

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

refframe→get\_module()

YRefFrame

refframe→module()refframe.get\_module()

---

Gets the YModule object for the device on which the function is located.

function `get_module()` As YModule

If the function cannot be located on any module, the returned instance of YModule is not shown as on-line.

**Returns :**

an instance of YModule



---

**refframe**→**get\_mountOrientation()****YRefFrame****refframe**→**mountOrientation()****refframe.get\_mountOrientation()**

---

Returns the installation orientation of the device, as configured in order to define the reference frame for the compass and the pitch/roll tilt sensors.

```
function get_mountOrientation( ) As Y_MOUNTORIENTATION
```

**Returns :**

a value among the enumeration Y\_MOUNTORIENTATION (Y\_MOUNTORIENTATION\_TWELVE, Y\_MOUNTORIENTATION\_THREE, Y\_MOUNTORIENTATION\_SIX, Y\_MOUNTORIENTATION\_NINE) corresponding to the orientation of the "X" arrow on the device, as on a clock dial seen from an observer in the center of the box. On the bottom face, the 12H orientation points to the front, while on the top face, the 12H orientation points to the rear.

On failure, throws an exception or returns a negative error code.

**refframe**→**get\_mountPosition()**

**YRefFrame**

**refframe**→**mountPosition()**

**refframe.get\_mountPosition()**

---

Returns the installation position of the device, as configured in order to define the reference frame for the compass and the pitch/roll tilt sensors.

function **get\_mountPosition**( ) As Y\_MOUNTPOSITION

**Returns :**

a value among the Y\_MOUNTPOSITION enumeration (Y\_MOUNTPOSITION\_BOTTOM, Y\_MOUNTPOSITION\_TOP, Y\_MOUNTPOSITION\_FRONT, Y\_MOUNTPOSITION\_RIGHT, Y\_MOUNTPOSITION\_REAR, Y\_MOUNTPOSITION\_LEFT), corresponding to the installation in a box, on one of the six faces.

On failure, throws an exception or returns a negative error code.

---

**refframe**→**get\_userData()****YRefFrame****refframe**→**userData()****refframe.get\_userData()**

---

Returns the value of the userData attribute, as previously stored using method `set_userData`.

```
function get_userData( ) As Object
```

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

**refframe→isOnline()refframe.isOnline()**

**YRefFrame**

---

Checks if the reference frame is currently reachable, without raising any error.

```
function isOnline( ) As Boolean
```

If there is a cached value for the reference frame in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the reference frame.

**Returns :**

`true` if the reference frame can be reached, and `false` otherwise

---

**refframe→load()refframe.load()****YRefFrame**

---

Preloads the reference frame cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

**refframe**→**more3DCalibration()**  
**refframe.more3DCalibration()**

**YRefFrame**

---

Continues the sensors tridimensional calibration process previously initiated using method `start3DCalibration`.

```
function more3DCalibration( ) As Integer
```

This method should be called approximately 5 times per second, while positioning the device according to the instructions provided by method `get_3DCalibrationHint`. Note that the instructions change during the calibration process. On failure, throws an exception or returns a negative error code.

---

**refframe**→**nextRefFrame()****refframe.nextRefFrame()****YRefFrame**

---

Continues the enumeration of reference frames started using `yFirstRefFrame()`.

```
function nextRefFrame( ) As YRefFrame
```

**Returns :**

a pointer to a `YRefFrame` object, corresponding to a reference frame currently online, or a `null` pointer if there are no more reference frames to enumerate.

**refframe**→**registerValueCallback()**  
**refframe.registerValueCallback()****YRefFrame**

Registers the callback function that is invoked on every change of advertised value.

```
function registerValueCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.



---

**refframe**→**save3DCalibration()**  
**refframe.save3DCalibration()**

---

**YRefFrame**

Applies the sensors tridimensional calibration parameters that have just been computed.

function **save3DCalibration**( ) As Integer

Remember to call the `saveToFlash()` method of the module if the changes must be kept when the device is restarted. On failure, throws an exception or returns a negative error code.

**refframe**→**set\_bearing()****YRefFrame****refframe**→**setBearing()****refframe.set\_bearing()**

Changes the reference bearing used by the compass.

```
function set_bearing( ByVal newval As Double) As Integer
```

The relative bearing indicated by the compass is the difference between the measured magnetic heading and the reference bearing indicated here. For instance, if you setup as reference bearing the value of the earth magnetic declination, the compass will provide the orientation relative to the geographic North. Similarly, when the sensor is not mounted along the standard directions because it has an additional yaw angle, you can set this angle in the reference bearing so that the compass provides the expected natural direction. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a floating point number corresponding to the reference bearing used by the compass

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**refframe**→**set\_logicalName()**  
**refframe**→**setLogicalName()**  
**refframe.set\_logicalName()**

**YRefFrame**

---

Changes the logical name of the reference frame.

```
function set_logicalName( ByVal newval As String) As Integer
```

You can use `yCheckLogicalName( )` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash( )` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the reference frame.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**refframe→set\_mountPosition()**  
**refframe→setMountPosition()**  
**refframe.set\_mountPosition()**

**YRefFrame**

Changes the compass and tilt sensor frame of reference.

function **set\_mountPosition( )** As Integer

The magnetic compass and the tilt sensors (pitch and roll) naturally work in the plane parallel to the earth surface. In case the device is not installed upright and horizontally, you must select its reference orientation (parallel to the earth surface) so that the measures are made relative to this position.

**Parameters :**

**position** a value among the Y\_MOUNTPOSITION enumeration (Y\_MOUNTPOSITION\_BOTTOM, Y\_MOUNTPOSITION\_TOP, Y\_MOUNTPOSITION\_FRONT, Y\_MOUNTPOSITION\_RIGHT, Y\_MOUNTPOSITION\_REAR, Y\_MOUNTPOSITION\_LEFT), corresponding to the installation in a box, on one of the six faces.

**orientation** a value among the enumeration Y\_MOUNTORIENTATION (Y\_MOUNTORIENTATION\_TWELVE, Y\_MOUNTORIENTATION\_THREE, Y\_MOUNTORIENTATION\_SIX, Y\_MOUNTORIENTATION\_NINE) corresponding to the orientation of the "X" arrow on the device, as on a clock dial seen from an observer in the center of the box. On the bottom face, the 12H orientation points to the front, while on the top face, the 12H orientation points to the rear. Remember to call the saveToFlash( ) method of the module if the modification must be kept.

---

**refframe**→**set\_userData()****YRefFrame****refframe**→**setUserData()****refframe.set\_userData()**

---

Stores a user context provided as argument in the `userData` attribute of the function.

```
procedure set_userData( ByVal data As Object)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

---

**refframe→start3DCalibration()**  
**refframe.start3DCalibration()**

---

**YRefFrame**

Initiates the sensors tridimensional calibration process.

```
function start3DCalibration( ) As Integer
```

This calibration is used at low level for inertial position estimation and to enhance the precision of the tilt sensors. After calling this method, the device should be moved according to the instructions provided by method `get_3DCalibrationHint`, and `more3DCalibration` should be invoked about 5 times per second. The calibration procedure is completed when the method `get_3DCalibrationProgress` returns 100. At this point, the computed calibration parameters can be applied using method `save3DCalibration`. The calibration process can be canceled at any time using method `cancel3DCalibration`. On failure, throws an exception or returns a negative error code.

## 3.38. Relay function interface

The Yoctopuce application programming interface allows you to switch the relay state. This change is not persistent: the relay will automatically return to its idle position whenever power is lost or if the module is restarted. The library can also generate automatically short pulses of determined duration. On devices with two output for each relay (double throw), the two outputs are named A and B, with output A corresponding to the idle position (at power off) and the output B corresponding to the active state. If you prefer the alternate default state, simply switch your cables on the board.

In order to use the functions described here, you should include:

js	<code>&lt;script type='text/javascript' src='yocto_relay.js'&gt;&lt;/script&gt;</code>
nodejs	<code>var yoctolib = require('yoctolib'); var YRelay = yoctolib.YRelay;</code>
php	<code>require_once('yocto_relay.php');</code>
c++	<code>#include "yocto_relay.h"</code>
m	<code>#import "yocto_relay.h"</code>
pas	<code>uses yocto_relay;</code>
vb	<code>yocto_relay.vb</code>
cs	<code>yocto_relay.cs</code>
java	<code>import com.yoctopuce.YoctoAPI.YRelay;</code>
py	<code>from yocto_relay import *</code>

### Global functions

#### **yFindRelay(func)**

Retrieves a relay for a given identifier.

#### **yFirstRelay()**

Starts the enumeration of relays currently accessible.

### YRelay methods

#### **relay→delayedPulse(ms\_delay, ms\_duration)**

Schedules a pulse.

#### **relay→describe()**

Returns a short text that describes unambiguously the instance of the relay in the form `TYPE (NAME) = SERIAL . FUNCTIONID`.

#### **relay→get\_advertisedValue()**

Returns the current value of the relay (no more than 6 characters).

#### **relay→get\_countdown()**

Returns the number of milliseconds remaining before a pulse (`delayedPulse()` call) When there is no scheduled pulse, returns zero.

#### **relay→get\_errorMessage()**

Returns the error message of the latest error with the relay.

#### **relay→get\_errorType()**

Returns the numerical error code of the latest error with the relay.

#### **relay→get\_friendlyName()**

Returns a global identifier of the relay in the format `MODULE_NAME . FUNCTION_NAME`.

#### **relay→get\_functionDescriptor()**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

#### **relay→get\_functionId()**

Returns the hardware identifier of the relay, without reference to the module.

#### **relay→get\_hardwareId()**

### 3. Reference

Returns the unique hardware identifier of the relay in the form `SERIAL.FUNCTIONID`.

#### **relay**→**get\_logicalName()**

Returns the logical name of the relay.

#### **relay**→**get\_maxTimeOnStateA()**

Retourne the maximum time (ms) allowed for `$THEFUNCTIONS$` to stay in state A before automatically switching back in to B state.

#### **relay**→**get\_maxTimeOnStateB()**

Retourne the maximum time (ms) allowed for `$THEFUNCTIONS$` to stay in state B before automatically switching back in to A state.

#### **relay**→**get\_module()**

Gets the `YModule` object for the device on which the function is located.

#### **relay**→**get\_module\_async(callback, context)**

Gets the `YModule` object for the device on which the function is located (asynchronous version).

#### **relay**→**get\_output()**

Returns the output state of the relays, when used as a simple switch (single throw).

#### **relay**→**get\_pulseTimer()**

Returns the number of milliseconds remaining before the relays is returned to idle position (state A), during a measured pulse generation.

#### **relay**→**get\_state()**

Returns the state of the relays (A for the idle position, B for the active position).

#### **relay**→**get\_stateAtPowerOn()**

Returns the state of the relays at device startup (A for the idle position, B for the active position, UNCHANGED for no change).

#### **relay**→**get\_userData()**

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

#### **relay**→**isOnline()**

Checks if the relay is currently reachable, without raising any error.

#### **relay**→**isOnline\_async(callback, context)**

Checks if the relay is currently reachable, without raising any error (asynchronous version).

#### **relay**→**load(msValidity)**

Preloads the relay cache with a specified validity duration.

#### **relay**→**load\_async(msValidity, callback, context)**

Preloads the relay cache with a specified validity duration (asynchronous version).

#### **relay**→**nextRelay()**

Continues the enumeration of relays started using `yFirstRelay()`.

#### **relay**→**pulse(ms\_duration)**

Sets the relay to output B (active) for a specified duration, then brings it automatically back to output A (idle state).

#### **relay**→**registerValueCallback(callback)**

Registers the callback function that is invoked on every change of advertised value.

#### **relay**→**set\_logicalName(newval)**

Changes the logical name of the relay.

#### **relay**→**set\_maxTimeOnStateA(newval)**

Sets the maximum time (ms) allowed for `$THEFUNCTIONS$` to stay in state A before automatically switching back in to B state.

#### **relay**→**set\_maxTimeOnStateB(newval)**



Sets the maximum time (ms) allowed for \$THEFUNCTIONS\$ to stay in state B before automatically switching back in to A state.

**relay→set\_output(newval)**

Changes the output state of the relays, when used as a simple switch (single throw).

**relay→set\_state(newval)**

Changes the state of the relays (A for the idle position, B for the active position).

**relay→set\_stateAtPowerOn(newval)**

Preset the state of the relays at device startup (A for the idle position, B for the active position, UNCHANGED for no modification).

**relay→set\_userData(data)**

Stores a user context provided as argument in the userData attribute of the function.

**relay→wait\_async(callback, context)**

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.

## YRelay.FindRelay() yFindRelay()yFindRelay()

YRelay

Retrieves a relay for a given identifier.

```
function yFindRelay( ByVal func As String) As YRelay
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the relay is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YRelay.isOnline()` to test if the relay is indeed online at a given time. In case of ambiguity when looking for a relay by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

**Parameters :**

**func** a string that uniquely characterizes the relay

**Returns :**

a `YRelay` object allowing you to drive the relay.

---

**YRelay.FirstRelay()**  
**yFirstRelay()****YRelay**

---

Starts the enumeration of relays currently accessible.

```
function yFirstRelay( ) As YRelay
```

Use the method `YRelay.nextRelay()` to iterate on next relays.

**Returns :**

a pointer to a `YRelay` object, corresponding to the first relay currently online, or a `null` pointer if there are none.

**relay**→**delayedPulse()****relay.delayedPulse()****YRelay**

Schedules a pulse.

```
function delayedPulse( ByVal ms_delay As Integer,  
                        ByVal ms_duration As Integer) As Integer
```

**Parameters :**

**ms\_delay** waiting time before the pulse, in milliseconds

**ms\_duration** pulse duration, in milliseconds

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**relay**→**describe()****relay.describe()****YRelay**

Returns a short text that describes unambiguously the instance of the relay in the form `TYPE(NAME)=SERIAL.FUNCTIONID`.

function **describe**( ) As String

More precisely, `TYPE` is the type of the function, `NAME` is the name used for the first access to the function, `SERIAL` is the serial number of the module if the module is connected or "unresolved", and `FUNCTIONID` is the hardware identifier of the function if the module is connected. For example, this method returns `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1` if the module is already connected or `Relay(BadCustomName.relay1)=unresolved` if the module has not yet been connected. This method does not trigger any USB or TCP transaction and can therefore be used in a debugger.

**Returns :**

a string that describes the relay (ex: `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1`)

**relay**→**get\_advertisedValue()**

**YRelay**

**relay**→**advertisedValue()****relay.get\_advertisedValue()**

---

Returns the current value of the relay (no more than 6 characters).

function **get\_advertisedValue()** As String

**Returns :**

a string corresponding to the current value of the relay (no more than 6 characters).

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

---

**relay**→**get\_countdown()****YRelay****relay**→**countdown()****relay.get\_countdown()**

---

Returns the number of milliseconds remaining before a pulse (`delayedPulse()` call) When there is no scheduled pulse, returns zero.

function **get\_countdown()** As Long

**Returns :**

an integer corresponding to the number of milliseconds remaining before a pulse (`delayedPulse()` call) When there is no scheduled pulse, returns zero

On failure, throws an exception or returns `Y_COUNTDOWN_INVALID`.

**relay**→**get\_errorMessage()**

**YRelay**

**relay**→**errorMessage()****relay**.**get\_errorMessage()**

---

Returns the error message of the latest error with the relay.

```
function get_errorMessage( ) As String
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using the relay object



---

**relay**→`get_errorType()`**YRelay****relay**→`errorType()`**relay**.`get_errorType()`

---

Returns the numerical error code of the latest error with the relay.

```
function get_errorType( ) As YRETCODE
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using the relay object

**relay**→**get\_functionDescriptor()**  
**relay**→**functionDescriptor()**  
**relay.get\_functionDescriptor()**

---

**YRelay**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

`function get_functionDescriptor( ) As YFUN_DESCR`

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`.

If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

---

**relay**→**get\_functionId()**

YRelay

**relay**→**functionId()****relay.get\_functionId()**

---

Returns the hardware identifier of the relay, without reference to the module.

```
function get_functionId( ) As String
```

For example `relay1`

**Returns :**

a string that identifies the relay (ex: `relay1`)

On failure, throws an exception or returns `Y_FUNCTIONID_INVALID`.

**relay**→**get\_hardwareId()**

**YRelay**

**relay**→**hardwareId()****relay.get\_hardwareId()**

---

Returns the unique hardware identifier of the relay in the form `SERIAL.FUNCTIONID`.

function **get\_hardwareId()** As String

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the relay (for example `RELAYLO1-123456.relay1`).

**Returns :**

a string that uniquely identifies the relay (ex: `RELAYLO1-123456.relay1`)

On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

---

**relay**→**get\_logicalName()****YRelay****relay**→**logicalName()****relay.get\_logicalName()**

---

Returns the logical name of the relay.

```
function get_logicalName( ) As String
```

**Returns :**

a string corresponding to the logical name of the relay.

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

**relay**→**get\_maxTimeOnStateA()**

**YRelay**

**relay**→**maxTimeOnStateA()**

**relay.get\_maxTimeOnStateA()**

---

Retourne the maximum time (ms) allowed for \$THEFUNCTIONS\$ to stay in state A before automatically switching back in to B state.

```
function get_maxTimeOnStateA( ) As Long
```

Zero means no maximum time.

**Returns :**

an integer

On failure, throws an exception or returns Y\_MAXTIMEONSTATEA\_INVALID.

---

**relay**→**get\_maxTimeOnStateB()****YRelay****relay**→**maxTimeOnStateB()****relay.get\_maxTimeOnStateB()**

---

Retourne the maximum time (ms) allowed for \$THEFUNCTIONS\$ to stay in state B before automatically switching back in to A state.

```
function get_maxTimeOnStateB( ) As Long
```

Zero means no maximum time.

**Returns :**

an integer

On failure, throws an exception or returns Y\_MAXTIMEONSTATEB\_INVALID.

**relay**→**get\_module()**

**YRelay**

**relay**→**module()****relay.get\_module()**

---

Gets the YModule object for the device on which the function is located.

function **get\_module**( ) As YModule

If the function cannot be located on any module, the returned instance of YModule is not shown as on-line.

**Returns :**

an instance of YModule



---

**relay**→**get\_output()****YRelay****relay**→**output()****relay.get\_output()**

---

Returns the output state of the relays, when used as a simple switch (single throw).

function **get\_output**( ) As Integer

**Returns :**

either `Y_OUTPUT_OFF` or `Y_OUTPUT_ON`, according to the output state of the relays, when used as a simple switch (single throw)

On failure, throws an exception or returns `Y_OUTPUT_INVALID`.

**relay**→**get\_pulseTimer()**

**YRelay**

**relay**→**pulseTimer()****relay.get\_pulseTimer()**

---

Returns the number of milliseconds remaining before the relays is returned to idle position (state A), during a measured pulse generation.

```
function get_pulseTimer( ) As Long
```

When there is no ongoing pulse, returns zero.

**Returns :**

an integer corresponding to the number of milliseconds remaining before the relays is returned to idle position (state A), during a measured pulse generation

On failure, throws an exception or returns `Y_PULSETIMER_INVALID`.

---

**relay**→**get\_state()****YRelay****relay**→**state()****relay.get\_state()**

---

Returns the state of the relays (A for the idle position, B for the active position).

```
function get_state( ) As Integer
```

**Returns :**

either `Y_STATE_A` or `Y_STATE_B`, according to the state of the relays (A for the idle position, B for the active position)

On failure, throws an exception or returns `Y_STATE_INVALID`.

**relay**→**get\_stateAtPowerOn()**

**YRelay**

**relay**→**stateAtPowerOn()****relay.get\_stateAtPowerOn()**

---

Returns the state of the relays at device startup (A for the idle position, B for the active position, UNCHANGED for no change).

function **get\_stateAtPowerOn()** As Integer

**Returns :**

a value among Y\_STATEATPOWERON\_UNCHANGED, Y\_STATEATPOWERON\_A and Y\_STATEATPOWERON\_B corresponding to the state of the relays at device startup (A for the idle position, B for the active position, UNCHANGED for no change)

On failure, throws an exception or returns Y\_STATEATPOWERON\_INVALID.

---

**relay**→**get\_userData()****YRelay****relay**→**userData()****relay.get\_userData()**

---

Returns the value of the userData attribute, as previously stored using method `set_userData`.

```
function get_userData( ) As Object
```

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

## relay→isOnline()relay.isOnline()

YRelay

---

Checks if the relay is currently reachable, without raising any error.

```
function isOnline( ) As Boolean
```

If there is a cached value for the relay in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the relay.

**Returns :**

true if the relay can be reached, and false otherwise

---

**relay**→**load()****relay.load()**

---

**YRelay**

Preloads the relay cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

**relay**→**nextRelay()**relay.nextRelay()

**YRelay**

---

Continues the enumeration of relays started using `yFirstRelay()`.

```
function nextRelay( ) As YRelay
```

**Returns :**

a pointer to a `YRelay` object, corresponding to a relay currently online, or a `null` pointer if there are no more relays to enumerate.



**relay**→**pulse()****relay.pulse()****YRelay**

Sets the relay to output B (active) for a specified duration, then brings it automatically back to output A (idle state).

```
function pulse( ByVal ms_duration As Integer) As Integer
```

**Parameters :**

**ms\_duration** pulse duration, in milliseconds

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**relay**→**registerValueCallback()**  
**relay.registerValueCallback()**

---

**YRelay**

Registers the callback function that is invoked on every change of advertised value.

```
function registerValueCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

---

**relay**→**set\_logicalName()****YRelay****relay**→**setLogicalName()****relay.set\_logicalName()**

---

Changes the logical name of the relay.

```
function set_logicalName( ByVal newval As String) As Integer
```

You can use `yCheckLogicalName( )` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash( )` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the relay.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**relay**→**set\_maxTimeOnStateA()**

**YRelay**

**relay**→**setMaxTimeOnStateA()**

**relay.set\_maxTimeOnStateA()**

---

Sets the maximum time (ms) allowed for \$THEFUNCTIONS\$ to stay in state A before automatically switching back in to B state.

```
function set_maxTimeOnStateA( ByVal newval As Long) As Integer
```

Use zero for no maximum time.

**Parameters :**

**newval** an integer

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**relay**→**set\_maxTimeOnStateB()****YRelay****relay**→**setMaxTimeOnStateB()****relay.set\_maxTimeOnStateB()**

---

Sets the maximum time (ms) allowed for \$THEFUNCTIONS\$ to stay in state B before automatically switching back in to A state.

```
function set_maxTimeOnStateB( ByVal newval As Long) As Integer
```

Use zero for no maximum time.

**Parameters :**

**newval** an integer

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

relay→set\_output()

YRelay

relay→setOutput()relay.set\_output()

---

Changes the output state of the relays, when used as a simple switch (single throw).

```
function set_output( ByVal newval As Integer) As Integer
```

**Parameters :**

**newval** either Y\_OUTPUT\_OFF or Y\_OUTPUT\_ON, according to the output state of the relays, when used as a simple switch (single throw)

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**relay**→**set\_state()****YRelay****relay**→**setState()****relay.set\_state()**

---

Changes the state of the relays (A for the idle position, B for the active position).

```
function set_state( ByVal newval As Integer) As Integer
```

**Parameters :**

**newval** either Y\_STATE\_A or Y\_STATE\_B, according to the state of the relays (A for the idle position, B for the active position)

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**relay**→**set\_stateAtPowerOn()**

**YRelay**

**relay**→**setStateAtPowerOn()**

**relay.set\_stateAtPowerOn()**

---

Preset the state of the relays at device startup (A for the idle position, B for the active position, UNCHANGED for no modification).

```
function set_stateAtPowerOn( ByVal newval As Integer) As Integer
```

Remember to call the matching module `saveToFlash()` method, otherwise this call will have no effect.

**Parameters :**

**newval** a value among `Y_STATEATPOWERON_UNCHANGED`, `Y_STATEATPOWERON_A` and `Y_STATEATPOWERON_B`

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.



---

**relay**→**set\_userData()****YRelay****relay**→**setUserData()****relay.set\_userData()**

---

Stores a user context provided as argument in the `userData` attribute of the function.

```
procedure set_userData( ByVal data As Object)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

## 3.39. Sensor function interface

The Yoctopuce application programming interface allows you to read an instant measure of the sensor, as well as the minimal and maximal values observed.

In order to use the functions described here, you should include:

js	<script type='text/javascript' src='yocto_api.js'></script>
nodejs	var yoctolib = require('yoctolib'); var YAPI = yoctolib.YAPI; var YModule = yoctolib.YModule;
php	require_once('yocto_api.php');
cpp	#include "yocto_api.h"
m	#import "yocto_api.h"
pas	uses yocto_api;
vb	yocto_api.vb
cs	yocto_api.cs
java	import com.yoctopuce.YoctoAPI.YModule;
py	from yocto_api import *

### Global functions

#### yFindSensor(func)

Retrieves a sensor for a given identifier.

#### yFirstSensor()

Starts the enumeration of sensors currently accessible.

### YSensor methods

#### sensor→calibrateFromPoints(rawValues, refValues)

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

#### sensor→describe()

Returns a short text that describes unambiguously the instance of the sensor in the form TYPE ( NAME ) = SERIAL . FUNCTIONID.

#### sensor→get\_advertisedValue()

Returns the current value of the sensor (no more than 6 characters).

#### sensor→get\_currentRawValue()

Returns the uncalibrated, unrounded raw value returned by the sensor, in the specified unit, as a floating point number.

#### sensor→get\_currentValue()

Returns the current value of the measure, in the specified unit, as a floating point number.

#### sensor→get\_errorMessage()

Returns the error message of the latest error with the sensor.

#### sensor→get\_errorType()

Returns the numerical error code of the latest error with the sensor.

#### sensor→get\_friendlyName()

Returns a global identifier of the sensor in the format MODULE\_NAME . FUNCTION\_NAME.

#### sensor→get\_functionDescriptor()

Returns a unique identifier of type YFUN\_DESCR corresponding to the function.

#### sensor→get\_functionId()

Returns the hardware identifier of the sensor, without reference to the module.

#### sensor→get\_hardwareId()

Returns the unique hardware identifier of the sensor in the form `SERIAL . FUNCTIONID`.

**sensor→get\_highestValue()**

Returns the maximal value observed for the measure since the device was started.

**sensor→get\_logFrequency()**

Returns the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory.

**sensor→get\_logicalName()**

Returns the logical name of the sensor.

**sensor→get\_lowestValue()**

Returns the minimal value observed for the measure since the device was started.

**sensor→get\_module()**

Gets the `YModule` object for the device on which the function is located.

**sensor→get\_module\_async(callback, context)**

Gets the `YModule` object for the device on which the function is located (asynchronous version).

**sensor→get\_recordedData(startTime, endTime)**

Retrieves a `DataSet` object holding historical data for this sensor, for a specified time interval.

**sensor→get\_reportFrequency()**

Returns the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function.

**sensor→get\_resolution()**

Returns the resolution of the measured values.

**sensor→get\_unit()**

Returns the measuring unit for the measure.

**sensor→get\_userData()**

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

**sensor→isOnline()**

Checks if the sensor is currently reachable, without raising any error.

**sensor→isOnline\_async(callback, context)**

Checks if the sensor is currently reachable, without raising any error (asynchronous version).

**sensor→load(msValidity)**

Preloads the sensor cache with a specified validity duration.

**sensor→loadCalibrationPoints(rawValues, refValues)**

Retrieves error correction data points previously entered using the method `calibrateFromPoints`.

**sensor→load\_async(msValidity, callback, context)**

Preloads the sensor cache with a specified validity duration (asynchronous version).

**sensor→nextSensor()**

Continues the enumeration of sensors started using `yFirstSensor()`.

**sensor→registerTimedReportCallback(callback)**

Registers the callback function that is invoked on every periodic timed notification.

**sensor→registerValueCallback(callback)**

Registers the callback function that is invoked on every change of advertised value.

**sensor→set\_highestValue(newval)**

Changes the recorded maximal value observed.

**sensor→set\_logFrequency(newval)**

Changes the datalogger recording frequency for this function.

**sensor→set\_logicalName(newval)**

### 3. Reference

---

Changes the logical name of the sensor.

**sensor**→**set\_lowestValue(newval)**

Changes the recorded minimal value observed.

**sensor**→**set\_reportFrequency(newval)**

Changes the timed value notification frequency for this function.

**sensor**→**set\_resolution(newval)**

Changes the resolution of the measured physical values.

**sensor**→**set\_userData(data)**

Stores a user context provided as argument in the userData attribute of the function.

**sensor**→**wait\_async(callback, context)**

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.

## YSensor.FindSensor() yFindSensor()yFindSensor()

YSensor

Retrieves a sensor for a given identifier.

```
function yFindSensor( ByVal func As String) As YSensor
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the sensor is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YSensor.IsOnline()` to test if the sensor is indeed online at a given time. In case of ambiguity when looking for a sensor by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

**Parameters :**

**func** a string that uniquely characterizes the sensor

**Returns :**

a `YSensor` object allowing you to drive the sensor.

## **YSensor.FirstSensor() yFirstSensor()yFirstSensor()**

---

**YSensor**

Starts the enumeration of sensors currently accessible.

```
function yFirstSensor( ) As YSensor
```

Use the method `YSensor.NextSensor()` to iterate on next sensors.

**Returns :**

a pointer to a `YSensor` object, corresponding to the first sensor currently online, or a `null` pointer if there are none.

---

**sensor**→**calibrateFromPoints()**  
**sensor.calibrateFromPoints()**

---

**YSensor**

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

**procedure** **calibrateFromPoints()**

It is possible to configure up to five correction points. Correction points must be provided in ascending order, and be in the range of the sensor. The device will automatically perform a linear interpolation of the error correction between specified points. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

For more information on advanced capabilities to refine the calibration of sensors, please contact [support@yoctopuce.com](mailto:support@yoctopuce.com).

**Parameters :**

**rawValues** array of floating point numbers, corresponding to the raw values returned by the sensor for the correction points.

**refValues** array of floating point numbers, corresponding to the corrected values for the correction points.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**sensor**→**describe()****sensor.describe()****YSensor**

Returns a short text that describes unambiguously the instance of the sensor in the form `TYPE (NAME) =SERIAL.FUNCTIONID`.

function **describe**( ) As String

More precisely, `TYPE` is the type of the function, `NAME` is the name used for the first access to the function, `SERIAL` is the serial number of the module if the module is connected or "unresolved", and `FUNCTIONID` is the hardware identifier of the function if the module is connected. For example, this method returns `Relay(MyCustomName.relay1)=RELAYL01-123456.relay1` if the module is already connected or `Relay(BadCustomeName.relay1)=unresolved` if the module has not yet been connected. This method does not trigger any USB or TCP transaction and can therefore be used in a debugger.

**Returns :**

a string that describes the sensor (ex: `Relay(MyCustomName.relay1)=RELAYL01-123456.relay1`)



---

**sensor**→**get\_advertisedValue()****YSensor****sensor**→**advertisedValue()****sensor.get\_advertisedValue()**

---

Returns the current value of the sensor (no more than 6 characters).

```
function get_advertisedValue( ) As String
```

**Returns :**

a string corresponding to the current value of the sensor (no more than 6 characters).

On failure, throws an exception or returns Y\_ADVERTISEDVALUE\_INVALID.

**sensor**→**get\_currentRawValue()**

**YSensor**

**sensor**→**currentRawValue()**

**sensor.get\_currentRawValue()**

---

Returns the uncalibrated, unrounded raw value returned by the sensor, in the specified unit, as a floating point number.

function **get\_currentRawValue( )** As Double

**Returns :**

a floating point number corresponding to the uncalibrated, unrounded raw value returned by the sensor, in the specified unit, as a floating point number

On failure, throws an exception or returns `Y_CURRENTRAWVALUE_INVALID`.

---

**sensor**→**get\_currentValue()****YSensor****sensor**→**currentValue()****sensor.get\_currentValue()**

---

Returns the current value of the measure, in the specified unit, as a floating point number.

function **get\_currentValue()** As Double

**Returns :**

a floating point number corresponding to the current value of the measure, in the specified unit, as a floating point number

On failure, throws an exception or returns **Y\_CURRENTVALUE\_INVALID**.

**sensor**→**get\_errorMessage()**

**YSensor**

**sensor**→**errorMessage()****sensor.get\_errorMessage()**

---

Returns the error message of the latest error with the sensor.

function **get\_errorMessage**( ) As String

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using the sensor object

---

**sensor**→**get\_errorType()****YSensor****sensor**→**errorType()****sensor.get\_errorType()**

---

Returns the numerical error code of the latest error with the sensor.

```
function get_errorType( ) As YRETCODE
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using the sensor object

**sensor**→**get\_functionDescriptor()**

**YSensor**

**sensor**→**functionDescriptor()**

**sensor.get\_functionDescriptor()**

---

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

`function get_functionDescriptor( )` As `YFUN_DESCR`

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`.

If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

---

**sensor**→**get\_functionId()****YSensor****sensor**→**functionId()****sensor.get\_functionId()**

---

Returns the hardware identifier of the sensor, without reference to the module.

function **get\_functionId**( ) As String

For example `relay1`

**Returns :**

a string that identifies the sensor (ex: `relay1`)

On failure, throws an exception or returns `Y_FUNCTIONID_INVALID`.

**sensor**→**get\_hardwareId()**

**YSensor**

**sensor**→**hardwareId()****sensor.get\_hardwareId()**

---

Returns the unique hardware identifier of the sensor in the form `SERIAL.FUNCTIONID`.

function **get\_hardwareId()** As String

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the sensor (for example `RELAYLO1-123456.relay1`).

**Returns :**

a string that uniquely identifies the sensor (ex: `RELAYLO1-123456.relay1`)

On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.



---

**sensor**→**get\_highestValue()****YSensor****sensor**→**highestValue()****sensor.get\_highestValue()**

---

Returns the maximal value observed for the measure since the device was started.

function **get\_highestValue()** As Double

**Returns :**

a floating point number corresponding to the maximal value observed for the measure since the device was started

On failure, throws an exception or returns `Y_HIGHESTVALUE_INVALID`.

**sensor**→**get\_logFrequency()**

**YSensor**

**sensor**→**logFrequency()****sensor.get\_logFrequency()**

---

Returns the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory.

function **get\_logFrequency()** As String

**Returns :**

a string corresponding to the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory

On failure, throws an exception or returns Y\_LOGFREQUENCY\_INVALID.

---

**sensor**→**get\_logicalName()****YSensor****sensor**→**logicalName()****sensor.get\_logicalName()**

---

Returns the logical name of the sensor.

```
function get_logicalName( ) As String
```

**Returns :**

a string corresponding to the logical name of the sensor.

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

**sensor**→**get\_lowestValue()**

**YSensor**

**sensor**→**lowestValue()****sensor.get\_lowestValue()**

---

Returns the minimal value observed for the measure since the device was started.

function **get\_lowestValue( )** As Double

**Returns :**

a floating point number corresponding to the minimal value observed for the measure since the device was started

On failure, throws an exception or returns **Y\_LOWESTVALUE\_INVALID**.

---

**sensor**→**get\_module()****YSensor****sensor**→**module()****sensor.get\_module()**

---

Gets the `YModule` object for the device on which the function is located.

function `get_module( )` As `YModule`

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

**Returns :**

an instance of `YModule`

**sensor**→**get\_recordedData()**

**YSensor**

**sensor**→**recordedData()****sensor.get\_recordedData()**

---

Retrieves a DataSet object holding historical data for this sensor, for a specified time interval.

```
function get_recordedData( ) As YDataSet
```

The measures will be retrieved from the data logger, which must have been turned on at the desired time. See the documentation of the DataSet class for information on how to get an overview of the recorded data, and how to load progressively a large set of measures from the data logger.

This function only works if the device uses a recent firmware, as DataSet objects are not supported by firmwares older than version 13000.

**Parameters :**

- startTime** the start of the desired measure time interval, as a Unix timestamp, i.e. the number of seconds since January 1, 1970 UTC. The special value 0 can be used to include any meaasure, without initial limit.
- endTime** the end of the desired measure time interval, as a Unix timestamp, i.e. the number of seconds since January 1, 1970 UTC. The special value 0 can be used to include any meaasure, without ending limit.

**Returns :**

an instance of YDataSet, providing access to historical data. Past measures can be loaded progressively using methods from the YDataSet object.

---

**sensor**→**get\_reportFrequency()****YSensor****sensor**→**reportFrequency()****sensor.get\_reportFrequency()**

---

Returns the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function.

```
function get_reportFrequency( ) As String
```

**Returns :**

a string corresponding to the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function

On failure, throws an exception or returns `Y_REPORTFREQUENCY_INVALID`.

**sensor**→**get\_resolution()**

**YSensor**

**sensor**→**resolution()****sensor.get\_resolution()**

---

Returns the resolution of the measured values.

function **get\_resolution()** As Double

The resolution corresponds to the numerical precision of the measures, which is not always the same as the actual precision of the sensor.

**Returns :**

a floating point number corresponding to the resolution of the measured values

On failure, throws an exception or returns `Y_RESOLUTION_INVALID`.



---

**sensor**→**get\_unit()****YSensor****sensor**→**unit()****sensor.get\_unit()**

---

Returns the measuring unit for the measure.

function **get\_unit**( ) As String

**Returns :**

a string corresponding to the measuring unit for the measure

On failure, throws an exception or returns `Y_UNIT_INVALID`.

**sensor**→**get\_userData()**

**YSensor**

**sensor**→**userData()****sensor.userData()**

---

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

function **get\_userData**( ) As Object

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

---

**sensor**→**isOnline()****sensor.isOnline()****YSensor**

---

Checks if the sensor is currently reachable, without raising any error.

```
function isOnline( ) As Boolean
```

If there is a cached value for the sensor in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the sensor.

**Returns :**

`true` if the sensor can be reached, and `false` otherwise

**sensor**→**load()****sensor.load()****YSensor**

Preloads the sensor cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**sensor**→**loadCalibrationPoints()**  
**sensor.loadCalibrationPoints()****YSensor**

---

Retrieves error correction data points previously entered using the method `calibrateFromPoints`.

procedure **loadCalibrationPoints( )**

**Parameters :**

**rawValues** array of floating point numbers, that will be filled by the function with the raw sensor values for the correction points.

**refValues** array of floating point numbers, that will be filled by the function with the desired values for the correction points.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**sensor**→**nextSensor()****sensor.nextSensor()**

**YSensor**

---

Continues the enumeration of sensors started using `yFirstSensor()`.

function **nextSensor()** As **YSensor**

**Returns :**

a pointer to a **YSensor** object, corresponding to a sensor currently online, or a `null` pointer if there are no more sensors to enumerate.

---

**sensor**→**registerTimedReportCallback()**  
**sensor.registerTimedReportCallback()**

---

**YSensor**

Registers the callback function that is invoked on every periodic timed notification.

```
function registerTimedReportCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and an `YMeasure` object describing the new advertised value.

**sensor**→**registerValueCallback()**  
**sensor.registerValueCallback()****YSensor**

Registers the callback function that is invoked on every change of advertised value.

```
function registerValueCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.



---

**sensor**→**set\_highestValue()****YSensor****sensor**→**setHighestValue()****sensor.set\_highestValue()**

---

Changes the recorded maximal value observed.

```
function set_highestValue( ByVal newval As Double) As Integer
```

**Parameters :**

**newval** a floating point number corresponding to the recorded maximal value observed

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**sensor**→**set\_logFrequency()**

**YSensor**

**sensor**→**setLogFrequency()**

**sensor.set\_logFrequency()**

---

Changes the datalogger recording frequency for this function.

```
function set_logFrequency( ByVal newval As String) As Integer
```

The frequency can be specified as samples per second, as sample per minute (for instance "15/m") or in samples per hour (eg. "4/h"). To disable recording for this function, use the value "OFF".

**Parameters :**

**newval** a string corresponding to the datalogger recording frequency for this function

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**sensor**→**set\_logicalName()****YSensor****sensor**→**setLogicalName()****sensor.set\_logicalName()**

---

Changes the logical name of the sensor.

```
function set_logicalName( ByVal newval As String) As Integer
```

You can use `yCheckLogicalName( )` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash( )` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the sensor.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**sensor**→**set\_lowestValue()**

**YSensor**

**sensor**→**setLowestValue()****sensor.set\_lowestValue()**

---

Changes the recorded minimal value observed.

```
function set_lowestValue( ByVal newval As Double) As Integer
```

**Parameters :**

**newval** a floating point number corresponding to the recorded minimal value observed

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**sensor**→**set\_reportFrequency()****YSensor****sensor**→**setReportFrequency()****sensor.set\_reportFrequency()**

---

Changes the timed value notification frequency for this function.

```
function set_reportFrequency( ByVal newval As String) As Integer
```

The frequency can be specified as samples per second, as sample per minute (for instance "15/m") or in samples per hour (eg. "4/h"). To disable timed value notifications for this function, use the value "OFF".

**Parameters :**

**newval** a string corresponding to the timed value notification frequency for this function

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**sensor**→**set\_resolution()**

**YSensor**

**sensor**→**setResolution()****sensor.set\_resolution()**

---

Changes the resolution of the measured physical values.

```
function set_resolution( ByVal newval As Double) As Integer
```

The resolution corresponds to the numerical precision when displaying value. It does not change the precision of the measure itself.

**Parameters :**

**newval** a floating point number corresponding to the resolution of the measured physical values

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**sensor**→**set\_userData()****YSensor****sensor**→**setUserData()****sensor.set\_userData()**

---

Stores a user context provided as argument in the `userData` attribute of the function.

```
procedure set_userData( ByVal data As Object)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

## 3.40. SerialPort function interface

The SerialPort function interface allows you to fully drive a Yoctopuce serial port, to send and receive data, and to configure communication parameters (baud rate, bit count, parity, flow control and protocol). Note that Yoctopuce serial ports are not exposed as virtual COM ports. They are meant to be used in the same way as all Yoctopuce devices.

In order to use the functions described here, you should include:

js	<script type='text/javascript' src='yocto_serialport.js'></script>
nodejs	var yoctolib = require('yoctolib'); var YSerialPort = yoctolib.YSerialPort;
php	require_once('yocto_serialport.php');
cpp	#include "yocto_serialport.h"
m	#import "yocto_serialport.h"
pas	uses yocto_serialport;
vb	yocto_serialport.vb
cs	yocto_serialport.cs
java	import com.yoctopuce.YoctoAPI.YSerialPort;
py	from yocto_serialport import *

### Global functions

#### yFindSerialPort(func)

Retrieves a serial port for a given identifier.

#### yFirstSerialPort()

Starts the enumeration of serial ports currently accessible.

### YSerialPort methods

#### serialport→describe()

Returns a short text that describes unambiguously the instance of the serial port in the form TYPE ( NAME ) =SERIAL . FUNCTIONID.

#### serialport→get\_CTS()

Read the level of the CTS line.

#### serialport→get\_advertisedValue()

Returns the current value of the serial port (no more than 6 characters).

#### serialport→get\_errCount()

Returns the total number of communication errors detected since last reset.

#### serialport→get\_errorMessage()

Returns the error message of the latest error with the serial port.

#### serialport→get\_errorType()

Returns the numerical error code of the latest error with the serial port.

#### serialport→get\_friendlyName()

Returns a global identifier of the serial port in the format MODULE\_NAME . FUNCTION\_NAME.

#### serialport→get\_functionDescriptor()

Returns a unique identifier of type YFUN\_DESCR corresponding to the function.

#### serialport→get\_functionId()

Returns the hardware identifier of the serial port, without reference to the module.

#### serialport→get\_hardwareId()

Returns the unique hardware identifier of the serial port in the form SERIAL . FUNCTIONID.

#### serialport→get\_lastMsg()



Returns the latest message fully received (for Line, Frame and Modbus protocols).

**serialport→get\_logicalName()**

Returns the logical name of the serial port.

**serialport→get\_module()**

Gets the YModule object for the device on which the function is located.

**serialport→get\_module\_async(callback, context)**

Gets the YModule object for the device on which the function is located (asynchronous version).

**serialport→get\_msgCount()**

Returns the total number of messages received since last reset.

**serialport→get\_protocol()**

Returns the type of protocol used over the serial line, as a string.

**serialport→get\_rxCount()**

Returns the total number of bytes received since last reset.

**serialport→get\_serialMode()**

Returns the serial port communication parameters, as a string such as "9600,8N1".

**serialport→get\_txCount()**

Returns the total number of bytes transmitted since last reset.

**serialport→get\_userData()**

Returns the value of the userData attribute, as previously stored using method set\_userData.

**serialport→isOnline()**

Checks if the serial port is currently reachable, without raising any error.

**serialport→isOnline\_async(callback, context)**

Checks if the serial port is currently reachable, without raising any error (asynchronous version).

**serialport→load(msValidity)**

Preloads the serial port cache with a specified validity duration.

**serialport→load\_async(msValidity, callback, context)**

Preloads the serial port cache with a specified validity duration (asynchronous version).

**serialport→modbusReadBits(slaveNo, pduAddr, nBits)**

Reads one or more contiguous internal bits (or coil status) from a MODBUS serial device.

**serialport→modbusReadInputBits(slaveNo, pduAddr, nBits)**

Reads one or more contiguous input bits (or discrete inputs) from a MODBUS serial device.

**serialport→modbusReadInputRegisters(slaveNo, pduAddr, nWords)**

Reads one or more contiguous input registers (read-only registers) from a MODBUS serial device.

**serialport→modbusReadRegisters(slaveNo, pduAddr, nWords)**

Reads one or more contiguous internal registers (holding registers) from a MODBUS serial device.

**serialport→modbusWriteAndReadRegisters(slaveNo, pduWriteAddr, values, pduReadAddr, nReadWords)**

Sets several contiguous internal registers (holding registers) on a MODBUS serial device, then performs a contiguous read of a set of (possibly different) internal registers.

**serialport→modbusWriteBit(slaveNo, pduAddr, value)**

Sets a single internal bit (or coil) on a MODBUS serial device.

**serialport→modbusWriteBits(slaveNo, pduAddr, bits)**

Sets several contiguous internal bits (or coils) on a MODBUS serial device.

**serialport→modbusWriteRegister(slaveNo, pduAddr, value)**

Sets a single internal register (or holding register) on a MODBUS serial device.

**serialport→modbusWriteRegisters(slaveNo, pduAddr, values)**

### 3. Reference

Sets several contiguous internal registers (or holding registers) on a MODBUS serial device.

#### **serialport**→**nextSerialPort()**

Continues the enumeration of serial ports started using `yFirstSerialPort()`.

#### **serialport**→**queryLine(query, maxWait)**

Sends a text line query to the serial port, and reads the reply, if any.

#### **serialport**→**queryMODBUS(slaveNo, pduBytes)**

Sends a message to a specified MODBUS slave connected to the serial port, and reads the reply, if any.

#### **serialport**→**readHex(nBytes)**

Reads data from the receive buffer as a hexadecimal string, starting at current stream position.

#### **serialport**→**readLine()**

Reads a single line (or message) from the receive buffer, starting at current stream position.

#### **serialport**→**readMessages(pattern, maxWait)**

Searches for incoming messages in the serial port receive buffer matching a given pattern, starting at current position.

#### **serialport**→**readStr(nChars)**

Reads data from the receive buffer as a string, starting at current stream position.

#### **serialport**→**read\_seek(rxCountVal)**

Changes the current internal stream position to the specified value.

#### **serialport**→**registerValueCallback(callback)**

Registers the callback function that is invoked on every change of advertised value.

#### **serialport**→**reset()**

Clears the serial port buffer and resets counters to zero.

#### **serialport**→**set\_RTS(val)**

Manually sets the state of the RTS line.

#### **serialport**→**set\_logicalName(newval)**

Changes the logical name of the serial port.

#### **serialport**→**set\_protocol(newval)**

Changes the type of protocol used over the serial line.

#### **serialport**→**set\_serialMode(newval)**

Changes the serial port communication parameters, with a string such as "9600,8N1".

#### **serialport**→**set\_userData(data)**

Stores a user context provided as argument in the `userData` attribute of the function.

#### **serialport**→**wait\_async(callback, context)**

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.

#### **serialport**→**writeArray(byteList)**

Sends a byte sequence (provided as a list of bytes) to the serial port.

#### **serialport**→**writeBin(buff)**

Sends a binary buffer to the serial port, as is.

#### **serialport**→**writeHex(hexString)**

Sends a byte sequence (provided as a hexadecimal string) to the serial port.

#### **serialport**→**writeLine(text)**

Sends an ASCII string to the serial port, followed by a line break (CR LF).

#### **serialport**→**writeMODBUS(hexString)**

Sends a MODBUS message (provided as a hexadecimal string) to the serial port.

#### **serialport**→**writeStr(text)**

Sends an ASCII string to the serial port, as is.

## YSerialPort.FindSerialPort() yFindSerialPort()yFindSerialPort()

YSerialPort

Retrieves a serial port for a given identifier.

```
function yFindSerialPort( ByVal func As String) As YSerialPort
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the serial port is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YSerialPort.IsOnline()` to test if the serial port is indeed online at a given time. In case of ambiguity when looking for a serial port by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

**Parameters :**

**func** a string that uniquely characterizes the serial port

**Returns :**

a `YSerialPort` object allowing you to drive the serial port.

---

**YSerialPort.FirstSerialPort()  
yFirstSerialPort()yFirstSerialPort()**

---

**YSerialPort**

Starts the enumeration of serial ports currently accessible.

```
function yFirstSerialPort( ) As YSerialPort
```

Use the method `YSerialPort.NextSerialPort()` to iterate on next serial ports.

**Returns :**

a pointer to a `YSerialPort` object, corresponding to the first serial port currently online, or a `null` pointer if there are none.

**serialport**→**describe()****serialport.describe()****YSerialPort**

Returns a short text that describes unambiguously the instance of the serial port in the form `TYPE (NAME) =SERIAL.FUNCTIONID`.

function **describe**( ) As String

More precisely, `TYPE` is the type of the function, `NAME` it the name used for the first access to the function, `SERIAL` is the serial number of the module if the module is connected or "unresolved", and `FUNCTIONID` is the hardware identifier of the function if the module is connected. For example, this method returns `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1` if the module is already connected or `Relay(BadCustomeName.relay1)=unresolved` if the module has not yet been connected. This method does not trigger any USB or TCP transaction and can therefore be used in a debugger.

**Returns :**

a string that describes the serial port (ex: `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1`)

---

**serialport**→**get\_CTS()**  
**serialport**→**CTS()****serialport.get\_CTS()**

---

**YSerialPort**

Read the level of the CTS line.

function **get\_CTS**( ) As Integer

The CTS line is usually driven by the RTS signal of the connected serial device.

**Returns :**

1 if the CTS line is high, 0 if the CTS line is low.

On failure, throws an exception or returns a negative error code.

**serialport**→**get\_advertisedValue()**

**YSerialPort**

**serialport**→**advertisedValue()**

**serialport.get\_advertisedValue()**

---

Returns the current value of the serial port (no more than 6 characters).

```
function get_advertisedValue( ) As String
```

**Returns :**

a string corresponding to the current value of the serial port (no more than 6 characters).

On failure, throws an exception or returns Y\_ADVERTISEDVALUE\_INVALID.



---

**serialport**→**get\_errCount()****YSerialPort****serialport**→**errCount()****serialport.get\_errCount()**

---

Returns the total number of communication errors detected since last reset.

function **get\_errCount**( ) As Integer

**Returns :**

an integer corresponding to the total number of communication errors detected since last reset

On failure, throws an exception or returns `Y_ERRCOUNT_INVALID`.

**serialport**→**get\_errorMessage()**

**YSerialPort**

**serialport**→**errorMessage()**

**serialport.get\_errorMessage()**

---

Returns the error message of the latest error with the serial port.

```
function get_errorMessage( ) As String
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using the serial port object

---

**serialport**→**get\_errorType()****YSerialPort****serialport**→**errorType()****serialport.get\_errorType()**

---

Returns the numerical error code of the latest error with the serial port.

```
function get_errorType( ) As YRETCODE
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using the serial port object

---

**serialport**→**get\_functionDescriptor()**  
**serialport**→**functionDescriptor()**  
**serialport.get\_functionDescriptor()**

---

**YSerialPort**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

```
function get_functionDescriptor( ) As YFUN_DESCR
```

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`.

If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

---

**serialport**→**get\_functionId()****YSerialPort****serialport**→**functionId()****serialport.get\_functionId()**

---

Returns the hardware identifier of the serial port, without reference to the module.

function **get\_functionId**( ) As String

For example `relay1`

**Returns :**

a string that identifies the serial port (ex: `relay1`)

On failure, throws an exception or returns `Y_FUNCTIONID_INVALID`.

**serialport**→**get\_hardwareId()**

**YSerialPort**

**serialport**→**hardwareId()****serialport.get\_hardwareId()**

---

Returns the unique hardware identifier of the serial port in the form `SERIAL.FUNCTIONID`.

function **get\_hardwareId()** As String

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the serial port (for example `RELAYLO1-123456.relay1`).

**Returns :**

a string that uniquely identifies the serial port (ex: `RELAYLO1-123456.relay1`)

On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

---

**serialport**→**get\_lastMsg()****YSerialPort****serialport**→**lastMsg()****serialport.get\_lastMsg()**

---

Returns the latest message fully received (for Line, Frame and Modbus protocols).

function **get\_lastMsg**( ) As String

**Returns :**

a string corresponding to the latest message fully received (for Line, Frame and Modbus protocols)

On failure, throws an exception or returns `Y_LASTMSG_INVALID`.

**serialport**→**get\_logicalName()**

**YSerialPort**

**serialport**→**logicalName()**

**serialport.get\_logicalName()**

---

Returns the logical name of the serial port.

```
function get_logicalName( ) As String
```

**Returns :**

a string corresponding to the logical name of the serial port.

On failure, throws an exception or returns Y\_LOGICALNAME\_INVALID.



---

**serialport**→**get\_module()****YSerialPort****serialport**→**module()****serialport.get\_module()**

---

Gets the YModule object for the device on which the function is located.

function **get\_module()** As YModule

If the function cannot be located on any module, the returned instance of YModule is not shown as on-line.

**Returns :**

an instance of YModule

**serialport**→**get\_msgCount()**

**YSerialPort**

**serialport**→**msgCount()****serialport.get\_msgCount()**

---

Returns the total number of messages received since last reset.

function **get\_msgCount**( ) As Integer

**Returns :**

an integer corresponding to the total number of messages received since last reset

On failure, throws an exception or returns `Y_MSGCOUNT_INVALID`.

---

**serialport**→**get\_protocol()****YSerialPort****serialport**→**protocol()****serialport.get\_protocol()**

---

Returns the type of protocol used over the serial line, as a string.

function **get\_protocol**( ) As String

Possible values are "Line" for ASCII messages separated by CR and/or LF, "Frame:[timeout]ms" for binary messages separated by a delay time, "Modbus-ASCII" for MODBUS messages in ASCII mode, "Modbus-RTU" for MODBUS messages in RTU mode, "Char" for a continuous ASCII stream or "Byte" for a continuous binary stream.

**Returns :**

a string corresponding to the type of protocol used over the serial line, as a string

On failure, throws an exception or returns Y\_PROTOCOL\_INVALID.

**serialport**→**get\_rxCount()**

**YSerialPort**

**serialport**→**rxCount()****serialport.get\_rxCount()**

---

Returns the total number of bytes received since last reset.

function **get\_rxCount**( ) As Integer

**Returns :**

an integer corresponding to the total number of bytes received since last reset

On failure, throws an exception or returns `Y_RXCOUNT_INVALID`.

---

**serialport**→**get\_serialMode()****YSerialPort****serialport**→**serialMode()****serialport.get\_serialMode()**

---

Returns the serial port communication parameters, as a string such as "9600,8N1".

function **get\_serialMode( )** As String

The string includes the baud rate, the number of data bits, the parity, and the number of stop bits. An optional suffix is included if flow control is active: "CtsRts" for hardware handshake, "XOnXOff" for logical flow control and "Simplex" for acquiring a shared bus using the RTS line (as used by some RS485 adapters for instance).

**Returns :**

a string corresponding to the serial port communication parameters, as a string such as "9600,8N1"

On failure, throws an exception or returns `Y_SERIALMODE_INVALID`.

**serialport**→**get\_txCount()**

**YSerialPort**

**serialport**→**txCount()****serialport.get\_txCount()**

---

Returns the total number of bytes transmitted since last reset.

function **get\_txCount**( ) As Integer

**Returns :**

an integer corresponding to the total number of bytes transmitted since last reset

On failure, throws an exception or returns `Y_TXCOUNT_INVALID`.

---

**serialport**→**get\_userData()****YSerialPort****serialport**→**userData()****serialport.get\_userData()**

---

Returns the value of the userData attribute, as previously stored using method `set_userData`.

```
function get_userData( ) As Object
```

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

## **serialport**→**isOnline()****serialport.isOnline()**

**YSerialPort**

---

Checks if the serial port is currently reachable, without raising any error.

function **isOnline**( ) As Boolean

If there is a cached value for the serial port in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the serial port.

**Returns :**

`true` if the serial port can be reached, and `false` otherwise



---

**serialport**→**load()****serialport.load()****YSerialPort**

---

Preloads the serial port cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

**serialport**→**modbusReadBits()**  
**serialport.modbusReadBits()****YSerialPort**

Reads one or more contiguous internal bits (or coil status) from a MODBUS serial device.

function **modbusReadBits**( ) As List

This method uses the MODBUS function code 0x01 (Read Coils).

**Parameters :**

- slaveNo** the address of the slave MODBUS device to query
- pduAddr** the relative address of the first bit/coil to read (zero-based)
- nBits** the number of bits/coils to read

**Returns :**

a vector of integers, each corresponding to one bit.

On failure, throws an exception or returns an empty array.

---

**serialport**→**modbusReadInputBits()**  
**serialport.modbusReadInputBits()**

---

**YSerialPort**

Reads one or more contiguous input bits (or discrete inputs) from a MODBUS serial device.

function **modbusReadInputBits**( ) As List

This method uses the MODBUS function code 0x02 (Read Discrete Inputs).

**Parameters :**

- slaveNo** the address of the slave MODBUS device to query
- pduAddr** the relative address of the first bit/input to read (zero-based)
- nBits** the number of bits/inputs to read

**Returns :**

a vector of integers, each corresponding to one bit.

On failure, throws an exception or returns an empty array.

**serialport**→**modbusReadInputRegisters()**  
**serialport.modbusReadInputRegisters()****YSerialPort**

Reads one or more contiguous input registers (read-only registers) from a MODBUS serial device.

function **modbusReadInputRegisters**( ) As List

This method uses the MODBUS function code 0x04 (Read Input Registers).

**Parameters :**

- slaveNo** the address of the slave MODBUS device to query
- pduAddr** the relative address of the first input register to read (zero-based)
- nWords** the number of input registers to read

**Returns :**

a vector of integers, each corresponding to one 16-bit input value.

On failure, throws an exception or returns an empty array.

---

**serialport**→**modbusReadRegisters()**  
**serialport.modbusReadRegisters()****YSerialPort**

---

Reads one or more contiguous internal registers (holding registers) from a MODBUS serial device.

function **modbusReadRegisters**( ) As List

This method uses the MODBUS function code 0x03 (Read Holding Registers).

**Parameters :**

- slaveNo** the address of the slave MODBUS device to query
- pduAddr** the relative address of the first holding register to read (zero-based)
- nWords** the number of holding registers to read

**Returns :**

a vector of integers, each corresponding to one 16-bit register value.

On failure, throws an exception or returns an empty array.

**serialport**→**modbusWriteAndReadRegisters()**  
**serialport.modbusWriteAndReadRegisters()****YSerialPort**

Sets several contiguous internal registers (holding registers) on a MODBUS serial device, then performs a contiguous read of a set of (possibly different) internal registers.

procedure **modbusWriteAndReadRegisters**( )

This method uses the MODBUS function code 0x17 (Read/Write Multiple Registers).

**Parameters :**

- slaveNo** the address of the slave MODBUS device to drive
- pduWriteAddr** the relative address of the first internal register to set (zero-based)
- values** the vector of 16 bit values to set
- pduReadAddr** the relative address of the first internal register to read (zero-based)
- nReadWords** the number of 16 bit values to read

**Returns :**

a vector of integers, each corresponding to one 16-bit register value read.

On failure, throws an exception or returns an empty array.

---

**serialport**→**modbusWriteBit()**  
**serialport.modbusWriteBit()**

---

**YSerialPort**

Sets a single internal bit (or coil) on a MODBUS serial device.

function **modbusWriteBit**( ) As Integer

This method uses the MODBUS function code 0x05 (Write Single Coil).

**Parameters :**

- slaveNo** the address of the slave MODBUS device to drive
- pduAddr** the relative address of the bit/coil to set (zero-based)
- value** the value to set (0 for OFF state, non-zero for ON state)

**Returns :**

the number of bits/coils affected on the device (1)

On failure, throws an exception or returns zero.

**serialport**→**modbusWriteBits()**  
**serialport.modbusWriteBits()****YSerialPort**

Sets several contiguous internal bits (or coils) on a MODBUS serial device.

procedure **modbusWriteBits( )**

This method uses the MODBUS function code 0x0f (Write Multiple Coils).

**Parameters :**

- slaveNo** the address of the slave MODBUS device to drive
- pduAddr** the relative address of the first bit/coil to set (zero-based)
- bits** the vector of bits to be set (one integer per bit)

**Returns :**

the number of bits/coils affected on the device

On failure, throws an exception or returns zero.



---

**serialport**→**modbusWriteRegister()**  
**serialport.modbusWriteRegister()**

---

**YSerialPort**

Sets a single internal register (or holding register) on a MODBUS serial device.

```
function modbusWriteRegister( ) As Integer
```

This method uses the MODBUS function code 0x06 (Write Single Register).

**Parameters :**

- slaveNo** the address of the slave MODBUS device to drive
- pduAddr** the relative address of the register to set (zero-based)
- value** the 16 bit value to set

**Returns :**

the number of registers affected on the device (1)

On failure, throws an exception or returns zero.

**serialport**→**modbusWriteRegisters()**  
**serialport.modbusWriteRegisters()****YSerialPort**

Sets several contiguous internal registers (or holding registers) on a MODBUS serial device.

procedure **modbusWriteRegisters**( )

This method uses the MODBUS function code 0x10 (Write Multiple Registers).

**Parameters :**

- slaveNo** the address of the slave MODBUS device to drive
- pduAddr** the relative address of the first internal register to set (zero-based)
- values** the vector of 16 bit values to set

**Returns :**

the number of registers affected on the device

On failure, throws an exception or returns zero.

---

**serialport**→**nextSerialPort()****serialport.nextSerialPort()****YSerialPort**

---

Continues the enumeration of serial ports started using `yFirstSerialPort()`.

```
function nextSerialPort( ) As YSerialPort
```

**Returns :**

a pointer to a `YSerialPort` object, corresponding to a serial port currently online, or a `null` pointer if there are no more serial ports to enumerate.

**serialport**→**queryLine()****serialport.queryLine()****YSerialPort**

Sends a text line query to the serial port, and reads the reply, if any.

```
function queryLine( ) As String
```

This function can only be used when the serial port is configured for 'Line' protocol.

**Parameters :**

**query** the line query to send (without CR/LF)

**maxWait** the maximum number of milliseconds to wait for a reply.

**Returns :**

the next text line received after sending the text query, as a string. Additional lines can be obtained by calling `readLine` or `readMessages`.

On failure, throws an exception or returns an empty array.

---

**serialport→queryMODBUS()  
serialport.queryMODBUS()**

---

**YSerialPort**

Sends a message to a specified MODBUS slave connected to the serial port, and reads the reply, if any.

procedure **queryMODBUS( )**

The message is the PDU, provided as a vector of bytes.

**Parameters :**

- slaveNo** the address of the slave MODBUS device to query
- pduBytes** the message to send (PDU), as a vector of bytes. The first byte of the PDU is the MODBUS function code.

**Returns :**

the received reply, as a vector of bytes.

On failure, throws an exception or returns an empty array (or a MODBUS error reply).

**serialport**→**readHex()****serialport.readHex()**

**YSerialPort**

Reads data from the receive buffer as a hexadecimal string, starting at current stream position.

```
function readHex( ) As String
```

If data at current stream position is not available anymore in the receive buffer, the function performs a short read.

**Parameters :**

**nBytes** the maximum number of bytes to read

**Returns :**

a string with receive buffer contents, encoded in hexadecimal

On failure, throws an exception or returns a negative error code.

---

**serialport**→**readLine()****serialport.readLine()****YSerialPort**

---

Reads a single line (or message) from the receive buffer, starting at current stream position.

```
function readLine( ) As String
```

This function can only be used when the serial port is configured for a message protocol, such as 'Line' mode or MODBUS protocols. It does not work in plain stream modes, eg. 'Char' or 'Byte').

If data at current stream position is not available anymore in the receive buffer, the function returns the oldest available line and moves the stream position just after. If no new full line is received, the function returns an empty line.

**Returns :**

a string with a single line of text

On failure, throws an exception or returns a negative error code.

**serialport**→**readMessages()**  
**serialport.readMessages()****YSerialPort**

Searches for incoming messages in the serial port receive buffer matching a given pattern, starting at current position.

function **readMessages**( ) As List

This function can only be used when the serial port is configured for a message protocol, such as 'Line' mode or MODBUS protocols. It does not work in plain stream modes, eg. 'Char' or 'Byte', for which there is no "start" of message.

The search returns all messages matching the expression provided as argument in the buffer. If no matching message is found, the search waits for one up to the specified maximum timeout (in milliseconds).

**Parameters :**

**pattern** a limited regular expression describing the expected message format, or an empty string if all messages should be returned (no filtering). When using binary protocols, the format applies to the hexadecimal representation of the message.

**maxWait** the maximum number of milliseconds to wait for a message if none is found in the receive buffer.

**Returns :**

an array of strings containing the messages found, if any. Binary messages are converted to hexadecimal representation.

On failure, throws an exception or returns an empty array.



---

**serialport**→**readStr()****serialport.readStr()****YSerialPort**

---

Reads data from the receive buffer as a string, starting at current stream position.

```
function readStr( ) As String
```

If data at current stream position is not available anymore in the receive buffer, the function performs a short read.

**Parameters :**

**nChars** the maximum number of characters to read

**Returns :**

a string with receive buffer contents

On failure, throws an exception or returns a negative error code.

**serialport**→**read\_seek()****serialport.read\_seek()**

**YSerialPort**

---

Changes the current internal stream position to the specified value.

```
function read_seek( ) As Integer
```

This function does not affect the device, it only changes the value stored in the YSerialPort object for the next read operations.

**Parameters :**

**rxCountVal** the absolute position index (value of rxCount) for next read operations.

**Returns :**

nothing.

---

**serialport**→**registerValueCallback()**  
**serialport.registerValueCallback()**

---

**YSerialPort**

Registers the callback function that is invoked on every change of advertised value.

```
function registerValueCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

**serialport**→**reset()****serialport.reset()**

**YSerialPort**

---

Clears the serial port buffer and resets counters to zero.

```
function reset( ) As Integer
```

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**serialport**→**set\_RTS()****YSerialPort****serialport**→**setRTS()****serialport.set\_RTS()**

---

Manually sets the state of the RTS line.

function **set\_RTS( )** As Integer

This function has no effect when hardware handshake is enabled, as the RTS line is driven automatically.

**Parameters :**

**val** 1 to turn RTS on, 0 to turn RTS off

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**serialport**→**set\_logicalName()****YSerialPort****serialport**→**setLogicalName()****serialport.set\_logicalName()**

---

Changes the logical name of the serial port.

```
function set_logicalName( ByVal newval As String) As Integer
```

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the serial port.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**serialport**→**set\_protocol()****YSerialPort****serialport**→**setProtocol()****serialport.set\_protocol()**

---

Changes the type of protocol used over the serial line.

```
function set_protocol( ByVal newval As String) As Integer
```

Possible values are "Line" for ASCII messages separated by CR and/or LF, "Frame:[timeout]ms" for binary messages separated by a delay time, "Modbus-ASCII" for MODBUS messages in ASCII mode, "Modbus-RTU" for MODBUS messages in RTU mode, "Char" for a continuous ASCII stream or "Byte" for a continuous binary stream.

**Parameters :**

**newval** a string corresponding to the type of protocol used over the serial line

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**serialport**→**set\_serialMode()****YSerialPort****serialport**→**setSerialMode()****serialport.set\_serialMode()**

Changes the serial port communication parameters, with a string such as "9600,8N1".

```
function set_serialMode( ByVal newval As String) As Integer
```

The string includes the baud rate, the number of data bits, the parity, and the number of stop bits. An optional suffix can be added to enable flow control: "CtsRts" for hardware handshake, "XOnXOff" for logical flow control and "Simplex" for acquiring a shared bus using the RTS line (as used by some RS485 adapters for instance).

**Parameters :**

**newval** a string corresponding to the serial port communication parameters, with a string such as "9600,8N1"

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.



---

**serialport**→**set\_userdata()****YSerialPort****serialport**→**setUserData()****serialport.set\_userdata()**

---

Stores a user context provided as argument in the `userData` attribute of the function.

```
procedure set_userdata( ByVal data As Object)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

**serialport**→**writeArray()****serialport.writeArray()****YSerialPort**

Sends a byte sequence (provided as a list of bytes) to the serial port.

```
procedure writeArray( )
```

**Parameters :**

**byteList** a list of byte codes

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**serialport**→**writeBin()****serialport.writeBin()**

---

**YSerialPort**

Sends a binary buffer to the serial port, as is.

procedure **writeBin**( )

**Parameters :**

**buff** the binary buffer to send

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**serialport**→**writeHex()****serialport.writeHex()****YSerialPort**

Sends a byte sequence (provided as a hexadecimal string) to the serial port.

```
function writeHex( ) As Integer
```

**Parameters :**

**hexString** a string of hexadecimal byte codes

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**serialport**→**writeLine()****serialport.writeLine()****YSerialPort**

---

Sends an ASCII string to the serial port, followed by a line break (CR LF).

```
function writeLine( ) As Integer
```

**Parameters :**

**text** the text string to send

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**serialport**→**writeMODBUS()****serialport.writeMODBUS()**

**YSerialPort**

---

Sends a MODBUS message (provided as a hexadecimal string) to the serial port.

function **writeMODBUS**( ) As Integer

The message must start with the slave address. The MODBUS CRC/LRC is automatically added by the function. This function does not wait for a reply.

**Parameters :**

**hexString** a hexadecimal message string, including device address but no CRC/LRC

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**serialport**→**writeStr()****serialport.writeStr()****YSerialPort**

---

Sends an ASCII string to the serial port, as is.

```
function writeStr( ) As Integer
```

**Parameters :**

**text** the text string to send

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

## 3.41. Servo function interface

Yoctopuce application programming interface allows you not only to move a servo to a given position, but also to specify the time interval in which the move should be performed. This makes it possible to synchronize two servos involved in a same move.

In order to use the functions described here, you should include:

js	<code>&lt;script type='text/javascript' src='yocto_servo.js'&gt;&lt;/script&gt;</code>
nodejs	<code>var yoctolib = require('yoctolib');</code> <code>var YServo = yoctolib.YServo;</code>
php	<code>require_once('yocto_servo.php');</code>
c++	<code>#include "yocto_servo.h"</code>
m	<code>#import "yocto_servo.h"</code>
pas	<code>uses yocto_servo;</code>
vb	<code>yocto_servo.vb</code>
cs	<code>yocto_servo.cs</code>
java	<code>import com.yoctopuce.YoctoAPI.YServo;</code>
py	<code>from yocto_servo import *</code>

### Global functions

#### **yFindServo(func)**

Retrieves a servo for a given identifier.

#### **yFirstServo()**

Starts the enumeration of servos currently accessible.

### YServo methods

#### **servo→describe()**

Returns a short text that describes unambiguously the instance of the servo in the form `TYPE ( NAME ) =SERIAL . FUNCTIONID`.

#### **servo→get\_advertisedValue()**

Returns the current value of the servo (no more than 6 characters).

#### **servo→get\_enabled()**

Returns the state of the servos.

#### **servo→get\_enabledAtPowerOn()**

Returns the servo signal generator state at power up.

#### **servo→get\_errorMessage()**

Returns the error message of the latest error with the servo.

#### **servo→get\_errorType()**

Returns the numerical error code of the latest error with the servo.

#### **servo→get\_friendlyName()**

Returns a global identifier of the servo in the format `MODULE_NAME . FUNCTION_NAME`.

#### **servo→get\_functionDescriptor()**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

#### **servo→get\_functionId()**

Returns the hardware identifier of the servo, without reference to the module.

#### **servo→get\_hardwareId()**

Returns the unique hardware identifier of the servo in the form `SERIAL . FUNCTIONID`.

#### **servo→get\_logicalName()**

Returns the logical name of the servo.



**servo→get\_module()**

Gets the YModule object for the device on which the function is located.

**servo→get\_module\_async(callback, context)**

Gets the YModule object for the device on which the function is located (asynchronous version).

**servo→get\_neutral()**

Returns the duration in microseconds of a neutral pulse for the servo.

**servo→get\_position()**

Returns the current servo position.

**servo→get\_positionAtPowerOn()**

Returns the servo position at device power up.

**servo→get\_range()**

Returns the current range of use of the servo.

**servo→get\_userData()**

Returns the value of the userData attribute, as previously stored using method set\_userData.

**servo→isOnline()**

Checks if the servo is currently reachable, without raising any error.

**servo→isOnline\_async(callback, context)**

Checks if the servo is currently reachable, without raising any error (asynchronous version).

**servo→load(msValidity)**

Preloads the servo cache with a specified validity duration.

**servo→load\_async(msValidity, callback, context)**

Preloads the servo cache with a specified validity duration (asynchronous version).

**servo→move(target, ms\_duration)**

Performs a smooth move at constant speed toward a given position.

**servo→nextServo()**

Continues the enumeration of servos started using yFirstServo().

**servo→registerValueCallback(callback)**

Registers the callback function that is invoked on every change of advertised value.

**servo→set\_enabled(newval)**

Stops or starts the servo.

**servo→set\_enabledAtPowerOn(newval)**

Configure the servo signal generator state at power up.

**servo→set\_logicalName(newval)**

Changes the logical name of the servo.

**servo→set\_neutral(newval)**

Changes the duration of the pulse corresponding to the neutral position of the servo.

**servo→set\_position(newval)**

Changes immediately the servo driving position.

**servo→set\_positionAtPowerOn(newval)**

Configure the servo position at device power up.

**servo→set\_range(newval)**

Changes the range of use of the servo, specified in per cents.

**servo→set\_userData(data)**

Stores a user context provided as argument in the userData attribute of the function.

**servo→wait\_async(callback, context)**

### 3. Reference

---

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.

## YServo.FindServo() yFindServo()yFindServo()

YServo

Retrieves a servo for a given identifier.

```
function yFindServo( ByVal func As String) As YServo
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the servo is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YServo.isOnline()` to test if the servo is indeed online at a given time. In case of ambiguity when looking for a servo by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

### Parameters :

**func** a string that uniquely characterizes the servo

### Returns :

a `YServo` object allowing you to drive the servo.

## **YServo.FirstServo() yFirstServo()yFirstServo()**

---

**YServo**

Starts the enumeration of servos currently accessible.

```
function yFirstServo( ) As YServo
```

Use the method `YServo.NextServo()` to iterate on next servos.

**Returns :**

a pointer to a `YServo` object, corresponding to the first servo currently online, or a `null` pointer if there are none.

**servo**→**describe()****servo.describe()****YServo**

Returns a short text that describes unambiguously the instance of the servo in the form `TYPE(NAME)=SERIAL.FUNCTIONID`.

function **describe**( ) As String

More precisely, `TYPE` is the type of the function, `NAME` is the name used for the first access to the function, `SERIAL` is the serial number of the module if the module is connected or "unresolved", and `FUNCTIONID` is the hardware identifier of the function if the module is connected. For example, this method returns `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1` if the module is already connected or `Relay(BadCustomName.relay1)=unresolved` if the module has not yet been connected. This method does not trigger any USB or TCP transaction and can therefore be used in a debugger.

**Returns :**

a string that describes the servo (ex: `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1`)

**servo**→**get\_advertisedValue()**

**YServo**

**servo**→**advertisedValue()****servo.get\_advertisedValue()**

---

Returns the current value of the servo (no more than 6 characters).

function **get\_advertisedValue()** As String

**Returns :**

a string corresponding to the current value of the servo (no more than 6 characters).

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

---

**servo**→**get\_enabled()**  
**servo**→**enabled()****servo.get\_enabled()**

---

**YServo**

Returns the state of the servos.

function **get\_enabled**( ) As Integer

**Returns :**

either `Y_ENABLED_FALSE` or `Y_ENABLED_TRUE`, according to the state of the servos

On failure, throws an exception or returns `Y_ENABLED_INVALID`.

**servo**→**get\_enabledAtPowerOn()**

**YServo**

**servo**→**enabledAtPowerOn()**

**servo.get\_enabledAtPowerOn()**

---

Returns the servo signal generator state at power up.

```
function get_enabledAtPowerOn( ) As Integer
```

**Returns :**

either `Y_ENABLEDATPOWERON_FALSE` or `Y_ENABLEDATPOWERON_TRUE`, according to the servo signal generator state at power up

On failure, throws an exception or returns `Y_ENABLEDATPOWERON_INVALID`.



---

**servo**→**get\_errorMessage()****YServo****servo**→**errorMessage()****servo**.**get\_errorMessage()**

---

Returns the error message of the latest error with the servo.

```
function get_errorMessage( ) As String
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using the servo object

**servo**→**get\_errorType()**

**YServo**

**servo**→**errorType()****servo.get\_errorType()**

---

Returns the numerical error code of the latest error with the servo.

function **get\_errorType**( ) As YRETCODE

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using the servo object

---

**servo**→**get\_functionDescriptor()**  
**servo**→**functionDescriptor()**  
**servo.get\_functionDescriptor()**

---

**YServo**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

function **get\_functionDescriptor**( ) As `YFUN_DESCR`

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`.

If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

**servo**→**get\_functionId()**

**YServo**

**servo**→**functionId()****servo.get\_functionId()**

---

Returns the hardware identifier of the servo, without reference to the module.

function **get\_functionId**( ) As String

For example `relay1`

**Returns :**

a string that identifies the servo (ex: `relay1`)

On failure, throws an exception or returns `Y_FUNCTIONID_INVALID`.

---

**servo**→**get\_hardwareId()****YServo****servo**→**hardwareId()****servo.get\_hardwareId()**

---

Returns the unique hardware identifier of the servo in the form `SERIAL.FUNCTIONID`.

function **get\_hardwareId()** As String

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the servo (for example `RELAYLO1-123456.relay1`).

**Returns :**

a string that uniquely identifies the servo (ex: `RELAYLO1-123456.relay1`)

On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

**servo**→**get\_logicalName()**

**YServo**

**servo**→**logicalName()****servo.get\_logicalName()**

---

Returns the logical name of the servo.

function **get\_logicalName**( ) As String

**Returns :**

a string corresponding to the logical name of the servo.

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

---

**servo**→**get\_module()****YServo****servo**→**module()****servo.get\_module()**

---

Gets the `YModule` object for the device on which the function is located.

```
function get_module( ) As YModule
```

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

**Returns :**

an instance of `YModule`

**servo**→**get\_neutral()**

**YServo**

**servo**→**neutral()****servo.get\_neutral()**

---

Returns the duration in microseconds of a neutral pulse for the servo.

function **get\_neutral()** As Integer

**Returns :**

an integer corresponding to the duration in microseconds of a neutral pulse for the servo

On failure, throws an exception or returns `Y_NEUTRAL_INVALID`.



---

**servo**→**get\_position()****YServo****servo**→**position()****servo.get\_position()**

---

Returns the current servo position.

function **get\_position**( ) As Integer

**Returns :**

an integer corresponding to the current servo position

On failure, throws an exception or returns `Y_POSITION_INVALID`.

**servo**→**get\_positionAtPowerOn()**

**YServo**

**servo**→**positionAtPowerOn()**

**servo.get\_positionAtPowerOn()**

---

Returns the servo position at device power up.

```
function get_positionAtPowerOn( ) As Integer
```

**Returns :**

an integer corresponding to the servo position at device power up

On failure, throws an exception or returns `Y_POSITIONATPOWERON_INVALID`.

---

**servo**→**get\_range()****YServo****servo**→**range()****servo.get\_range()**

---

Returns the current range of use of the servo.

function **get\_range**( ) As Integer

**Returns :**

an integer corresponding to the current range of use of the servo

On failure, throws an exception or returns `Y_RANGE_INVALID`.

**servo**→**get\_userData()**

**YServo**

**servo**→**userData()****servo.get\_userData()**

---

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

function **get\_userData**( ) As Object

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

---

**servo→isOnline()****servo.isOnline()**

---

**YServo**

Checks if the servo is currently reachable, without raising any error.

```
function isOnline( ) As Boolean
```

If there is a cached value for the servo in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the servo.

**Returns :**

`true` if the servo can be reached, and `false` otherwise

**servo**→**load()****servo.load()****YServo**

Preloads the servo cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

**servo→move()****servo.move()**

YServo

Performs a smooth move at constant speed toward a given position.

```
function move( ByVal target As Integer,  
                ByVal ms_duration As Integer) As Integer
```

**Parameters :**

**target** new position at the end of the move  
**ms\_duration** total duration of the move, in milliseconds

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**servo**→**nextServo()****servo.nextServo()**

**YServo**

---

Continues the enumeration of servos started using `yFirstServo()`.

```
function nextServo( ) As YServo
```

**Returns :**

a pointer to a `YServo` object, corresponding to a servo currently online, or a `null` pointer if there are no more servos to enumerate.



---

**servo→registerValueCallback()**  
**servo.registerValueCallback()**

---

YServo

Registers the callback function that is invoked on every change of advertised value.

```
function registerValueCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

**servo**→**set\_enabled()**

**YServo**

**servo**→**setEnabled()****servo.set\_enabled()**

---

Stops or starts the servo.

```
function set_enabled( ByVal newval As Integer) As Integer
```

**Parameters :**

**newval** either Y\_ENABLED\_FALSE or Y\_ENABLED\_TRUE

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**servo**→**set\_enabledAtPowerOn()****YServo****servo**→**setEnabledAtPowerOn()****servo.set\_enabledAtPowerOn()**

---

Configure the servo signal generator state at power up.

```
function set_enabledAtPowerOn( ByVal newval As Integer) As Integer
```

Remember to call the matching module `saveToFlash()` method, otherwise this call will have no effect.

**Parameters :**

**newval** either `Y_ENABLEDATPOWERON_FALSE` or `Y_ENABLEDATPOWERON_TRUE`

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

**servo**→**set\_logicalName()****YServo****servo**→**setLogicalName()****servo.set\_logicalName()**

Changes the logical name of the servo.

```
function set_logicalName( ByVal newval As String) As Integer
```

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the servo.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**servo**→**set\_neutral()****YServo****servo**→**setNeutral()****servo.set\_neutral()**

---

Changes the duration of the pulse corresponding to the neutral position of the servo.

```
function set_neutral( ByVal newval As Integer) As Integer
```

The duration is specified in microseconds, and the standard value is 1500 [us]. This setting makes it possible to shift the range of use of the servo. Be aware that using a range higher than what is supported by the servo is likely to damage the servo.

**Parameters :**

**newval** an integer corresponding to the duration of the pulse corresponding to the neutral position of the servo

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**servo**→**set\_position()**

**YServo**

**servo**→**setPosition()****servo.set\_position()**

---

Changes immediately the servo driving position.

```
function set_position( ByVal newval As Integer) As Integer
```

**Parameters :**

**newval** an integer corresponding to immediately the servo driving position

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**servo**→**set\_positionAtPowerOn()**  
**servo**→**setPositionAtPowerOn()**  
**servo.set\_positionAtPowerOn()**

---

**YServo**

Configure the servo position at device power up.

```
function set_positionAtPowerOn( ByVal newval As Integer) As Integer
```

Remember to call the matching module `saveToFlash()` method, otherwise this call will have no effect.

**Parameters :**

**newval** an integer

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**servo**→**set\_range()**

**YServo**

**servo**→**setRange()****servo.set\_range()**

---

Changes the range of use of the servo, specified in per cents.

```
function set_range( ByVal newval As Integer) As Integer
```

A range of 100% corresponds to a standard control signal, that varies from 1 [ms] to 2 [ms], When using a servo that supports a double range, from 0.5 [ms] to 2.5 [ms], you can select a range of 200%. Be aware that using a range higher than what is supported by the servo is likely to damage the servo.

**Parameters :**

**newval** an integer corresponding to the range of use of the servo, specified in per cents

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.



---

**servo**→**set\_userData()****YServo****servo**→**setUserData()****servo.set\_userData()**

---

Stores a user context provided as argument in the userData attribute of the function.

procedure **set\_userData**( ByVal **data** As Object)

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

## 3.42. Temperature function interface

The Yoctopuce application programming interface allows you to read an instant measure of the sensor, as well as the minimal and maximal values observed.

In order to use the functions described here, you should include:

js	<script type='text/javascript' src='yocto_temperature.js'></script>
nodejs	var yoctolib = require('yoctolib'); var YTemperature = yoctolib.YTemperature;
php	require_once('yocto_temperature.php');
c++	#include "yocto_temperature.h"
m	#import "yocto_temperature.h"
pas	uses yocto_temperature;
vb	yocto_temperature.vb
cs	yocto_temperature.cs
java	import com.yoctopuce.YoctoAPI.YTemperature;
py	from yocto_temperature import *

### Global functions

#### yFindTemperature(func)

Retrieves a temperature sensor for a given identifier.

#### yFirstTemperature()

Starts the enumeration of temperature sensors currently accessible.

### YTemperature methods

#### temperature→calibrateFromPoints(rawValues, refValues)

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

#### temperature→describe()

Returns a short text that describes unambiguously the instance of the temperature sensor in the form `TYPE ( NAME ) = SERIAL . FUNCTIONID`.

#### temperature→get\_advertisedValue()

Returns the current value of the temperature sensor (no more than 6 characters).

#### temperature→get\_currentRawValue()

Returns the uncalibrated, unrounded raw value returned by the sensor, in Celsius, as a floating point number.

#### temperature→get\_currentValue()

Returns the current value of the temperature, in Celsius, as a floating point number.

#### temperature→get\_errorMessage()

Returns the error message of the latest error with the temperature sensor.

#### temperature→get\_errorType()

Returns the numerical error code of the latest error with the temperature sensor.

#### temperature→get\_friendlyName()

Returns a global identifier of the temperature sensor in the format `MODULE_NAME . FUNCTION_NAME`.

#### temperature→get\_functionDescriptor()

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

#### temperature→get\_functionId()

Returns the hardware identifier of the temperature sensor, without reference to the module.

#### temperature→get\_hardwareId()

Returns the unique hardware identifier of the temperature sensor in the form `SERIAL . FUNCTIONID`.

**temperature**→**get\_highestValue()**

Returns the maximal value observed for the temperature since the device was started.

**temperature**→**get\_logFrequency()**

Returns the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory.

**temperature**→**get\_logicalName()**

Returns the logical name of the temperature sensor.

**temperature**→**get\_lowestValue()**

Returns the minimal value observed for the temperature since the device was started.

**temperature**→**get\_module()**

Gets the `YModule` object for the device on which the function is located.

**temperature**→**get\_module\_async(callback, context)**

Gets the `YModule` object for the device on which the function is located (asynchronous version).

**temperature**→**get\_recordedData(startTime, endTime)**

Retrieves a `DataSet` object holding historical data for this sensor, for a specified time interval.

**temperature**→**get\_reportFrequency()**

Returns the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function.

**temperature**→**get\_resolution()**

Returns the resolution of the measured values.

**temperature**→**get\_sensorType()**

Returns the temperature sensor type.

**temperature**→**get\_unit()**

Returns the measuring unit for the temperature.

**temperature**→**get\_userData()**

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

**temperature**→**isOnline()**

Checks if the temperature sensor is currently reachable, without raising any error.

**temperature**→**isOnline\_async(callback, context)**

Checks if the temperature sensor is currently reachable, without raising any error (asynchronous version).

**temperature**→**load(msValidity)**

Preloads the temperature sensor cache with a specified validity duration.

**temperature**→**loadCalibrationPoints(rawValues, refValues)**

Retrieves error correction data points previously entered using the method `calibrateFromPoints`.

**temperature**→**load\_async(msValidity, callback, context)**

Preloads the temperature sensor cache with a specified validity duration (asynchronous version).

**temperature**→**nextTemperature()**

Continues the enumeration of temperature sensors started using `yFirstTemperature()`.

**temperature**→**registerTimedReportCallback(callback)**

Registers the callback function that is invoked on every periodic timed notification.

**temperature**→**registerValueCallback(callback)**

Registers the callback function that is invoked on every change of advertised value.

**temperature**→**set\_highestValue(newval)**

Changes the recorded maximal value observed.

**temperature**→**set\_logFrequency(newval)**

Changes the datalogger recording frequency for this function.

### 3. Reference

---

**temperature**→**set\_logicalName(newval)**

Changes the logical name of the temperature sensor.

**temperature**→**set\_lowestValue(newval)**

Changes the recorded minimal value observed.

**temperature**→**set\_reportFrequency(newval)**

Changes the timed value notification frequency for this function.

**temperature**→**set\_resolution(newval)**

Changes the resolution of the measured physical values.

**temperature**→**set\_sensorType(newval)**

Modify the temperature sensor type.

**temperature**→**set\_userData(data)**

Stores a user context provided as argument in the userData attribute of the function.

**temperature**→**wait\_async(callback, context)**

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.

## YTemperature.FindTemperature() yFindTemperature()yFindTemperature()

YTemperature

Retrieves a temperature sensor for a given identifier.

```
function yFindTemperature( ByVal func As String) As YTemperature
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the temperature sensor is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YTemperature.isOnline()` to test if the temperature sensor is indeed online at a given time. In case of ambiguity when looking for a temperature sensor by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

### Parameters :

**func** a string that uniquely characterizes the temperature sensor

### Returns :

a `YTemperature` object allowing you to drive the temperature sensor.

## **YTemperature.FirstTemperature() yFirstTemperature()yFirstTemperature()**

---

**YTemperature**

Starts the enumeration of temperature sensors currently accessible.

```
function yFirstTemperature( ) As YTemperature
```

Use the method `YTemperature.nextTemperature()` to iterate on next temperature sensors.

**Returns :**

a pointer to a `YTemperature` object, corresponding to the first temperature sensor currently online, or a `null` pointer if there are none.

---

**temperature**→**calibrateFromPoints()**  
**temperature.calibrateFromPoints()****YTemperature**

---

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

procedure **calibrateFromPoints()** ( )

It is possible to configure up to five correction points. Correction points must be provided in ascending order, and be in the range of the sensor. The device will automatically perform a linear interpolation of the error correction between specified points. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

For more information on advanced capabilities to refine the calibration of sensors, please contact [support@yoctopuce.com](mailto:support@yoctopuce.com).

**Parameters :**

**rawValues** array of floating point numbers, corresponding to the raw values returned by the sensor for the correction points.

**refValues** array of floating point numbers, corresponding to the corrected values for the correction points.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**temperature**→**describe()****temperature.describe()****YTemperature**

Returns a short text that describes unambiguously the instance of the temperature sensor in the form `TYPE (NAME) =SERIAL . FUNCTIONID`.

function **describe**( ) As String

More precisely, `TYPE` is the type of the function, `NAME` it the name used for the first access to the function, `SERIAL` is the serial number of the module if the module is connected or "unresolved", and `FUNCTIONID` is the hardware identifier of the function if the module is connected. For example, this method returns `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1` if the module is already connected or `Relay(BadCustomeName.relay1)=unresolved` if the module has not yet been connected. This method does not trigger any USB or TCP transaction and can therefore be used in a debugger.

**Returns :**

a string that describes the temperature sensor (ex:  
`Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1`)



---

**temperature**→**get\_advertisedValue()****YTemperature****temperature**→**advertisedValue()****temperature.get\_advertisedValue()**

---

Returns the current value of the temperature sensor (no more than 6 characters).

```
function get_advertisedValue( ) As String
```

**Returns :**

a string corresponding to the current value of the temperature sensor (no more than 6 characters).

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

**temperature**→**get\_currentRawValue()**

**YTemperature**

**temperature**→**currentRawValue()**

**temperature.get\_currentRawValue()**

---

Returns the uncalibrated, unrounded raw value returned by the sensor, in Celsius, as a floating point number.

```
function get_currentRawValue( ) As Double
```

**Returns :**

a floating point number corresponding to the uncalibrated, unrounded raw value returned by the sensor, in Celsius, as a floating point number

On failure, throws an exception or returns `Y_CURRENTRAWVALUE_INVALID`.

---

**temperature**→**get\_currentValue()****YTemperature****temperature**→**currentValue()****temperature.get\_currentValue()**

---

Returns the current value of the temperature, in Celsius, as a floating point number.

```
function get_currentValue( ) As Double
```

**Returns :**

a floating point number corresponding to the current value of the temperature, in Celsius, as a floating point number

On failure, throws an exception or returns `Y_CURRENTVALUE_INVALID`.

**temperature**→**get\_errorMessage()**  
**temperature**→**errorMessage()**  
**temperature.get\_errorMessage()**

---

**YTemperature**

Returns the error message of the latest error with the temperature sensor.

```
function get_errorMessage( ) As String
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using the temperature sensor object

---

**temperature**→**get\_errorType()**  
**temperature**→**errorType()**  
**temperature.get\_errorType()**

---

**YTemperature**

Returns the numerical error code of the latest error with the temperature sensor.

```
function get_errorType( ) As YRETCODE
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using the temperature sensor object

**temperature**→**get\_functionDescriptor()**

**YTemperature**

**temperature**→**functionDescriptor()**

**temperature.get\_functionDescriptor()**

---

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

`function get_functionDescriptor( )` As `YFUN_DESCR`

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`.

If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

---

**temperature**→**get\_functionId()****YTemperature****temperature**→**functionId()****temperature.get\_functionId()**

---

Returns the hardware identifier of the temperature sensor, without reference to the module.

```
function get_functionId( ) As String
```

For example `relay1`

**Returns :**

a string that identifies the temperature sensor (ex: `relay1`)

On failure, throws an exception or returns `Y_FUNCTIONID_INVALID`.

**temperature**→**get\_hardwareId()**

**YTemperature**

**temperature**→**hardwareId()**

**temperature.get\_hardwareId()**

---

Returns the unique hardware identifier of the temperature sensor in the form `SERIAL.FUNCTIONID`.

function **get\_hardwareId()** As String

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the temperature sensor (for example `RELAYLO1-123456.relay1`).

**Returns :**

a string that uniquely identifies the temperature sensor (ex: `RELAYLO1-123456.relay1`)

On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.



---

**temperature**→**get\_highestValue()****YTemperature****temperature**→**highestValue()****temperature.get\_highestValue()**

---

Returns the maximal value observed for the temperature since the device was started.

```
function get_highestValue( ) As Double
```

**Returns :**

a floating point number corresponding to the maximal value observed for the temperature since the device was started

On failure, throws an exception or returns `Y_HIGHESTVALUE_INVALID`.

**temperature**→**get\_logFrequency()**

**YTemperature**

**temperature**→**logFrequency()**

**temperature.get\_logFrequency()**

---

Returns the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory.

function **get\_logFrequency()** As String

**Returns :**

a string corresponding to the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory

On failure, throws an exception or returns `Y_LOGFREQUENCY_INVALID`.

---

**temperature**→**get\_logicalName()****YTemperature****temperature**→**logicalName()****temperature.get\_logicalName()**

---

Returns the logical name of the temperature sensor.

```
function get_logicalName( ) As String
```

**Returns :**

a string corresponding to the logical name of the temperature sensor.

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

**temperature**→**get\_lowestValue()**  
**temperature**→**lowestValue()**  
**temperature.get\_lowestValue()**

---

**YTemperature**

Returns the minimal value observed for the temperature since the device was started.

```
function get_lowestValue( ) As Double
```

**Returns :**

a floating point number corresponding to the minimal value observed for the temperature since the device was started

On failure, throws an exception or returns Y\_LOWESTVALUE\_INVALID.

---

**temperature**→**get\_module()****YTemperature****temperature**→**module()****temperature.get\_module()**

---

Gets the `YModule` object for the device on which the function is located.

function **get\_module()** As `YModule`

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

**Returns :**

an instance of `YModule`

**temperature**→**get\_recordedData()**

**YTemperature**

**temperature**→**recordedData()**

**temperature.get\_recordedData()**

---

Retrieves a DataSet object holding historical data for this sensor, for a specified time interval.

```
function get_recordedData( ) As YDataSet
```

The measures will be retrieved from the data logger, which must have been turned on at the desired time. See the documentation of the DataSet class for information on how to get an overview of the recorded data, and how to load progressively a large set of measures from the data logger.

This function only works if the device uses a recent firmware, as DataSet objects are not supported by firmwares older than version 13000.

**Parameters :**

**startTime** the start of the desired measure time interval, as a Unix timestamp, i.e. the number of seconds since January 1, 1970 UTC. The special value 0 can be used to include any measure, without initial limit.

**endTime** the end of the desired measure time interval, as a Unix timestamp, i.e. the number of seconds since January 1, 1970 UTC. The special value 0 can be used to include any measure, without ending limit.

**Returns :**

an instance of YDataSet, providing access to historical data. Past measures can be loaded progressively using methods from the YDataSet object.

---

**temperature**→**get\_reportFrequency()**

**YTemperature**

**temperature**→**reportFrequency()**

**temperature.get\_reportFrequency()**

---

Returns the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function.

```
function get_reportFrequency( ) As String
```

**Returns :**

a string corresponding to the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function

On failure, throws an exception or returns `Y_REPORTFREQUENCY_INVALID`.

**temperature**→**get\_resolution()**  
**temperature**→**resolution()**  
**temperature.get\_resolution()**

---

**YTemperature**

Returns the resolution of the measured values.

```
function get_resolution( ) As Double
```

The resolution corresponds to the numerical precision of the measures, which is not always the same as the actual precision of the sensor.

**Returns :**

a floating point number corresponding to the resolution of the measured values

On failure, throws an exception or returns Y\_RESOLUTION\_INVALID.



---

**temperature**→**get\_sensorType()****YTemperature****temperature**→**sensorType()****temperature.get\_sensorType()**

---

Returns the temperature sensor type.

```
function get_sensorType( ) As Integer
```

**Returns :**

a value among `Y_SENSORTYPE_DIGITAL`, `Y_SENSORTYPE_TYPE_K`, `Y_SENSORTYPE_TYPE_E`, `Y_SENSORTYPE_TYPE_J`, `Y_SENSORTYPE_TYPE_N`, `Y_SENSORTYPE_TYPE_R`, `Y_SENSORTYPE_TYPE_S`, `Y_SENSORTYPE_TYPE_T`, `Y_SENSORTYPE_PT100_4WIRES`, `Y_SENSORTYPE_PT100_3WIRES` and `Y_SENSORTYPE_PT100_2WIRES` corresponding to the temperature sensor type

On failure, throws an exception or returns `Y_SENSORTYPE_INVALID`.

**temperature**→**get\_unit()**

**YTemperature**

**temperature**→**unit()****temperature.get\_unit()**

---

Returns the measuring unit for the temperature.

function **get\_unit**( ) As String

**Returns :**

a string corresponding to the measuring unit for the temperature

On failure, throws an exception or returns `Y_UNIT_INVALID`.

---

**temperature**→**get\_userData()****YTemperature****temperature**→**userData()****temperature.get\_userData()**

---

Returns the value of the userData attribute, as previously stored using method `set_userData`.

```
function get_userData( ) As Object
```

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

**temperature**→**isOnline()****temperature.isOnline()**

**YTemperature**

---

Checks if the temperature sensor is currently reachable, without raising any error.

function **isOnline**( ) As Boolean

If there is a cached value for the temperature sensor in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the temperature sensor.

**Returns :**

`true` if the temperature sensor can be reached, and `false` otherwise

**temperature**→**load()****temperature.load()****YTemperature**

Preloads the temperature sensor cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

**temperature→loadCalibrationPoints()  
temperature.loadCalibrationPoints()**

**YTemperature**

Retrieves error correction data points previously entered using the method `calibrateFromPoints`.

procedure **loadCalibrationPoints**( )

**Parameters :**

**rawValues** array of floating point numbers, that will be filled by the function with the raw sensor values for the correction points.

**refValues** array of floating point numbers, that will be filled by the function with the desired values for the correction points.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**temperature**→**nextTemperature()**  
**temperature.nextTemperature()**

---

**YTemperature**

Continues the enumeration of temperature sensors started using `yFirstTemperature()`.

```
function nextTemperature( ) As YTemperature
```

**Returns :**

a pointer to a `YTemperature` object, corresponding to a temperature sensor currently online, or a `null` pointer if there are no more temperature sensors to enumerate.

**temperature**→**registerTimedReportCallback()**  
**temperature.registerTimedReportCallback()**

**YTemperature**

---

Registers the callback function that is invoked on every periodic timed notification.

```
function registerTimedReportCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and an `YMeasure` object describing the new advertised value.



---

**temperature**→**registerValueCallback()**  
**temperature.registerValueCallback()**

---

**YTemperature**

Registers the callback function that is invoked on every change of advertised value.

```
function registerValueCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

**temperature**→**set\_highestValue()**  
**temperature**→**setHighestValue()**  
**temperature.set\_highestValue()**

---

**YTemperature**

Changes the recorded maximal value observed.

```
function set_highestValue( ByVal newval As Double) As Integer
```

**Parameters :**

**newval** a floating point number corresponding to the recorded maximal value observed

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**temperature**→**set\_logFrequency()****YTemperature****temperature**→**setLogFrequency()****temperature.set\_logFrequency()**

---

Changes the datalogger recording frequency for this function.

```
function set_logFrequency( ByVal newval As String) As Integer
```

The frequency can be specified as samples per second, as sample per minute (for instance "15/m") or in samples per hour (eg. "4/h"). To disable recording for this function, use the value "OFF".

**Parameters :**

**newval** a string corresponding to the datalogger recording frequency for this function

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**temperature**→**set\_logicalName()**

**YTemperature**

**temperature**→**setLogicalName()**

**temperature.set\_logicalName()**

---

Changes the logical name of the temperature sensor.

```
function set_logicalName( ByVal newval As String) As Integer
```

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the temperature sensor.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**temperature**→**set\_lowestValue()****YTemperature****temperature**→**setLowestValue()****temperature.set\_lowestValue()**

---

Changes the recorded minimal value observed.

```
function set_lowestValue( ByVal newval As Double) As Integer
```

**Parameters :**

**newval** a floating point number corresponding to the recorded minimal value observed

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**temperature**→**set\_reportFrequency()**

**YTemperature**

**temperature**→**setReportFrequency()**

**temperature.set\_reportFrequency()**

---

Changes the timed value notification frequency for this function.

```
function set_reportFrequency( ByVal newval As String) As Integer
```

The frequency can be specified as samples per second, as sample per minute (for instance "15/m") or in samples per hour (eg. "4/h"). To disable timed value notifications for this function, use the value "OFF".

**Parameters :**

**newval** a string corresponding to the timed value notification frequency for this function

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**temperature**→**set\_resolution()**  
**temperature**→**setResolution()**  
**temperature.set\_resolution()**

**YTemperature**

---

Changes the resolution of the measured physical values.

```
function set_resolution( ByVal newval As Double) As Integer
```

The resolution corresponds to the numerical precision when displaying value. It does not change the precision of the measure itself.

**Parameters :**

**newval** a floating point number corresponding to the resolution of the measured physical values

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**temperature**→**set\_sensorType()**  
**temperature**→**setSensorType()**  
**temperature.set\_sensorType()**

**YTemperature**

Modify the temperature sensor type.

```
function set_sensorType( ByVal newval As Integer) As Integer
```

This function is used to to define the type of thermocouple (K,E...) used with the device. This will have no effect if module is using a digital sensor. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a value among `Y_SENSORTYPE_DIGITAL`, `Y_SENSORTYPE_TYPE_K`, `Y_SENSORTYPE_TYPE_E`, `Y_SENSORTYPE_TYPE_J`, `Y_SENSORTYPE_TYPE_N`, `Y_SENSORTYPE_TYPE_R`, `Y_SENSORTYPE_TYPE_S`, `Y_SENSORTYPE_TYPE_T`, `Y_SENSORTYPE_PT100_4WIRES`, `Y_SENSORTYPE_PT100_3WIRES` and `Y_SENSORTYPE_PT100_2WIRES`

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.



---

**temperature**→**set\_userData()****YTemperature****temperature**→**setUserData()****temperature.set\_userData()**

---

Stores a user context provided as argument in the `userData` attribute of the function.

```
procedure set_userData( ByVal data As Object)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

## 3.43. Tilt function interface

The Yoctopuce application programming interface allows you to read an instant measure of the sensor, as well as the minimal and maximal values observed.

In order to use the functions described here, you should include:

js	<script type='text/javascript' src='yocto_tilt.js'></script>
nodejs	var yoctolib = require('yoctolib'); var YTilt = yoctolib.YTilt;
php	require_once('yocto_tilt.php');
c++	#include "yocto_tilt.h"
m	#import "yocto_tilt.h"
pas	uses yocto_tilt;
vb	yocto_tilt.vb
cs	yocto_tilt.cs
java	import com.yoctopuce.YoctoAPI.YTilt;
py	from yocto_tilt import *

### Global functions

#### yFindTilt(func)

Retrieves a tilt sensor for a given identifier.

#### yFirstTilt()

Starts the enumeration of tilt sensors currently accessible.

### YTilt methods

#### tilt→calibrateFromPoints(rawValues, refValues)

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

#### tilt→describe()

Returns a short text that describes unambiguously the instance of the tilt sensor in the form `TYPE ( NAME ) = SERIAL . FUNCTIONID`.

#### tilt→get\_advertisedValue()

Returns the current value of the tilt sensor (no more than 6 characters).

#### tilt→get\_currentRawValue()

Returns the uncalibrated, unrounded raw value returned by the sensor, in degrees, as a floating point number.

#### tilt→get\_currentValue()

Returns the current value of the inclination, in degrees, as a floating point number.

#### tilt→get\_errorMessage()

Returns the error message of the latest error with the tilt sensor.

#### tilt→get\_errorType()

Returns the numerical error code of the latest error with the tilt sensor.

#### tilt→get\_friendlyName()

Returns a global identifier of the tilt sensor in the format `MODULE_NAME . FUNCTION_NAME`.

#### tilt→get\_functionDescriptor()

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

#### tilt→get\_functionId()

Returns the hardware identifier of the tilt sensor, without reference to the module.

#### tilt→get\_hardwareId()

Returns the unique hardware identifier of the tilt sensor in the form `SERIAL . FUNCTIONID`.

**tilt→get\_highestValue()**

Returns the maximal value observed for the inclination since the device was started.

**tilt→get\_logFrequency()**

Returns the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory.

**tilt→get\_logicalName()**

Returns the logical name of the tilt sensor.

**tilt→get\_lowestValue()**

Returns the minimal value observed for the inclination since the device was started.

**tilt→get\_module()**

Gets the `YModule` object for the device on which the function is located.

**tilt→get\_module\_async(callback, context)**

Gets the `YModule` object for the device on which the function is located (asynchronous version).

**tilt→get\_recordedData(startTime, endTime)**

Retrieves a `DataSet` object holding historical data for this sensor, for a specified time interval.

**tilt→get\_reportFrequency()**

Returns the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function.

**tilt→get\_resolution()**

Returns the resolution of the measured values.

**tilt→get\_unit()**

Returns the measuring unit for the inclination.

**tilt→get\_userData()**

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

**tilt→isOnline()**

Checks if the tilt sensor is currently reachable, without raising any error.

**tilt→isOnline\_async(callback, context)**

Checks if the tilt sensor is currently reachable, without raising any error (asynchronous version).

**tilt→load(msValidity)**

Preloads the tilt sensor cache with a specified validity duration.

**tilt→loadCalibrationPoints(rawValues, refValues)**

Retrieves error correction data points previously entered using the method `calibrateFromPoints`.

**tilt→load\_async(msValidity, callback, context)**

Preloads the tilt sensor cache with a specified validity duration (asynchronous version).

**tilt→nextTilt()**

Continues the enumeration of tilt sensors started using `yFirstTilt()`.

**tilt→registerTimedReportCallback(callback)**

Registers the callback function that is invoked on every periodic timed notification.

**tilt→registerValueCallback(callback)**

Registers the callback function that is invoked on every change of advertised value.

**tilt→set\_highestValue(newval)**

Changes the recorded maximal value observed.

**tilt→set\_logFrequency(newval)**

Changes the datalogger recording frequency for this function.

**tilt→set\_logicalName(newval)**

Changes the logical name of the tilt sensor.

### 3. Reference

---

**tilt**→**set\_lowestValue(newval)**

Changes the recorded minimal value observed.

**tilt**→**set\_reportFrequency(newval)**

Changes the timed value notification frequency for this function.

**tilt**→**set\_resolution(newval)**

Changes the resolution of the measured physical values.

**tilt**→**set\_userData(data)**

Stores a user context provided as argument in the userData attribute of the function.

**tilt**→**wait\_async(callback, context)**

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.

## YTilt.FindTilt() yFindTilt()yFindTilt()

YTilt

Retrieves a tilt sensor for a given identifier.

```
function yFindTilt( ByVal func As String) As YTilt
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the tilt sensor is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YTilt.isOnline()` to test if the tilt sensor is indeed online at a given time. In case of ambiguity when looking for a tilt sensor by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

### Parameters :

**func** a string that uniquely characterizes the tilt sensor

### Returns :

a `YTilt` object allowing you to drive the tilt sensor.

## YTilt.FirstTilt() yFirstTilt()yFirstTilt()

---

YTilt

Starts the enumeration of tilt sensors currently accessible.

```
function yFirstTilt( ) As YTilt
```

Use the method `YTilt.nextTilt()` to iterate on next tilt sensors.

**Returns :**

a pointer to a `YTilt` object, corresponding to the first tilt sensor currently online, or a `null` pointer if there are none.

**tilt→calibrateFromPoints()****tilt.calibrateFromPoints()****YTilt**

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

procedure **calibrateFromPoints()**

It is possible to configure up to five correction points. Correction points must be provided in ascending order, and be in the range of the sensor. The device will automatically perform a linear interpolation of the error correction between specified points. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

For more information on advanced capabilities to refine the calibration of sensors, please contact [support@yoctopuce.com](mailto:support@yoctopuce.com).

**Parameters :**

**rawValues** array of floating point numbers, corresponding to the raw values returned by the sensor for the correction points.

**refValues** array of floating point numbers, corresponding to the corrected values for the correction points.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**tilt**→**describe()****tilt.describe()****YTilt**

Returns a short text that describes unambiguously the instance of the tilt sensor in the form `TYPE (NAME) =SERIAL.FUNCTIONID`.

function **describe**( ) As String

More precisely, `TYPE` is the type of the function, `NAME` is the name used for the first access to the function, `SERIAL` is the serial number of the module if the module is connected or "unresolved", and `FUNCTIONID` is the hardware identifier of the function if the module is connected. For example, this method returns `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1` if the module is already connected or `Relay(BadCustomeName.relay1)=unresolved` if the module has not yet been connected. This method does not trigger any USB or TCP transaction and can therefore be used in a debugger.

**Returns :**

a string that describes the tilt sensor (ex: `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1`)



---

**tilt**→**get\_advertisedValue()****YTilt****tilt**→**advertisedValue()****tilt.get\_advertisedValue()**

---

Returns the current value of the tilt sensor (no more than 6 characters).

function **get\_advertisedValue( )** As String

**Returns :**

a string corresponding to the current value of the tilt sensor (no more than 6 characters).

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

**tilt**→**get\_currentRawValue()**

**YTilt**

**tilt**→**currentRawValue()****tilt.get\_currentRawValue()**

---

Returns the uncalibrated, unrounded raw value returned by the sensor, in degrees, as a floating point number.

```
function get_currentRawValue( ) As Double
```

**Returns :**

a floating point number corresponding to the uncalibrated, unrounded raw value returned by the sensor, in degrees, as a floating point number

On failure, throws an exception or returns Y\_CURRENTRAWVALUE\_INVALID.

---

**tilt**→**get\_currentValue()****YTilt****tilt**→**currentValue()****tilt.get\_currentValue()**

---

Returns the current value of the inclination, in degrees, as a floating point number.

function **get\_currentValue()** As Double

**Returns :**

a floating point number corresponding to the current value of the inclination, in degrees, as a floating point number

On failure, throws an exception or returns `Y_CURRENTVALUE_INVALID`.

**tilt**→**get\_errorMessage()**

**YTilt**

**tilt**→**errorMessage()****tilt.get\_errorMessage()**

---

Returns the error message of the latest error with the tilt sensor.

```
function get_errorMessage( ) As String
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using the tilt sensor object

---

**tilt**→**get\_errorType()**

YTilt

**tilt**→**errorType()****tilt.get\_errorType()**

---

Returns the numerical error code of the latest error with the tilt sensor.

```
function get_errorType( ) As YRETCODE
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using the tilt sensor object

**tilt**→**get\_functionDescriptor()**

**YTilt**

**tilt**→**functionDescriptor()****tilt.get\_functionDescriptor()**

---

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

function **get\_functionDescriptor()** As `YFUN_DESCR`

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`.

If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

---

**tilt**→**get\_functionId()****YTilt****tilt**→**functionId()****tilt.get\_functionId()**

---

Returns the hardware identifier of the tilt sensor, without reference to the module.

function **get\_functionId**( ) As String

For example `relay1`

**Returns :**

a string that identifies the tilt sensor (ex: `relay1`)

On failure, throws an exception or returns `Y_FUNCTIONID_INVALID`.

**tilt**→**get\_hardwareId()**

**YTilt**

**tilt**→**hardwareId()****tilt.get\_hardwareId()**

---

Returns the unique hardware identifier of the tilt sensor in the form `SERIAL.FUNCTIONID`.

```
function get_hardwareId( ) As String
```

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the tilt sensor (for example `RELAYLO1-123456.relay1`).

**Returns :**

a string that uniquely identifies the tilt sensor (ex: `RELAYLO1-123456.relay1`)

On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.



---

**tilt**→**get\_highestValue()****YTilt****tilt**→**highestValue()****tilt.get\_highestValue()**

---

Returns the maximal value observed for the inclination since the device was started.

```
function get_highestValue( ) As Double
```

**Returns :**

a floating point number corresponding to the maximal value observed for the inclination since the device was started

On failure, throws an exception or returns `Y_HIGHESTVALUE_INVALID`.

**tilt**→**get\_logFrequency()**

**YTilt**

**tilt**→**logFrequency()****tilt.get\_logFrequency()**

---

Returns the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory.

function **get\_logFrequency**( ) As String

**Returns :**

a string corresponding to the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory

On failure, throws an exception or returns Y\_LOGFREQUENCY\_INVALID.

---

**tilt**→**get\_logicalName()****YTilt****tilt**→**logicalName()****tilt.get\_logicalName()**

---

Returns the logical name of the tilt sensor.

```
function get_logicalName( ) As String
```

**Returns :**

a string corresponding to the logical name of the tilt sensor.

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

**tilt**→**get\_lowestValue()**

**YTilt**

**tilt**→**lowestValue()****tilt.get\_lowestValue()**

---

Returns the minimal value observed for the inclination since the device was started.

function **get\_lowestValue()** As Double

**Returns :**

a floating point number corresponding to the minimal value observed for the inclination since the device was started

On failure, throws an exception or returns `Y_LOWESTVALUE_INVALID`.

---

**tilt**→**get\_module()****YTilt****tilt**→**module()****tilt.get\_module()**

---

Gets the `YModule` object for the device on which the function is located.

```
function get_module( ) As YModule
```

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

**Returns :**

an instance of `YModule`

**tilt**→**get\_recordedData()****YTilt****tilt**→**recordedData()****tilt.get\_recordedData()**

Retrieves a DataSet object holding historical data for this sensor, for a specified time interval.

```
function get_recordedData( ) As YDataSet
```

The measures will be retrieved from the data logger, which must have been turned on at the desired time. See the documentation of the DataSet class for information on how to get an overview of the recorded data, and how to load progressively a large set of measures from the data logger.

This function only works if the device uses a recent firmware, as DataSet objects are not supported by firmwares older than version 13000.

**Parameters :**

- startTime** the start of the desired measure time interval, as a Unix timestamp, i.e. the number of seconds since January 1, 1970 UTC. The special value 0 can be used to include any measure, without initial limit.
- endTime** the end of the desired measure time interval, as a Unix timestamp, i.e. the number of seconds since January 1, 1970 UTC. The special value 0 can be used to include any measure, without ending limit.

**Returns :**

an instance of YDataSet, providing access to historical data. Past measures can be loaded progressively using methods from the YDataSet object.

---

**tilt**→**get\_reportFrequency()****YTilt****tilt**→**reportFrequency()****tilt.get\_reportFrequency()**

---

Returns the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function.

```
function get_reportFrequency( ) As String
```

**Returns :**

a string corresponding to the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function

On failure, throws an exception or returns `Y_REPORTFREQUENCY_INVALID`.

**tilt**→**get\_resolution()**

**YTilt**

**tilt**→**resolution()****tilt.get\_resolution()**

---

Returns the resolution of the measured values.

```
function get_resolution( ) As Double
```

The resolution corresponds to the numerical precision of the measures, which is not always the same as the actual precision of the sensor.

**Returns :**

a floating point number corresponding to the resolution of the measured values

On failure, throws an exception or returns `Y_RESOLUTION_INVALID`.



---

**tilt**→**get\_unit()****YTilt****tilt**→**unit()****tilt.get\_unit()**

---

Returns the measuring unit for the inclination.

function **get\_unit**( ) As String

**Returns :**

a string corresponding to the measuring unit for the inclination

On failure, throws an exception or returns `Y_UNIT_INVALID`.

**tilt**→**get\_userData()**

**YTilt**

**tilt**→**userData()****tilt.get\_userData()**

---

Returns the value of the userData attribute, as previously stored using method `set_userData`.

function **get\_userData**( ) As Object

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

**tilt→isOnline()tilt.isOnline()****YTilt**

Checks if the tilt sensor is currently reachable, without raising any error.

```
function isOnline( ) As Boolean
```

If there is a cached value for the tilt sensor in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the tilt sensor.

**Returns :**

`true` if the tilt sensor can be reached, and `false` otherwise

**tilt**→**load()****tilt.load()**

YTilt

Preloads the tilt sensor cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**tilt→loadCalibrationPoints()**  
**tilt.loadCalibrationPoints()**

---

YTilt

Retrieves error correction data points previously entered using the method `calibrateFromPoints`.

procedure **loadCalibrationPoints( )**

**Parameters :**

**rawValues** array of floating point numbers, that will be filled by the function with the raw sensor values for the correction points.

**refValues** array of floating point numbers, that will be filled by the function with the desired values for the correction points.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**tilt**→**nextTilt()**(**tilt.nextTilt()**)

**YTilt**

---

Continues the enumeration of tilt sensors started using `yFirstTilt()`.

function `nextTilt()` As `YTilt`

**Returns :**

a pointer to a `YTilt` object, corresponding to a tilt sensor currently online, or a `null` pointer if there are no more tilt sensors to enumerate.

---

**tilt**→**registerTimedReportCallback()**  
**tilt.registerTimedReportCallback()**

---

**YTilt**

Registers the callback function that is invoked on every periodic timed notification.

```
function registerTimedReportCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and an `YMeasure` object describing the new advertised value.

**tilt**→**registerValueCallback()**  
**tilt.registerValueCallback()**

YTilt

Registers the callback function that is invoked on every change of advertised value.

```
function registerValueCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.



---

**tilt**→**set\_highestValue()**

YTilt

**tilt**→**setHighestValue()****tilt.set\_highestValue()**

---

Changes the recorded maximal value observed.

```
function set_highestValue( ByVal newval As Double) As Integer
```

**Parameters :**

**newval** a floating point number corresponding to the recorded maximal value observed

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**tilt**→**set\_logFrequency()****YTilt****tilt**→**setLogFrequency()****tilt.set\_logFrequency()**

Changes the datalogger recording frequency for this function.

```
function set_logFrequency( ByVal newval As String) As Integer
```

The frequency can be specified as samples per second, as sample per minute (for instance "15/m") or in samples per hour (eg. "4/h"). To disable recording for this function, use the value "OFF".

**Parameters :**

**newval** a string corresponding to the datalogger recording frequency for this function

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**tilt**→**set\_logicalName()**

YTilt

**tilt**→**setLogicalName()****tilt.set\_logicalName()**

---

Changes the logical name of the tilt sensor.

```
function set_logicalName( ByVal newval As String) As Integer
```

You can use `yCheckLogicalName( )` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash( )` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the tilt sensor.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**tilt**→**set\_lowestValue()**

**YTilt**

**tilt**→**setLowestValue()****tilt.set\_lowestValue()**

---

Changes the recorded minimal value observed.

```
function set_lowestValue( ByVal newval As Double) As Integer
```

**Parameters :**

**newval** a floating point number corresponding to the recorded minimal value observed

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**tilt**→**set\_reportFrequency()****YTilt****tilt**→**setReportFrequency()****tilt.set\_reportFrequency()**

---

Changes the timed value notification frequency for this function.

```
function set_reportFrequency( ByVal newval As String) As Integer
```

The frequency can be specified as samples per second, as sample per minute (for instance "15/m") or in samples per hour (eg. "4/h"). To disable timed value notifications for this function, use the value "OFF".

**Parameters :**

**newval** a string corresponding to the timed value notification frequency for this function

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**tilt**→**set\_resolution()**

**YTilt**

**tilt**→**setResolution()****tilt.set\_resolution()**

---

Changes the resolution of the measured physical values.

```
function set_resolution( ByVal newval As Double) As Integer
```

The resolution corresponds to the numerical precision when displaying value. It does not change the precision of the measure itself.

**Parameters :**

**newval** a floating point number corresponding to the resolution of the measured physical values

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**tilt**→**set\_userData()**

YTilt

**tilt**→**setUserData()****tilt.set\_userData()**

---

Stores a user context provided as argument in the userData attribute of the function.

```
procedure set_userData( ByVal data As Object)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

## 3.44. Voc function interface

The Yoctopuce application programming interface allows you to read an instant measure of the sensor, as well as the minimal and maximal values observed.

In order to use the functions described here, you should include:

js	<code>&lt;script type='text/javascript' src='yocto_voc.js'&gt;&lt;/script&gt;</code>
nodejs	<code>var yoctolib = require('yoctolib'); var YVoc = yoctolib.YVoc;</code>
php	<code>require_once('yocto_voc.php');</code>
c++	<code>#include "yocto_voc.h"</code>
m	<code>#import "yocto_voc.h"</code>
pas	<code>uses yocto_voc;</code>
vb	<code>yocto_voc.vb</code>
cs	<code>yocto_voc.cs</code>
java	<code>import com.yoctopuce.YoctoAPI.YVoc;</code>
py	<code>from yocto_voc import *</code>

### Global functions

#### **yFindVoc(func)**

Retrieves a Volatile Organic Compound sensor for a given identifier.

#### **yFirstVoc()**

Starts the enumeration of Volatile Organic Compound sensors currently accessible.

### YVoc methods

#### **voc→calibrateFromPoints(rawValues, refValues)**

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

#### **voc→describe()**

Returns a short text that describes unambiguously the instance of the Volatile Organic Compound sensor in the form `TYPE ( NAME ) = SERIAL . FUNCTIONID`.

#### **voc→get\_advertisedValue()**

Returns the current value of the Volatile Organic Compound sensor (no more than 6 characters).

#### **voc→get\_currentRawValue()**

Returns the uncalibrated, unrounded raw value returned by the sensor, in ppm (vol), as a floating point number.

#### **voc→get\_currentValue()**

Returns the current value of the estimated VOC concentration, in ppm (vol), as a floating point number.

#### **voc→get\_errorMessage()**

Returns the error message of the latest error with the Volatile Organic Compound sensor.

#### **voc→get\_errorType()**

Returns the numerical error code of the latest error with the Volatile Organic Compound sensor.

#### **voc→get\_friendlyName()**

Returns a global identifier of the Volatile Organic Compound sensor in the format `MODULE_NAME . FUNCTION_NAME`.

#### **voc→get\_functionDescriptor()**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

#### **voc→get\_functionId()**

Returns the hardware identifier of the Volatile Organic Compound sensor, without reference to the module.

#### **voc→get\_hardwareId()**



Returns the unique hardware identifier of the Volatile Organic Compound sensor in the form `SERIAL.FUNCTIONID`.

**`voc`→`get_highestValue()`**

Returns the maximal value observed for the estimated VOC concentration since the device was started.

**`voc`→`get_logFrequency()`**

Returns the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory.

**`voc`→`get_logicalName()`**

Returns the logical name of the Volatile Organic Compound sensor.

**`voc`→`get_lowestValue()`**

Returns the minimal value observed for the estimated VOC concentration since the device was started.

**`voc`→`get_module()`**

Gets the `YModule` object for the device on which the function is located.

**`voc`→`get_module_async(callback, context)`**

Gets the `YModule` object for the device on which the function is located (asynchronous version).

**`voc`→`get_recordedData(startTime, endTime)`**

Retrieves a `DataSet` object holding historical data for this sensor, for a specified time interval.

**`voc`→`get_reportFrequency()`**

Returns the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function.

**`voc`→`get_resolution()`**

Returns the resolution of the measured values.

**`voc`→`get_unit()`**

Returns the measuring unit for the estimated VOC concentration.

**`voc`→`get_userData()`**

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

**`voc`→`isOnline()`**

Checks if the Volatile Organic Compound sensor is currently reachable, without raising any error.

**`voc`→`isOnline_async(callback, context)`**

Checks if the Volatile Organic Compound sensor is currently reachable, without raising any error (asynchronous version).

**`voc`→`load(msValidity)`**

Preloads the Volatile Organic Compound sensor cache with a specified validity duration.

**`voc`→`loadCalibrationPoints(rawValues, refValues)`**

Retrieves error correction data points previously entered using the method `calibrateFromPoints`.

**`voc`→`load_async(msValidity, callback, context)`**

Preloads the Volatile Organic Compound sensor cache with a specified validity duration (asynchronous version).

**`voc`→`nextVoc()`**

Continues the enumeration of Volatile Organic Compound sensors started using `yFirstVoc()`.

**`voc`→`registerTimedReportCallback(callback)`**

Registers the callback function that is invoked on every periodic timed notification.

**`voc`→`registerValueCallback(callback)`**

Registers the callback function that is invoked on every change of advertised value.

**`voc`→`set_highestValue(newval)`**

Changes the recorded maximal value observed.

### 3. Reference

---

**voc**→**set\_logFrequency(newval)**

Changes the datalogger recording frequency for this function.

**voc**→**set\_logicalName(newval)**

Changes the logical name of the Volatile Organic Compound sensor.

**voc**→**set\_lowestValue(newval)**

Changes the recorded minimal value observed.

**voc**→**set\_reportFrequency(newval)**

Changes the timed value notification frequency for this function.

**voc**→**set\_resolution(newval)**

Changes the resolution of the measured physical values.

**voc**→**set\_userData(data)**

Stores a user context provided as argument in the userData attribute of the function.

**voc**→**wait\_async(callback, context)**

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.

## YVoc.FindVoc() yFindVoc()yFindVoc()

YVoc

Retrieves a Volatile Organic Compound sensor for a given identifier.

```
function yFindVoc( ByVal func As String) As YVoc
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the Volatile Organic Compound sensor is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YVoc.IsOnline()` to test if the Volatile Organic Compound sensor is indeed online at a given time. In case of ambiguity when looking for a Volatile Organic Compound sensor by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

**Parameters :**

**func** a string that uniquely characterizes the Volatile Organic Compound sensor

**Returns :**

a YVoc object allowing you to drive the Volatile Organic Compound sensor.

## **YVoc.FirstVoc() yFirstVoc()yFirstVoc()**

---

**YVoc**

Starts the enumeration of Volatile Organic Compound sensors currently accessible.

```
function yFirstVoc( ) As YVoc
```

Use the method `YVoc.nextVoc()` to iterate on next Volatile Organic Compound sensors.

**Returns :**

a pointer to a `YVoc` object, corresponding to the first Volatile Organic Compound sensor currently online, or a `null` pointer if there are none.

**voc**→**calibrateFromPoints()****voc.calibrateFromPoints()****YVoc**

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

procedure **calibrateFromPoints()**

It is possible to configure up to five correction points. Correction points must be provided in ascending order, and be in the range of the sensor. The device will automatically perform a linear interpolation of the error correction between specified points. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

For more information on advanced capabilities to refine the calibration of sensors, please contact [support@yoctopuce.com](mailto:support@yoctopuce.com).

**Parameters :**

**rawValues** array of floating point numbers, corresponding to the raw values returned by the sensor for the correction points.

**refValues** array of floating point numbers, corresponding to the corrected values for the correction points.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**voc**→**describe()****voc.describe()**

**YVoc**

Returns a short text that describes unambiguously the instance of the Volatile Organic Compound sensor in the form `TYPE (NAME )=SERIAL . FUNCTIONID`.

function **describe**( ) As String

More precisely, `TYPE` is the type of the function, `NAME` it the name used for the first access to the function, `SERIAL` is the serial number of the module if the module is connected or "unresolved", and `FUNCTIONID` is the hardware identifier of the function if the module is connected. For example, this method returns `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1` if the module is already connected or `Relay(BadCustomeName.relay1)=unresolved` if the module has not yet been connected. This method does not trigger any USB or TCP transaction and can therefore be used in a debugger.

**Returns :**

a string that describes the Volatile Organic Compound sensor (ex:  
`Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1`)

---

**voc**→**get\_advertisedValue()****YVoc****voc**→**advertisedValue()****voc.get\_advertisedValue()**

---

Returns the current value of the Volatile Organic Compound sensor (no more than 6 characters).

function **get\_advertisedValue( )** As String

**Returns :**

a string corresponding to the current value of the Volatile Organic Compound sensor (no more than 6 characters).

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.

**voc**→**get\_currentRawValue()**

**YVoc**

**voc**→**currentRawValue()****voc.get\_currentRawValue()**

---

Returns the uncalibrated, unrounded raw value returned by the sensor, in ppm (vol), as a floating point number.

```
function get_currentRawValue( ) As Double
```

**Returns :**

a floating point number corresponding to the uncalibrated, unrounded raw value returned by the sensor, in ppm (vol), as a floating point number

On failure, throws an exception or returns Y\_CURRENTRAWVALUE\_INVALID.



---

**voc**→**get\_currentValue()****YVoc****voc**→**currentValue()****voc.get\_currentValue()**

---

Returns the current value of the estimated VOC concentration, in ppm (vol), as a floating point number.

```
function get_currentValue( ) As Double
```

**Returns :**

a floating point number corresponding to the current value of the estimated VOC concentration, in ppm (vol), as a floating point number

On failure, throws an exception or returns `Y_CURRENTVALUE_INVALID`.

**voc**→**get\_errorMessage()**

**YVoc**

**voc**→**errorMessage()****voc.get\_errorMessage()**

---

Returns the error message of the latest error with the Volatile Organic Compound sensor.

**function** **get\_errorMessage**( ) As String

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using the Volatile Organic Compound sensor object

---

**voc**→**get\_errorType()****YVoc****voc**→**errorType()****voc.get\_errorType()**

---

Returns the numerical error code of the latest error with the Volatile Organic Compound sensor.

```
function get_errorType( ) As YRETCODE
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using the Volatile Organic Compound sensor object

**voc**→**get\_functionDescriptor()**

**YVoc**

**voc**→**functionDescriptor()**

**voc.get\_functionDescriptor()**

---

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

`function get_functionDescriptor( ) As YFUN_DESCR`

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`.

If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

---

**voc**→**get\_functionId()****YVoc****voc**→**functionId()****voc.get\_functionId()**

---

Returns the hardware identifier of the Volatile Organic Compound sensor, without reference to the module.

```
function get_functionId( ) As String
```

For example `relay1`

**Returns :**

a string that identifies the Volatile Organic Compound sensor (ex: `relay1`)

On failure, throws an exception or returns `Y_FUNCTIONID_INVALID`.

**voc**→**get\_hardwareId()**

**YVoc**

**voc**→**hardwareId()****voc.get\_hardwareId()**

---

Returns the unique hardware identifier of the Volatile Organic Compound sensor in the form `SERIAL.FUNCTIONID`.

`function get_hardwareId( ) As String`

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the Volatile Organic Compound sensor (for example `RELAYLO1-123456.relay1`).

**Returns :**

a string that uniquely identifies the Volatile Organic Compound sensor (ex: `RELAYLO1-123456.relay1`)

On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

---

**voc**→**get\_highestValue()****YVoc****voc**→**highestValue()****voc.get\_highestValue()**

---

Returns the maximal value observed for the estimated VOC concentration since the device was started.

```
function get_highestValue( ) As Double
```

**Returns :**

a floating point number corresponding to the maximal value observed for the estimated VOC concentration since the device was started

On failure, throws an exception or returns `Y_HIGHESTVALUE_INVALID`.

**voc**→**get\_logFrequency()**

**YVoc**

**voc**→**logFrequency()****voc.get\_logFrequency()**

---

Returns the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory.

function **get\_logFrequency( )** As String

**Returns :**

a string corresponding to the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory

On failure, throws an exception or returns Y\_LOGFREQUENCY\_INVALID.



---

**voc**→**get\_logicalName()****YVoc****voc**→**logicalName()****voc.get\_logicalName()**

---

Returns the logical name of the Volatile Organic Compound sensor.

```
function get_logicalName( ) As String
```

**Returns :**

a string corresponding to the logical name of the Volatile Organic Compound sensor.

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

**voc**→**get\_lowestValue()**

**YVoc**

**voc**→**lowestValue()****voc.get\_lowestValue()**

---

Returns the minimal value observed for the estimated VOC concentration since the device was started.

```
function get_lowestValue( ) As Double
```

**Returns :**

a floating point number corresponding to the minimal value observed for the estimated VOC concentration since the device was started

On failure, throws an exception or returns Y\_LOWESTVALUE\_INVALID.

---

**voc**→**get\_module()****YVoc****voc**→**module()****voc.get\_module()**

---

Gets the YModule object for the device on which the function is located.

function **get\_module()** As YModule

If the function cannot be located on any module, the returned instance of YModule is not shown as on-line.

**Returns :**

an instance of YModule

**voc**→**get\_recordedData()****YVoc****voc**→**recordedData()****voc.get\_recordedData()**

Retrieves a DataSet object holding historical data for this sensor, for a specified time interval.

```
function get_recordedData( ) As YDataSet
```

The measures will be retrieved from the data logger, which must have been turned on at the desired time. See the documentation of the DataSet class for information on how to get an overview of the recorded data, and how to load progressively a large set of measures from the data logger.

This function only works if the device uses a recent firmware, as DataSet objects are not supported by firmwares older than version 13000.

**Parameters :**

- startTime** the start of the desired measure time interval, as a Unix timestamp, i.e. the number of seconds since January 1, 1970 UTC. The special value 0 can be used to include any measure, without initial limit.
- endTime** the end of the desired measure time interval, as a Unix timestamp, i.e. the number of seconds since January 1, 1970 UTC. The special value 0 can be used to include any measure, without ending limit.

**Returns :**

an instance of YDataSet, providing access to historical data. Past measures can be loaded progressively using methods from the YDataSet object.

---

**voc**→**get\_reportFrequency()****YVoc****voc**→**reportFrequency()****voc.get\_reportFrequency()**

---

Returns the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function.

```
function get_reportFrequency( ) As String
```

**Returns :**

a string corresponding to the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function

On failure, throws an exception or returns Y\_REPORTFREQUENCY\_INVALID.

**voc**→**get\_resolution()**

**YVoc**

**voc**→**resolution()****voc.get\_resolution()**

---

Returns the resolution of the measured values.

```
function get_resolution( ) As Double
```

The resolution corresponds to the numerical precision of the measures, which is not always the same as the actual precision of the sensor.

**Returns :**

a floating point number corresponding to the resolution of the measured values

On failure, throws an exception or returns `Y_RESOLUTION_INVALID`.

---

**voc**→**get\_unit()****YVoc****voc**→**unit()****voc.get\_unit()**

---

Returns the measuring unit for the estimated VOC concentration.

function **get\_unit**( ) As String

**Returns :**

a string corresponding to the measuring unit for the estimated VOC concentration

On failure, throws an exception or returns `Y_UNIT_INVALID`.

**voc**→**get\_userData()**

**YVoc**

**voc**→**userData()****voc.get\_userData()**

---

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

function `get_userData( )` As Object

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.



**voc→isOnline()voc.isOnline()****YVoc**

Checks if the Volatile Organic Compound sensor is currently reachable, without raising any error.

```
function isOnline( ) As Boolean
```

If there is a cached value for the Volatile Organic Compound sensor in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the Volatile Organic Compound sensor.

**Returns :**

`true` if the Volatile Organic Compound sensor can be reached, and `false` otherwise

**voc**→**load()****voc.load()****YVoc**

Preloads the Volatile Organic Compound sensor cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**voc→loadCalibrationPoints()**  
**voc.loadCalibrationPoints()****YVoc**

---

Retrieves error correction data points previously entered using the method `calibrateFromPoints`.

procedure **loadCalibrationPoints( )**

**Parameters :**

**rawValues** array of floating point numbers, that will be filled by the function with the raw sensor values for the correction points.

**refValues** array of floating point numbers, that will be filled by the function with the desired values for the correction points.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**voc**→**nextVoc()**(**voc.nextVoc()**)

**YVoc**

---

Continues the enumeration of Volatile Organic Compound sensors started using `yFirstVoc()`.

```
function nextVoc( ) As YVoc
```

**Returns :**

a pointer to a `YVoc` object, corresponding to a Volatile Organic Compound sensor currently online, or a `null` pointer if there are no more Volatile Organic Compound sensors to enumerate.

---

**voc**→**registerTimedReportCallback()**  
**voc.registerTimedReportCallback()**

---

**YVoc**

Registers the callback function that is invoked on every periodic timed notification.

```
function registerTimedReportCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and an `YMeasure` object describing the new advertised value.

**voc**→**registerValueCallback()**  
**voc.registerValueCallback()**

YVoc

Registers the callback function that is invoked on every change of advertised value.

```
function registerValueCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

---

**voc**→**set\_highestValue()****YVoc****voc**→**setHighestValue()****voc.set\_highestValue()**

---

Changes the recorded maximal value observed.

```
function set_highestValue( ByVal newval As Double) As Integer
```

**Parameters :**

**newval** a floating point number corresponding to the recorded maximal value observed

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**voc**→**set\_logFrequency()****YVoc****voc**→**setLogFrequency()****voc.set\_logFrequency()**

Changes the datalogger recording frequency for this function.

```
function set_logFrequency( ByVal newval As String) As Integer
```

The frequency can be specified as samples per second, as sample per minute (for instance "15/m") or in samples per hour (eg. "4/h"). To disable recording for this function, use the value "OFF".

**Parameters :**

**newval** a string corresponding to the datalogger recording frequency for this function

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.



---

**voc**→**set\_logicalName()****YVoc****voc**→**setLogicalName()****voc.set\_logicalName()**

---

Changes the logical name of the Volatile Organic Compound sensor.

```
function set_logicalName( ByVal newval As String) As Integer
```

You can use `yCheckLogicalName( )` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash( )` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the Volatile Organic Compound sensor.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**voc**→**set\_lowestValue()**

**YVoc**

**voc**→**setLowestValue()****voc.set\_lowestValue()**

---

Changes the recorded minimal value observed.

```
function set_lowestValue( ByVal newval As Double) As Integer
```

**Parameters :**

**newval** a floating point number corresponding to the recorded minimal value observed

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**voc**→**set\_reportFrequency()****YVoc****voc**→**setReportFrequency()****voc.set\_reportFrequency()**

---

Changes the timed value notification frequency for this function.

```
function set_reportFrequency( ByVal newval As String) As Integer
```

The frequency can be specified as samples per second, as sample per minute (for instance "15/m") or in samples per hour (eg. "4/h"). To disable timed value notifications for this function, use the value "OFF".

**Parameters :**

**newval** a string corresponding to the timed value notification frequency for this function

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**voc**→**set\_resolution()**

**YVoc**

**voc**→**setResolution()****voc.set\_resolution()**

---

Changes the resolution of the measured physical values.

```
function set_resolution( ByVal newval As Double) As Integer
```

The resolution corresponds to the numerical precision when displaying value. It does not change the precision of the measure itself.

**Parameters :**

**newval** a floating point number corresponding to the resolution of the measured physical values

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**voc**→**set\_userdata()****YVoc****voc**→**setUserData()****voc.set\_userdata()**

---

Stores a user context provided as argument in the `userData` attribute of the function.

```
procedure set_userdata( ByVal data As Object)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

## 3.45. Voltage function interface

The Yoctopuce application programming interface allows you to read an instant measure of the sensor, as well as the minimal and maximal values observed.

In order to use the functions described here, you should include:

js	<script type='text/javascript' src='yocto_voltage.js'></script>
nodejs	var yoctolib = require('yoctolib'); var YVoltage = yoctolib.YVoltage;
php	require_once('yocto_voltage.php');
c++	#include "yocto_voltage.h"
m	#import "yocto_voltage.h"
pas	uses yocto_voltage;
vb	yocto_voltage.vb
cs	yocto_voltage.cs
java	import com.yoctopuce.YoctoAPI.YVoltage;
py	from yocto_voltage import *

### Global functions

#### yFindVoltage(func)

Retrieves a voltage sensor for a given identifier.

#### yFirstVoltage()

Starts the enumeration of voltage sensors currently accessible.

### YVoltage methods

#### voltage→calibrateFromPoints(rawValues, refValues)

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

#### voltage→describe()

Returns a short text that describes unambiguously the instance of the voltage sensor in the form `TYPE ( NAME ) = SERIAL . FUNCTIONID`.

#### voltage→get\_advertisedValue()

Returns the current value of the voltage sensor (no more than 6 characters).

#### voltage→get\_currentRawValue()

Returns the uncalibrated, unrounded raw value returned by the sensor, in Volt, as a floating point number.

#### voltage→get\_currentValue()

Returns the current value of the voltage, in Volt, as a floating point number.

#### voltage→get\_errorMessage()

Returns the error message of the latest error with the voltage sensor.

#### voltage→get\_errorType()

Returns the numerical error code of the latest error with the voltage sensor.

#### voltage→get\_friendlyName()

Returns a global identifier of the voltage sensor in the format `MODULE_NAME . FUNCTION_NAME`.

#### voltage→get\_functionDescriptor()

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

#### voltage→get\_functionId()

Returns the hardware identifier of the voltage sensor, without reference to the module.

#### voltage→get\_hardwareId()

Returns the unique hardware identifier of the voltage sensor in the form `SERIAL . FUNCTIONID`.

**voltage**→**get\_highestValue()**

Returns the maximal value observed for the voltage since the device was started.

**voltage**→**get\_logFrequency()**

Returns the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory.

**voltage**→**get\_logicalName()**

Returns the logical name of the voltage sensor.

**voltage**→**get\_lowestValue()**

Returns the minimal value observed for the voltage since the device was started.

**voltage**→**get\_module()**

Gets the `YModule` object for the device on which the function is located.

**voltage**→**get\_module\_async(callback, context)**

Gets the `YModule` object for the device on which the function is located (asynchronous version).

**voltage**→**get\_recordedData(startTime, endTime)**

Retrieves a `DataSet` object holding historical data for this sensor, for a specified time interval.

**voltage**→**get\_reportFrequency()**

Returns the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function.

**voltage**→**get\_resolution()**

Returns the resolution of the measured values.

**voltage**→**get\_unit()**

Returns the measuring unit for the voltage.

**voltage**→**get\_userData()**

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

**voltage**→**isOnline()**

Checks if the voltage sensor is currently reachable, without raising any error.

**voltage**→**isOnline\_async(callback, context)**

Checks if the voltage sensor is currently reachable, without raising any error (asynchronous version).

**voltage**→**load(msValidity)**

Preloads the voltage sensor cache with a specified validity duration.

**voltage**→**loadCalibrationPoints(rawValues, refValues)**

Retrieves error correction data points previously entered using the method `calibrateFromPoints`.

**voltage**→**load\_async(msValidity, callback, context)**

Preloads the voltage sensor cache with a specified validity duration (asynchronous version).

**voltage**→**nextVoltage()**

Continues the enumeration of voltage sensors started using `yFirstVoltage()`.

**voltage**→**registerTimedReportCallback(callback)**

Registers the callback function that is invoked on every periodic timed notification.

**voltage**→**registerValueCallback(callback)**

Registers the callback function that is invoked on every change of advertised value.

**voltage**→**set\_highestValue(newval)**

Changes the recorded maximal value observed.

**voltage**→**set\_logFrequency(newval)**

Changes the datalogger recording frequency for this function.

**voltage**→**set\_logicalName(newval)**

Changes the logical name of the voltage sensor.

### 3. Reference

---

**voltage**→**set\_lowestValue(newval)**

Changes the recorded minimal value observed.

**voltage**→**set\_reportFrequency(newval)**

Changes the timed value notification frequency for this function.

**voltage**→**set\_resolution(newval)**

Changes the resolution of the measured physical values.

**voltage**→**set\_userData(data)**

Stores a user context provided as argument in the userData attribute of the function.

**voltage**→**wait\_async(callback, context)**

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.



## YVoltage.FindVoltage() yFindVoltage()yFindVoltage()

YVoltage

Retrieves a voltage sensor for a given identifier.

```
function yFindVoltage( ByVal func As String) As YVoltage
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the voltage sensor is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YVoltage.IsOnline()` to test if the voltage sensor is indeed online at a given time. In case of ambiguity when looking for a voltage sensor by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

**Parameters :**

**func** a string that uniquely characterizes the voltage sensor

**Returns :**

a `YVoltage` object allowing you to drive the voltage sensor.

## **YVoltage.FirstVoltage() yFirstVoltage()yFirstVoltage()**

---

**YVoltage**

Starts the enumeration of voltage sensors currently accessible.

```
function yFirstVoltage( ) As YVoltage
```

Use the method `YVoltage.nextVoltage()` to iterate on next voltage sensors.

**Returns :**

a pointer to a `YVoltage` object, corresponding to the first voltage sensor currently online, or a `null` pointer if there are none.

---

**voltage**→**calibrateFromPoints()**  
**voltage.calibrateFromPoints()**

---

**YVoltage**

Configures error correction data points, in particular to compensate for a possible perturbation of the measure caused by an enclosure.

**procedure calibrateFromPoints( )**

It is possible to configure up to five correction points. Correction points must be provided in ascending order, and be in the range of the sensor. The device will automatically perform a linear interpolation of the error correction between specified points. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

For more information on advanced capabilities to refine the calibration of sensors, please contact [support@yoctopuce.com](mailto:support@yoctopuce.com).

**Parameters :**

**rawValues** array of floating point numbers, corresponding to the raw values returned by the sensor for the correction points.

**refValues** array of floating point numbers, corresponding to the corrected values for the correction points.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**voltage→describe()****voltage.describe()****YVoltage**

Returns a short text that describes unambiguously the instance of the voltage sensor in the form `TYPE (NAME) =SERIAL . FUNCTIONID`.

function **describe**( ) As String

More precisely, `TYPE` is the type of the function, `NAME` it the name used for the first access to the function, `SERIAL` is the serial number of the module if the module is connected or "unresolved", and `FUNCTIONID` is the hardware identifier of the function if the module is connected. For example, this method returns `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1` if the module is already connected or `Relay(BadCustomeName.relay1)=unresolved` if the module has not yet been connected. This method does not trigger any USB or TCP transaction and can therefore be used in a debugger.

**Returns :**

a string that describes the voltage sensor (ex: `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1`)

---

**voltage**→**get\_advertisedValue()****YVoltage****voltage**→**advertisedValue()****voltage.get\_advertisedValue()**

---

Returns the current value of the voltage sensor (no more than 6 characters).

```
function get_advertisedValue( ) As String
```

**Returns :**

a string corresponding to the current value of the voltage sensor (no more than 6 characters).

On failure, throws an exception or returns Y\_ADVERTISEDVALUE\_INVALID.

**voltage**→**get\_currentRawValue()**

**YVoltage**

**voltage**→**currentRawValue()**

**voltage.get\_currentRawValue()**

---

Returns the uncalibrated, unrounded raw value returned by the sensor, in Volt, as a floating point number.

```
function get_currentRawValue( ) As Double
```

**Returns :**

a floating point number corresponding to the uncalibrated, unrounded raw value returned by the sensor, in Volt, as a floating point number

On failure, throws an exception or returns `Y_CURRENTRAWVALUE_INVALID`.

---

**voltage**→**get\_currentValue()****YVoltage****voltage**→**currentValue()****voltage.get\_currentValue()**

---

Returns the current value of the voltage, in Volt, as a floating point number.

function **get\_currentValue()** As Double

**Returns :**

a floating point number corresponding to the current value of the voltage, in Volt, as a floating point number

On failure, throws an exception or returns `Y_CURRENTVALUE_INVALID`.

**voltage**→**get\_errorMessage()**

**YVoltage**

**voltage**→**errorMessage()****voltage**.**get\_errorMessage()**

---

Returns the error message of the latest error with the voltage sensor.

```
function get_errorMessage( ) As String
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using the voltage sensor object



---

**voltage**→**get\_errorType()****YVoltage****voltage**→**errorType()****voltage.get\_errorType()**

---

Returns the numerical error code of the latest error with the voltage sensor.

```
function get_errorType( ) As YRETCODE
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using the voltage sensor object

**voltage**→**get\_functionDescriptor()**

**YVoltage**

**voltage**→**functionDescriptor()**

**voltage.get\_functionDescriptor()**

---

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

`function get_functionDescriptor( ) As YFUN_DESCR`

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`.

If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

---

**voltage**→**get\_functionId()****YVoltage****voltage**→**functionId()****voltage.get\_functionId()**

---

Returns the hardware identifier of the voltage sensor, without reference to the module.

function **get\_functionId()** As String

For example `relay1`

**Returns :**

a string that identifies the voltage sensor (ex: `relay1`)

On failure, throws an exception or returns `Y_FUNCTIONID_INVALID`.

**voltage**→**get\_hardwareId()**

**YVoltage**

**voltage**→**hardwareId()****voltage.get\_hardwareId()**

---

Returns the unique hardware identifier of the voltage sensor in the form `SERIAL.FUNCTIONID`.

function **get\_hardwareId()** As String

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the voltage sensor (for example `RELAYLO1-123456.relay1`).

**Returns :**

a string that uniquely identifies the voltage sensor (ex: `RELAYLO1-123456.relay1`)

On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

---

**voltage**→**get\_highestValue()****YVoltage****voltage**→**highestValue()****voltage.get\_highestValue()**

---

Returns the maximal value observed for the voltage since the device was started.

function **get\_highestValue()** As Double

**Returns :**

a floating point number corresponding to the maximal value observed for the voltage since the device was started

On failure, throws an exception or returns Y\_HIGHESTVALUE\_INVALID.

**voltage**→**get\_logFrequency()**

**YVoltage**

**voltage**→**logFrequency()****voltage.get\_logFrequency()**

---

Returns the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory.

function **get\_logFrequency()** As String

**Returns :**

a string corresponding to the datalogger recording frequency for this function, or "OFF" when measures are not stored in the data logger flash memory

On failure, throws an exception or returns Y\_LOGFREQUENCY\_INVALID.

---

**voltage**→**get\_logicalName()****YVoltage****voltage**→**logicalName()****voltage.get\_logicalName()**

---

Returns the logical name of the voltage sensor.

```
function get_logicalName( ) As String
```

**Returns :**

a string corresponding to the logical name of the voltage sensor.

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

**voltage**→**get\_lowestValue()**

**YVoltage**

**voltage**→**lowestValue()****voltage.get\_lowestValue()**

---

Returns the minimal value observed for the voltage since the device was started.

function **get\_lowestValue()** As Double

**Returns :**

a floating point number corresponding to the minimal value observed for the voltage since the device was started

On failure, throws an exception or returns `Y_LOWESTVALUE_INVALID`.



---

**voltage**→**get\_module()****YVoltage****voltage**→**module()****voltage.get\_module()**

---

Gets the YModule object for the device on which the function is located.

function **get\_module()** As YModule

If the function cannot be located on any module, the returned instance of YModule is not shown as on-line.

**Returns :**

an instance of YModule

**voltage**→**get\_recordedData()**

**YVoltage**

**voltage**→**recordedData()****voltage.get\_recordedData()**

---

Retrieves a DataSet object holding historical data for this sensor, for a specified time interval.

```
function get_recordedData( ) As YDataSet
```

The measures will be retrieved from the data logger, which must have been turned on at the desired time. See the documentation of the DataSet class for information on how to get an overview of the recorded data, and how to load progressively a large set of measures from the data logger.

This function only works if the device uses a recent firmware, as DataSet objects are not supported by firmwares older than version 13000.

**Parameters :**

- startTime** the start of the desired measure time interval, as a Unix timestamp, i.e. the number of seconds since January 1, 1970 UTC. The special value 0 can be used to include any meaasure, without initial limit.
- endTime** the end of the desired measure time interval, as a Unix timestamp, i.e. the number of seconds since January 1, 1970 UTC. The special value 0 can be used to include any meaasure, without ending limit.

**Returns :**

an instance of YDataSet, providing access to historical data. Past measures can be loaded progressively using methods from the YDataSet object.

---

**voltage**→**get\_reportFrequency()****YVoltage****voltage**→**reportFrequency()****voltage.get\_reportFrequency()**

---

Returns the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function.

```
function get_reportFrequency( ) As String
```

**Returns :**

a string corresponding to the timed value notification frequency, or "OFF" if timed value notifications are disabled for this function

On failure, throws an exception or returns `Y_REPORTFREQUENCY_INVALID`.

**voltage**→**get\_resolution()**

**YVoltage**

**voltage**→**resolution()****voltage.get\_resolution()**

---

Returns the resolution of the measured values.

```
function get_resolution( ) As Double
```

The resolution corresponds to the numerical precision of the measures, which is not always the same as the actual precision of the sensor.

**Returns :**

a floating point number corresponding to the resolution of the measured values

On failure, throws an exception or returns `Y_RESOLUTION_INVALID`.

---

**voltage**→**get\_unit()****YVoltage****voltage**→**unit()****voltage.get\_unit()**

---

Returns the measuring unit for the voltage.

function **get\_unit()** As String

**Returns :**

a string corresponding to the measuring unit for the voltage

On failure, throws an exception or returns `Y_UNIT_INVALID`.

**voltage**→**get\_userData()**

**YVoltage**

**voltage**→**userData()****voltage.get\_userData()**

---

Returns the value of the userData attribute, as previously stored using method `set_userData`.

function **get\_userData**( ) As Object

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

---

**voltage**→**isOnline()****voltage.isOnline()****YVoltage**

---

Checks if the voltage sensor is currently reachable, without raising any error.

```
function isOnline( ) As Boolean
```

If there is a cached value for the voltage sensor in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the voltage sensor.

**Returns :**

`true` if the voltage sensor can be reached, and `false` otherwise

**voltage**→**load()****voltage.load()****YVoltage**

Preloads the voltage sensor cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.



---

**voltage→loadCalibrationPoints()**  
**voltage.loadCalibrationPoints()****YVoltage**

---

Retrieves error correction data points previously entered using the method `calibrateFromPoints`.

procedure **loadCalibrationPoints( )**

**Parameters :**

**rawValues** array of floating point numbers, that will be filled by the function with the raw sensor values for the correction points.

**refValues** array of floating point numbers, that will be filled by the function with the desired values for the correction points.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**voltage**→**nextVoltage()****voltage.nextVoltage()**

**YVoltage**

---

Continues the enumeration of voltage sensors started using `yFirstVoltage()`.

function **nextVoltage()** As YVoltage

**Returns :**

a pointer to a YVoltage object, corresponding to a voltage sensor currently online, or a null pointer if there are no more voltage sensors to enumerate.

---

**voltage**→**registerTimedReportCallback()**  
**voltage.registerTimedReportCallback()**

---

**YVoltage**

Registers the callback function that is invoked on every periodic timed notification.

```
function registerTimedReportCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and an `YMeasure` object describing the new advertised value.

**voltage→registerValueCallback()**  
**voltage.registerValueCallback()****YVoltage**

Registers the callback function that is invoked on every change of advertised value.

```
function registerValueCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

---

**voltage**→**set\_highestValue()****YVoltage****voltage**→**setHighestValue()****voltage.set\_highestValue()**

---

Changes the recorded maximal value observed.

```
function set_highestValue( ByVal newval As Double) As Integer
```

**Parameters :**

**newval** a floating point number corresponding to the recorded maximal value observed

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**voltage**→**set\_logFrequency()**

**YVoltage**

**voltage**→**setLogFrequency()**

**voltage.set\_logFrequency()**

---

Changes the datalogger recording frequency for this function.

```
function set_logFrequency( ByVal newval As String) As Integer
```

The frequency can be specified as samples per second, as sample per minute (for instance "15/m") or in samples per hour (eg. "4/h"). To disable recording for this function, use the value "OFF".

**Parameters :**

**newval** a string corresponding to the datalogger recording frequency for this function

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**voltage**→**set\_logicalName()****YVoltage****voltage**→**setLogicalName(voltage.set\_logicalName())**

---

Changes the logical name of the voltage sensor.

```
function set_logicalName( ByVal newval As String) As Integer
```

You can use `yCheckLogicalName( )` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash( )` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the voltage sensor.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**voltage**→**set\_lowestValue()**

**YVoltage**

**voltage**→**setLowestValue()****voltage.set\_lowestValue()**

---

Changes the recorded minimal value observed.

```
function set_lowestValue( ByVal newval As Double) As Integer
```

**Parameters :**

**newval** a floating point number corresponding to the recorded minimal value observed

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.



---

**voltage**→**set\_reportFrequency()****YVoltage****voltage**→**setReportFrequency()****voltage.set\_reportFrequency()**

---

Changes the timed value notification frequency for this function.

```
function set_reportFrequency( ByVal newval As String) As Integer
```

The frequency can be specified as samples per second, as sample per minute (for instance "15/m") or in samples per hour (eg. "4/h"). To disable timed value notifications for this function, use the value "OFF".

**Parameters :**

**newval** a string corresponding to the timed value notification frequency for this function

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**voltage**→**set\_resolution()**

**YVoltage**

**voltage**→**setResolution()****voltage.set\_resolution()**

---

Changes the resolution of the measured physical values.

```
function set_resolution( ByVal newval As Double) As Integer
```

The resolution corresponds to the numerical precision when displaying value. It does not change the precision of the measure itself.

**Parameters :**

**newval** a floating point number corresponding to the resolution of the measured physical values

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**voltage**→**set\_userdata()****YVoltage****voltage**→**setUserData()****voltage.set\_userdata()**

---

Stores a user context provided as argument in the `userData` attribute of the function.

```
procedure set_userdata( ByVal data As Object)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

## 3.46. Voltage source function interface

Yoctopuce application programming interface allows you to control the module voltage output. You affect absolute output values or make transitions

In order to use the functions described here, you should include:

js	<script type='text/javascript' src='yocto_vsource.js'></script>
php	require_once('yocto_vsource.php');
cpp	#include "yocto_vsource.h"
m	#import "yocto_vsource.h"
pas	uses yocto_vsource;
vb	yocto_vsource.vb
cs	yocto_vsource.cs
java	import com.yoctopuce.YoctoAPI.YVSource;
py	from yocto_vsource import *

Global functions	
<b>yFindVSource(func)</b>	Retrieves a voltage source for a given identifier.
<b>yFirstVSource()</b>	Starts the enumeration of voltage sources currently accessible.
YVSource methods	
<b>vsource→describe()</b>	Returns a short text that describes the function in the form TYPE ( NAME ) =SERIAL . FUNCTIONID.
<b>vsource→get_advertisedValue()</b>	Returns the current value of the voltage source (no more than 6 characters).
<b>vsource→get_errorMessage()</b>	Returns the error message of the latest error with this function.
<b>vsource→get_errorType()</b>	Returns the numerical error code of the latest error with this function.
<b>vsource→get_extPowerFailure()</b>	Returns true if external power supply voltage is too low.
<b>vsource→get_failure()</b>	Returns true if the module is in failure mode.
<b>vsource→get_friendlyName()</b>	Returns a global identifier of the function in the format MODULE_NAME . FUNCTION_NAME.
<b>vsource→get_functionDescriptor()</b>	Returns a unique identifier of type YFUN_DESCR corresponding to the function.
<b>vsource→get_functionId()</b>	Returns the hardware identifier of the function, without reference to the module.
<b>vsource→get_hardwareId()</b>	Returns the unique hardware identifier of the function in the form SERIAL . FUNCTIONID.
<b>vsource→get_logicalName()</b>	Returns the logical name of the voltage source.
<b>vsource→get_module()</b>	Gets the YModule object for the device on which the function is located.
<b>vsource→get_module_async(callback, context)</b>	

Gets the `YModule` object for the device on which the function is located (asynchronous version).

**`vsource`→`get_overCurrent()`**

Returns true if the appliance connected to the device is too greedy .

**`vsource`→`get_overHeat()`**

Returns TRUE if the module is overheating.

**`vsource`→`get_overLoad()`**

Returns true if the device is not able to maintain the requested voltage output .

**`vsource`→`get_regulationFailure()`**

Returns true if the voltage output is too high regarding the requested voltage .

**`vsource`→`get_unit()`**

Returns the measuring unit for the voltage.

**`vsource`→`get_userData()`**

Returns the value of the `userData` attribute, as previously stored using method `set_userData`.

**`vsource`→`get_voltage()`**

Returns the voltage output command (mV)

**`vsource`→`isOnline()`**

Checks if the function is currently reachable, without raising any error.

**`vsource`→`isOnline_async(callback, context)`**

Checks if the function is currently reachable, without raising any error (asynchronous version).

**`vsource`→`load(msValidity)`**

Preloads the function cache with a specified validity duration.

**`vsource`→`load_async(msValidity, callback, context)`**

Preloads the function cache with a specified validity duration (asynchronous version).

**`vsource`→`nextVSource()`**

Continues the enumeration of voltage sources started using `yFirstVSource()` .

**`vsource`→`pulse(voltage, ms_duration)`**

Sets device output to a specific volatage, for a specified duration, then brings it automatically to 0V.

**`vsource`→`registerValueCallback(callback)`**

Registers the callback function that is invoked on every change of advertised value.

**`vsource`→`set_logicalName(newval)`**

Changes the logical name of the voltage source.

**`vsource`→`set_userData(data)`**

Stores a user context provided as argument in the `userData` attribute of the function.

**`vsource`→`set_voltage(newval)`**

Tunes the device output voltage (milliVolts).

**`vsource`→`voltageMove(target, ms_duration)`**

Performs a smooth move at constant speed toward a given value.

**`vsource`→`wait_async(callback, context)`**

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.

## yFindVSource() — YVSource.FindVSource()yFindVSource()

Retrieves a voltage source for a given identifier.

```
function yFindVSource( ByVal func As String) As YVSource
```

## yFindVSource() — YVSource.FindVSource()yFindVSource()

Retrieves a voltage source for a given identifier.

js	function yFindVSource( func)
php	function yFindVSource( \$func)
cpp	YVSource* yFindVSource( const string& func)
m	YVSource* yFindVSource( NSString* func)
pas	function yFindVSource( func: string): TYVSource
vb	function yFindVSource( ByVal func As String) As YVSource
cs	YVSource FindVSource( string func)
java	YVSource FindVSource( String func)
py	def FindVSource( func)

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the voltage source is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YVSource.IsOnline()` to test if the voltage source is indeed online at a given time. In case of ambiguity when looking for a voltage source by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

### Parameters :

**func** a string that uniquely characterizes the voltage source

### Returns :

a `YVSource` object allowing you to drive the voltage source.

## **yFirstVSource() — YVSource.FirstVSource(yFirstVSource())**

YVSource

Starts the enumeration of voltage sources currently accessible.

```
function yFirstVSource( ) As YVSource
```

## **yFirstVSource() — YVSource.FirstVSource(yFirstVSource())**

Starts the enumeration of voltage sources currently accessible.

<code>js</code>	<code>function <b>yFirstVSource</b>( )</code>
<code>php</code>	<code>function <b>yFirstVSource</b>( )</code>
<code>cpp</code>	<code>YVSource* <b>yFirstVSource</b>( )</code>
<code>m</code>	<code>YVSource* <b>yFirstVSource</b>( )</code>
<code>pas</code>	<code>function <b>yFirstVSource</b>( ): TYVSource</code>
<code>vb</code>	<code>function <b>yFirstVSource</b>( ) As YVSource</code>
<code>cs</code>	<code>YVSource <b>FirstVSource</b>( )</code>
<code>java</code>	<code>YVSource <b>FirstVSource</b>( )</code>
<code>py</code>	<code>def <b>FirstVSource</b>( )</code>

Use the method `YVSource.nextVSource( )` to iterate on next voltage sources.

### **Returns :**

a pointer to a `YVSource` object, corresponding to the first voltage source currently online, or a `null` pointer if there are none.

**vsource**→**describe()**vsource.describe()

**YVSource**

Returns a short text that describes the function in the form `TYPE (NAME) =SERIAL . FUNCTIONID`.

function **describe**( ) As String

**vsource**→**describe()**vsource.describe()

Returns a short text that describes the function in the form `TYPE (NAME) =SERIAL . FUNCTIONID`.

- `js` function **describe**( )
- `php` function **describe**( )
- `cpp` string **describe**( )
- `m` `-(NSString*) describe`
- `pas` function **describe**( ): string
- `vb` function **describe**( ) As String
- `cs` string **describe**( )
- `java` String **describe**( )

More precisely, `TYPE` is the type of the function, `NAME` it the name used for the first access to the function, `SERIAL` is the serial number of the module if the module is connected or "unresolved", and `FUNCTIONID` is the hardware identifier of the function if the module is connected. For example, this method returns `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1` if the module is already connected or `Relay(BadCustomeName.relay1)=unresolved` if the module has not yet been connected. This method does not trigger any USB or TCP transaction and can therefore be used in a debugger.

**Returns :**

a string that describes the function (ex: `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1`)



**vsource**→**get\_advertisedValue()****YVSource****vsource**→**advertisedValue()****vsource.get\_advertisedValue()**


---

Returns the current value of the voltage source (no more than 6 characters).

function **get\_advertisedValue()** As String

**vsource**→**get\_advertisedValue()****vsource**→**advertisedValue()****vsource.get\_advertisedValue()**


---

Returns the current value of the voltage source (no more than 6 characters).

`js` function **get\_advertisedValue()**

`php` function **get\_advertisedValue()**

`cpp` string **get\_advertisedValue()**

`m` -(NSString\*) advertisedValue

`pas` function **get\_advertisedValue()**: string

`vb` function **get\_advertisedValue()** As String

`cs` string **get\_advertisedValue()**

`java` String **get\_advertisedValue()**

`py` def **get\_advertisedValue()**

`cmd` YVSource **target get\_advertisedValue**

**Returns :**

a string corresponding to the current value of the voltage source (no more than 6 characters)

On failure, throws an exception or returns Y\_ADVERTISEDVALUE\_INVALID.

**vsource**→**get\_errorMessage()****YVSource****vsource**→**errorMessage()****vsource.get\_errorMessage()**

---

Returns the error message of the latest error with this function.

```
function get_errorMessage( ) As String
```

**vsource**→**get\_errorMessage()****vsource**→**errorMessage()****vsource.get\_errorMessage()**

---

Returns the error message of the latest error with this function.

```
js function get_errorMessage( )
```

```
php function get_errorMessage( )
```

```
cpp string get_errorMessage( )
```

```
m -(NSString*) errorMessage
```

```
pas function get_errorMessage( ): string
```

```
vb function get_errorMessage( ) As String
```

```
cs string get_errorMessage( )
```

```
java String get_errorMessage( )
```

```
py def get_errorMessage( )
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using this function object

---

**vsource**→**get\_errorType()****YVSource****vsource**→**errorType()****vsource.get\_errorType()**

---

Returns the numerical error code of the latest error with this function.

```
function get_errorType( ) As YRETCODE
```

**vsource**→**get\_errorType()****vsource**→**errorType()****vsource.get\_errorType()**

---

Returns the numerical error code of the latest error with this function.

```
js function get_errorType( )  
php function get_errorType( )  
cpp YRETCODE get_errorType( )  
pas function get_errorType( ): YRETCODE  
vb function get_errorType( ) As YRETCODE  
cs YRETCODE get_errorType( )  
java int get_errorType( )  
py def get_errorType( )
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using this function object

---

**vsource**→**get\_extPowerFailure()**

YVSource

**vsource**→**extPowerFailure()****vsource.get\_extPowerFailure()**

---

Returns true if external power supply voltage is too low.

```
function get_extPowerFailure( ) As Integer
```

**vsource**→**get\_extPowerFailure()****vsource**→**extPowerFailure()****vsource.get\_extPowerFailure()**

---

Returns true if external power supply voltage is too low.

js	function <b>get_extPowerFailure</b> ( )
php	function <b>get_extPowerFailure</b> ( )
cpp	Y_EXTPOWERFAILURE_enum <b>get_extPowerFailure</b> ( )
m	-(Y_EXTPOWERFAILURE_enum) extPowerFailure
pas	function <b>get_extPowerFailure</b> ( ): Integer
vb	function <b>get_extPowerFailure</b> ( ) As Integer
cs	int <b>get_extPowerFailure</b> ( )
java	int <b>get_extPowerFailure</b> ( )
py	def <b>get_extPowerFailure</b> ( )
cmd	YVSource <b>target</b> <b>get_extPowerFailure</b>

**Returns :**

either Y\_EXTPOWERFAILURE\_FALSE or Y\_EXTPOWERFAILURE\_TRUE, according to true if external power supply voltage is too low

On failure, throws an exception or returns Y\_EXTPOWERFAILURE\_INVALID.

**vsource**→**get\_failure()****YVSource****vsource**→**failure()****vsource.get\_failure()**

Returns true if the module is in failure mode.

function **get\_failure()** As Integer**vsource**→**get\_failure()****vsource**→**failure()****vsource.get\_failure()**

Returns true if the module is in failure mode.

js	function <b>get_failure()</b>
php	function <b>get_failure()</b>
cpp	Y_FAILURE_enum <b>get_failure()</b>
m	-(Y_FAILURE_enum) failure
pas	function <b>get_failure()</b> : Integer
vb	function <b>get_failure()</b> As Integer
cs	int <b>get_failure()</b>
java	int <b>get_failure()</b>
py	def <b>get_failure()</b>
cmd	YVSource <b>target get_failure</b>

More information can be obtained by testing `get_overheat`, `get_overcurrent` etc... When a error condition is met, the output voltage is set to zéro and cannot be changed until the `reset()` function is called.

**Returns :**

either `Y_FAILURE_FALSE` or `Y_FAILURE_TRUE`, according to true if the module is in failure mode

On failure, throws an exception or returns `Y_FAILURE_INVALID`.

**vsource**→**get\_functionDescriptor()**  
**vsource**→**functionDescriptor()**  
**vsource.get\_vsourceDescriptor()**

Returns a unique identifier of type YFUN\_DESCR corresponding to the function.

function **get\_functionDescriptor( )** As YFUN\_DESCR

**vsource**→**get\_functionDescriptor()**  
**vsource**→**functionDescriptor()****vsource.get\_vsourceDescriptor()**

Returns a unique identifier of type YFUN\_DESCR corresponding to the function.

- `js` function **get\_functionDescriptor( )**
- `php` function **get\_functionDescriptor( )**
- `cpp` YFUN\_DESCR **get\_functionDescriptor( )**
- `m` -(YFUN\_DESCR) functionDescriptor
- `pas` function **get\_functionDescriptor( )**: YFUN\_DESCR
- `vb` function **get\_functionDescriptor( )** As YFUN\_DESCR
- `cs` YFUN\_DESCR **get\_functionDescriptor( )**
- `java` String **get\_functionDescriptor( )**
- `py` def **get\_functionDescriptor( )**

This identifier can be used to test if two instances of YFunction reference the same physical function on the same physical device.

**Returns :**

an identifier of type YFUN\_DESCR. If the function has never been contacted, the returned value is Y\_FUNCTIONDESCRIPTOR\_INVALID.

---

**vsource**→**get\_functionId()**

YVSource

**vsource**→**functionId()****vsource.get\_vsourceId()**

---

Returns the hardware identifier of the function, without reference to the module.

```
function get_functionId( ) As String
```

**vsource**→**get\_functionId()****vsource**→**functionId()****vsource.get\_vsourceId()**

---

Returns the hardware identifier of the function, without reference to the module.

js	function <b>get_functionId</b> ( )
php	function <b>get_functionId</b> ( )
cpp	string <b>get_functionId</b> ( )
m	-(NSString*) <b>functionId</b>
vb	function <b>get_functionId</b> ( ) As String
cs	string <b>get_functionId</b> ( )
java	String <b>get_functionId</b> ( )

For example `relay1`

**Returns :**

a string that identifies the function (ex: `relay1`) On failure, throws an exception or returns `Y_FUNCTIONID_INVALID`.

**vsource**→**get\_hardwareId()****YVSource****vsource**→**hardwareId()****vsource.get\_hardwareId()**

---

Returns the unique hardware identifier of the function in the form `SERIAL.FUNCTIONID`.

function **get\_hardwareId()** As String

**vsource**→**get\_hardwareId()****vsource**→**hardwareId()****vsource.get\_hardwareId()**

---

Returns the unique hardware identifier of the function in the form `SERIAL.FUNCTIONID`.

`js` function **get\_hardwareId()**

`php` function **get\_hardwareId()**

`cpp` string **get\_hardwareId()**

`m` `-(NSString*) hardwareId`

`vb` function **get\_hardwareId()** As String

`cs` string **get\_hardwareId()**

`java` String **get\_hardwareId()**

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the function. (for example `RELAYLO1-123456.relay1`)

**Returns :**

a string that uniquely identifies the function (ex: `RELAYLO1-123456.relay1`) On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.



---

**vsource**→**get\_logicalName()****YVSource****vsource**→**logicalName()****vsource.get\_logicalName()**

---

Returns the logical name of the voltage source.

```
function get_logicalName( ) As String
```

**vsource**→**get\_logicalName()****vsource**→**logicalName()****vsource.get\_logicalName()**

---

Returns the logical name of the voltage source.

js	function <b>get_logicalName</b> ( )
php	function <b>get_logicalName</b> ( )
cpp	string <b>get_logicalName</b> ( )
m	-(NSString*) logicalName
pas	function <b>get_logicalName</b> ( ): string
vb	function <b>get_logicalName</b> ( ) As String
cs	string <b>get_logicalName</b> ( )
java	String <b>get_logicalName</b> ( )
py	def <b>get_logicalName</b> ( )
cmd	YVSource <b>target</b> <b>get_logicalName</b>

**Returns :**

a string corresponding to the logical name of the voltage source

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

**vsource**→**get\_module()****vsource**→**module()****vsource.get\_module()**

Gets the YModule object for the device on which the function is located.

```
function get_module( ) As YModule
```

**vsource**→**get\_module()****vsource**→**module()****vsource.get\_module()**

Gets the YModule object for the device on which the function is located.

js	function <b>get_module</b> ( )
php	function <b>get_module</b> ( )
cpp	YModule * <b>get_module</b> ( )
m	-(YModule*) module
pas	function <b>get_module</b> ( ): TModule
vb	function <b>get_module</b> ( ) As YModule
cs	YModule <b>get_module</b> ( )
java	YModule <b>get_module</b> ( )
py	def <b>get_module</b> ( )

If the function cannot be located on any module, the returned instance of YModule is not shown as on-line.

**Returns :**

an instance of YModule

**vsource**→**get\_overCurrent()****YVSource****vsource**→**overCurrent()****vsource.get\_overCurrent()**


---

Returns true if the appliance connected to the device is too greedy .

```
function get_overCurrent( ) As Integer
```

**vsource**→**get\_overCurrent()****vsource**→**overCurrent()****vsource.get\_overCurrent()**


---

Returns true if the appliance connected to the device is too greedy .

js	function <b>get_overCurrent</b> ( )
php	function <b>get_overCurrent</b> ( )
cpp	Y_OVERCURRENT_enum <b>get_overCurrent</b> ( )
m	-(Y_OVERCURRENT_enum) overCurrent
pas	function <b>get_overCurrent</b> ( ): Integer
vb	function <b>get_overCurrent</b> ( ) As Integer
cs	int <b>get_overCurrent</b> ( )
java	int <b>get_overCurrent</b> ( )
py	def <b>get_overCurrent</b> ( )
cmd	YVSource <b>target</b> <b>get_overCurrent</b>

**Returns :**

either Y\_OVERCURRENT\_FALSE or Y\_OVERCURRENT\_TRUE, according to true if the appliance connected to the device is too greedy

On failure, throws an exception or returns Y\_OVERCURRENT\_INVALID.

**vsource**→**get\_overHeat()****vsource**→**overHeat()****vsource.get\_overHeat()**

---

Returns TRUE if the module is overheating.

```
function get_overHeat( ) As Integer
```

**vsource**→**get\_overHeat()****vsource**→**overHeat()****vsource.get\_overHeat()**

---

Returns TRUE if the module is overheating.

js	function <b>get_overHeat</b> ( )
php	function <b>get_overHeat</b> ( )
cpp	Y_OVERHEAT_enum <b>get_overHeat</b> ( )
m	-(Y_OVERHEAT_enum) overHeat
pas	function <b>get_overHeat</b> ( ): Integer
vb	function <b>get_overHeat</b> ( ) As Integer
cs	int <b>get_overHeat</b> ( )
java	int <b>get_overHeat</b> ( )
py	def <b>get_overHeat</b> ( )
cmd	YVSource <b>target get_overHeat</b>

**Returns :**

either Y\_OVERHEAT\_FALSE or Y\_OVERHEAT\_TRUE, according to TRUE if the module is overheating

On failure, throws an exception or returns Y\_OVERHEAT\_INVALID.

**vsource**→**get\_overLoad()****YVSource****vsource**→**overLoad()****vsource.get\_overLoad()**


---

Returns true if the device is not able to maintaint the requested voltage output .

```
function get_overLoad( ) As Integer
```

**vsource**→**get\_overLoad()****vsource**→**overLoad()****vsource.get\_overLoad()**


---

Returns true if the device is not able to maintaint the requested voltage output .

js	function <b>get_overLoad</b> ( )
php	function <b>get_overLoad</b> ( )
cpp	Y_OVERLOAD_enum <b>get_overLoad</b> ( )
m	-(Y_OVERLOAD_enum) overLoad
pas	function <b>get_overLoad</b> ( ): Integer
vb	function <b>get_overLoad</b> ( ) As Integer
cs	int <b>get_overLoad</b> ( )
java	int <b>get_overLoad</b> ( )
py	def <b>get_overLoad</b> ( )
cmd	YVSource <b>target</b> <b>get_overLoad</b>

**Returns :**

either Y\_OVERLOAD\_FALSE or Y\_OVERLOAD\_TRUE, according to true if the device is not able to maintaint the requested voltage output

On failure, throws an exception or returns Y\_OVERLOAD\_INVALID.

**vsource**→**get\_regulationFailure()****YVSource****vsource**→**regulationFailure()****vsource.get\_regulationFailure()**

Returns true if the voltage output is too high regarding the requested voltage .

function **get\_regulationFailure**( ) As Integer

**vsource**→**get\_regulationFailure()****vsource**→**regulationFailure(vsource.get\_regulationFailure())**

Returns true if the voltage output is too high regarding the requested voltage .

js	function <b>get_regulationFailure</b> ( )
php	function <b>get_regulationFailure</b> ( )
cpp	Y_REGULATIONFAILURE_enum <b>get_regulationFailure</b> ( )
m	-(Y_REGULATIONFAILURE_enum) regulationFailure
pas	function <b>get_regulationFailure</b> ( ): Integer
vb	function <b>get_regulationFailure</b> ( ) As Integer
cs	int <b>get_regulationFailure</b> ( )
java	int <b>get_regulationFailure</b> ( )
py	def <b>get_regulationFailure</b> ( )
cmd	YVSource <b>target</b> <b>get_regulationFailure</b>

**Returns :**

either Y\_REGULATIONFAILURE\_FALSE or Y\_REGULATIONFAILURE\_TRUE, according to true if the voltage output is too high regarding the requested voltage

On failure, throws an exception or returns Y\_REGULATIONFAILURE\_INVALID.

**vsource**→**get\_unit()****YVSource****vsource**→**unit()****vsource.get\_unit()**

---

Returns the measuring unit for the voltage.

```
function get_unit( ) As String
```

**vsource**→**get\_unit()****vsource**→**unit()****vsource.get\_unit()**

---

Returns the measuring unit for the voltage.

js	function <b>get_unit</b> ( )
php	function <b>get_unit</b> ( )
cpp	string <b>get_unit</b> ( )
m	-(NSString*) unit
pas	function <b>get_unit</b> ( ): string
vb	function <b>get_unit</b> ( ) As String
cs	string <b>get_unit</b> ( )
java	String <b>get_unit</b> ( )
py	def <b>get_unit</b> ( )
cmd	YVSource <b>target</b> <b>get_unit</b>

**Returns :**

a string corresponding to the measuring unit for the voltage

On failure, throws an exception or returns Y\_UNIT\_INVALID.

**vsource**→**get\_userData()****YVSource****vsource**→**userData()****vsource.get\_userData()**

Returns the value of the userData attribute, as previously stored using method `set_userData`.

```
function get_userData( ) As Object
```

**vsource**→**get\_userData()****vsource**→**userData()****vsource.get\_userData()**

Returns the value of the userData attribute, as previously stored using method `set_userData`.

```
js function get_userData( )
```

```
php function get_userData( )
```

```
cpp void * get_userData( )
```

```
m -(void*) userData
```

```
pas function get_userData( ): Tobject
```

```
vb function get_userData( ) As Object
```

```
cs object get_userData( )
```

```
java Object get_userData( )
```

```
py def get_userData( )
```

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.



---

**vsource**→**get\_voltage()****YVSource****vsource**→**voltage()****vsource.get\_voltage()**

---

Returns the voltage output command (mV)

function **get\_voltage**( ) As Integer**vsource**→**get\_voltage()****vsource**→**voltage()****vsource.get\_voltage()**

---

Returns the voltage output command (mV)

`js` function **get\_voltage**( )`php` function **get\_voltage**( )`cpp` int **get\_voltage**( )`m` -(int) voltage`pas` function **get\_voltage**( ): LongInt`vb` function **get\_voltage**( ) As Integer`cs` int **get\_voltage**( )`java` int **get\_voltage**( )`py` def **get\_voltage**( )**Returns :**

an integer corresponding to the voltage output command (mV)

On failure, throws an exception or returns Y\_VOLTAGE\_INVALID.

**vsource**→**isOnline()****vsource.isOnline()**

YVSource

Checks if the function is currently reachable, without raising any error.

```
function isOnline( ) As Boolean
```

**vsource**→**isOnline()****vsource.isOnline()**

Checks if the function is currently reachable, without raising any error.

js	function <b>isOnline</b> ( )
php	function <b>isOnline</b> ( )
cpp	bool <b>isOnline</b> ( )
m	-(BOOL) <b>isOnline</b>
pas	function <b>isOnline</b> ( ): boolean
vb	function <b>isOnline</b> ( ) As Boolean
cs	bool <b>isOnline</b> ( )
java	boolean <b>isOnline</b> ( )
py	def <b>isOnline</b> ( )

If there is a cached value for the function in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the requested function.

**Returns :**

`true` if the function can be reached, and `false` otherwise

**vsource**→**load()****vsource.load()****YVSource**

Preloads the function cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

**vsource**→**load()****vsource.load()**

Preloads the function cache with a specified validity duration.

js	function load( msValidity)
php	function load( \$msValidity)
cpp	YRETCODE load( int msValidity)
m	-(YRETCODE) load : (int) msValidity
pas	function load( msValidity: integer): YRETCODE
vb	function load( ByVal msValidity As Integer) As YRETCODE
cs	YRETCODE load( int msValidity)
java	int load( long msValidity)
py	def load( msValidity)

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds. On failure, throws an exception or returns a negative error code.

---

**vsource**→**nextVSource()****vsource.nextVSource()**

**YVSource**

---

Continues the enumeration of voltage sources started using `yFirstVSource()`.

```
function nextVSource( ) As YVSource
```

---

**vsource**→**nextVSource()****vsource.nextVSource()**

---

Continues the enumeration of voltage sources started using `yFirstVSource()`.

js	function <b>nextVSource</b> ( )
php	function <b>nextVSource</b> ( )
cpp	YVSource * <b>nextVSource</b> ( )
m	-(YVSource*) <b>nextVSource</b>
pas	function <b>nextVSource</b> ( ): TYVSource
vb	function <b>nextVSource</b> ( ) As YVSource
cs	YVSource <b>nextVSource</b> ( )
java	YVSource <b>nextVSource</b> ( )
py	def <b>nextVSource</b> ( )

**Returns :**

a pointer to a `YVSource` object, corresponding to a voltage source currently online, or a `null` pointer if there are no more voltage sources to enumerate.

**vsource**→**pulse()****vsource.pulse()****YVSource**

Sets device output to a specific volatage, for a specified duration, then brings it automatically to 0V.

```
function pulse( ByVal voltage As Integer,
                ByVal ms_duration As Integer) As Integer
```

**vsource**→**pulse()****vsource.pulse()**

Sets device output to a specific volatage, for a specified duration, then brings it automatically to 0V.

js	function <b>pulse</b> ( <b>voltage</b> , <b>ms_duration</b> )
php	function <b>pulse</b> ( <b>\$voltage</b> , <b>\$ms_duration</b> )
cpp	int <b>pulse</b> ( int <b>voltage</b> , int <b>ms_duration</b> )
m	-(int) <b>pulse</b> : (int) <b>voltage</b> : (int) <b>ms_duration</b>
pas	function <b>pulse</b> ( <b>voltage</b> : integer, <b>ms_duration</b> : integer): integer
vb	function <b>pulse</b> ( ByVal <b>voltage</b> As Integer,                 ByVal <b>ms_duration</b> As Integer) As Integer
cs	int <b>pulse</b> ( int <b>voltage</b> , int <b>ms_duration</b> )
java	int <b>pulse</b> ( int <b>voltage</b> , int <b>ms_duration</b> )
py	def <b>pulse</b> ( <b>voltage</b> , <b>ms_duration</b> )
cmd	YVSource <b>target pulse voltage ms_duration</b>

**Parameters :**

**voltage** pulse voltage, in millivolts  
**ms\_duration** pulse duration, in milliseconds

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

## **vsource**→**registerValueCallback()** **vsource.registerValueCallback()**

YVSource

Registers the callback function that is invoked on every change of advertised value.

```
procedure registerValueCallback( ByVal callback As GenericUpdateCallback)
```

## **vsource**→**registerValueCallback()****vsource.registerValueCallback()**

Registers the callback function that is invoked on every change of advertised value.

```
js function registerValueCallback( callback)
php function registerValueCallback( $callback)
cpp void registerValueCallback( YDisplayUpdateCallback callback)
pas procedure registerValueCallback( callback: TGenericUpdateCallback)
vb procedure registerValueCallback( ByVal callback As GenericUpdateCallback)
cs void registerValueCallback( UpdateCallback callback)
java void registerValueCallback( UpdateCallback callback)
py def registerValueCallback( callback)
m -(void) registerValueCallback : (YFunctionUpdateCallback) callback
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

### Parameters :

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

**vsource**→**set\_logicalName()****YVSource****vsource**→**setLogicalName()****vsource.set\_logicalName()**


---

Changes the logical name of the voltage source.

```
function set_logicalName( ByVal newval As String) As Integer
```

**vsource**→**set\_logicalName()****vsource**→**setLogicalName()****vsource.set\_logicalName()**


---

Changes the logical name of the voltage source.

js	function <b>set_logicalName</b> ( newval)
php	function <b>set_logicalName</b> ( \$newval)
cpp	int <b>set_logicalName</b> ( const string& newval)
m	-(int) setLogicalName : (NSString*) newval
pas	function <b>set_logicalName</b> ( newval: string): integer
vb	function <b>set_logicalName</b> ( ByVal newval As String) As Integer
cs	int <b>set_logicalName</b> ( string newval)
java	int <b>set_logicalName</b> ( String newval)
py	def <b>set_logicalName</b> ( newval)
cmd	YVSource <b>target set_logicalName</b> newval

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the voltage source

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**vsource**→**set\_userData()****vsource**→**setUserData()****vsource.set\_userData()**

Stores a user context provided as argument in the `userData` attribute of the function.

```
procedure set_userData( ByVal data As Object)
```

**vsource**→**set\_userData()****vsource**→**setUserData()****vsource.set\_userData()**

Stores a user context provided as argument in the `userData` attribute of the function.

js	function <b>set_userData</b> ( <b>data</b> )
php	function <b>set_userData</b> ( <b>\$data</b> )
cpp	void <b>set_userData</b> ( void* <b>data</b> )
m	-(void) <b>setUserData</b> : (void*) <b>data</b>
pas	procedure <b>set_userData</b> ( <b>data</b> : Tobject)
vb	procedure <b>set_userData</b> ( ByVal <b>data</b> As Object)
cs	void <b>set_userData</b> ( object <b>data</b> )
java	void <b>set_userData</b> ( Object <b>data</b> )
py	def <b>set_userData</b> ( <b>data</b> )

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored



**vsource**→**set\_voltage()**  
**vsource**→**setVoltage()****vsource.set\_voltage()**

YVSource

Tunes the device output voltage (milliVolts).

```
function set_voltage( ByVal newval As Integer) As Integer
```

**vsource**→**set\_voltage()**  
**vsource**→**setVoltage()****vsource.set\_voltage()**

Tunes the device output voltage (milliVolts).

js	function <b>set_voltage</b> ( <b>newval</b> )
php	function <b>set_voltage</b> ( \$ <b>newval</b> )
cpp	int <b>set_voltage</b> ( int <b>newval</b> )
m	-(int) setVoltage : (int) <b>newval</b>
pas	function <b>set_voltage</b> ( <b>newval</b> : LongInt): integer
vb	function <b>set_voltage</b> ( ByVal <b>newval</b> As Integer) As Integer
cs	int <b>set_voltage</b> ( int <b>newval</b> )
java	int <b>set_voltage</b> ( int <b>newval</b> )
py	def <b>set_voltage</b> ( <b>newval</b> )
cmd	YVSource <b>target</b> <b>set_voltage</b> <b>newval</b>

#### Parameters :

**newval** an integer

#### Returns :

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**vsource**→**voltageMove()****vsource.voltageMove()****YVSource**

Performs a smooth move at constant speed toward a given value.

```
function voltageMove( ByVal target As Integer,  
                      ByVal ms_duration As Integer) As Integer
```

**vsource**→**voltageMove()****vsource.voltageMove()**

Performs a smooth move at constant speed toward a given value.

```
js function voltageMove( target, ms_duration)  
php function voltageMove( $target, $ms_duration)  
cpp int voltageMove( int target, int ms_duration)  
m -(int) voltageMove : (int) target : (int) ms_duration  
pas function voltageMove( target: integer, ms_duration: integer): integer  
vb function voltageMove( ByVal target As Integer,  
                      ByVal ms_duration As Integer) As Integer  
cs int voltageMove( int target, int ms_duration)  
java int voltageMove( int target, int ms_duration)  
py def voltageMove( target, ms_duration)  
cmd YVSource target voltageMove target ms_duration
```

**Parameters :**

**target** new output value at end of transition, in millivolts.  
**ms\_duration** transition duration, in milliseconds

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

## 3.47. WakeUpMonitor function interface

The WakeUpMonitor function handles globally all wake-up sources, as well as automated sleep mode.

In order to use the functions described here, you should include:

js	<script type='text/javascript' src='yocto_wakeupmonitor.js'></script>
nodejs	var yoctolib = require('yoctolib'); var YWakeUpMonitor = yoctolib.YWakeUpMonitor;
php	require_once('yocto_wakeupmonitor.php');
c++	#include "yocto_wakeupmonitor.h"
m	#import "yocto_wakeupmonitor.h"
pas	uses yocto_wakeupmonitor;
vb	yocto_wakeupmonitor.vb
cs	yocto_wakeupmonitor.cs
java	import com.yoctopuce.YoctoAPI.YWakeUpMonitor;
py	from yocto_wakeupmonitor import *

### Global functions

#### yFindWakeUpMonitor(func)

Retrieves a monitor for a given identifier.

#### yFirstWakeUpMonitor()

Starts the enumeration of monitors currently accessible.

### YWakeUpMonitor methods

#### wakeupmonitor→describe()

Returns a short text that describes unambiguously the instance of the monitor in the form TYPE (NAME) = SERIAL . FUNCTIONID.

#### wakeupmonitor→get\_advertisedValue()

Returns the current value of the monitor (no more than 6 characters).

#### wakeupmonitor→get\_errorMessage()

Returns the error message of the latest error with the monitor.

#### wakeupmonitor→get\_errorType()

Returns the numerical error code of the latest error with the monitor.

#### wakeupmonitor→get\_friendlyName()

Returns a global identifier of the monitor in the format MODULE\_NAME . FUNCTION\_NAME.

#### wakeupmonitor→get\_functionDescriptor()

Returns a unique identifier of type YFUN\_DESCR corresponding to the function.

#### wakeupmonitor→get\_functionId()

Returns the hardware identifier of the monitor, without reference to the module.

#### wakeupmonitor→get\_hardwareId()

Returns the unique hardware identifier of the monitor in the form SERIAL . FUNCTIONID.

#### wakeupmonitor→get\_logicalName()

Returns the logical name of the monitor.

#### wakeupmonitor→get\_module()

Gets the YModule object for the device on which the function is located.

#### wakeupmonitor→get\_module\_async(callback, context)

Gets the YModule object for the device on which the function is located (asynchronous version).

#### wakeupmonitor→get\_nextWakeUp()

### 3. Reference

Returns the next scheduled wake up date/time (UNIX format)
<b>wakeupmonitor</b> → <b>get_powerDuration()</b> Returns the maximal wake up time (in seconds) before automatically going to sleep.
<b>wakeupmonitor</b> → <b>get_sleepCountdown()</b> Returns the delay before the next sleep period.
<b>wakeupmonitor</b> → <b>get_userData()</b> Returns the value of the userData attribute, as previously stored using method <code>set_userData</code> .
<b>wakeupmonitor</b> → <b>get_wakeUpReason()</b> Returns the latest wake up reason.
<b>wakeupmonitor</b> → <b>get_wakeUpState()</b> Returns the current state of the monitor
<b>wakeupmonitor</b> → <b>isOnline()</b> Checks if the monitor is currently reachable, without raising any error.
<b>wakeupmonitor</b> → <b>isOnline_async(callback, context)</b> Checks if the monitor is currently reachable, without raising any error (asynchronous version).
<b>wakeupmonitor</b> → <b>load(msValidity)</b> Preloads the monitor cache with a specified validity duration.
<b>wakeupmonitor</b> → <b>load_async(msValidity, callback, context)</b> Preloads the monitor cache with a specified validity duration (asynchronous version).
<b>wakeupmonitor</b> → <b>nextWakeUpMonitor()</b> Continues the enumeration of monitors started using <code>yFirstWakeUpMonitor()</code> .
<b>wakeupmonitor</b> → <b>registerValueCallback(callback)</b> Registers the callback function that is invoked on every change of advertised value.
<b>wakeupmonitor</b> → <b>resetSleepCountDown()</b> Resets the sleep countdown.
<b>wakeupmonitor</b> → <b>set_logicalName(newval)</b> Changes the logical name of the monitor.
<b>wakeupmonitor</b> → <b>set_nextWakeUp(newval)</b> Changes the days of the week when a wake up must take place.
<b>wakeupmonitor</b> → <b>set_powerDuration(newval)</b> Changes the maximal wake up time (seconds) before automatically going to sleep.
<b>wakeupmonitor</b> → <b>set_sleepCountdown(newval)</b> Changes the delay before the next sleep period.
<b>wakeupmonitor</b> → <b>set_userData(data)</b> Stores a user context provided as argument in the userData attribute of the function.
<b>wakeupmonitor</b> → <b>sleep(secBeforeSleep)</b> Goes to sleep until the next wake up condition is met, the RTC time must have been set before calling this function.
<b>wakeupmonitor</b> → <b>sleepFor(secUntilWakeUp, secBeforeSleep)</b> Goes to sleep for a specific duration or until the next wake up condition is met, the RTC time must have been set before calling this function.
<b>wakeupmonitor</b> → <b>sleepUntil(wakeUpTime, secBeforeSleep)</b> Go to sleep until a specific date is reached or until the next wake up condition is met, the RTC time must have been set before calling this function.
<b>wakeupmonitor</b> → <b>wait_async(callback, context)</b>

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.

**wakeupmonitor**→**wakeUp()**

Forces a wake up.

## YWakeUpMonitor.FindWakeUpMonitor() yFindWakeUpMonitor()yFindWakeUpMonitor()

YWakeUpMonitor

Retrieves a monitor for a given identifier.

```
function yFindWakeUpMonitor( ByVal func As String) As YWakeUpMonitor
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the monitor is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YWakeUpMonitor.IsOnline()` to test if the monitor is indeed online at a given time. In case of ambiguity when looking for a monitor by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

**Parameters :**

**func** a string that uniquely characterizes the monitor

**Returns :**

a `YWakeUpMonitor` object allowing you to drive the monitor.

---

**YWakeUpMonitor.FirstWakeUpMonitor()  
yFirstWakeUpMonitor()yFirstWakeUpMonitor()**

---

**YWakeUpMonitor**

Starts the enumeration of monitors currently accessible.

```
function yFirstWakeUpMonitor( ) As YWakeUpMonitor
```

Use the method `YWakeUpMonitor.nextWakeUpMonitor()` to iterate on next monitors.

**Returns :**

a pointer to a `YWakeUpMonitor` object, corresponding to the first monitor currently online, or a `null` pointer if there are none.

**wakeupmonitor→describe()  
wakeupmonitor.describe()****YWakeUpMonitor**

Returns a short text that describes unambiguously the instance of the monitor in the form `TYPE (NAME) =SERIAL . FUNCTIONID`.

```
function describe( ) As String
```

More precisely, `TYPE` is the type of the function, `NAME` is the name used for the first access to the function, `SERIAL` is the serial number of the module if the module is connected or "unresolved", and `FUNCTIONID` is the hardware identifier of the function if the module is connected. For example, this method returns `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1` if the module is already connected or `Relay(BadCustomeName.relay1)=unresolved` if the module has not yet been connected. This method does not trigger any USB or TCP transaction and can therefore be used in a debugger.

**Returns :**

a string that describes the monitor (ex: `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1`)



---

**wakeupmonitor**→**get\_advertisedValue()****YWakeUpMonitor****wakeupmonitor**→**advertisedValue()****wakeupmonitor.get\_advertisedValue()**

---

Returns the current value of the monitor (no more than 6 characters).

```
function get_advertisedValue( ) As String
```

**Returns :**

a string corresponding to the current value of the monitor (no more than 6 characters).

On failure, throws an exception or returns Y\_ADVERTISEDVALUE\_INVALID.

wakeupmonitor→get\_errorMessage()

YWakeUpMonitor

wakeupmonitor→errorMessage()

wakeupmonitor.get\_errorMessage()

---

Returns the error message of the latest error with the monitor.

```
function get_errorMessage( ) As String
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using the monitor object

---

**wakeupmonitor**→**get\_errorType()****YWakeUpMonitor****wakeupmonitor**→**errorType()****wakeupmonitor.get\_errorType()**

---

Returns the numerical error code of the latest error with the monitor.

```
function get_errorType( ) As YRETCODE
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using the monitor object

**wakeupmonitor**→**get\_functionDescriptor()**  
**wakeupmonitor**→**functionDescriptor()**  
**wakeupmonitor.get\_functionDescriptor()**

---

**YWakeUpMonitor**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

```
function get_functionDescriptor( ) As YFUN_DESCR
```

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`.

If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

---

**wakeupmonitor**→**get\_functionId()****YWakeUpMonitor****wakeupmonitor**→**functionId()****wakeupmonitor.get\_functionId()**

---

Returns the hardware identifier of the monitor, without reference to the module.

```
function get_functionId( ) As String
```

For example `relay1`

**Returns :**

a string that identifies the monitor (ex: `relay1`)

On failure, throws an exception or returns `Y_FUNCTIONID_INVALID`.

**wakeupmonitor**→**get\_hardwareId()**  
**wakeupmonitor**→**hardwareId()**  
**wakeupmonitor.get\_hardwareId()**

---

**YWakeUpMonitor**

Returns the unique hardware identifier of the monitor in the form `SERIAL.FUNCTIONID`.

```
function get_hardwareId( ) As String
```

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the monitor (for example `RELAYLO1-123456.relay1`).

**Returns :**

a string that uniquely identifies the monitor (ex: `RELAYLO1-123456.relay1`)

On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

---

**wakeupmonitor**→**get\_logicalName()****YWakeUpMonitor****wakeupmonitor**→**logicalName()****wakeupmonitor.get\_logicalName()**

---

Returns the logical name of the monitor.

```
function get_logicalName( ) As String
```

**Returns :**

a string corresponding to the logical name of the monitor.

On failure, throws an exception or returns `Y_LOGICALNAME_INVALID`.

**wakeupmonitor**→**get\_module()**  
**wakeupmonitor**→**module()**  
**wakeupmonitor.get\_module()**

---

**YWakeUpMonitor**

Gets the `YModule` object for the device on which the function is located.

```
function get_module( ) As YModule
```

If the function cannot be located on any module, the returned instance of `YModule` is not shown as on-line.

**Returns :**

an instance of `YModule`



---

**wakeupmonitor**→**get\_nextWakeUp()****YWakeUpMonitor****wakeupmonitor**→**nextWakeUp()****wakeupmonitor.get\_nextWakeUp()**

---

Returns the next scheduled wake up date/time (UNIX format)

function **get\_nextWakeUp( )** As Long

**Returns :**

an integer corresponding to the next scheduled wake up date/time (UNIX format)

On failure, throws an exception or returns `Y_NEXTWAKEUP_INVALID`.

wakeupmonitor→get\_powerDuration()

YWakeUpMonitor

wakeupmonitor→powerDuration()

wakeupmonitor.get\_powerDuration()

---

Returns the maximal wake up time (in seconds) before automatically going to sleep.

function **get\_powerDuration**( ) As Integer

**Returns :**

an integer corresponding to the maximal wake up time (in seconds) before automatically going to sleep

On failure, throws an exception or returns Y\_POWERDURATION\_INVALID.

---

wakeupmonitor→get\_sleepCountdown()

YWakeUpMonitor

wakeupmonitor→sleepCountdown()

wakeupmonitor.get\_sleepCountdown()

---

Returns the delay before the next sleep period.

```
function get_sleepCountdown( ) As Integer
```

**Returns :**

an integer corresponding to the delay before the next sleep period

On failure, throws an exception or returns Y\_SLEEPDOWNDOWN\_INVALID.

wakeupmonitor→get\_userData()

YWakeUpMonitor

wakeupmonitor→userData()

wakeupmonitor.get\_userData()

---

Returns the value of the userData attribute, as previously stored using method `set_userData`.

```
function get_userData( ) As Object
```

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

---

**wakeupmonitor**→**get\_wakeUpReason()**  
**wakeupmonitor**→**wakeUpReason()**  
**wakeupmonitor.get\_wakeUpReason()**

---

**YWakeUpMonitor**

Returns the latest wake up reason.

```
function get_wakeUpReason( ) As Integer
```

**Returns :**

a value among Y\_WAKEUPREASON\_USBPOWER, Y\_WAKEUPREASON\_EXTPOWER, Y\_WAKEUPREASON\_ENDOFSLEEP, Y\_WAKEUPREASON\_EXTSIG1, Y\_WAKEUPREASON\_SCHEDULE1 and Y\_WAKEUPREASON\_SCHEDULE2 corresponding to the latest wake up reason

On failure, throws an exception or returns Y\_WAKEUPREASON\_INVALID.

wakeupmonitor→get\_wakeUpState()

YWakeUpMonitor

wakeupmonitor→wakeUpState()

wakeupmonitor.get\_wakeUpState()

---

Returns the current state of the monitor

```
function get_wakeUpState( ) As Integer
```

**Returns :**

either Y\_WAKEUPSTATE\_SLEEPING or Y\_WAKEUPSTATE\_AWAKE, according to the current state of the monitor

On failure, throws an exception or returns Y\_WAKEUPSTATE\_INVALID.

---

**wakeupmonitor**→**isOnline()**wakeupmonitor.isOnline()**YWakeUpMonitor**

---

Checks if the monitor is currently reachable, without raising any error.

```
function isOnline( ) As Boolean
```

If there is a cached value for the monitor in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the monitor.

**Returns :**

`true` if the monitor can be reached, and `false` otherwise

**wakeupmonitor**→**load()**wakeupmonitor.load()**YWakeUpMonitor**

Preloads the monitor cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.



---

**wakeupmonitor**→**nextWakeUpMonitor()**  
**wakeupmonitor.nextWakeUpMonitor()**

---

**YWakeUpMonitor**

Continues the enumeration of monitors started using `yFirstWakeUpMonitor()`.

```
function nextWakeUpMonitor( ) As YWakeUpMonitor
```

**Returns :**

a pointer to a `YWakeUpMonitor` object, corresponding to a monitor currently online, or a `null` pointer if there are no more monitors to enumerate.

**wakeupmonitor→registerValueCallback()  
wakeupmonitor.registerValueCallback()**

**YWakeUpMonitor**

---

Registers the callback function that is invoked on every change of advertised value.

```
function registerValueCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

---

**wakeupmonitor**→**resetSleepCountDown()**  
**wakeupmonitor.resetSleepCountDown()**

---

**YWakeUpMonitor**

Resets the sleep countdown.

function **resetSleepCountDown**( ) As Integer

**Returns :**

YAPI\_SUCCESS if the call succeeds. On failure, throws an exception or returns a negative error code.

wakeupmonitor→set\_logicalName()  
wakeupmonitor→setLogicalName()  
wakeupmonitor.set\_logicalName()

---

YWakeUpMonitor

Changes the logical name of the monitor.

```
function set_logicalName( ByVal newval As String) As Integer
```

You can use `yCheckLogicalName()` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash()` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the monitor.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**wakeupmonitor**→**set\_nextWakeUp()****YWakeUpMonitor****wakeupmonitor**→**setNextWakeUp()****wakeupmonitor.set\_nextWakeUp()**

---

Changes the days of the week when a wake up must take place.

```
function set_nextWakeUp( ByVal newval As Long) As Integer
```

**Parameters :**

**newval** an integer corresponding to the days of the week when a wake up must take place

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

wakeupmonitor→set\_powerDuration()  
wakeupmonitor→setPowerDuration()  
wakeupmonitor.set\_powerDuration()

---

YWakeUpMonitor

Changes the maximal wake up time (seconds) before automatically going to sleep.

```
function set_powerDuration( ByVal newval As Integer) As Integer
```

**Parameters :**

**newval** an integer corresponding to the maximal wake up time (seconds) before automatically going to sleep

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

wakeupmonitor→set\_sleepCountdown()

YWakeUpMonitor

wakeupmonitor→setSleepCountdown()

wakeupmonitor.set\_sleepCountdown()

---

Changes the delay before the next sleep period.

```
function set_sleepCountdown( ByVal newval As Integer) As Integer
```

**Parameters :**

**newval** an integer corresponding to the delay before the next sleep period

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**wakeupmonitor**→**set\_userData()**  
**wakeupmonitor**→**setUserData()**  
**wakeupmonitor.set\_userData()**

---

**YWakeUpMonitor**

Stores a user context provided as argument in the userData attribute of the function.

```
procedure set_userData( ByVal data As Object)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored



**wakeupmonitor**→**sleep()**wakeupmonitor.sleep()**YWakeUpMonitor**

Goes to sleep until the next wake up condition is met, the RTC time must have been set before calling this function.

function **sleep**( ) As Integer

**Parameters :**

**secBeforeSleep** number of seconds before going into sleep mode,

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**wakeupmonitor→sleepFor()**  
**wakeupmonitor.sleepFor()**

**YWakeUpMonitor**

Goes to sleep for a specific duration or until the next wake up condition is met, the RTC time must have been set before calling this function.

```
function sleepFor( ) As Integer
```

The count down before sleep can be canceled with `resetSleepCountDown`.

**Parameters :**

**secUntilWakeUp** number of seconds before next wake up

**secBeforeSleep** number of seconds before going into sleep mode

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**wakeupmonitor**→**sleepUntil()**  
**wakeupmonitor.sleepUntil()**

---

**YWakeUpMonitor**

Go to sleep until a specific date is reached or until the next wake up condition is met, the RTC time must have been set before calling this function.

```
function sleepUntil( ) As Integer
```

The count down before sleep can be canceled with `resetSleepCountDown`.

**Parameters :**

**wakeUpTime** wake-up datetime (UNIX format)  
**secBeforeSleep** number of seconds before going into sleep mode

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

wakeupmonitor→wakeUp()wakeupmonitor.wakeUp()

YWakeUpMonitor

---

Forces a wake up.

```
function wakeUp( ) As Integer
```

## 3.48. WakeUpSchedule function interface

The WakeUpSchedule function implements a wake up condition. The wake up time is specified as a set of months and/or days and/or hours and/or minutes when the wake up should happen.

In order to use the functions described here, you should include:

js	<script type='text/javascript' src='yocto_wakeupschedule.js'></script>
nodejs	var yoctolib = require('yoctolib'); var YWakeUpSchedule = yoctolib.YWakeUpSchedule;
php	require_once('yocto_wakeupschedule.php');
c++	#include "yocto_wakeupschedule.h"
m	#import "yocto_wakeupschedule.h"
pas	uses yocto_wakeupschedule;
vb	yocto_wakeupschedule.vb
cs	yocto_wakeupschedule.cs
java	import com.yoctopuce.YoctoAPI.YWakeUpSchedule;
py	from yocto_wakeupschedule import *

### Global functions

#### yFindWakeUpSchedule(func)

Retrieves a wake up schedule for a given identifier.

#### yFirstWakeUpSchedule()

Starts the enumeration of wake up schedules currently accessible.

### YWakeUpSchedule methods

#### wakeupschedule→describe()

Returns a short text that describes unambiguously the instance of the wake up schedule in the form `TYPE ( NAME ) = SERIAL . FUNCTIONID`.

#### wakeupschedule→get\_advertisedValue()

Returns the current value of the wake up schedule (no more than 6 characters).

#### wakeupschedule→get\_errorMessage()

Returns the error message of the latest error with the wake up schedule.

#### wakeupschedule→get\_errorType()

Returns the numerical error code of the latest error with the wake up schedule.

#### wakeupschedule→get\_friendlyName()

Returns a global identifier of the wake up schedule in the format `MODULE_NAME . FUNCTION_NAME`.

#### wakeupschedule→get\_functionDescriptor()

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

#### wakeupschedule→get\_functionId()

Returns the hardware identifier of the wake up schedule, without reference to the module.

#### wakeupschedule→get\_hardwareId()

Returns the unique hardware identifier of the wake up schedule in the form `SERIAL . FUNCTIONID`.

#### wakeupschedule→get\_hours()

Returns the hours scheduled for wake up.

#### wakeupschedule→get\_logicalName()

Returns the logical name of the wake up schedule.

#### wakeupschedule→get\_minutes()

Returns all the minutes of each hour that are scheduled for wake up.

#### wakeupschedule→get\_minutesA()

### 3. Reference

	Returns the minutes in the 00-29 interval of each hour scheduled for wake up.
<b>wakeupschedule→get_minutesB()</b>	Returns the minutes in the 30-59 interval of each hour scheduled for wake up.
<b>wakeupschedule→get_module()</b>	Gets the YModule object for the device on which the function is located.
<b>wakeupschedule→get_module_async(callback, context)</b>	Gets the YModule object for the device on which the function is located (asynchronous version).
<b>wakeupschedule→get_monthDays()</b>	Returns the days of the month scheduled for wake up.
<b>wakeupschedule→get_months()</b>	Returns the months scheduled for wake up.
<b>wakeupschedule→get_nextOccurence()</b>	Returns the date/time (seconds) of the next wake up occurrence
<b>wakeupschedule→get_userData()</b>	Returns the value of the userData attribute, as previously stored using method set_userdata.
<b>wakeupschedule→get_weekDays()</b>	Returns the days of the week scheduled for wake up.
<b>wakeupschedule→isOnline()</b>	Checks if the wake up schedule is currently reachable, without raising any error.
<b>wakeupschedule→isOnline_async(callback, context)</b>	Checks if the wake up schedule is currently reachable, without raising any error (asynchronous version).
<b>wakeupschedule→load(msValidity)</b>	Preloads the wake up schedule cache with a specified validity duration.
<b>wakeupschedule→load_async(msValidity, callback, context)</b>	Preloads the wake up schedule cache with a specified validity duration (asynchronous version).
<b>wakeupschedule→nextWakeUpSchedule()</b>	Continues the enumeration of wake up schedules started using yFirstWakeUpSchedule().
<b>wakeupschedule→registerValueCallback(callback)</b>	Registers the callback function that is invoked on every change of advertised value.
<b>wakeupschedule→set_hours(newval)</b>	Changes the hours when a wake up must take place.
<b>wakeupschedule→set_logicalName(newval)</b>	Changes the logical name of the wake up schedule.
<b>wakeupschedule→set_minutes(bitmap)</b>	Changes all the minutes where a wake up must take place.
<b>wakeupschedule→set_minutesA(newval)</b>	Changes the minutes in the 00-29 interval when a wake up must take place.
<b>wakeupschedule→set_minutesB(newval)</b>	Changes the minutes in the 30-59 interval when a wake up must take place.
<b>wakeupschedule→set_monthDays(newval)</b>	Changes the days of the month when a wake up must take place.
<b>wakeupschedule→set_months(newval)</b>	Changes the months when a wake up must take place.
<b>wakeupschedule→set_userData(data)</b>	Stores a user context provided as argument in the userData attribute of the function.

**wakeupschedule**→**set\_weekDays(newval)**

Changes the days of the week when a wake up must take place.

**wakeupschedule**→**wait\_async(callback, context)**

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.

## YWakeUpSchedule.FindWakeUpSchedule() yFindWakeUpSchedule()yFindWakeUpSchedule()

YWakeUpSchedule

Retrieves a wake up schedule for a given identifier.

```
function yFindWakeUpSchedule( ByVal func As String) As YWakeUpSchedule
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the wake up schedule is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YWakeUpSchedule.IsOnline()` to test if the wake up schedule is indeed online at a given time. In case of ambiguity when looking for a wake up schedule by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

**Parameters :**

**func** a string that uniquely characterizes the wake up schedule

**Returns :**

a `YWakeUpSchedule` object allowing you to drive the wake up schedule.



---

**YWakeUpSchedule.FirstWakeUpSchedule()  
yFirstWakeUpSchedule()yFirstWakeUpSchedule()**

---

**YWakeUpSchedule**

Starts the enumeration of wake up schedules currently accessible.

```
function yFirstWakeUpSchedule( ) As YWakeUpSchedule
```

Use the method `YWakeUpSchedule.nextWakeUpSchedule()` to iterate on next wake up schedules.

**Returns :**

a pointer to a `YWakeUpSchedule` object, corresponding to the first wake up schedule currently online, or a `null` pointer if there are none.

**wakeupschedule**→**describe()**  
**wakeupschedule.describe()****YWakeUpSchedule**

Returns a short text that describes unambiguously the instance of the wake up schedule in the form `TYPE (NAME) =SERIAL . FUNCTIONID`.

function **describe**( ) As String

More precisely, `TYPE` is the type of the function, `NAME` it the name used for the first access to the function, `SERIAL` is the serial number of the module if the module is connected or "unresolved", and `FUNCTIONID` is the hardware identifier of the function if the module is connected. For example, this method returns `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1` if the module is already connected or `Relay(BadCustomeName.relay1)=unresolved` if the module has not yet been connected. This method does not trigger any USB or TCP transaction and can therefore be used in a debugger.

**Returns :**

a string that describes the wake up schedule (ex:  
`Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1`)

---

**wakeupschedule**→**get\_advertisedValue()****YWakeUpSchedule****wakeupschedule**→**advertisedValue()****wakeupschedule.get\_advertisedValue()**

---

Returns the current value of the wake up schedule (no more than 6 characters).

```
function get_advertisedValue( ) As String
```

**Returns :**

a string corresponding to the current value of the wake up schedule (no more than 6 characters).

On failure, throws an exception or returns Y\_ADVERTISEDVALUE\_INVALID.

`wakeupschedule`→`get_errorMessage()`

**YWakeUpSchedule**

`wakeupschedule`→`errorMessage()`

`wakeupschedule`.`get_errorMessage()`

---

Returns the error message of the latest error with the wake up schedule.

```
function get_errorMessage( ) As String
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using the wake up schedule object

---

**wakeupschedule**→**get\_errorType()****YWakeUpSchedule****wakeupschedule**→**errorType()****wakeupschedule.get\_errorType()**

---

Returns the numerical error code of the latest error with the wake up schedule.

```
function get_errorType( ) As YRETCODE
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using the wake up schedule object

`wakeupschedule`→`get_functionDescriptor()`

`YWakeUpSchedule`

`wakeupschedule`→`functionDescriptor()`

`wakeupschedule.get_functionDescriptor()`

---

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

```
function get_functionDescriptor() As YFUN_DESCR
```

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`.

If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

---

**wakeupschedule→get\_functionId()****YWakeUpSchedule****wakeupschedule→functionId()****wakeupschedule.get\_functionId()**

---

Returns the hardware identifier of the wake up schedule, without reference to the module.

```
function get_functionId( ) As String
```

For example `relay1`

**Returns :**

a string that identifies the wake up schedule (ex: `relay1`)

On failure, throws an exception or returns `Y_FUNCTIONID_INVALID`.

**wakeupschedule**→**get\_hardwareId()**

**YWakeUpSchedule**

**wakeupschedule**→**hardwareId()**

**wakeupschedule.get\_hardwareId()**

---

Returns the unique hardware identifier of the wake up schedule in the form `SERIAL.FUNCTIONID`.

function **get\_hardwareId**( ) As String

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the wake up schedule (for example `RELAYLO1-123456.relay1`).

**Returns :**

a string that uniquely identifies the wake up schedule (ex: `RELAYLO1-123456.relay1`)

On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.



---

**wakeupschedule→get\_hours()**

**YWakeUpSchedule**

**wakeupschedule→hours()**

**wakeupschedule.get\_hours()**

---

Returns the hours scheduled for wake up.

```
function get_hours( ) As Integer
```

**Returns :**

an integer corresponding to the hours scheduled for wake up

On failure, throws an exception or returns `Y_HOURS_INVALID`.

**wakeupschedule**→**get\_logicalName()**

**YWakeUpSchedule**

**wakeupschedule**→**logicalName()**

**wakeupschedule.get\_logicalName()**

---

Returns the logical name of the wake up schedule.

```
function get_logicalName( ) As String
```

**Returns :**

a string corresponding to the logical name of the wake up schedule.

On failure, throws an exception or returns Y\_LOGICALNAME\_INVALID.

---

**wakeupschedule→get\_minutes()**

**YWakeUpSchedule**

**wakeupschedule→minutes()**

**wakeupschedule.get\_minutes()**

---

Returns all the minutes of each hour that are scheduled for wake up.

```
function get_minutes( ) As Long
```

**wakeupschedule→get\_minutesA()**

**YWakeUpSchedule**

**wakeupschedule→minutesA()**

**wakeupschedule.get\_minutesA()**

---

Returns the minutes in the 00-29 interval of each hour scheduled for wake up.

```
function get_minutesA( ) As Integer
```

**Returns :**

an integer corresponding to the minutes in the 00-29 interval of each hour scheduled for wake up

On failure, throws an exception or returns Y\_MINUTESA\_INVALID.

---

**wakeupschedule→get\_minutesB()****YWakeUpSchedule****wakeupschedule→minutesB()****wakeupschedule.get\_minutesB()**

---

Returns the minutes in the 30-59 interval of each hour scheduled for wake up.

```
function get_minutesB( ) As Integer
```

**Returns :**

an integer corresponding to the minutes in the 30-59 interval of each hour scheduled for wake up

On failure, throws an exception or returns Y\_MINUTESB\_INVALID.

**wakeupschedule→get\_module()**

**YWakeUpSchedule**

**wakeupschedule→module()**

**wakeupschedule.get\_module()**

---

Gets the YModule object for the device on which the function is located.

function **get\_module()** As YModule

If the function cannot be located on any module, the returned instance of YModule is not shown as on-line.

**Returns :**

an instance of YModule

---

**wakeupschedule**→**get\_monthDays()****YWakeUpSchedule****wakeupschedule**→**monthDays()****wakeupschedule.get\_monthDays()**

---

Returns the days of the month scheduled for wake up.

```
function get_monthDays( ) As Integer
```

**Returns :**

an integer corresponding to the days of the month scheduled for wake up

On failure, throws an exception or returns `Y_MONTHDAYS_INVALID`.

**wakeupschedule→get\_months()**  
**wakeupschedule→months()**  
**wakeupschedule.get\_months()**

---

**YWakeUpSchedule**

Returns the months scheduled for wake up.

```
function get_months( ) As Integer
```

**Returns :**

an integer corresponding to the months scheduled for wake up

On failure, throws an exception or returns Y\_MONTHS\_INVALID.



---

**wakeupschedule→get\_nextOccurence()****YWakeUpSchedule****wakeupschedule→nextOccurence()****wakeupschedule.get\_nextOccurence()**

---

Returns the date/time (seconds) of the next wake up occurrence

```
function get_nextOccurence( ) As Long
```

**Returns :**

an integer corresponding to the date/time (seconds) of the next wake up occurrence

On failure, throws an exception or returns Y\_NEXTOCCURENCE\_INVALID.

**wakeupschedule**→**get\_userData()**

**YWakeUpSchedule**

**wakeupschedule**→**userData()**

**wakeupschedule.get\_userData()**

---

Returns the value of the userData attribute, as previously stored using method `set_userData`.

```
function get_userData( ) As Object
```

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

---

**wakeupschedule→get\_weekDays()**

**YWakeUpSchedule**

**wakeupschedule→weekDays()**

**wakeupschedule.get\_weekDays()**

---

Returns the days of the week scheduled for wake up.

```
function get_weekDays( ) As Integer
```

**Returns :**

an integer corresponding to the days of the week scheduled for wake up

On failure, throws an exception or returns Y\_WEEKDAYS\_INVALID.

**wakeupschedule**→**isOnline()**  
**wakeupschedule.isOnline()**

**YWakeUpSchedule**

---

Checks if the wake up schedule is currently reachable, without raising any error.

```
function isOnline( ) As Boolean
```

If there is a cached value for the wake up schedule in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the wake up schedule.

**Returns :**

`true` if the wake up schedule can be reached, and `false` otherwise

---

**wakeupschedule→load()wakeupschedule.load()****YWakeUpSchedule**

---

Preloads the wake up schedule cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

**wakeupschedule**→**nextWakeUpSchedule()**  
**wakeupschedule.nextWakeUpSchedule()**

**YWakeUpSchedule**

---

Continues the enumeration of wake up schedules started using `yFirstWakeUpSchedule()`.

function **nextWakeUpSchedule()** As YWakeUpSchedule

**Returns :**

a pointer to a YWakeUpSchedule object, corresponding to a wake up schedule currently online, or a null pointer if there are no more wake up schedules to enumerate.

---

**wakeupschedule→registerValueCallback()  
wakeupschedule.registerValueCallback()**

---

**YWakeUpSchedule**

Registers the callback function that is invoked on every change of advertised value.

```
function registerValueCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

wakeupschedule→set\_hours()

YWakeUpSchedule

wakeupschedule→setHours()

wakeupschedule.set\_hours()

---

Changes the hours when a wake up must take place.

```
function set_hours( ByVal newval As Integer) As Integer
```

**Parameters :**

**newval** an integer corresponding to the hours when a wake up must take place

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.



---

**wakeupschedule**→**set\_logicalName()****YWakeUpSchedule****wakeupschedule**→**setLogicalName()****wakeupschedule.set\_logicalName()**

---

Changes the logical name of the wake up schedule.

```
function set_logicalName( ByVal newval As String) As Integer
```

You can use `yCheckLogicalName( )` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash( )` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the wake up schedule.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**wakeupschedule→set\_minutes()**

**YWakeUpSchedule**

**wakeupschedule→setMinutes()**

**wakeupschedule.set\_minutes()**

---

Changes all the minutes where a wake up must take place.

```
function set_minutes( ) As Integer
```

**Parameters :**

**bitmap** Minutes 00-59 of each hour scheduled for wake up.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**wakeupschedule→set\_minutesA()****YWakeUpSchedule****wakeupschedule→setMinutesA()****wakeupschedule.set\_minutesA()**

---

Changes the minutes in the 00-29 interval when a wake up must take place.

```
function set_minutesA( ByVal newval As Integer) As Integer
```

**Parameters :**

**newval** an integer corresponding to the minutes in the 00-29 interval when a wake up must take place

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

wakeupschedule→set\_minutesB()

YWakeUpSchedule

wakeupschedule→setMinutesB()

wakeupschedule.set\_minutesB()

---

Changes the minutes in the 30-59 interval when a wake up must take place.

```
function set_minutesB( ByVal newval As Integer) As Integer
```

**Parameters :**

**newval** an integer corresponding to the minutes in the 30-59 interval when a wake up must take place

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**wakeupschedule**→**set\_monthDays()****YWakeUpSchedule****wakeupschedule**→**setMonthDays()****wakeupschedule.set\_monthDays()**

---

Changes the days of the month when a wake up must take place.

```
function set_monthDays( ByVal newval As Integer) As Integer
```

**Parameters :**

**newval** an integer corresponding to the days of the month when a wake up must take place

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

wakeupschedule→set\_months()

YWakeUpSchedule

wakeupschedule→setMonths()

wakeupschedule.set\_months()

---

Changes the months when a wake up must take place.

```
function set_months( ByVal newval As Integer) As Integer
```

**Parameters :**

**newval** an integer corresponding to the months when a wake up must take place

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**wakeupschedule**→**set\_userData()****YWakeUpSchedule****wakeupschedule**→**setUserData()****wakeupschedule.set\_userData()**

---

Stores a user context provided as argument in the userData attribute of the function.

```
procedure set_userData( ByVal data As Object)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

wakeupschedule→set\_weekDays()

YWakeUpSchedule

wakeupschedule→setWeekDays()

wakeupschedule.set\_weekDays()

---

Changes the days of the week when a wake up must take place.

```
function set_weekDays( ByVal newval As Integer) As Integer
```

**Parameters :**

**newval** an integer corresponding to the days of the week when a wake up must take place

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.



## 3.49. Watchdog function interface

The watchdog function works like a relay and can cause a brief power cut to an appliance after a preset delay to force this appliance to reset. The Watchdog must be called from time to time to reset the timer and prevent the appliance reset. The watchdog can be driven directly with *pulse* and *delayedpulse* methods to switch off an appliance for a given duration.

In order to use the functions described here, you should include:

js	<script type='text/javascript' src='yocto_watchdog.js'></script>
nodejs	var yoctolib = require('yoctolib'); var YWatchdog = yoctolib.YWatchdog;
php	require_once('yocto_watchdog.php');
cpp	#include "yocto_watchdog.h"
m	#import "yocto_watchdog.h"
pas	uses yocto_watchdog;
vb	yocto_watchdog.vb
cs	yocto_watchdog.cs
java	import com.yoctopuce.YoctoAPI.YWatchdog;
py	from yocto_watchdog import *

### Global functions

#### yFindWatchdog(func)

Retrieves a watchdog for a given identifier.

#### yFirstWatchdog()

Starts the enumeration of watchdog currently accessible.

### YWatchdog methods

#### watchdog→delayedPulse(ms\_delay, ms\_duration)

Schedules a pulse.

#### watchdog→describe()

Returns a short text that describes unambiguously the instance of the watchdog in the form `TYPE (NAME) = SERIAL . FUNCTIONID`.

#### watchdog→get\_advertisedValue()

Returns the current value of the watchdog (no more than 6 characters).

#### watchdog→get\_autoStart()

Returns the watchdog running state at module power on.

#### watchdog→get\_countdown()

Returns the number of milliseconds remaining before a pulse (`delayedPulse()` call) When there is no scheduled pulse, returns zero.

#### watchdog→get\_errorMessage()

Returns the error message of the latest error with the watchdog.

#### watchdog→get\_errorType()

Returns the numerical error code of the latest error with the watchdog.

#### watchdog→get\_friendlyName()

Returns a global identifier of the watchdog in the format `MODULE_NAME . FUNCTION_NAME`.

#### watchdog→get\_functionDescriptor()

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

#### watchdog→get\_functionId()

Returns the hardware identifier of the watchdog, without reference to the module.

**watchdog→get\_hardwareId()**

Returns the unique hardware identifier of the watchdog in the form SERIAL . FUNCTIONID.

**watchdog→get\_logicalName()**

Returns the logical name of the watchdog.

**watchdog→get\_maxTimeOnStateA()**

Retourne the maximum time (ms) allowed for \$THEFUNCTIONS\$ to stay in state A before automatically switching back in to B state.

**watchdog→get\_maxTimeOnStateB()**

Retourne the maximum time (ms) allowed for \$THEFUNCTIONS\$ to stay in state B before automatically switching back in to A state.

**watchdog→get\_module()**

Gets the YModule object for the device on which the function is located.

**watchdog→get\_module\_async(callback, context)**

Gets the YModule object for the device on which the function is located (asynchronous version).

**watchdog→get\_output()**

Returns the output state of the watchdog, when used as a simple switch (single throw).

**watchdog→get\_pulseTimer()**

Returns the number of milliseconds remaining before the watchdog is returned to idle position (state A), during a measured pulse generation.

**watchdog→get\_running()**

Returns the watchdog running state.

**watchdog→get\_state()**

Returns the state of the watchdog (A for the idle position, B for the active position).

**watchdog→get\_stateAtPowerOn()**

Returns the state of the watchdog at device startup (A for the idle position, B for the active position, UNCHANGED for no change).

**watchdog→get\_triggerDelay()**

Returns the waiting duration before a reset is automatically triggered by the watchdog, in milliseconds.

**watchdog→get\_triggerDuration()**

Returns the duration of resets caused by the watchdog, in milliseconds.

**watchdog→get\_userData()**

Returns the value of the userData attribute, as previously stored using method set\_userData.

**watchdog→isOnline()**

Checks if the watchdog is currently reachable, without raising any error.

**watchdog→isOnline\_async(callback, context)**

Checks if the watchdog is currently reachable, without raising any error (asynchronous version).

**watchdog→load(msValidity)**

Preloads the watchdog cache with a specified validity duration.

**watchdog→load\_async(msValidity, callback, context)**

Preloads the watchdog cache with a specified validity duration (asynchronous version).

**watchdog→nextWatchdog()**

Continues the enumeration of watchdog started using yFirstWatchdog( ).

**watchdog→pulse(ms\_duration)**

Sets the relay to output B (active) for a specified duration, then brings it automatically back to output A (idle state).

**watchdog→registerValueCallback(callback)**

Registers the callback function that is invoked on every change of advertised value.

**watchdog→resetWatchdog()**

Resets the watchdog.

**watchdog→set\_autoStart(newval)**

Changes the watchdog running state at module power on.

**watchdog→set\_logicalName(newval)**

Changes the logical name of the watchdog.

**watchdog→set\_maxTimeOnStateA(newval)**

Sets the maximum time (ms) allowed for \$THEFUNCTIONS\$ to stay in state A before automatically switching back in to B state.

**watchdog→set\_maxTimeOnStateB(newval)**

Sets the maximum time (ms) allowed for \$THEFUNCTIONS\$ to stay in state B before automatically switching back in to A state.

**watchdog→set\_output(newval)**

Changes the output state of the watchdog, when used as a simple switch (single throw).

**watchdog→set\_running(newval)**

Changes the running state of the watchdog.

**watchdog→set\_state(newval)**

Changes the state of the watchdog (A for the idle position, B for the active position).

**watchdog→set\_stateAtPowerOn(newval)**

Preset the state of the watchdog at device startup (A for the idle position, B for the active position, UNCHANGED for no modification).

**watchdog→set\_triggerDelay(newval)**

Changes the waiting delay before a reset is triggered by the watchdog, in milliseconds.

**watchdog→set\_triggerDuration(newval)**

Changes the duration of resets caused by the watchdog, in milliseconds.

**watchdog→set\_userData(data)**

Stores a user context provided as argument in the userData attribute of the function.

**watchdog→wait\_async(callback, context)**

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.

## YWatchdog.FindWatchdog() yFindWatchdog()yFindWatchdog()

YWatchdog

Retrieves a watchdog for a given identifier.

```
function yFindWatchdog( ByVal func As String) As YWatchdog
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the watchdog is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YWatchdog.isOnline()` to test if the watchdog is indeed online at a given time. In case of ambiguity when looking for a watchdog by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

**Parameters :**

**func** a string that uniquely characterizes the watchdog

**Returns :**

a `YWatchdog` object allowing you to drive the watchdog.

---

**YWatchdog.FirstWatchdog()  
yFirstWatchdog()yFirstWatchdog()**

---

**YWatchdog**

Starts the enumeration of watchdog currently accessible.

```
function yFirstWatchdog( ) As YWatchdog
```

Use the method `YWatchdog.nextWatchdog( )` to iterate on next watchdog.

**Returns :**

a pointer to a `YWatchdog` object, corresponding to the first watchdog currently online, or a `null` pointer if there are none.

**watchdog**→**delayedPulse()****watchdog.delayedPulse()**

**YWatchdog**

---

Schedules a pulse.

```
function delayedPulse( ByVal ms_delay As Integer,  
                      ByVal ms_duration As Integer) As Integer
```

**Parameters :**

**ms\_delay** waiting time before the pulse, in milliseconds

**ms\_duration** pulse duration, in milliseconds

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**watchdog→describe()watchdog.describe()****YWatchdog**

Returns a short text that describes unambiguously the instance of the watchdog in the form `TYPE(NAME)=SERIAL.FUNCTIONID`.

function **describe**( ) As String

More precisely, `TYPE` is the type of the function, `NAME` is the name used for the first access to the function, `SERIAL` is the serial number of the module if the module is connected or "unresolved", and `FUNCTIONID` is the hardware identifier of the function if the module is connected. For example, this method returns `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1` if the module is already connected or `Relay(BadCustomName.relay1)=unresolved` if the module has not yet been connected. This method does not trigger any USB or TCP transaction and can therefore be used in a debugger.

**Returns :**

a string that describes the watchdog (ex: `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1`)

**watchdog**→**get\_advertisedValue()**

**YWatchdog**

**watchdog**→**advertisedValue()**

**watchdog.get\_advertisedValue()**

---

Returns the current value of the watchdog (no more than 6 characters).

function **get\_advertisedValue( )** As String

**Returns :**

a string corresponding to the current value of the watchdog (no more than 6 characters).

On failure, throws an exception or returns `Y_ADVERTISEDVALUE_INVALID`.



---

**watchdog**→**get\_autoStart()****YWatchdog****watchdog**→**autoStart()****watchdog.get\_autoStart()**

---

Returns the watchdog running state at module power on.

function **get\_autoStart**( ) As Integer

**Returns :**

either `Y_AUTOSTART_OFF` or `Y_AUTOSTART_ON`, according to the watchdog running state at module power on

On failure, throws an exception or returns `Y_AUTOSTART_INVALID`.

**watchdog**→**get\_countdown()**

**YWatchdog**

**watchdog**→**countdown()****watchdog.get\_countdown()**

---

Returns the number of milliseconds remaining before a pulse (delayedPulse() call) When there is no scheduled pulse, returns zero.

function **get\_countdown()** As Long

**Returns :**

an integer corresponding to the number of milliseconds remaining before a pulse (delayedPulse() call) When there is no scheduled pulse, returns zero

On failure, throws an exception or returns Y\_COUNTDOWN\_INVALID.

---

**watchdog**→**get\_errorMessage()****YWatchdog****watchdog**→**errorMessage()****watchdog.get\_errorMessage()**

---

Returns the error message of the latest error with the watchdog.

```
function get_errorMessage( ) As String
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using the watchdog object

**watchdog**→**get\_errorType()**

**YWatchdog**

**watchdog**→**errorType()****watchdog.get\_errorType()**

---

Returns the numerical error code of the latest error with the watchdog.

```
function get_errorType( ) As YRETCODE
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using the watchdog object

---

**watchdog**→**get\_functionDescriptor()****YWatchdog****watchdog**→**functionDescriptor()****watchdog.get\_functionDescriptor()**

---

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

function **get\_functionDescriptor**( ) As `YFUN_DESCR`

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`.

If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.

**watchdog**→**get\_functionId()**

**YWatchdog**

**watchdog**→**functionId()****watchdog.get\_functionId()**

---

Returns the hardware identifier of the watchdog, without reference to the module.

function **get\_functionId**( ) As String

For example `relay1`

**Returns :**

a string that identifies the watchdog (ex: `relay1`)

On failure, throws an exception or returns `Y_FUNCTIONID_INVALID`.

---

**watchdog**→**get\_hardwareId()****YWatchdog****watchdog**→**hardwareId()****watchdog.get\_hardwareId()**

---

Returns the unique hardware identifier of the watchdog in the form `SERIAL.FUNCTIONID`.

function **get\_hardwareId()** As String

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the watchdog (for example `RELAYLO1-123456.relay1`).

**Returns :**

a string that uniquely identifies the watchdog (ex: `RELAYLO1-123456.relay1`)

On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

**watchdog**→**get\_logicalName()**

**YWatchdog**

**watchdog**→**logicalName()**

**watchdog.get\_logicalName()**

---

Returns the logical name of the watchdog.

```
function get_logicalName( ) As String
```

**Returns :**

a string corresponding to the logical name of the watchdog.

On failure, throws an exception or returns Y\_LOGICALNAME\_INVALID.



---

**watchdog→get\_maxTimeOnStateA()****YWatchdog****watchdog→maxTimeOnStateA()****watchdog.get\_maxTimeOnStateA()**

---

Retourne the maximum time (ms) allowed for \$THEFUNCTIONS\$ to stay in state A before automatically switching back in to B state.

```
function get_maxTimeOnStateA( ) As Long
```

Zero means no maximum time.

**Returns :**

an integer

On failure, throws an exception or returns Y\_MAXTIMEONSTATEA\_INVALID.

**watchdog**→**get\_maxTimeOnStateB()**

**YWatchdog**

**watchdog**→**maxTimeOnStateB()**

**watchdog.get\_maxTimeOnStateB()**

---

Retourne the maximum time (ms) allowed for \$THEFUNCTIONS\$ to stay in state B before automatically switching back in to A state.

```
function get_maxTimeOnStateB( ) As Long
```

Zero means no maximum time.

**Returns :**

an integer

On failure, throws an exception or returns Y\_MAXTIMEONSTATEB\_INVALID.

---

**watchdog→get\_module()****YWatchdog****watchdog→module()watchdog.get\_module()**

---

Gets the YModule object for the device on which the function is located.

function **get\_module( )** As YModule

If the function cannot be located on any module, the returned instance of YModule is not shown as on-line.

**Returns :**

an instance of YModule

**watchdog**→**get\_output()**

**YWatchdog**

**watchdog**→**output()****watchdog.get\_output()**

---

Returns the output state of the watchdog, when used as a simple switch (single throw).

function **get\_output( )** As Integer

**Returns :**

either `Y_OUTPUT_OFF` or `Y_OUTPUT_ON`, according to the output state of the watchdog, when used as a simple switch (single throw)

On failure, throws an exception or returns `Y_OUTPUT_INVALID`.

---

**watchdog**→**get\_pulseTimer()****YWatchdog****watchdog**→**pulseTimer()****watchdog.get\_pulseTimer()**

---

Returns the number of milliseconds remaining before the watchdog is returned to idle position (state A), during a measured pulse generation.

```
function get_pulseTimer( ) As Long
```

When there is no ongoing pulse, returns zero.

**Returns :**

an integer corresponding to the number of milliseconds remaining before the watchdog is returned to idle position (state A), during a measured pulse generation

On failure, throws an exception or returns `Y_PULSETIMER_INVALID`.

**watchdog**→**get\_running()**

**YWatchdog**

**watchdog**→**running()****watchdog.get\_running()**

---

Returns the watchdog running state.

function **get\_running**( ) As Integer

**Returns :**

either `Y_RUNNING_OFF` or `Y_RUNNING_ON`, according to the watchdog running state

On failure, throws an exception or returns `Y_RUNNING_INVALID`.

---

**watchdog**→**get\_state()****YWatchdog****watchdog**→**state()****watchdog.get\_state()**

---

Returns the state of the watchdog (A for the idle position, B for the active position).

function **get\_state**( ) As Integer

**Returns :**

either `Y_STATE_A` or `Y_STATE_B`, according to the state of the watchdog (A for the idle position, B for the active position)

On failure, throws an exception or returns `Y_STATE_INVALID`.

**watchdog**→**get\_stateAtPowerOn()**

**YWatchdog**

**watchdog**→**stateAtPowerOn()**

**watchdog.get\_stateAtPowerOn()**

---

Returns the state of the watchdog at device startup (A for the idle position, B for the active position, UNCHANGED for no change).

```
function get_stateAtPowerOn( ) As Integer
```

**Returns :**

a value among `Y_STATEATPOWERON_UNCHANGED`, `Y_STATEATPOWERON_A` and `Y_STATEATPOWERON_B` corresponding to the state of the watchdog at device startup (A for the idle position, B for the active position, UNCHANGED for no change)

On failure, throws an exception or returns `Y_STATEATPOWERON_INVALID`.



---

**watchdog→get\_triggerDelay()****YWatchdog****watchdog→triggerDelay()****watchdog.get\_triggerDelay()**

---

Returns the waiting duration before a reset is automatically triggered by the watchdog, in milliseconds.

```
function get_triggerDelay( ) As Long
```

**Returns :**

an integer corresponding to the waiting duration before a reset is automatically triggered by the watchdog, in milliseconds

On failure, throws an exception or returns `Y_TRIGGERDELAY_INVALID`.

**watchdog**→**get\_triggerDuration()**

**YWatchdog**

**watchdog**→**triggerDuration()**

**watchdog.get\_triggerDuration()**

---

Returns the duration of resets caused by the watchdog, in milliseconds.

```
function get_triggerDuration( ) As Long
```

**Returns :**

an integer corresponding to the duration of resets caused by the watchdog, in milliseconds

On failure, throws an exception or returns `Y_TRIGGERDURATION_INVALID`.

---

**watchdog**→**get\_userdata()****YWatchdog****watchdog**→**userData()****watchdog.get\_userdata()**

---

Returns the value of the `userData` attribute, as previously stored using method `set_userdata`.

```
function get_userdata( ) As Object
```

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

## watchdog→isOnline()watchdog.isOnline()

YWatchdog

---

Checks if the watchdog is currently reachable, without raising any error.

function **isOnline**( ) As Boolean

If there is a cached value for the watchdog in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the watchdog.

**Returns :**

true if the watchdog can be reached, and false otherwise

---

**watchdog→load()watchdog.load()****YWatchdog**

---

Preloads the watchdog cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

**watchdog**→**nextWatchdog()**  
**watchdog.nextWatchdog()**

**YWatchdog**

---

Continues the enumeration of watchdog started using `yFirstWatchdog()`.

```
function nextWatchdog( ) As YWatchdog
```

**Returns :**

a pointer to a `YWatchdog` object, corresponding to a watchdog currently online, or a `null` pointer if there are no more watchdog to enumerate.

---

**watchdog→pulse()watchdog.pulse()****YWatchdog**

---

Sets the relay to output B (active) for a specified duration, then brings it automatically back to output A (idle state).

```
function pulse( ByVal ms_duration As Integer) As Integer
```

**Parameters :**

**ms\_duration** pulse duration, in milliseconds

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**watchdog**→**registerValueCallback()**  
**watchdog.registerValueCallback()****YWatchdog**

Registers the callback function that is invoked on every change of advertised value.

```
function registerValueCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.



---

**watchdog→resetWatchdog()  
watchdog.resetWatchdog()**

---

**YWatchdog**

Resets the watchdog.

function **resetWatchdog**( ) As Integer

When the watchdog is running, this function must be called on a regular basis to prevent the watchdog to trigger

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**watchdog**→**set\_autoStart()**

**YWatchdog**

**watchdog**→**setAutoStart()****watchdog.set\_autoStart()**

---

Changes the watchdog runningstae at module power on.

```
function set_autoStart( ByVal newval As Integer) As Integer
```

Remember to call the `saveToFlash()` method and then to reboot the module to apply this setting.

**Parameters :**

**newval** either `Y_AUTOSTART_OFF` or `Y_AUTOSTART_ON`, according to the watchdog runningstae at module power on

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**watchdog**→**set\_logicalName()****YWatchdog****watchdog**→**setLogicalName()****watchdog.set\_logicalName()**

---

Changes the logical name of the watchdog.

```
function set_logicalName( ByVal newval As String) As Integer
```

You can use `yCheckLogicalName( )` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash( )` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the watchdog.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**watchdog**→**set\_maxTimeOnStateA()**

**YWatchdog**

**watchdog**→**setMaxTimeOnStateA()**

**watchdog.set\_maxTimeOnStateA()**

---

Sets the maximum time (ms) allowed for \$THEFUNCTIONS\$ to stay in state A before automatically switching back in to B state.

```
function set_maxTimeOnStateA( ByVal newval As Long) As Integer
```

Use zero for no maximum time.

**Parameters :**

**newval** an integer

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**watchdog**→**set\_maxTimeOnStateB()****YWatchdog****watchdog**→**setMaxTimeOnStateB()****watchdog.set\_maxTimeOnStateB()**

---

Sets the maximum time (ms) allowed for \$THEFUNCTIONS\$ to stay in state B before automatically switching back in to A state.

```
function set_maxTimeOnStateB( ByVal newval As Long) As Integer
```

Use zero for no maximum time.

**Parameters :**

**newval** an integer

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**watchdog**→**set\_output()**

**YWatchdog**

**watchdog**→**setOutput()****watchdog.set\_output()**

---

Changes the output state of the watchdog, when used as a simple switch (single throw).

```
function set_output( ByVal newval As Integer) As Integer
```

**Parameters :**

**newval** either Y\_OUTPUT\_OFF or Y\_OUTPUT\_ON, according to the output state of the watchdog, when used as a simple switch (single throw)

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**watchdog**→**set\_running()****YWatchdog****watchdog**→**setRunning()****watchdog.set\_running()**

---

Changes the running state of the watchdog.

```
function set_running( ByVal newval As Integer) As Integer
```

**Parameters :**

**newval** either Y\_RUNNING\_OFF or Y\_RUNNING\_ON, according to the running state of the watchdog

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**watchdog**→**set\_state()**

**YWatchdog**

**watchdog**→**setState()****watchdog.set\_state()**

---

Changes the state of the watchdog (A for the idle position, B for the active position).

```
function set_state( ByVal newval As Integer) As Integer
```

**Parameters :**

**newval** either Y\_STATE\_A or Y\_STATE\_B, according to the state of the watchdog (A for the idle position, B for the active position)

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.



---

**watchdog→set\_stateAtPowerOn()****YWatchdog****watchdog→setStateAtPowerOn()****watchdog.set\_stateAtPowerOn()**

---

Preset the state of the watchdog at device startup (A for the idle position, B for the active position, UNCHANGED for no modification).

```
function set_stateAtPowerOn( ByVal newval As Integer) As Integer
```

Remember to call the matching module `saveToFlash()` method, otherwise this call will have no effect.

**Parameters :**

**newval** a value among `Y_STATEATPOWERON_UNCHANGED`, `Y_STATEATPOWERON_A` and `Y_STATEATPOWERON_B`

**Returns :**

`YAPI_SUCCESS` if the call succeeds.

On failure, throws an exception or returns a negative error code.

**watchdog**→**set\_triggerDelay()**

**YWatchdog**

**watchdog**→**setTriggerDelay()**

**watchdog.set\_triggerDelay()**

---

Changes the waiting delay before a reset is triggered by the watchdog, in milliseconds.

```
function set_triggerDelay( ByVal newval As Long) As Integer
```

**Parameters :**

**newval** an integer corresponding to the waiting delay before a reset is triggered by the watchdog, in milliseconds

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**watchdog→set\_triggerDuration()****YWatchdog****watchdog→setTriggerDuration()****watchdog.set\_triggerDuration()**

---

Changes the duration of resets caused by the watchdog, in milliseconds.

```
function set_triggerDuration( ByVal newval As Long) As Integer
```

**Parameters :**

**newval** an integer corresponding to the duration of resets caused by the watchdog, in milliseconds

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**watchdog**→**set\_userData()**

**YWatchdog**

**watchdog**→**setUserData()****watchdog.set\_userData()**

---

Stores a user context provided as argument in the `userData` attribute of the function.

```
procedure set_userData( ByVal data As Object)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored

## 3.50. Wireless function interface

YWireless functions provides control over wireless network parameters and status for devices that are wireless-enabled.

In order to use the functions described here, you should include:

js	<script type='text/javascript' src='yocto_wireless.js'></script>
nodejs	var yoctolib = require('yoctolib'); var YWireless = yoctolib.YWireless;
php	require_once('yocto_wireless.php');
c++	#include "yocto_wireless.h"
m	#import "yocto_wireless.h"
pas	uses yocto_wireless;
vb	yocto_wireless.vb
cs	yocto_wireless.cs
java	import com.yoctopuce.YoctoAPI.YWireless;
py	from yocto_wireless import *

### Global functions

#### yFindWireless(func)

Retrieves a wireless lan interface for a given identifier.

#### yFirstWireless()

Starts the enumeration of wireless lan interfaces currently accessible.

### YWireless methods

#### wireless→adhocNetwork(ssid, securityKey)

Changes the configuration of the wireless lan interface to create an ad-hoc wireless network, without using an access point.

#### wireless→describe()

Returns a short text that describes unambiguously the instance of the wireless lan interface in the form `TYPE ( NAME ) = SERIAL . FUNCTIONID`.

#### wireless→get\_advertisedValue()

Returns the current value of the wireless lan interface (no more than 6 characters).

#### wireless→get\_channel()

Returns the 802.11 channel currently used, or 0 when the selected network has not been found.

#### wireless→get\_detectedWlans()

Returns a list of YWlanRecord objects that describe detected Wireless networks.

#### wireless→get\_errorMessage()

Returns the error message of the latest error with the wireless lan interface.

#### wireless→get\_errorType()

Returns the numerical error code of the latest error with the wireless lan interface.

#### wireless→get\_friendlyName()

Returns a global identifier of the wireless lan interface in the format `MODULE_NAME . FUNCTION_NAME`.

#### wireless→get\_functionDescriptor()

Returns a unique identifier of type YFUN\_DESCR corresponding to the function.

#### wireless→get\_functionId()

Returns the hardware identifier of the wireless lan interface, without reference to the module.

#### wireless→get\_hardwareId()

Returns the unique hardware identifier of the wireless lan interface in the form `SERIAL . FUNCTIONID`.

**wireless**→**get\_linkQuality()**

Returns the link quality, expressed in percent.

**wireless**→**get\_logicalName()**

Returns the logical name of the wireless lan interface.

**wireless**→**get\_message()**

Returns the latest status message from the wireless interface.

**wireless**→**get\_module()**

Gets the YModule object for the device on which the function is located.

**wireless**→**get\_module\_async(callback, context)**

Gets the YModule object for the device on which the function is located (asynchronous version).

**wireless**→**get\_security()**

Returns the security algorithm used by the selected wireless network.

**wireless**→**get\_ssid()**

Returns the wireless network name (SSID).

**wireless**→**get\_userData()**

Returns the value of the userData attribute, as previously stored using method `set_userData`.

**wireless**→**isOnline()**

Checks if the wireless lan interface is currently reachable, without raising any error.

**wireless**→**isOnline\_async(callback, context)**

Checks if the wireless lan interface is currently reachable, without raising any error (asynchronous version).

**wireless**→**joinNetwork(ssid, securityKey)**

Changes the configuration of the wireless lan interface to connect to an existing access point (infrastructure mode).

**wireless**→**load(msValidity)**

Preloads the wireless lan interface cache with a specified validity duration.

**wireless**→**load\_async(msValidity, callback, context)**

Preloads the wireless lan interface cache with a specified validity duration (asynchronous version).

**wireless**→**nextWireless()**

Continues the enumeration of wireless lan interfaces started using `yFirstWireless()`.

**wireless**→**registerValueCallback(callback)**

Registers the callback function that is invoked on every change of advertised value.

**wireless**→**set\_logicalName(newval)**

Changes the logical name of the wireless lan interface.

**wireless**→**set\_userData(data)**

Stores a user context provided as argument in the userData attribute of the function.

**wireless**→**softAPNetwork(ssid, securityKey)**

Changes the configuration of the wireless lan interface to create a new wireless network by emulating a WiFi access point (Soft AP).

**wireless**→**wait\_async(callback, context)**

Waits for all pending asynchronous commands on the module to complete, and invoke the user-provided callback function.

## YWireless.FindWireless() yFindWireless()yFindWireless()

YWireless

Retrieves a wireless lan interface for a given identifier.

```
function yFindWireless( ByVal func As String) As YWireless
```

The identifier can be specified using several formats:

- FunctionLogicalName
- ModuleSerialNumber.FunctionIdentifier
- ModuleSerialNumber.FunctionLogicalName
- ModuleLogicalName.FunctionIdentifier
- ModuleLogicalName.FunctionLogicalName

This function does not require that the wireless lan interface is online at the time it is invoked. The returned object is nevertheless valid. Use the method `YWireless.isOnline()` to test if the wireless lan interface is indeed online at a given time. In case of ambiguity when looking for a wireless lan interface by logical name, no error is notified: the first instance found is returned. The search is performed first by hardware name, then by logical name.

**Parameters :**

**func** a string that uniquely characterizes the wireless lan interface

**Returns :**

a `YWireless` object allowing you to drive the wireless lan interface.

## **YWireless.FirstWireless() yFirstWireless()yFirstWireless()**

---

**YWireless**

Starts the enumeration of wireless lan interfaces currently accessible.

```
function yFirstWireless( ) As YWireless
```

Use the method `YWireless.nextWireless()` to iterate on next wireless lan interfaces.

**Returns :**

a pointer to a `YWireless` object, corresponding to the first wireless lan interface currently online, or a `null` pointer if there are none.



**wireless**→**adhocNetwork()****wireless.adhocNetwork()****YWireless**

Changes the configuration of the wireless lan interface to create an ad-hoc wireless network, without using an access point.

```
function adhocNetwork( ) As Integer
```

On the YoctoHub-Wireless-g, it is best to use `softAPNetworkInstead()`, which emulates an access point (Soft AP) which is more efficient and more widely supported than ad-hoc networks.

When a security key is specified for an ad-hoc network, the network is protected by a WEP40 key (5 characters or 10 hexadecimal digits) or WEP128 key (13 characters or 26 hexadecimal digits). It is recommended to use a well-randomized WEP128 key using 26 hexadecimal digits to maximize security. Remember to call the `saveToFlash()` method and then to reboot the module to apply this setting.

**Parameters :**

**ssid** the name of the network to connect to  
**securityKey** the network key, as a character string

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

**wireless**→**describe()****wireless.describe()****YWireless**

Returns a short text that describes unambiguously the instance of the wireless lan interface in the form `TYPE (NAME) = SERIAL . FUNCTIONID`.

function **describe**( ) As String

More precisely, `TYPE` is the type of the function, `NAME` it the name used for the first access to the function, `SERIAL` is the serial number of the module if the module is connected or "unresolved", and `FUNCTIONID` is the hardware identifier of the function if the module is connected. For example, this method returns `Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1` if the module is already connected or `Relay(BadCustomeName.relay1)=unresolved` if the module has not yet been connected. This method does not trigger any USB or TCP transaction and can therefore be used in a debugger.

**Returns :**

a string that describes the wireless lan interface (ex:  
`Relay(MyCustomName.relay1)=RELAYLO1-123456.relay1`)

---

**wireless**→**get\_advertisedValue()****YWireless****wireless**→**advertisedValue()****wireless.get\_advertisedValue()**

---

Returns the current value of the wireless lan interface (no more than 6 characters).

```
function get_advertisedValue( ) As String
```

**Returns :**

a string corresponding to the current value of the wireless lan interface (no more than 6 characters).

On failure, throws an exception or returns Y\_ADVERTISEDVALUE\_INVALID.

**wireless**→**get\_channel()**

**YWireless**

**wireless**→**channel()****wireless.get\_channel()**

---

Returns the 802.11 channel currently used, or 0 when the selected network has not been found.

function **get\_channel**( ) As Integer

**Returns :**

an integer corresponding to the 802.11 channel currently used, or 0 when the selected network has not been found

On failure, throws an exception or returns `Y_CHANNEL_INVALID`.

---

**wireless**→**get\_detectedWlans()****YWireless****wireless**→**detectedWlans()****wireless.get\_detectedWlans()**

---

Returns a list of `YWlanRecord` objects that describe detected Wireless networks.

```
function get_detectedWlans( ) As List
```

This list is not updated when the module is already connected to an access point (infrastructure mode). To force an update of this list, `adhocNetwork( )` must be called to disconnect the module from the current network. The returned list must be unallocated by the caller.

**Returns :**

a list of `YWlanRecord` objects, containing the SSID, channel, link quality and the type of security of the wireless network.

On failure, throws an exception or returns an empty list.

**wireless**→**get\_errorMessage()**  
**wireless**→**errorMessage()**  
**wireless.get\_errorMessage()**

---

**YWireless**

Returns the error message of the latest error with the wireless lan interface.

```
function get_errorMessage( ) As String
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a string corresponding to the latest error message that occurred while using the wireless lan interface object

---

**wireless**→**get\_errorType()****YWireless****wireless**→**errorType()****wireless.get\_errorType()**

---

Returns the numerical error code of the latest error with the wireless lan interface.

```
function get_errorType( ) As YRETCODE
```

This method is mostly useful when using the Yoctopuce library with exceptions disabled.

**Returns :**

a number corresponding to the code of the latest error that occurred while using the wireless lan interface object

**wireless**→**get\_functionDescriptor()**  
**wireless**→**functionDescriptor()**  
**wireless.get\_functionDescriptor()**

---

**YWireless**

Returns a unique identifier of type `YFUN_DESCR` corresponding to the function.

```
function get_functionDescriptor( ) As YFUN_DESCR
```

This identifier can be used to test if two instances of `YFunction` reference the same physical function on the same physical device.

**Returns :**

an identifier of type `YFUN_DESCR`.

If the function has never been contacted, the returned value is `Y_FUNCTIONDESCRIPTOR_INVALID`.



---

**wireless**→**get\_functionId()****YWireless****wireless**→**functionId()****wireless.get\_functionId()**

---

Returns the hardware identifier of the wireless lan interface, without reference to the module.

function **get\_functionId**( ) As String

For example `relay1`

**Returns :**

a string that identifies the wireless lan interface (ex: `relay1`)

On failure, throws an exception or returns `Y_FUNCTIONID_INVALID`.

**wireless**→**get\_hardwareId()**

**YWireless**

**wireless**→**hardwareId()****wireless.get\_hardwareId()**

---

Returns the unique hardware identifier of the wireless lan interface in the form `SERIAL.FUNCTIONID`.

`function get_hardwareId( ) As String`

The unique hardware identifier is composed of the device serial number and of the hardware identifier of the wireless lan interface (for example `RELAYLO1-123456.relay1`).

**Returns :**

a string that uniquely identifies the wireless lan interface (ex: `RELAYLO1-123456.relay1`)

On failure, throws an exception or returns `Y_HARDWAREID_INVALID`.

---

**wireless**→**get\_linkQuality()****YWireless****wireless**→**linkQuality()****wireless.get\_linkQuality()**

---

Returns the link quality, expressed in percent.

```
function get_linkQuality( ) As Integer
```

**Returns :**

an integer corresponding to the link quality, expressed in percent

On failure, throws an exception or returns `Y_LINKQUALITY_INVALID`.

wireless→**get\_logicalName()**

**YWireless**

wireless→**logicalName()**wireless.**get\_logicalName()**

---

Returns the logical name of the wireless lan interface.

function **get\_logicalName**( ) As String

**Returns :**

a string corresponding to the logical name of the wireless lan interface.

On failure, throws an exception or returns Y\_LOGICALNAME\_INVALID.

---

**wireless**→**get\_message()****YWireless****wireless**→**message()****wireless.get\_message()**

---

Returns the latest status message from the wireless interface.

function **get\_message**( ) As String

**Returns :**

a string corresponding to the latest status message from the wireless interface

On failure, throws an exception or returns `Y_MESSAGE_INVALID`.

**wireless**→**get\_module()**

**YWireless**

**wireless**→**module()****wireless.get\_module()**

---

Gets the YModule object for the device on which the function is located.

function **get\_module()** As YModule

If the function cannot be located on any module, the returned instance of YModule is not shown as on-line.

**Returns :**

an instance of YModule

---

**wireless**→**get\_security()****YWireless****wireless**→**security()****wireless.get\_security()**

---

Returns the security algorithm used by the selected wireless network.

function **get\_security**( ) As Integer

**Returns :**

a value among Y\_SECURITY\_UNKNOWN, Y\_SECURITY\_OPEN, Y\_SECURITY\_WEP, Y\_SECURITY\_WPA and Y\_SECURITY\_WPA2 corresponding to the security algorithm used by the selected wireless network

On failure, throws an exception or returns Y\_SECURITY\_INVALID.

**wireless**→**get\_ssid()**

**YWireless**

**wireless**→**ssid()****wireless.get\_ssid()**

---

Returns the wireless network name (SSID).

function **get\_ssid**( ) As String

**Returns :**

a string corresponding to the wireless network name (SSID)

On failure, throws an exception or returns Y\_SSID\_INVALID.



---

**wireless**→**get\_userData()****YWireless****wireless**→**userData()****wireless.get\_userData()**

---

Returns the value of the userData attribute, as previously stored using method `set_userData`.

```
function get_userData( ) As Object
```

This attribute is never touched directly by the API, and is at disposal of the caller to store a context.

**Returns :**

the object stored previously by the caller.

**wireless**→**isOnline()****wireless.isOnline()**

**YWireless**

---

Checks if the wireless lan interface is currently reachable, without raising any error.

function **isOnline**( ) As Boolean

If there is a cached value for the wireless lan interface in cache, that has not yet expired, the device is considered reachable. No exception is raised if there is an error while trying to contact the device hosting the wireless lan interface.

**Returns :**

`true` if the wireless lan interface can be reached, and `false` otherwise

**wireless**→**joinNetwork()****wireless.joinNetwork()****YWireless**

Changes the configuration of the wireless lan interface to connect to an existing access point (infrastructure mode).

```
function joinNetwork( ) As Integer
```

Remember to call the `saveToFlash( )` method and then to reboot the module to apply this setting.

**Parameters :**

**ssid** the name of the network to connect to  
**securityKey** the network key, as a character string

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

**wireless**→**load()****wireless.load()****YWireless**

Preloads the wireless lan interface cache with a specified validity duration.

```
function load( ByVal msValidity As Integer) As YRETCODE
```

By default, whenever accessing a device, all function attributes are kept in cache for the standard duration (5 ms). This method can be used to temporarily mark the cache as valid for a longer period, in order to reduce network traffic for instance.

**Parameters :**

**msValidity** an integer corresponding to the validity attributed to the loaded function parameters, in milliseconds

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.

---

**wireless**→**nextWireless()****wireless.nextWireless()****YWireless**

---

Continues the enumeration of wireless lan interfaces started using `yFirstWireless()`.

```
function nextWireless( ) As YWireless
```

**Returns :**

a pointer to a `YWireless` object, corresponding to a wireless lan interface currently online, or a null pointer if there are no more wireless lan interfaces to enumerate.

**wireless**→**registerValueCallback()**  
**wireless.registerValueCallback()****YWireless**

Registers the callback function that is invoked on every change of advertised value.

```
function registerValueCallback( ) As Integer
```

The callback is invoked only during the execution of `ySleep` or `yHandleEvents`. This provides control over the time when the callback is triggered. For good responsiveness, remember to call one of these two functions periodically. To unregister a callback, pass a null pointer as argument.

**Parameters :**

**callback** the callback function to call, or a null pointer. The callback function should take two arguments: the function object of which the value has changed, and the character string describing the new advertised value.

**wireless**→**set\_logicalName()**  
**wireless**→**setLogicalName()**  
**wireless.set\_logicalName()**

**YWireless**

---

Changes the logical name of the wireless lan interface.

```
function set_logicalName( ByVal newval As String) As Integer
```

You can use `yCheckLogicalName( )` prior to this call to make sure that your parameter is valid. Remember to call the `saveToFlash( )` method of the module if the modification must be kept.

**Parameters :**

**newval** a string corresponding to the logical name of the wireless lan interface.

**Returns :**

YAPI\_SUCCESS if the call succeeds.

On failure, throws an exception or returns a negative error code.

**wireless**→**set\_userdata()**

**YWireless**

**wireless**→**setUserData()****wireless.set\_userdata()**

---

Stores a user context provided as argument in the `userData` attribute of the function.

```
procedure set_userdata( ByVal data As Object)
```

This attribute is never touched by the API, and is at disposal of the caller to store a context.

**Parameters :**

**data** any kind of object to be stored



**wireless**→**softAPNetwork()****wireless.softAPNetwork()****YWireless**

Changes the configuration of the wireless lan interface to create a new wireless network by emulating a WiFi access point (Soft AP).

```
function softAPNetwork( ) As Integer
```

This function can only be used with the YoctoHub-Wireless-g.

When a security key is specified for a SoftAP network, the network is protected by a WEP40 key (5 characters or 10 hexadecimal digits) or WEP128 key (13 characters or 26 hexadecimal digits). It is recommended to use a well-randomized WEP128 key using 26 hexadecimal digits to maximize security. Remember to call the `saveToFlash()` method and then to reboot the module to apply this setting.

**Parameters :**

**ssid** the name of the network to connect to  
**securityKey** the network key, as a character string

**Returns :**

YAPI\_SUCCESS when the call succeeds.

On failure, throws an exception or returns a negative error code.



# Index

## A

Accelerometer 31  
adhocNetwork, YWireless 1716  
Altitude 72  
AnButton 113

## B

Basic 3  
Blueprint 10  
brakingForceMove, YMotor 852

## C

calibrate, YLightSensor 717  
calibrateFromPoints, YAccelerometer 35  
calibrateFromPoints, YAltitude 76  
calibrateFromPoints, YCarbonDioxide 154  
calibrateFromPoints, YCompass 220  
calibrateFromPoints, YCurrent 259  
calibrateFromPoints, YGenericSensor 531  
calibrateFromPoints, YGyro 579  
calibrateFromPoints, YHumidity 653  
calibrateFromPoints, YLightSensor 718  
calibrateFromPoints, YMagnetometer 758  
calibrateFromPoints, YPower 970  
calibrateFromPoints, YPressure 1012  
calibrateFromPoints, YPwmInput 1050  
calibrateFromPoints, YQt 1156  
calibrateFromPoints, YSensor 1290  
calibrateFromPoints, YTemperature 1418  
calibrateFromPoints, YTilt 1458  
calibrateFromPoints, YVoc 1496  
calibrateFromPoints, YVoltage 1534  
callbackLogin, YNetwork 893  
cancel3DCalibration, YRefFrame 1220  
CarbonDioxide 150  
checkFirmware, YModule 805  
CheckLogicalName, YAPI 12  
clear, YDisplayLayer 445  
clearConsole, YDisplayLayer 446  
Clock 1190  
ColorLed 188  
Compass 216  
Configuration 1216  
consoleOut, YDisplayLayer 447  
copyLayerContent, YDisplay 402  
Current 255

## D

Data 326, 328, 340  
DataLogger 293  
delayedPulse, YDigitalIO 359  
delayedPulse, YRelay 1255

delayedPulse, YWatchdog 1673  
describe, YAccelerometer 36  
describe, YAltitude 77  
describe, YAnButton 117  
describe, YCarbonDioxide 155  
describe, YColorLed 191  
describe, YCompass 221  
describe, YCurrent 260  
describe, YDataLogger 297  
describe, YDigitalIO 360  
describe, YDisplay 403  
describe, YDualPower 479  
describe, YFiles 503  
describe, YGenericSensor 532  
describe, YGyro 580  
describe, YHubPort 628  
describe, YHumidity 654  
describe, YLed 690  
describe, YLightSensor 719  
describe, YMagnetometer 759  
describe, YModule 806  
describe, YMotor 853  
describe, YNetwork 894  
describe, YOsControl 947  
describe, YPower 971  
describe, YPressure 1013  
describe, YPwmInput 1051  
describe, YPwmOutput 1097  
describe, YPwmPowerSource 1133  
describe, YQt 1157  
describe, YRealTimeClock 1193  
describe, YRefFrame 1221  
describe, YRelay 1256  
describe, YSensor 1291  
describe, YSerialPort 1329  
describe, YServo 1384  
describe, YTemperature 1419  
describe, YTilt 1459  
describe, YVoc 1497  
describe, YVoltage 1535  
describe, YVSource 1571  
describe, YWakeUpMonitor 1603  
describe, YWakeUpSchedule 1637  
describe, YWatchdog 1674  
describe, YWireless 1717  
Digital 355  
DisableExceptions, YAPI 13  
Display 398  
DisplayLayer 444  
download, YFiles 504  
download, YModule 807  
drawBar, YDisplayLayer 448  
drawBitmap, YDisplayLayer 449  
drawCircle, YDisplayLayer 450  
drawDisc, YDisplayLayer 451

drawImage, YDisplayLayer 452  
drawPixel, YDisplayLayer 453  
drawRect, YDisplayLayer 454  
drawText, YDisplayLayer 455  
drivingForceMove, YMotor 854  
dutyCycleMove, YPwmOutput 1098

## E

EnableExceptions, YAPI 14  
Error 8  
External 476

## F

fade, YDisplay 404  
Files 500  
FindAccelerometer, YAccelerometer 33  
FindAltitude, YAltitude 74  
FindAnButton, YAnButton 115  
FindCarbonDioxide, YCarbonDioxide 152  
FindColorLed, YColorLed 189  
FindCompass, YCompass 218  
FindCurrent, YCurrent 257  
FindDataLogger, YDataLogger 295  
FindDigitalIO, YDigitalIO 357  
FindDisplay, YDisplay 400  
FindDualPower, YDualPower 477  
FindFiles, YFiles 501  
FindGenericSensor, YGenericSensor 529  
FindGyro, YGyro 577  
FindHubPort, YHubPort 626  
FindHumidity, YHumidity 651  
FindLed, YLed 688  
FindLightSensor, YLightSensor 715  
FindMagnetometer, YMagnetometer 756  
FindModule, YModule 803  
FindMotor, YMotor 850  
FindNetwork, YNetwork 891  
FindOsControl, YOsControl 945  
FindPower, YPower 968  
FindPressure, YPressure 1010  
FindPwmInput, YPwmInput 1048  
FindPwmOutput, YPwmOutput 1095  
FindPwmPowerSource, YPwmPowerSource 1131  
FindQt, YQt 1154  
FindRealTimeClock, YRealTimeClock 1191  
FindRefFrame, YRefFrame 1218  
FindRelay, YRelay 1253  
FindSensor, YSensor 1288  
FindSerialPort, YSerialPort 1327  
FindServo, YServo 1382  
FindTemperature, YTemperature 1416  
FindTilt, YTilt 1456  
FindVoc, YVoc 1494  
FindVoltage, YVoltage 1532  
FindVSource, YVSource 1569  
FindWakeUpMonitor, YWakeUpMonitor 1601  
FindWakeUpSchedule, YWakeUpSchedule 1635

FindWatchdog, YWatchdog 1671  
FindWireless, YWireless 1714  
FirstAccelerometer, YAccelerometer 34  
FirstAltitude, YAltitude 75  
FirstAnButton, YAnButton 116  
FirstCarbonDioxide, YCarbonDioxide 153  
FirstColorLed, YColorLed 190  
FirstCompass, YCompass 219  
FirstCurrent, YCurrent 258  
FirstDataLogger, YDataLogger 296  
FirstDigitalIO, YDigitalIO 358  
FirstDisplay, YDisplay 401  
FirstDualPower, YDualPower 478  
FirstFiles, YFiles 502  
FirstGenericSensor, YGenericSensor 530  
FirstGyro, YGyro 578  
FirstHubPort, YHubPort 627  
FirstHumidity, YHumidity 652  
FirstLed, YLed 689  
FirstLightSensor, YLightSensor 716  
FirstMagnetometer, YMagnetometer 757  
FirstModule, YModule 804  
FirstMotor, YMotor 851  
FirstNetwork, YNetwork 892  
FirstOsControl, YOsControl 946  
FirstPower, YPower 969  
FirstPressure, YPressure 1011  
FirstPwmInput, YPwmInput 1049  
FirstPwmOutput, YPwmOutput 1096  
FirstPwmPowerSource, YPwmPowerSource 1132  
FirstQt, YQt 1155  
FirstRealTimeClock, YRealTimeClock 1192  
FirstRefFrame, YRefFrame 1219  
FirstRelay, YRelay 1254  
FirstSensor, YSensor 1289  
FirstSerialPort, YSerialPort 1328  
FirstServo, YServo 1383  
FirstTemperature, YTemperature 1417  
FirstTilt, YTilt 1457  
FirstVoc, YVoc 1495  
FirstVoltage, YVoltage 1533  
FirstVSource, YVSource 1570  
FirstWakeUpMonitor, YWakeUpMonitor 1602  
FirstWakeUpSchedule, YWakeUpSchedule 1636  
FirstWatchdog, YWatchdog 1672  
FirstWireless, YWireless 1715  
forgetAllDataStreams, YDataLogger 298  
format\_fs, YFiles 505  
Formatted 326  
Frame 1216  
FreeAPI, YAPI 15  
functionCount, YModule 808  
functionId, YModule 809  
functionName, YModule 810  
Functions 11  
functionValue, YModule 811

## G

General 11

GenericSensor 527

get\_3DCalibrationHint, YRefFrame 1222

get\_3DCalibrationLogMsg, YRefFrame 1223

get\_3DCalibrationProgress, YRefFrame 1224

get\_3DCalibrationStage, YRefFrame 1225

get\_3DCalibrationStageProgress, YRefFrame 1226

get\_adminPassword, YNetwork 895

get\_advertisedValue, YAccelerometer 37

get\_advertisedValue, YAltitude 78

get\_advertisedValue, YAnButton 118

get\_advertisedValue, YCarbonDioxide 156

get\_advertisedValue, YColorLed 192

get\_advertisedValue, YCompass 222

get\_advertisedValue, YCurrent 261

get\_advertisedValue, YDataLogger 299

get\_advertisedValue, YDigitalIO 361

get\_advertisedValue, YDisplay 405

get\_advertisedValue, YDualPower 480

get\_advertisedValue, YFiles 506

get\_advertisedValue, YGenericSensor 533

get\_advertisedValue, YGyro 581

get\_advertisedValue, YHubPort 629

get\_advertisedValue, YHumidity 655

get\_advertisedValue, YLed 691

get\_advertisedValue, YLightSensor 720

get\_advertisedValue, YMagnetometer 760

get\_advertisedValue, YMotor 855

get\_advertisedValue, YNetwork 896

get\_advertisedValue, YOsControl 948

get\_advertisedValue, YPower 972

get\_advertisedValue, YPressure 1014

get\_advertisedValue, YPwmInput 1052

get\_advertisedValue, YPwmOutput 1099

get\_advertisedValue, YPwmPowerSource 1134

get\_advertisedValue, YQt 1158

get\_advertisedValue, YRealTimeClock 1194

get\_advertisedValue, YRefFrame 1227

get\_advertisedValue, YRelay 1257

get\_advertisedValue, YSensor 1292

get\_advertisedValue, YSerialPort 1331

get\_advertisedValue, YServo 1385

get\_advertisedValue, YTemperature 1420

get\_advertisedValue, YTilt 1460

get\_advertisedValue, YVoc 1498

get\_advertisedValue, YVoltage 1536

get\_advertisedValue, YVSource 1572

get\_advertisedValue, YWakeUpMonitor 1604

get\_advertisedValue, YWakeUpSchedule 1638

get\_advertisedValue, YWatchdog 1675

get\_advertisedValue, YWireless 1718

get\_allSettings, YModule 812

get\_analogCalibration, YAnButton 119

get\_autoStart, YDataLogger 300

get\_autoStart, YWatchdog 1676

get\_averageValue, YDataStream 341

get\_averageValue, YMeasure 795

get\_baudRate, YHubPort 630

get\_beacon, YModule 813

get\_beaconDriven, YDataLogger 301

get\_bearing, YRefFrame 1228

get\_bitDirection, YDigitalIO 362

get\_bitOpenDrain, YDigitalIO 363

get\_bitPolarity, YDigitalIO 364

get\_bitState, YDigitalIO 365

get\_blinking, YLed 692

get\_brakingForce, YMotor 856

get\_brightness, YDisplay 406

get\_calibratedValue, YAnButton 120

get\_calibrationMax, YAnButton 121

get\_calibrationMin, YAnButton 122

get\_callbackCredentials, YNetwork 897

get\_callbackEncoding, YNetwork 898

get\_callbackMaxDelay, YNetwork 899

get\_callbackMethod, YNetwork 900

get\_callbackMinDelay, YNetwork 901

get\_callbackUrl, YNetwork 902

get\_channel, YWireless 1719

get\_columnCount, YDataStream 342

get\_columnNames, YDataStream 343

get\_cosPhi, YPower 973

get\_countdown, YRelay 1258

get\_countdown, YWatchdog 1677

get\_CTS, YSerialPort 1330

get\_currentRawValue, YAccelerometer 38

get\_currentRawValue, YAltitude 79

get\_currentRawValue, YCarbonDioxide 157

get\_currentRawValue, YCompass 223

get\_currentRawValue, YCurrent 262

get\_currentRawValue, YGenericSensor 534

get\_currentRawValue, YGyro 582

get\_currentRawValue, YHumidity 656

get\_currentRawValue, YLightSensor 721

get\_currentRawValue, YMagnetometer 761

get\_currentRawValue, YPower 974

get\_currentRawValue, YPressure 1015

get\_currentRawValue, YPwmInput 1053

get\_currentRawValue, YQt 1159

get\_currentRawValue, YSensor 1293

get\_currentRawValue, YTemperature 1421

get\_currentRawValue, YTilt 1461

get\_currentRawValue, YVoc 1499

get\_currentRawValue, YVoltage 1537

get\_currentRunIndex, YDataLogger 302

get\_currentValue, YAccelerometer 39

get\_currentValue, YAltitude 80

get\_currentValue, YCarbonDioxide 158

get\_currentValue, YCompass 224

get\_currentValue, YCurrent 263

get\_currentValue, YGenericSensor 535

get\_currentValue, YGyro 583

get\_currentValue, YHumidity 657

get\_currentValue, YLightSensor 722

get\_currentValue, YMagnetometer 762

get\_currentValue, YPower 975

get\_currentValue, YPressure 1016  
get\_currentValue, YPwmInput 1054  
get\_currentValue, YQt 1160  
get\_currentValue, YSensor 1294  
get\_currentValue, YTemperature 1422  
get\_currentValue, YTilt 1462  
get\_currentValue, YVoc 1500  
get\_currentValue, YVoltage 1538  
get\_cutOffVoltage, YMotor 857  
get\_data, YDataStream 344  
get\_dataRows, YDataStream 345  
get\_dataSamplesIntervalMs, YDataStream 346  
get\_dataSets, YDataLogger 303  
get\_dataStreams, YDataLogger 304  
get\_dateTime, YRealTimeClock 1195  
get\_detectedWlans, YWireless 1720  
get\_discoverable, YNetwork 903  
get\_display, YDisplayLayer 456  
get\_displayHeight, YDisplay 407  
get\_displayHeight, YDisplayLayer 457  
get\_displayLayer, YDisplay 408  
get\_displayType, YDisplay 409  
get\_displayWidth, YDisplay 410  
get\_displayWidth, YDisplayLayer 458  
get\_drivingForce, YMotor 858  
get\_duration, YDataStream 347  
get\_dutyCycle, YPwmInput 1055  
get\_dutyCycle, YPwmOutput 1100  
get\_dutyCycleAtPowerOn, YPwmOutput 1101  
get\_enabled, YDisplay 411  
get\_enabled, YHubPort 631  
get\_enabled, YPwmOutput 1102  
get\_enabled, YServo 1386  
get\_enabledAtPowerOn, YPwmOutput 1103  
get\_enabledAtPowerOn, YServo 1387  
get\_endTimeUTC, YDataSet 329  
get\_endTimeUTC, YMeasure 796  
get\_errCount, YSerialPort 1332  
get\_errorMessage, YAccelerometer 40  
get\_errorMessage, YAltitude 81  
get\_errorMessage, YAnButton 123  
get\_errorMessage, YCarbonDioxide 159  
get\_errorMessage, YColorLed 193  
get\_errorMessage, YCompass 225  
get\_errorMessage, YCurrent 264  
get\_errorMessage, YDataLogger 305  
get\_errorMessage, YDigitalIO 366  
get\_errorMessage, YDisplay 412  
get\_errorMessage, YDualPower 481  
get\_errorMessage, YFiles 507  
get\_errorMessage, YGenericSensor 536  
get\_errorMessage, YGyro 584  
get\_errorMessage, YHubPort 632  
get\_errorMessage, YHumidity 658  
get\_errorMessage, YLed 693  
get\_errorMessage, YLightSensor 723  
get\_errorMessage, YMagnetometer 763  
get\_errorMessage, YModule 814  
get\_errorMessage, YMotor 859  
get\_errorMessage, YNetwork 904  
get\_errorMessage, YOsControl 949  
get\_errorMessage, YPower 976  
get\_errorMessage, YPressure 1017  
get\_errorMessage, YPwmInput 1056  
get\_errorMessage, YPwmOutput 1104  
get\_errorMessage, YPwmPowerSource 1135  
get\_errorMessage, YQt 1161  
get\_errorMessage, YRealTimeClock 1196  
get\_errorMessage, YRefFrame 1229  
get\_errorMessage, YRelay 1259  
get\_errorMessage, YSensor 1295  
get\_errorMessage, YSerialPort 1333  
get\_errorMessage, YServo 1388  
get\_errorMessage, YTemperature 1423  
get\_errorMessage, YTilt 1463  
get\_errorMessage, YVoc 1501  
get\_errorMessage, YVoltage 1539  
get\_errorMessage, YVSource 1573  
get\_errorMessage, YWakeUpMonitor 1605  
get\_errorMessage, YWakeUpSchedule 1639  
get\_errorMessage, YWatchdog 1678  
get\_errorMessage, YWireless 1721  
get\_errorType, YAccelerometer 41  
get\_errorType, YAltitude 82  
get\_errorType, YAnButton 124  
get\_errorType, YCarbonDioxide 160  
get\_errorType, YColorLed 194  
get\_errorType, YCompass 226  
get\_errorType, YCurrent 265  
get\_errorType, YDataLogger 306  
get\_errorType, YDigitalIO 367  
get\_errorType, YDisplay 413  
get\_errorType, YDualPower 482  
get\_errorType, YFiles 508  
get\_errorType, YGenericSensor 537  
get\_errorType, YGyro 585  
get\_errorType, YHubPort 633  
get\_errorType, YHumidity 659  
get\_errorType, YLed 694  
get\_errorType, YLightSensor 724  
get\_errorType, YMagnetometer 764  
get\_errorType, YModule 815  
get\_errorType, YMotor 860  
get\_errorType, YNetwork 905  
get\_errorType, YOsControl 950  
get\_errorType, YPower 977  
get\_errorType, YPressure 1018  
get\_errorType, YPwmInput 1057  
get\_errorType, YPwmOutput 1105  
get\_errorType, YPwmPowerSource 1136  
get\_errorType, YQt 1162  
get\_errorType, YRealTimeClock 1197  
get\_errorType, YRefFrame 1230  
get\_errorType, YRelay 1260  
get\_errorType, YSensor 1296  
get\_errorType, YSerialPort 1334  
get\_errorType, YServo 1389  
get\_errorType, YTemperature 1424

get\_errorType, YTilt 1464  
get\_errorType, YVoc 1502  
get\_errorType, YVoltage 1540  
get\_errorType, YVSource 1574  
get\_errorType, YWakeUpMonitor 1606  
get\_errorType, YWakeUpSchedule 1640  
get\_errorType, YWatchdog 1679  
get\_errorType, YWireless 1722  
get\_extPowerFailure, YVSource 1575  
get\_extVoltage, YDualPower 483  
get\_failSafeTimeout, YMotor 861  
get\_failure, YVSource 1576  
get\_filesCount, YFiles 509  
get\_firmwareRelease, YModule 816  
get\_freeSpace, YFiles 510  
get\_frequency, YMotor 862  
get\_frequency, YPwmInput 1058  
get\_frequency, YPwmOutput 1106  
get\_functionDescriptor, YAccelerometer 42  
get\_functionDescriptor, YAltitude 83  
get\_functionDescriptor, YAnButton 125  
get\_functionDescriptor, YCarbonDioxide 161  
get\_functionDescriptor, YColorLed 195  
get\_functionDescriptor, YCompass 227  
get\_functionDescriptor, YCurrent 266  
get\_functionDescriptor, YDataLogger 307  
get\_functionDescriptor, YDigitalIO 368  
get\_functionDescriptor, YDisplay 414  
get\_functionDescriptor, YDualPower 484  
get\_functionDescriptor, YFiles 511  
get\_functionDescriptor, YGenericSensor 538  
get\_functionDescriptor, YGyro 586  
get\_functionDescriptor, YHubPort 634  
get\_functionDescriptor, YHumidity 660  
get\_functionDescriptor, YLed 695  
get\_functionDescriptor, YLightSensor 725  
get\_functionDescriptor, YMagnetometer 765  
get\_functionDescriptor, YMotor 863  
get\_functionDescriptor, YNetwork 906  
get\_functionDescriptor, YOsControl 951  
get\_functionDescriptor, YPower 978  
get\_functionDescriptor, YPressure 1019  
get\_functionDescriptor, YPwmInput 1059  
get\_functionDescriptor, YPwmOutput 1107  
get\_functionDescriptor, YPwmPowerSource 1137  
get\_functionDescriptor, YQt 1163  
get\_functionDescriptor, YRealTimeClock 1198  
get\_functionDescriptor, YRefFrame 1231  
get\_functionDescriptor, YRelay 1261  
get\_functionDescriptor, YSensor 1297  
get\_functionDescriptor, YSerialPort 1335  
get\_functionDescriptor, YServo 1390  
get\_functionDescriptor, YTemperature 1425  
get\_functionDescriptor, YTilt 1465  
get\_functionDescriptor, YVoc 1503  
get\_functionDescriptor, YVoltage 1541  
get\_functionDescriptor, YVSource 1577  
get\_functionDescriptor, YWakeUpMonitor 1607  
get\_functionDescriptor, YWakeUpSchedule 1641  
get\_functionDescriptor, YWatchdog 1680  
get\_functionDescriptor, YWireless 1723  
get\_functionId, YAccelerometer 43  
get\_functionId, YAltitude 84  
get\_functionId, YAnButton 126  
get\_functionId, YCarbonDioxide 162  
get\_functionId, YColorLed 196  
get\_functionId, YCompass 228  
get\_functionId, YCurrent 267  
get\_functionId, YDataLogger 308  
get\_functionId, YDataSet 330  
get\_functionId, YDigitalIO 369  
get\_functionId, YDisplay 415  
get\_functionId, YDualPower 485  
get\_functionId, YFiles 512  
get\_functionId, YGenericSensor 539  
get\_functionId, YGyro 587  
get\_functionId, YHubPort 635  
get\_functionId, YHumidity 661  
get\_functionId, YLed 696  
get\_functionId, YLightSensor 726  
get\_functionId, YMagnetometer 766  
get\_functionId, YMotor 864  
get\_functionId, YNetwork 907  
get\_functionId, YOsControl 952  
get\_functionId, YPower 979  
get\_functionId, YPressure 1020  
get\_functionId, YPwmInput 1060  
get\_functionId, YPwmOutput 1108  
get\_functionId, YPwmPowerSource 1138  
get\_functionId, YQt 1164  
get\_functionId, YRealTimeClock 1199  
get\_functionId, YRefFrame 1232  
get\_functionId, YRelay 1262  
get\_functionId, YSensor 1298  
get\_functionId, YSerialPort 1336  
get\_functionId, YServo 1391  
get\_functionId, YTemperature 1426  
get\_functionId, YTilt 1466  
get\_functionId, YVoc 1504  
get\_functionId, YVoltage 1542  
get\_functionId, YVSource 1578  
get\_functionId, YWakeUpMonitor 1608  
get\_functionId, YWakeUpSchedule 1642  
get\_functionId, YWatchdog 1681  
get\_functionId, YWireless 1724  
get\_hardwareId, YAccelerometer 44  
get\_hardwareId, YAltitude 85  
get\_hardwareId, YAnButton 127  
get\_hardwareId, YCarbonDioxide 163  
get\_hardwareId, YColorLed 197  
get\_hardwareId, YCompass 229  
get\_hardwareId, YCurrent 268  
get\_hardwareId, YDataLogger 309  
get\_hardwareId, YDataSet 331  
get\_hardwareId, YDigitalIO 370  
get\_hardwareId, YDisplay 416  
get\_hardwareId, YDualPower 486  
get\_hardwareId, YFiles 513

get\_hardwareId, YGenericSensor 540  
get\_hardwareId, YGyro 588  
get\_hardwareId, YHubPort 636  
get\_hardwareId, YHumidity 662  
get\_hardwareId, YLed 697  
get\_hardwareId, YLightSensor 727  
get\_hardwareId, YMagnetometer 767  
get\_hardwareId, YModule 817  
get\_hardwareId, YMotor 865  
get\_hardwareId, YNetwork 908  
get\_hardwareId, YOsControl 953  
get\_hardwareId, YPower 980  
get\_hardwareId, YPressure 1021  
get\_hardwareId, YPwmInput 1061  
get\_hardwareId, YPwmOutput 1109  
get\_hardwareId, YPwmPowerSource 1139  
get\_hardwareId, YQt 1165  
get\_hardwareId, YRealTimeClock 1200  
get\_hardwareId, YRefFrame 1233  
get\_hardwareId, YRelay 1263  
get\_hardwareId, YSensor 1299  
get\_hardwareId, YSerialPort 1337  
get\_hardwareId, YServo 1392  
get\_hardwareId, YTemperature 1427  
get\_hardwareId, YTilt 1467  
get\_hardwareId, YVoc 1505  
get\_hardwareId, YVoltage 1543  
get\_hardwareId, YVSource 1579  
get\_hardwareId, YWakeUpMonitor 1609  
get\_hardwareId, YWakeUpSchedule 1643  
get\_hardwareId, YWatchdog 1682  
get\_hardwareId, YWireless 1725  
get\_heading, YGyro 589  
get\_highestValue, YAccelerometer 45  
get\_highestValue, YAltitude 86  
get\_highestValue, YCarbonDioxide 164  
get\_highestValue, YCompass 230  
get\_highestValue, YCurrent 269  
get\_highestValue, YGenericSensor 541  
get\_highestValue, YGyro 590  
get\_highestValue, YHumidity 663  
get\_highestValue, YLightSensor 728  
get\_highestValue, YMagnetometer 768  
get\_highestValue, YPower 981  
get\_highestValue, YPressure 1022  
get\_highestValue, YPwmInput 1062  
get\_highestValue, YQt 1166  
get\_highestValue, YSensor 1300  
get\_highestValue, YTemperature 1428  
get\_highestValue, YTilt 1468  
get\_highestValue, YVoc 1506  
get\_highestValue, YVoltage 1544  
get\_hours, YWakeUpSchedule 1644  
get\_hslColor, YColorLed 198  
get\_icon2d, YModule 818  
get\_ipAddress, YNetwork 909  
get\_isPressed, YAnButton 128  
get\_lastLogs, YModule 819  
get\_lastMsg, YSerialPort 1338  
get\_lastTimePressed, YAnButton 129  
get\_lastTimeReleased, YAnButton 130  
get\_layerCount, YDisplay 417  
get\_layerHeight, YDisplay 418  
get\_layerHeight, YDisplayLayer 459  
get\_layerWidth, YDisplay 419  
get\_layerWidth, YDisplayLayer 460  
get\_linkQuality, YWireless 1726  
get\_list, YFiles 514  
get\_logFrequency, YAccelerometer 46  
get\_logFrequency, YAltitude 87  
get\_logFrequency, YCarbonDioxide 165  
get\_logFrequency, YCompass 231  
get\_logFrequency, YCurrent 270  
get\_logFrequency, YGenericSensor 542  
get\_logFrequency, YGyro 591  
get\_logFrequency, YHumidity 664  
get\_logFrequency, YLightSensor 729  
get\_logFrequency, YMagnetometer 769  
get\_logFrequency, YPower 982  
get\_logFrequency, YPressure 1023  
get\_logFrequency, YPwmInput 1063  
get\_logFrequency, YQt 1167  
get\_logFrequency, YSensor 1301  
get\_logFrequency, YTemperature 1429  
get\_logFrequency, YTilt 1469  
get\_logFrequency, YVoc 1507  
get\_logFrequency, YVoltage 1545  
get\_logicalName, YAccelerometer 47  
get\_logicalName, YAltitude 88  
get\_logicalName, YAnButton 131  
get\_logicalName, YCarbonDioxide 166  
get\_logicalName, YColorLed 199  
get\_logicalName, YCompass 232  
get\_logicalName, YCurrent 271  
get\_logicalName, YDataLogger 310  
get\_logicalName, YDigitalIO 371  
get\_logicalName, YDisplay 420  
get\_logicalName, YDualPower 487  
get\_logicalName, YFiles 515  
get\_logicalName, YGenericSensor 543  
get\_logicalName, YGyro 592  
get\_logicalName, YHubPort 637  
get\_logicalName, YHumidity 665  
get\_logicalName, YLed 698  
get\_logicalName, YLightSensor 730  
get\_logicalName, YMagnetometer 770  
get\_logicalName, YModule 820  
get\_logicalName, YMotor 866  
get\_logicalName, YNetwork 910  
get\_logicalName, YOsControl 954  
get\_logicalName, YPower 983  
get\_logicalName, YPressure 1024  
get\_logicalName, YPwmInput 1064  
get\_logicalName, YPwmOutput 1110  
get\_logicalName, YPwmPowerSource 1140  
get\_logicalName, YQt 1168  
get\_logicalName, YRealTimeClock 1201  
get\_logicalName, YRefFrame 1234



get\_logicalName, YRelay 1264  
get\_logicalName, YSensor 1302  
get\_logicalName, YSerialPort 1339  
get\_logicalName, YServo 1393  
get\_logicalName, YTemperature 1430  
get\_logicalName, YTilt 1470  
get\_logicalName, YVoc 1508  
get\_logicalName, YVoltage 1546  
get\_logicalName, YVSource 1580  
get\_logicalName, YWakeUpMonitor 1610  
get\_logicalName, YWakeUpSchedule 1645  
get\_logicalName, YWatchdog 1683  
get\_logicalName, YWireless 1727  
get\_lowestValue, YAccelerometer 48  
get\_lowestValue, YAltitude 89  
get\_lowestValue, YCarbonDioxide 167  
get\_lowestValue, YCompass 233  
get\_lowestValue, YCurrent 272  
get\_lowestValue, YGenericSensor 544  
get\_lowestValue, YGyro 593  
get\_lowestValue, YHumidity 666  
get\_lowestValue, YLightSensor 731  
get\_lowestValue, YMagnetometer 771  
get\_lowestValue, YPower 984  
get\_lowestValue, YPressure 1025  
get\_lowestValue, YPwmInput 1065  
get\_lowestValue, YQt 1169  
get\_lowestValue, YSensor 1303  
get\_lowestValue, YTemperature 1431  
get\_lowestValue, YTilt 1471  
get\_lowestValue, YVoc 1509  
get\_lowestValue, YVoltage 1547  
get\_luminosity, YLed 699  
get\_luminosity, YModule 821  
get\_macAddress, YNetwork 911  
get\_magneticHeading, YCompass 234  
get\_maxTimeOnStateA, YRelay 1265  
get\_maxTimeOnStateA, YWatchdog 1684  
get\_maxTimeOnStateB, YRelay 1266  
get\_maxTimeOnStateB, YWatchdog 1685  
get\_maxValue, YDataStream 348  
get\_maxValue, YMeasure 797  
get\_measures, YDataSet 332  
get\_measureType, YLightSensor 732  
get\_message, YWireless 1728  
get\_meter, YPower 985  
get\_meterTimer, YPower 986  
get\_minutes, YWakeUpSchedule 1646  
get\_minutesA, YWakeUpSchedule 1647  
get\_minutesB, YWakeUpSchedule 1648  
get\_minValue, YDataStream 349  
get\_minValue, YMeasure 798  
get\_module, YAccelerometer 49  
get\_module, YAltitude 90  
get\_module, YAnButton 132  
get\_module, YCarbonDioxide 168  
get\_module, YColorLed 200  
get\_module, YCompass 235  
get\_module, YCurrent 273  
get\_module, YDataLogger 311  
get\_module, YDigitalIO 372  
get\_module, YDisplay 421  
get\_module, YDualPower 488  
get\_module, YFiles 516  
get\_module, YGenericSensor 545  
get\_module, YGyro 594  
get\_module, YHubPort 638  
get\_module, YHumidity 667  
get\_module, YLed 700  
get\_module, YLightSensor 733  
get\_module, YMagnetometer 772  
get\_module, YMotor 867  
get\_module, YNetwork 912  
get\_module, YOsControl 955  
get\_module, YPower 987  
get\_module, YPressure 1026  
get\_module, YPwmInput 1066  
get\_module, YPwmOutput 1111  
get\_module, YPwmPowerSource 1141  
get\_module, YQt 1170  
get\_module, YRealTimeClock 1202  
get\_module, YRefFrame 1235  
get\_module, YRelay 1267  
get\_module, YSensor 1304  
get\_module, YSerialPort 1340  
get\_module, YServo 1394  
get\_module, YTemperature 1432  
get\_module, YTilt 1472  
get\_module, YVoc 1510  
get\_module, YVoltage 1548  
get\_module, YVSource 1581  
get\_module, YWakeUpMonitor 1611  
get\_module, YWakeUpSchedule 1649  
get\_module, YWatchdog 1686  
get\_module, YWireless 1729  
get\_monthDays, YWakeUpSchedule 1650  
get\_months, YWakeUpSchedule 1651  
get\_motorStatus, YMotor 868  
get\_mountOrientation, YRefFrame 1236  
get\_mountPosition, YRefFrame 1237  
get\_msgCount, YSerialPort 1341  
get\_neutral, YServo 1395  
get\_nextOccurrence, YWakeUpSchedule 1652  
get\_nextWakeUp, YWakeUpMonitor 1612  
get\_orientation, YDisplay 422  
get\_output, YRelay 1268  
get\_output, YWatchdog 1687  
get\_outputVoltage, YDigitalIO 373  
get\_overCurrent, YVSource 1582  
get\_overCurrentLimit, YMotor 869  
get\_overHeat, YVSource 1583  
get\_overLoad, YVSource 1584  
get\_period, YPwmInput 1067  
get\_period, YPwmOutput 1112  
get\_persistentSettings, YModule 822  
get\_pitch, YGyro 595  
get\_poeCurrent, YNetwork 913  
get\_portDirection, YDigitalIO 374

get\_portOpenDrain, YDigitalIO 375  
get\_portPolarity, YDigitalIO 376  
get\_portSize, YDigitalIO 377  
get\_portState, YDigitalIO 378  
get\_portState, YHubPort 639  
get\_position, YServo 1396  
get\_positionAtPowerOn, YServo 1397  
get\_power, YLed 701  
get\_powerControl, YDualPower 489  
get\_powerDuration, YWakeUpMonitor 1613  
get\_powerMode, YPwmPowerSource 1142  
get\_powerState, YDualPower 490  
get\_preview, YDataSet 333  
get\_primaryDNS, YNetwork 914  
get\_productId, YModule 823  
get\_productName, YModule 824  
get\_productRelease, YModule 825  
get\_progress, YDataSet 334  
get\_protocol, YSerialPort 1342  
get\_pulseCounter, YAnButton 133  
get\_pulseCounter, YPwmInput 1068  
get\_pulseDuration, YPwmInput 1069  
get\_pulseDuration, YPwmOutput 1113  
get\_pulseTimer, YAnButton 134  
get\_pulseTimer, YPwmInput 1070  
get\_pulseTimer, YRelay 1269  
get\_pulseTimer, YWatchdog 1688  
get\_pwmReportMode, YPwmInput 1071  
get\_qnh, YAltitude 91  
get\_quaternionW, YGyro 596  
get\_quaternionX, YGyro 597  
get\_quaternionY, YGyro 598  
get\_quaternionZ, YGyro 599  
get\_range, YServo 1398  
get\_rawValue, YAnButton 135  
get\_readiness, YNetwork 915  
get\_rebootCountdown, YModule 826  
get\_recordedData, YAccelerometer 50  
get\_recordedData, YAltitude 92  
get\_recordedData, YCarbonDioxide 169  
get\_recordedData, YCompass 236  
get\_recordedData, YCurrent 274  
get\_recordedData, YGenericSensor 546  
get\_recordedData, YGyro 600  
get\_recordedData, YHumidity 668  
get\_recordedData, YLightSensor 734  
get\_recordedData, YMagnetometer 773  
get\_recordedData, YPower 988  
get\_recordedData, YPressure 1027  
get\_recordedData, YPwmInput 1072  
get\_recordedData, YQt 1171  
get\_recordedData, YSensor 1305  
get\_recordedData, YTemperature 1433  
get\_recordedData, YTilt 1473  
get\_recordedData, YVoc 1511  
get\_recordedData, YVoltage 1549  
get\_recording, YDataLogger 312  
get\_regulationFailure, YVSource 1585  
get\_reportFrequency, YAccelerometer 41  
get\_reportFrequency, YAltitude 93  
get\_reportFrequency, YCarbonDioxide 170  
get\_reportFrequency, YCompass 237  
get\_reportFrequency, YCurrent 275  
get\_reportFrequency, YGenericSensor 547  
get\_reportFrequency, YGyro 601  
get\_reportFrequency, YHumidity 669  
get\_reportFrequency, YLightSensor 735  
get\_reportFrequency, YMagnetometer 774  
get\_reportFrequency, YPower 989  
get\_reportFrequency, YPressure 1028  
get\_reportFrequency, YPwmInput 1073  
get\_reportFrequency, YQt 1172  
get\_reportFrequency, YSensor 1306  
get\_reportFrequency, YTemperature 1434  
get\_reportFrequency, YTilt 1474  
get\_reportFrequency, YVoc 1512  
get\_reportFrequency, YVoltage 1550  
get\_resolution, YAccelerometer 52  
get\_resolution, YAltitude 94  
get\_resolution, YCarbonDioxide 171  
get\_resolution, YCompass 238  
get\_resolution, YCurrent 276  
get\_resolution, YGenericSensor 548  
get\_resolution, YGyro 602  
get\_resolution, YHumidity 670  
get\_resolution, YLightSensor 736  
get\_resolution, YMagnetometer 775  
get\_resolution, YPower 990  
get\_resolution, YPressure 1029  
get\_resolution, YPwmInput 1074  
get\_resolution, YQt 1173  
get\_resolution, YSensor 1307  
get\_resolution, YTemperature 1435  
get\_resolution, YTilt 1475  
get\_resolution, YVoc 1513  
get\_resolution, YVoltage 1551  
get\_rgbColor, YColorLed 201  
get\_rgbColorAtPowerOn, YColorLed 202  
get\_roll, YGyro 603  
get\_router, YNetwork 916  
get\_rowCount, YDataStream 350  
get\_runIndex, YDataStream 351  
get\_running, YWatchdog 1689  
get\_rxCount, YSerialPort 1343  
get\_secondaryDNS, YNetwork 917  
get\_security, YWireless 1730  
get\_sensitivity, YAnButton 136  
get\_sensorType, YTemperature 1436  
get\_serialMode, YSerialPort 1344  
get\_serialNumber, YModule 827  
get\_shutdownCountdown, YOsControl 956  
get\_signalBias, YGenericSensor 549  
get\_signalRange, YGenericSensor 550  
get\_signalUnit, YGenericSensor 551  
get\_signalValue, YGenericSensor 552  
get\_sleepCountdown, YWakeUpMonitor 1614  
get\_ssid, YWireless 1731  
get\_starterTime, YMotor 870

get\_startTime, YDataStream 352  
get\_startTimeUTC, YDataRun 326  
get\_startTimeUTC, YDataSet 335  
get\_startTimeUTC, YDataStream 353  
get\_startTimeUTC, YMeasure 799  
get\_startupSeq, YDisplay 423  
get\_state, YRelay 1270  
get\_state, YWatchdog 1690  
get\_stateAtPowerOn, YRelay 1271  
get\_stateAtPowerOn, YWatchdog 1691  
get\_subnetMask, YNetwork 918  
get\_summary, YDataSet 336  
get\_timeSet, YRealTimeClock 1203  
get\_timeUTC, YDataLogger 313  
get\_triggerDelay, YWatchdog 1692  
get\_triggerDuration, YWatchdog 1693  
get\_txCount, YSerialPort 1345  
get\_unit, YAccelerometer 53  
get\_unit, YAltitude 95  
get\_unit, YCarbonDioxide 172  
get\_unit, YCompass 239  
get\_unit, YCurrent 277  
get\_unit, YDataSet 337  
get\_unit, YGenericSensor 553  
get\_unit, YGyro 604  
get\_unit, YHumidity 671  
get\_unit, YLightSensor 737  
get\_unit, YMagnetometer 776  
get\_unit, YPower 991  
get\_unit, YPressure 1030  
get\_unit, YPwmInput 1075  
get\_unit, YQt 1174  
get\_unit, YSensor 1308  
get\_unit, YTemperature 1437  
get\_unit, YTilt 1476  
get\_unit, YVoc 1514  
get\_unit, YVoltage 1552  
get\_unit, YVSource 1586  
get\_unixTime, YRealTimeClock 1204  
get\_upTime, YModule 828  
get\_usbCurrent, YModule 829  
get\_userData, YAccelerometer 54  
get\_userData, YAltitude 96  
get\_userData, YAnButton 137  
get\_userData, YCarbonDioxide 173  
get\_userData, YColorLed 203  
get\_userData, YCompass 240  
get\_userData, YCurrent 278  
get\_userData, YDataLogger 314  
get\_userData, YDigitalIO 379  
get\_userData, YDisplay 424  
get\_userData, YDualPower 491  
get\_userData, YFiles 517  
get\_userData, YGenericSensor 554  
get\_userData, YGyro 605  
get\_userData, YHubPort 640  
get\_userData, YHumidity 672  
get\_userData, YLed 702  
get\_userData, YLightSensor 738

get\_userData, YMagnetometer 777  
get\_userData, YModule 830  
get\_userData, YMotor 871  
get\_userData, YNetwork 919  
get\_userData, YOsControl 957  
get\_userData, YPower 992  
get\_userData, YPressure 1031  
get\_userData, YPwmInput 1076  
get\_userData, YPwmOutput 1114  
get\_userData, YPwmPowerSource 1143  
get\_userData, YQt 1175  
get\_userData, YRealTimeClock 1205  
get\_userData, YRefFrame 1238  
get\_userData, YRelay 1272  
get\_userData, YSensor 1309  
get\_userData, YSerialPort 1346  
get\_userData, YServo 1399  
get\_userData, YTemperature 1438  
get\_userData, YTilt 1477  
get\_userData, YVoc 1515  
get\_userData, YVoltage 1553  
get\_userData, YVSource 1587  
get\_userData, YWakeUpMonitor 1615  
get\_userData, YWakeUpSchedule 1653  
get\_userData, YWatchdog 1694  
get\_userData, YWireless 1732  
get\_userPassword, YNetwork 920  
get\_userVar, YModule 831  
get\_utcOffset, YRealTimeClock 1206  
get\_valueRange, YGenericSensor 555  
get\_voltage, YVSource 1588  
get\_wakeUpReason, YWakeUpMonitor 1616  
get\_wakeUpState, YWakeUpMonitor 1617  
get\_weekDays, YWakeUpSchedule 1654  
get\_wwwWatchdogDelay, YNetwork 921  
get\_xValue, YAccelerometer 55  
get\_xValue, YGyro 606  
get\_xValue, YMagnetometer 778  
get\_yValue, YAccelerometer 56  
get\_yValue, YGyro 607  
get\_yValue, YMagnetometer 779  
get\_zValue, YAccelerometer 57  
get\_zValue, YGyro 608  
get\_zValue, YMagnetometer 780  
GetAPIVersion, YAPI 16  
GetTickCount, YAPI 17  
Gyroscope 575

## H

HandleEvents, YAPI 18  
hide, YDisplayLayer 461  
hslMove, YColorLed 204  
Humidity 649

## I

InitAPI, YAPI 19  
Installation 3  
Interface 31, 72, 113, 150, 188, 216, 255, 293,

355, 398, 444, 476, 500, 527, 575, 625, 649,  
687, 713, 754, 801, 848, 888, 966, 1008, 1046,  
1093, 1130, 1152, 1190, 1251, 1286, 1324,  
1380, 1414, 1454, 1492, 1530, 1568, 1599,  
1633, 1669, 1713

Introduction 1

isOnline, YAccelerometer 58  
isOnline, YAltitude 97  
isOnline, YAnButton 138  
isOnline, YCarbonDioxide 174  
isOnline, YColorLed 205  
isOnline, YCompass 241  
isOnline, YCurrent 279  
isOnline, YDataLogger 315  
isOnline, YDigitalIO 380  
isOnline, YDisplay 425  
isOnline, YDualPower 492  
isOnline, YFiles 518  
isOnline, YGenericSensor 556  
isOnline, YGyro 609  
isOnline, YHubPort 641  
isOnline, YHumidity 673  
isOnline, YLed 703  
isOnline, YLightSensor 739  
isOnline, YMagnetometer 781  
isOnline, YModule 832  
isOnline, YMotor 872  
isOnline, YNetwork 922  
isOnline, YOsControl 958  
isOnline, YPower 993  
isOnline, YPressure 1032  
isOnline, YPwmInput 1077  
isOnline, YPwmOutput 1115  
isOnline, YPwmPowerSource 1144  
isOnline, YQt 1176  
isOnline, YRealTimeClock 1207  
isOnline, YRefFrame 1239  
isOnline, YRelay 1273  
isOnline, YSensor 1310  
isOnline, YSerialPort 1347  
isOnline, YServo 1400  
isOnline, YTemperature 1439  
isOnline, YTilt 1478  
isOnline, YVoc 1516  
isOnline, YVoltage 1554  
isOnline, YVSource 1589  
isOnline, YWakeUpMonitor 1618  
isOnline, YWakeUpSchedule 1655  
isOnline, YWatchdog 1695  
isOnline, YWireless 1733

## J

joinNetwork, YWireless 1734

## K

keepALive, YMotor 873

## L

LightSensor 713  
lineTo, YDisplayLayer 462  
load, YAccelerometer 59  
load, YAltitude 98  
load, YAnButton 139  
load, YCarbonDioxide 175  
load, YColorLed 206  
load, YCompass 242  
load, YCurrent 280  
load, YDataLogger 316  
load, YDigitalIO 381  
load, YDisplay 426  
load, YDualPower 493  
load, YFiles 519  
load, YGenericSensor 557  
load, YGyro 610  
load, YHubPort 642  
load, YHumidity 674  
load, YLed 704  
load, YLightSensor 740  
load, YMagnetometer 782  
load, YModule 833  
load, YMotor 874  
load, YNetwork 923  
load, YOsControl 959  
load, YPower 994  
load, YPressure 1033  
load, YPwmInput 1078  
load, YPwmOutput 1116  
load, YPwmPowerSource 1145  
load, YQt 1177  
load, YRealTimeClock 1208  
load, YRefFrame 1240  
load, YRelay 1274  
load, YSensor 1311  
load, YSerialPort 1348  
load, YServo 1401  
load, YTemperature 1440  
load, YTilt 1479  
load, YVoc 1517  
load, YVoltage 1555  
load, YVSource 1590  
load, YWakeUpMonitor 1619  
load, YWakeUpSchedule 1656  
load, YWatchdog 1696  
load, YWireless 1735  
loadCalibrationPoints, YAccelerometer 60  
loadCalibrationPoints, YAltitude 99  
loadCalibrationPoints, YCarbonDioxide 176  
loadCalibrationPoints, YCompass 243  
loadCalibrationPoints, YCurrent 281  
loadCalibrationPoints, YGenericSensor 558  
loadCalibrationPoints, YGyro 611  
loadCalibrationPoints, YHumidity 675  
loadCalibrationPoints, YLightSensor 741  
loadCalibrationPoints, YMagnetometer 783  
loadCalibrationPoints, YPower 995

loadCalibrationPoints, YPressure 1034  
loadCalibrationPoints, YPwmInput 1079  
loadCalibrationPoints, YQt 1178  
loadCalibrationPoints, YSensor 1312  
loadCalibrationPoints, YTemperature 1441  
loadCalibrationPoints, YTilt 1480  
loadCalibrationPoints, YVoc 1518  
loadCalibrationPoints, YVoltage 1556  
loadMore, YDataSet 338

## M

Magnetometer 754  
Measured 795  
modbusReadBits, YSerialPort 1349  
modbusReadInputBits, YSerialPort 1350  
modbusReadInputRegisters, YSerialPort 1351  
modbusReadRegisters, YSerialPort 1352  
modbusWriteAndReadRegisters, YSerialPort 1353  
modbusWriteBit, YSerialPort 1354  
modbusWriteBits, YSerialPort 1355  
modbusWriteRegister, YSerialPort 1356  
modbusWriteRegisters, YSerialPort 1357  
Module 5, 801  
more3DCalibration, YRefFrame 1241  
Motor 848  
move, YServo 1402  
moveTo, YDisplayLayer 463

## N

.NET 3  
Network 888  
newSequence, YDisplay 427  
nextAccelerometer, YAccelerometer 61  
nextAltitude, YAltitude 100  
nextAnButton, YAnButton 140  
nextCarbonDioxide, YCarbonDioxide 177  
nextColorLed, YColorLed 207  
nextCompass, YCompass 244  
nextCurrent, YCurrent 282  
nextDataLogger, YDataLogger 317  
nextDigitalIO, YDigitalIO 382  
nextDisplay, YDisplay 428  
nextDualPower, YDualPower 494  
nextFiles, YFiles 520  
nextGenericSensor, YGenericSensor 559  
nextGyro, YGyro 612  
nextHubPort, YHubPort 643  
nextHumidity, YHumidity 676  
nextLed, YLed 705  
nextLightSensor, YLightSensor 742  
nextMagnetometer, YMagnetometer 784  
nextModule, YModule 834  
nextMotor, YMotor 875  
nextNetwork, YNetwork 924  
nextOsControl, YOControl 960  
nextPower, YPower 996  
nextPressure, YPressure 1035

nextPwmInput, YPwmInput 1080  
nextPwmOutput, YPwmOutput 1117  
nextPwmPowerSource, YPwmPowerSource 1146  
nextQt, YQt 1179  
nextRealTimeClock, YRealTimeClock 1209  
nextRefFrame, YRefFrame 1242  
nextRelay, YRelay 1275  
nextSensor, YSensor 1313  
nextSerialPort, YSerialPort 1358  
nextServo, YServo 1403  
nextTemperature, YTemperature 1442  
nextTilt, YTilt 1481  
nextVoc, YVoc 1519  
nextVoltage, YVoltage 1557  
nextVSource, YVSource 1591  
nextWakeUpMonitor, YWakeUpMonitor 1620  
nextWakeUpSchedule, YWakeUpSchedule 1657  
nextWatchdog, YWatchdog 1697  
nextWireless, YWireless 1736

## O

Object 444

## P

pauseSequence, YDisplay 429  
ping, YNetwork 925  
playSequence, YDisplay 430  
Port 625  
Power 476, 966  
PreregisterHub, YAPI 20  
Pressure 1008  
Project 3  
pulse, YDigitalIO 383  
pulse, YRelay 1276  
pulse, YVSource 1592  
pulse, YWatchdog 1698  
pulseDurationMove, YPwmOutput 1118  
PwmInput 1046  
PwmPowerSource 1130

## Q

Quaternion 1152  
queryLine, YSerialPort 1359  
queryMODBUS, YSerialPort 1360

## R

read\_seek, YSerialPort 1365  
readHex, YSerialPort 1361  
readLine, YSerialPort 1362  
readMessages, YSerialPort 1363  
readStr, YSerialPort 1364  
Real 1190  
reboot, YModule 835  
Recorded 328  
Reference 10, 1216  
registerAnglesCallback, YGyro 613

RegisterDeviceArrivalCallback, YAPI 21  
RegisterDeviceRemovalCallback, YAPI 22  
RegisterHub, YAPI 23  
RegisterHubDiscoveryCallback, YAPI 24  
registerLogCallback, YModule 836  
RegisterLogFunction, YAPI 25  
registerQuaternionCallback, YGyro 614  
registerTimedReportCallback, YAccelerometer 62  
registerTimedReportCallback, YAltitude 101  
registerTimedReportCallback, YCarbonDioxide 178  
registerTimedReportCallback, YCompass 245  
registerTimedReportCallback, YCurrent 283  
registerTimedReportCallback, YGenericSensor 560  
registerTimedReportCallback, YGyro 615  
registerTimedReportCallback, YHumidity 677  
registerTimedReportCallback, YLightSensor 743  
registerTimedReportCallback, YMagnetometer 785  
registerTimedReportCallback, YPower 997  
registerTimedReportCallback, YPressure 1036  
registerTimedReportCallback, YPwmInput 1081  
registerTimedReportCallback, YQt 1180  
registerTimedReportCallback, YSensor 1314  
registerTimedReportCallback, YTemperature 1443  
registerTimedReportCallback, YTilt 1482  
registerTimedReportCallback, YVoc 1520  
registerTimedReportCallback, YVoltage 1558  
registerValueCallback, YAccelerometer 63  
registerValueCallback, YAltitude 102  
registerValueCallback, YAnButton 141  
registerValueCallback, YCarbonDioxide 179  
registerValueCallback, YColorLed 208  
registerValueCallback, YCompass 246  
registerValueCallback, YCurrent 284  
registerValueCallback, YDataLogger 318  
registerValueCallback, YDigitalIO 384  
registerValueCallback, YDisplay 431  
registerValueCallback, YDualPower 495  
registerValueCallback, YFiles 521  
registerValueCallback, YGenericSensor 561  
registerValueCallback, YGyro 616  
registerValueCallback, YHubPort 644  
registerValueCallback, YHumidity 678  
registerValueCallback, YLed 706  
registerValueCallback, YLightSensor 744  
registerValueCallback, YMagnetometer 786  
registerValueCallback, YMotor 876  
registerValueCallback, YNetwork 926  
registerValueCallback, YOsControl 961  
registerValueCallback, YPower 998  
registerValueCallback, YPressure 1037  
registerValueCallback, YPwmInput 1082  
registerValueCallback, YPwmOutput 1119  
registerValueCallback, YPwmPowerSource 1147  
registerValueCallback, YQt 1181

registerValueCallback, YRealTimeClock 1210  
registerValueCallback, YRefFrame 1243  
registerValueCallback, YRelay 1277  
registerValueCallback, YSensor 1315  
registerValueCallback, YSerialPort 1366  
registerValueCallback, YServo 1404  
registerValueCallback, YTemperature 1444  
registerValueCallback, YTilt 1483  
registerValueCallback, YVoc 1521  
registerValueCallback, YVoltage 1559  
registerValueCallback, YVSource 1593  
registerValueCallback, YWakeUpMonitor 1621  
registerValueCallback, YWakeUpSchedule 1658  
registerValueCallback, YWatchdog 1699  
registerValueCallback, YWireless 1737  
Relay 1251  
remove, YFiles 522  
reset, YDisplayLayer 464  
reset, YPower 999  
reset, YSerialPort 1367  
resetAll, YDisplay 432  
resetCounter, YAnButton 142  
resetCounter, YPwmInput 1083  
resetSleepCountDown, YWakeUpMonitor 1622  
resetStatus, YMotor 877  
resetWatchdog, YWatchdog 1700  
revertFromFlash, YModule 837  
rgbMove, YColorLed 209

## S

save3DCalibration, YRefFrame 1244  
saveSequence, YDisplay 433  
saveToFlash, YModule 838  
selectColorPen, YDisplayLayer 465  
selectEraser, YDisplayLayer 466  
selectFont, YDisplayLayer 467  
selectGrayPen, YDisplayLayer 468  
Sensor 1286  
Sequence 326, 328, 340  
SerialPort 1324  
Servo 1380  
set\_adminPassword, YNetwork 927  
set\_allSettings, YModule 839  
set\_analogCalibration, YAnButton 143  
set\_autoStart, YDataLogger 319  
set\_autoStart, YWatchdog 1701  
set\_beacon, YModule 840  
set\_beaconDriven, YDataLogger 320  
set\_bearing, YRefFrame 1245  
set\_bitDirection, YDigitalIO 385  
set\_bitOpenDrain, YDigitalIO 386  
set\_bitPolarity, YDigitalIO 387  
set\_bitState, YDigitalIO 388  
set\_blinking, YLed 707  
set\_brakingForce, YMotor 878  
set\_brightness, YDisplay 434  
set\_calibrationMax, YAnButton 144  
set\_calibrationMin, YAnButton 145  
set\_callbackCredentials, YNetwork 928

set\_callbackEncoding, YNetwork 929  
set\_callbackMaxDelay, YNetwork 930  
set\_callbackMethod, YNetwork 931  
set\_callbackMinDelay, YNetwork 932  
set\_callbackUrl, YNetwork 933  
set\_currentValue, YAltitude 103  
set\_cutOffVoltage, YMotor 879  
set\_discoverable, YNetwork 934  
set\_drivingForce, YMotor 880  
set\_dutyCycle, YPwmOutput 1120  
set\_dutyCycleAtPowerOn, YPwmOutput 1121  
set\_enabled, YDisplay 435  
set\_enabled, YHubPort 645  
set\_enabled, YPwmOutput 1122  
set\_enabled, YServo 1405  
set\_enabledAtPowerOn, YPwmOutput 1123  
set\_enabledAtPowerOn, YServo 1406  
set\_failSafeTimeout, YMotor 881  
set\_frequency, YMotor 882  
set\_frequency, YPwmOutput 1124  
set\_highestValue, YAccelerometer 64  
set\_highestValue, YAltitude 104  
set\_highestValue, YCarbonDioxide 180  
set\_highestValue, YCompass 247  
set\_highestValue, YCurrent 285  
set\_highestValue, YGenericSensor 562  
set\_highestValue, YGyro 617  
set\_highestValue, YHumidity 679  
set\_highestValue, YLightSensor 745  
set\_highestValue, YMagnetometer 787  
set\_highestValue, YPower 1000  
set\_highestValue, YPressure 1038  
set\_highestValue, YPwmInput 1084  
set\_highestValue, YQt 1182  
set\_highestValue, YSensor 1316  
set\_highestValue, YTemperature 1445  
set\_highestValue, YTilt 1484  
set\_highestValue, YVoc 1522  
set\_highestValue, YVoltage 1560  
set\_hours, YWakeUpSchedule 1659  
set\_hslColor, YColorLed 210  
set\_logFrequency, YAccelerometer 65  
set\_logFrequency, YAltitude 105  
set\_logFrequency, YCarbonDioxide 181  
set\_logFrequency, YCompass 248  
set\_logFrequency, YCurrent 286  
set\_logFrequency, YGenericSensor 563  
set\_logFrequency, YGyro 618  
set\_logFrequency, YHumidity 680  
set\_logFrequency, YLightSensor 746  
set\_logFrequency, YMagnetometer 788  
set\_logFrequency, YPower 1001  
set\_logFrequency, YPressure 1039  
set\_logFrequency, YPwmInput 1085  
set\_logFrequency, YQt 1183  
set\_logFrequency, YSensor 1317  
set\_logFrequency, YTemperature 1446  
set\_logFrequency, YTilt 1485  
set\_logFrequency, YVoc 1523  
set\_logFrequency, YVoltage 1561  
set\_logicalName, YAccelerometer 66  
set\_logicalName, YAltitude 106  
set\_logicalName, YAnButton 146  
set\_logicalName, YCarbonDioxide 182  
set\_logicalName, YColorLed 211  
set\_logicalName, YCompass 249  
set\_logicalName, YCurrent 287  
set\_logicalName, YDataLogger 321  
set\_logicalName, YDigitalIO 389  
set\_logicalName, YDisplay 436  
set\_logicalName, YDualPower 496  
set\_logicalName, YFiles 523  
set\_logicalName, YGenericSensor 564  
set\_logicalName, YGyro 619  
set\_logicalName, YHubPort 646  
set\_logicalName, YHumidity 681  
set\_logicalName, YLed 708  
set\_logicalName, YLightSensor 747  
set\_logicalName, YMagnetometer 789  
set\_logicalName, YModule 841  
set\_logicalName, YMotor 883  
set\_logicalName, YNetwork 935  
set\_logicalName, YOsControl 962  
set\_logicalName, YPower 1002  
set\_logicalName, YPressure 1040  
set\_logicalName, YPwmInput 1086  
set\_logicalName, YPwmOutput 1125  
set\_logicalName, YPwmPowerSource 1148  
set\_logicalName, YQt 1184  
set\_logicalName, YRealTimeClock 1211  
set\_logicalName, YRefFrame 1246  
set\_logicalName, YRelay 1278  
set\_logicalName, YSensor 1318  
set\_logicalName, YSerialPort 1369  
set\_logicalName, YServo 1407  
set\_logicalName, YTemperature 1447  
set\_logicalName, YTilt 1486  
set\_logicalName, YVoc 1524  
set\_logicalName, YVoltage 1562  
set\_logicalName, YVSource 1594  
set\_logicalName, YWakeUpMonitor 1623  
set\_logicalName, YWakeUpSchedule 1660  
set\_logicalName, YWatchdog 1702  
set\_logicalName, YWireless 1738  
set\_lowestValue, YAccelerometer 67  
set\_lowestValue, YAltitude 107  
set\_lowestValue, YCarbonDioxide 183  
set\_lowestValue, YCompass 250  
set\_lowestValue, YCurrent 288  
set\_lowestValue, YGenericSensor 565  
set\_lowestValue, YGyro 620  
set\_lowestValue, YHumidity 682  
set\_lowestValue, YLightSensor 748  
set\_lowestValue, YMagnetometer 790  
set\_lowestValue, YPower 1003  
set\_lowestValue, YPressure 1041  
set\_lowestValue, YPwmInput 1087  
set\_lowestValue, YQt 1185

set\_lowestValue, YSensor 1319  
set\_lowestValue, YTemperature 1448  
set\_lowestValue, YTilt 1487  
set\_lowestValue, YVoc 1525  
set\_lowestValue, YVoltage 1563  
set\_luminosity, YLed 709  
set\_luminosity, YModule 842  
set\_maxTimeOnStateA, YRelay 1279  
set\_maxTimeOnStateA, YWatchdog 1703  
set\_maxTimeOnStateB, YRelay 1280  
set\_maxTimeOnStateB, YWatchdog 1704  
set\_measureType, YLightSensor 749  
set\_minutes, YWakeUpSchedule 1661  
set\_minutesA, YWakeUpSchedule 1662  
set\_minutesB, YWakeUpSchedule 1663  
set\_monthDays, YWakeUpSchedule 1664  
set\_months, YWakeUpSchedule 1665  
set\_mountPosition, YRefFrame 1247  
set\_neutral, YServo 1408  
set\_nextWakeUp, YWakeUpMonitor 1624  
set\_orientation, YDisplay 437  
set\_output, YRelay 1281  
set\_output, YWatchdog 1705  
set\_outputVoltage, YDigitalIO 390  
set\_overCurrentLimit, YMotor 884  
set\_period, YPwmOutput 1126  
set\_portDirection, YDigitalIO 391  
set\_portOpenDrain, YDigitalIO 392  
set\_portPolarity, YDigitalIO 393  
set\_portState, YDigitalIO 394  
set\_position, YServo 1409  
set\_positionAtPowerOn, YServo 1410  
set\_power, YLed 710  
set\_powerControl, YDualPower 497  
set\_powerDuration, YWakeUpMonitor 1625  
set\_powerMode, YPwmPowerSource 1149  
set\_primaryDNS, YNetwork 936  
set\_protocol, YSerialPort 1370  
set\_pulseDuration, YPwmOutput 1127  
set\_pwmReportMode, YPwmInput 1088  
set\_qnh, YAltitude 108  
set\_range, YServo 1411  
set\_recording, YDataLogger 322  
set\_reportFrequency, YAccelerometer 68  
set\_reportFrequency, YAltitude 109  
set\_reportFrequency, YCarbonDioxide 184  
set\_reportFrequency, YCompass 251  
set\_reportFrequency, YCurrent 289  
set\_reportFrequency, YGenericSensor 566  
set\_reportFrequency, YGyro 621  
set\_reportFrequency, YHumidity 683  
set\_reportFrequency, YLightSensor 750  
set\_reportFrequency, YMagnetometer 791  
set\_reportFrequency, YPower 1004  
set\_reportFrequency, YPressure 1042  
set\_reportFrequency, YPwmInput 1089  
set\_reportFrequency, YQt 1186  
set\_reportFrequency, YSensor 1320  
set\_reportFrequency, YTemperature 1449  
set\_reportFrequency, YTilt 1488  
set\_reportFrequency, YVoc 1526  
set\_reportFrequency, YVoltage 1564  
set\_resolution, YAccelerometer 69  
set\_resolution, YAltitude 110  
set\_resolution, YCarbonDioxide 185  
set\_resolution, YCompass 252  
set\_resolution, YCurrent 290  
set\_resolution, YGenericSensor 567  
set\_resolution, YGyro 622  
set\_resolution, YHumidity 684  
set\_resolution, YLightSensor 751  
set\_resolution, YMagnetometer 792  
set\_resolution, YPower 1005  
set\_resolution, YPressure 1043  
set\_resolution, YPwmInput 1090  
set\_resolution, YQt 1187  
set\_resolution, YSensor 1321  
set\_resolution, YTemperature 1450  
set\_resolution, YTilt 1489  
set\_resolution, YVoc 1527  
set\_resolution, YVoltage 1565  
set\_rgbColor, YColorLed 212  
set\_rgbColorAtPowerOn, YColorLed 213  
set\_RTS, YSerialPort 1368  
set\_running, YWatchdog 1706  
set\_secondaryDNS, YNetwork 937  
set\_sensitivity, YAnButton 147  
set\_sensorType, YTemperature 1451  
set\_serialMode, YSerialPort 1371  
set\_signalBias, YGenericSensor 568  
set\_signalRange, YGenericSensor 569  
set\_sleepCountdown, YWakeUpMonitor 1626  
set\_starterTime, YMotor 885  
set\_startupSeq, YDisplay 438  
set\_state, YRelay 1282  
set\_state, YWatchdog 1707  
set\_stateAtPowerOn, YRelay 1283  
set\_stateAtPowerOn, YWatchdog 1708  
set\_timeUTC, YDataLogger 323  
set\_triggerDelay, YWatchdog 1709  
set\_triggerDuration, YWatchdog 1710  
set\_unit, YGenericSensor 570  
set\_unixTime, YRealTimeClock 1212  
set\_userData, YAccelerometer 70  
set\_userData, YAltitude 111  
set\_userData, YAnButton 148  
set\_userData, YCarbonDioxide 186  
set\_userData, YColorLed 214  
set\_userData, YCompass 253  
set\_userData, YCurrent 291  
set\_userData, YDataLogger 324  
set\_userData, YDigitalIO 395  
set\_userData, YDisplay 439  
set\_userData, YDualPower 498  
set\_userData, YFiles 524  
set\_userData, YGenericSensor 571  
set\_userData, YGyro 623  
set\_userData, YHubPort 647



set\_userData, YHumidity 685  
set\_userData, YLed 711  
set\_userData, YLightSensor 752  
set\_userData, YMagnetometer 793  
set\_userData, YModule 843  
set\_userData, YMotor 886  
set\_userData, YNetwork 938  
set\_userData, YOsControl 963  
set\_userData, YPower 1006  
set\_userData, YPressure 1044  
set\_userData, YPwmInput 1091  
set\_userData, YPwmOutput 1128  
set\_userData, YPwmPowerSource 1150  
set\_userData, YQt 1188  
set\_userData, YRealTimeClock 1213  
set\_userData, YRefFrame 1248  
set\_userData, YRelay 1284  
set\_userData, YSensor 1322  
set\_userData, YSerialPort 1372  
set\_userData, YServo 1412  
set\_userData, YTemperature 1452  
set\_userData, YTilt 1490  
set\_userData, YVoc 1528  
set\_userData, YVoltage 1566  
set\_userData, YVSource 1595  
set\_userData, YWakeUpMonitor 1627  
set\_userData, YWakeUpSchedule 1666  
set\_userData, YWatchdog 1711  
set\_userData, YWireless 1739  
set\_userPassword, YNetwork 939  
set\_userVar, YModule 844  
set\_utcOffset, YRealTimeClock 1214  
set\_valueRange, YGenericSensor 572  
set\_voltage, YVSource 1596  
set\_weekDays, YWakeUpSchedule 1667  
set\_wwwWatchdogDelay, YNetwork 940  
setAntialiasingMode, YDisplayLayer 469  
setConsoleBackground, YDisplayLayer 470  
setConsoleMargins, YDisplayLayer 471  
setConsoleWordWrap, YDisplayLayer 472  
setLayerPosition, YDisplayLayer 473  
shutdown, YOsControl 964  
Sleep, YAPI 26  
sleep, YWakeUpMonitor 1628  
sleepFor, YWakeUpMonitor 1629  
sleepUntil, YWakeUpMonitor 1630  
softAPNetwork, YWireless 1740  
Source 1568  
start3DCalibration, YRefFrame 1249  
stopSequence, YDisplay 440  
Supply 476  
swapLayerContent, YDisplay 441

## T

Temperature 1414  
Tilt 1454  
Time 1190  
toggle\_bitState, YDigitalIO 396  
triggerFirmwareUpdate, YModule 845

TriggerHubDiscovery, YAPI 27

## U

Unformatted 340  
unhide, YDisplayLayer 474  
UnregisterHub, YAPI 28  
UpdateDeviceList, YAPI 29  
updateFirmware, YModule 846  
upload, YDisplay 442  
upload, YFiles 525  
useDHCP, YNetwork 941  
useStaticIP, YNetwork 942

## V

Value 795  
Visual 3  
Voltage 1530, 1568  
voltageMove, YVSource 1597

## W

wakeUp, YWakeUpMonitor 1631  
WakeUpMonitor 1599  
WakeUpSchedule 1633  
Watchdog 1669  
Wireless 1713  
writeArray, YSerialPort 1373  
writeBin, YSerialPort 1374  
writeHex, YSerialPort 1375  
writeLine, YSerialPort 1376  
writeMODBUS, YSerialPort 1377  
writeStr, YSerialPort 1378

## Y

YAccelerometer 33-70  
YAltitude 74-111  
YAnButton 115-148  
YAPI 12-29  
YCarbonDioxide 152-186  
yCheckLogicalName 12  
YColorLed 189-214  
YCompass 218-253  
YCurrent 257-291  
YDataLogger 295-324  
YDataRun 326  
YDataSet 329-338  
YDataStream 341-353  
YDigitalIO 357-396  
yDisableExceptions 13  
YDisplay 400-442  
YDisplayLayer 445-474  
YDualPower 477-498  
yEnableExceptions 14  
YFiles 501-525  
yFindAccelerometer 33  
yFindAltitude 74  
yFindAnButton 115  
yFindCarbonDioxide 152

yFindColorLed 189  
yFindCompass 218  
yFindCurrent 257  
yFindDataLogger 295  
yFindDigitalIO 357  
yFindDisplay 400  
yFindDualPower 477  
yFindFiles 501  
yFindGenericSensor 529  
yFindGyro 577  
yFindHubPort 626  
yFindHumidity 651  
yFindLed 688  
yFindLightSensor 715  
yFindMagnetometer 756  
yFindModule 803  
yFindMotor 850  
yFindNetwork 891  
yFindOsControl 945  
yFindPower 968  
yFindPressure 1010  
yFindPwmInput 1048  
yFindPwmOutput 1095  
yFindPwmPowerSource 1131  
yFindQt 1154  
yFindRealTimeClock 1191  
yFindRefFrame 1218  
yFindRelay 1253  
yFindSensor 1288  
yFindSerialPort 1327  
yFindServo 1382  
yFindTemperature 1416  
yFindTilt 1456  
yFindVoc 1494  
yFindVoltage 1532  
yFindVSource 1569  
yFindWakeUpMonitor 1601  
yFindWakeUpSchedule 1635  
yFindWatchdog 1671  
yFindWireless 1714  
yFirstAccelerometer 34  
yFirstAltitude 75  
yFirstAnButton 116  
yFirstCarbonDioxide 153  
yFirstColorLed 190  
yFirstCompass 219  
yFirstCurrent 258  
yFirstDataLogger 296  
yFirstDigitalIO 358  
yFirstDisplay 401  
yFirstDualPower 478  
yFirstFiles 502  
yFirstGenericSensor 530  
yFirstGyro 578  
yFirstHubPort 627  
yFirstHumidity 652  
yFirstLed 689  
yFirstLightSensor 716  
yFirstMagnetometer 757

yFirstModule 804  
yFirstMotor 851  
yFirstNetwork 892  
yFirstOsControl 946  
yFirstPower 969  
yFirstPressure 1011  
yFirstPwmInput 1049  
yFirstPwmOutput 1096  
yFirstPwmPowerSource 1132  
yFirstQt 1155  
yFirstRealTimeClock 1192  
yFirstRefFrame 1219  
yFirstRelay 1254  
yFirstSensor 1289  
yFirstSerialPort 1328  
yFirstServo 1383  
yFirstTemperature 1417  
yFirstTilt 1457  
yFirstVoc 1495  
yFirstVoltage 1533  
yFirstVSource 1570  
yFirstWakeUpMonitor 1602  
yFirstWakeUpSchedule 1636  
yFirstWatchdog 1672  
yFirstWireless 1715  
yFreeAPI 15  
YGenericSensor 529-573  
yGetAPIVersion 16  
yGetTickCount 17  
YGyro 577-623  
yHandleEvents 18  
YHubPort 626-647  
YHumidity 651-685  
yInitAPI 19  
YLed 688-711  
YLightSensor 715-752  
YMagnetometer 756-793  
YMeasure 795-799  
YModule 803-846  
YMotor 850-886  
YNetwork 891-942  
Yocto-Demo 3  
Yocto-hub 625  
YOsControl 945-964  
YPower 968-1006  
yPreregisterHub 20  
YPressure 1010-1044  
YPwmInput 1048-1091  
YPwmOutput 1095-1128  
YPwmPowerSource 1131-1150  
YQt 1154-1188  
YRealTimeClock 1191-1214  
YRefFrame 1218-1249  
yRegisterDeviceArrivalCallback 21  
yRegisterDeviceRemovalCallback 22  
yRegisterHub 23  
yRegisterHubDiscoveryCallback 24  
yRegisterLogFunction 25  
YRelay 1253-1284

YSensor 1288-1322  
YSerialPort 1327-1378  
YServo 1382-1412  
ySleep 26  
YTemperature 1416-1452  
YTilt 1456-1490  
yTriggerHubDiscovery 27  
yUnregisterHub 28  
yUpdateDeviceList 29  
YVoc 1494-1528

YVoltage 1532-1566  
YVSource 1569-1597  
YWakeUpMonitor 1601-1631  
YWakeUpSchedule 1635-1667  
YWatchdog 1671-1711  
YWireless 1714-1740

## **Z**

zeroAdjust, YGenericSensor 573